RR RACE

4-STROKE
350 /390 / 430/ 480



Rideability

Beta motorcycles

2026
OWNERS MANUAL

RR 350-390-430-480 RACE EURO 5 PLUS

Thanks for you preference, and have a good time! This handbook contains the information you need to properly operate and maintain your motorcycle.

The data, specifications and images shown in this manual does not constitute an engagement on the part of BETAMOTOR S.p.A. BETAMOTOR reserves the right to make any changes and improvements to its models at any moment and without notice.

Code 037.44.144.83.00

IMPORTANT

We recommend you to check all the tightenings after the first one or two hours' ride over rough ground. Special attention should be paid to the following parts:

- rear sprocket
- ensure that the footrests are properly fixed
- front/rear brake levers/calipers/discs
- check that the plastics are properly fastened
- engine bolts
- shock absorber bolts/swingarm
- wheel hubs/spokes
- rear frame
- pipe connections
- tensioning the chain

IMPORTANT

In the event of interventions on the vehicle, contact Betamotor after-sales service.

The operations specified in the maintenance schedule must be performed exclusively at an authorised Betamotor workshop and must be registered on the Betanet portal. Failure to register will result in rendering the warranty null and void.

Use of the vehicle in heavy-duty conditions, for example, on sand, circuits/off-road tracks with wet, dusty or muddy terrain, can result in above-average wear of components such as the drive system, brake system, air filter or suspension parts. Therefore, inspection or replacement of the components may be necessary even before the first service is due.

CONTENTS

Operating instructions 5
Symbols 5
Riding safety 6

CHAPTER 1 GENERAL INFORMATION 7
Vehicle identification data 8
Tools kit 8
Familiarizing with the vehicle 9
Specifications 10
Bulbs 13
Fuses 13
Recommended lubricants and liquid 13

CHAPTER 2 OPERATION 15
Main parts 16
Dashboard operating instructions 19
Checks before and after use 28
Running in 28
Fuelling 29
Starting the engine 30
Engine shut-down 30
Vehicle preparation for use in heavy-duty conditions 31

CHAPTER 3 ADJUSTMENTS 33
Key to symbols 34
Brakes 34
Clutch 35
Adjustment of gas clearance 35
Idle adjustment 35
Handlebar adjustment 35
Adjusting fork 37
Shock absorber 39

CHAPTER 4 CHECKS AND MAINTENANCE 43
Engine oil 44
Gearbox oil 46
Liquid coolant 47
Air filter 50
Spark plug 53

CONTENTS

Front brake....54
Rear brake....57
Clutch control....60
Check and adjusting of steering play....62
Fork....63
Front wheel....63
Tyres....64
Rear suspension leverage....64
Chain....65
Headlight....66
Tail light....67
Battery....68
Fuses....70
Cleaning the vehicle....71
Electrical connector maintenance....72
Prolonged inactivity....74
Scheduled maintenance vehicle....75
Tightening torque overview....77

CHAPTER 5 REMOVING AND INSTALLING SUPERSTRUCTURES....79
Removing and installing of the saddle....80
Removing and installing air filter cover panel....81
Removing and installing of the rear mudguard....82
Removing and installing of the engine protection....84
Removing and installing of the tank....85
Removing and installing the headlamp mask....90

CHAPTER 6 TROUBLESHOOTING....91
Troubleshooting....92

EN

OPERATING INSTRUCTIONS

- The vehicle must be accompanied by: number-plate, registration document, tax disc and insurance.
- Do not sit on the vehicle when it is on its stand.
- Do not start the engine in closed places.

WARNING
Any modifications and tampering with the vehicle during the warranty period exempt the manufacturer from all responsibility and invalidate warranty.

SYMBOLS


SAFETY/ATTENTION
Failure to respect information marked with this symbol can entail a personal hazard.


INTEGRITY OF THE VEHICLE
Failure to respect information marked with this symbol can entail serious damage to the vehicle and termination of the warranty.


FLAMMABLE LIQUID HAZARD


Read the use and maintenance manual carefully.


MANDATORY TO WEAR PROTECTIVE CLOTHING
Use of the vehicle is subject to wearing specific protective clothing and safety footwear.


PROTECTIVE GLOVES MANDATORY
To perform the operations described, it is mandatory to wear protective gloves.


FORBIDDEN TO USE NAKED FLAMES OR POSSIBLE UNCONTROLLED IGNITION SOURCES


NO SMOKING


DO NOT USE MOBILE PHONE


CORROSIVE SUBSTANCES HAZARD
Liquids marked with this symbol are highly corrosive: handle with care


POISONING HAZARD

RIDING SAFETY

- Observe the Highway Code.
- Always wear approved personal protective equipment.
- Always keep the crash helmet visor clean.
- Do not keep sharp or brittle objects in your pockets while riding.
- Properly adjust the rearview mirrors.
- Always ride in a seated position, with both hands on the handlebars and both feet on the footrests.
- Never ride abreast with other vehicles.
- Do not tow and avoid being towed by other vehicles.
- Always keep a safe distance from other vehicles.
- Do not start off while the vehicle is on its stand.
- Avoid swaying and wheelies as they are extremely dangerous for your own and other people's safety as well as for your vehicle.
- Always apply both brakes on dry roads with no gravel and sand. Using one brake may be dangerous and cause uncontrolled skidding.
- To reduce the braking distance, always apply both brakes.
- On wet roads and in off-road riding, drive with care and at moderate speed. Take special care in applying the brakes.

CHAPTER 1 GENERAL INFORMATION


CONTENTS

Vehicle identification data 8
- Frame identification 8
- Engine identification 8

Tools kit 8
Familiarizing with the vehicle 9
- Main parts 9

Specifications 10
- Weight 10
- Dimensions 10
- Tyres 10
- Wheels 10
- Capacities 10
- Front suspension 11
- Rear suspension 11
- Front brake 11
- Rear brake 11
- Engine 12


Bulbs 13
Fuses 13
Recommended lubricants and liquid 13



VEHICLE IDENTIFICATION DATA

FRAME IDENTIFICATION

Frame identification data **A** are stamped on the right side of the steering head tube.



ENGINE IDENTIFICATION


Engine identification data **B** are stamped in the area shown in the figure.



TOOLS KIT

The following items are supplied as standard: operation, maintenance manual, tool kit and the cable adapter to connect the CAN socket to a scantool (see photo).

FAMILIARIZING WITH THE VEHICLE



MAIN PARTS

1 - Fuel tank
2 - Tank cap
3 - Silencer
4 - Rear shock absorber
5 - Headlight
6 - Rear light
7 - Side stand
8 - Fork
9 - Rider's footrests
10 - Lower bumper (Bumper kit)
11 - Saddle
12 - Engine
13 - Front mudguard
14 - Number-plate holder
15 - Kick-start
16 - Gear lever
17 - Rear brake lever
18 - Front brake lever
19 - Clutch lever
20 - Throttle
21 - Fork covers
22 - Rear mudguard
23 - Cover air filter
24 - Front indicators
25 - Rear indicators
26 - Carbon Canister *

* For markets where required

SPECIFICATIONS

WEIGHT

Dry weight in running order

Version	Total [kg]	Front [kg]	Rear [kg]
RR 350 - RR 390	107,5	52,7	54,8
RR 430 - RR 480	107,5	52,7	54,8

DIMENSIONS

maximum length (with plate holder) ..... 2180 mm
maximum width ..... 830 mm
overall height ..... 1275 mm
wheelbase (RR350) ..... 1476 mm
(RR390-430-480) ..... 1480 mm
saddle height..... 950 mm
ground clearance..... 335 mm
footrest height..... 427 mm

TYRES

Dimensions		Pressure [Bar]	
Front tyre	**Rear tyre**	**Front tyre**	**Rear tyre**
90/90-21	**140/80-18**	**1,5 (road use)**	**1,8 (road use)**
		1 (off-road use)	**1 (off-road use)**

WHEELS

Version	Dimensions	
	Front	**Rear**
RR 350 - 390 - 430 - 480	J 21x1.6	J 18x2,15

CAPACITIES

fuel tank*.....9 liters
including reserve.....2,5 liters
coolant circuit.....1,3 liters
engine oil..... 750 ml following normal maintenance work
.....800 ml following a complete engine review
gear oil..... 750 ml following normal maintenance work
.....800 ml following a complete engine review

*Such data is referred to a conditioned and arranged tank

FRONT SUSPENSION

Open cartridge hydraulic upside-down fork (Ø48 mm shafts)

Version	RR 350-390-430-480
Spring (K - [N/mm])	4,7
Oil type	KYB FORK OIL 01M
Oil quantity internal cartridge# [cc]	195
Oil quantity external cartridge# [cc]	320
Wheel excursion [mm]	300
Compression clicks (from completely closed)	12
Rebound clicks (from completely closed)	12

For a completely dry fork

REAR SUSPENSION

Version	RR 350-390-430-480
Spring (K - [daN/mm])	5,4
Static sag load (see page 40) [mm]	35
Shock absorber travel [mm]	130
Rear wheel travel [mm]	287
Compression clicks, high speeds (from completely closed)	12
Compression clicks, low speeds (from completely closed)	13
Rebound clicks (from completely closed)	13

FRONT BRAKE

Ø 260 mm disc and dual-piston floating caliper

REAR BRAKE

Ø240 mm disc and single-piston floating caliper

ENGINE

Version	RR 350	RR 390	RR 430	RR 480
Type	Single-cylinder, 4-stroke			
Bore x stroke [mm]	88x57,4	88x63,4	95x60,8	100x60,8
Displacement [cm³]	349,1	386	431	478
Compression ratio	13,19:1	12,5:1	12,3:1	11,9:1
CO_2 [g/km] * #	80	79	91	88
Fuel consumption [l/100km] * #	3,7	3,3	3,8	4,1

* Only valid for EUROPA version
# WMTC cycle related data, for class L vehicles

Fuel system.....electronic injection, double injector

Cooling system ..... forced liquid circulation by pump

Spark plug ..... NGK LKAR 8A - 9

Clutch.....wet, multidisc

Transmission..... 6-speed with front claw clutch

Version	RR 350	RR 390	RR 430	RR 480
Primary drive	28/76	28/76	31/72	31/72
Gear ratio 1st gear	12/31	12/31	12/31	12/31
Gear ratio 2nd gear	15/28	15/28	15/28	15/28
Gear ratio 3rd gear	19/28	19/28	19/28	19/28
Gear ratio 4th gear	20/24	20/24	20/24	20/24
Gear ratio 5th gear	27/27	27/27	27/27	27/27
Gear ratio 6th gear	28/24	28/24	28/24	28/24
Final drive	13/50	13/49	13/49	13/49

* Only valid for EUROPA version

Starting.....electric starter (Kick-starter optional)

BULBS

High beam/low beam .....HS1 12V - 35/35W
Parking/daytime ..... 12V - W5W
Turn indicators ..... 12V - H6W
Rear position light/Stop light/License plate light .....LED

FUSES

Six 10A
three of them spare

RECOMMENDED LUBRICANTS AND LIQUID

To maximize the vehicle's performance and ensure many years of trouble-free operation, we recommend using the following products:

PRODUCT TYPE	SPECIFICATIONS
FUEL	GASOLINE E5 95 RON
ENGINE OIL	LIQUI MOLY MOTORBIKE 4T SYNTH 10W-50 OFFROAD RACE
GEAR AND CLUTCH OIL	LIQUI MOLY MOTORBIKE 4T SYNTH 10W-50 OFFROAD RACE
BRAKE OIL	LIQUI MOLY BRAKE FLUID DOT 5.1
CLUTCH ACTUATOR OIL	LIQUI MOLY BRAKE FLUID DOT 5.1
FORK OIL	KYB FORK OIL 01M
TIE ROD GREASE	LIQUI MOLY SCHMIERFIX
LIQUID COOLANT	LIQUI MOLY COOLANT READY MIX RAF12+

Note:
It is essential that all renewals should be performed with the products listed in the table above.

CHAPTER 2 OPERATION


2

CONTENTS

Main parts 16
- Fuel tank cap 16
- Clutch lever 16
- LH switch 16
- RH switch 17
- Front brake lever and gas control 17
- Gear change lever 17
- Brake pedal 17
- Side stand 18
- Keys 18
- Steering lock 18

Dashboard operating instructions 19
- Main parts 19
- Warning lights 20
- Battery replacement 21
- Adjust button function instruction 22
- Select button function instruction 23
- To Enter the Setting Mode 24

Checks before and after use 28
Running in 28
Fuelling 29
Starting the engine 30
Engine shut-down 30
Vehicle preparation for use in heavy-duty conditions 31




MAIN PARTS

FUEL TANK CAP


Disconnect the ventilation pipe **1**.
To open the tank turn the cap **2** anticlockwise.

To close the fuel tank's cap, set it on the tank and crew it clockwise.



CLUTCH LEVER

Clutch lever is fitted to the left-hand side of the handlebars.



LH SWITCH

The dip and service switch is located on the left side of the handlebar and is composed as follows:

1 - Horn button;

2 - Dip switch:

parking lights and high beam;

parking lights and low beam;


3 - Flash-to-pass button;

4 - Turn signal light switch: shifting lever left or right activates the left or right indicators. When released, the lever returns to the central position. Press it to turn the indicators off.

RH SWITCH


Starter button **1** is located on the right-hand side of the handlebars and operate the electric engine starter. For startup, refer to page 30. Do not press the button **1** while the engine is running.

The button **2** turns off the engine.




FRONT BRAKE LEVER AND GAS CONTROL

The front brake lever **A** and the gas throttle **B** are located on the right side of the handlebar.




GEAR CHANGE LEVER


Gear change lever is fitted to the left side of the engine.
The positions corresponding to the different gears are shown in the figure.



BRAKE PEDAL

Brake pedal is located in front of the right-hand footrest.






SIDE STAND

Press down side stand with the foot and lean the vehicle against it.
Ensure that the ground is solid and the vehicle stands steadily.


WARNING: do not climb on the vehicle when the side stand is down.



If the vehicle is used off-road, the closed stand can be further fastened by means of rubber band.

KEYS

The vehicle is supplied with two keys (one key and its spare).




STEERING LOCK

To activate the steering lock:
- turn the handlebar counter-clockwise;
- push the key and turn counter-clockwise;
Remove the key from this position.
To deactivate the steering lock:
- turn the key clockwise;
- turn the handlebar clockwise;
From this position, the handlebar is free to move, the key can be removed.

WARNING: do not keep the spare key inside the vehicle, but in a safe place.
We suggest you note the code number stamped on the keys. In this way you can obtain a duplicate.

DASHBOARD OPERATING INSTRUCTIONS

MAIN PARTS



Time
Clock: 12/24 MODE
Stopwatch: According to setup distance to record the testing time.
Speed Log: Average speed and max speed record.

Speedometer
Display range: 0~360km/h (0~225 MPH)
Display unit: km/h or MPH

Battery
Inner Battery Level:
Display range: 4 levels.


Indicator lights
High beam light (Blue)
Fuel reserve
MIL (Engine management system fault)
Turn indicators (Green)

Adjust Button
Press the **Adjust button** in the main screen to switch between ODO, TripA/B, Total Hour meter, Hour meter A/B.
Press and hold the **Adjust button** for 3 seconds in Trip A/B screen to reset.
Press and hold the **Adjust button** for 3 seconds in Hour meter A/B screen to reset.

Select button
Press the **Select button** in the main screen to switch between 12/24 hour mode, speedometer record, topwatch , and MAX record.

Odo meter
Display range: 0~99999 km (miles), reset automatically after 99999 km (miles).
Display unit: 1 km (mile).

Trip meter
Display range: 0~9999.9 km (miles), reset automatically after 999.9 km (miles).
Display unit: 0.1 km (mile).



1 Headlight indicator
The system activates the indicator in synchrony with the activation of the mains beams.

2 Turn indicator lights
The system activates the indicator in synchrony with the activation of the turn indicators.


3 Reserve indicator light
If the warning light turns on, refuel as soon as possible. The reserve amount is shown on page 10.


4 MIL indicator light (Engine management system fault)
The MIL warning light combined with the CHECK message on the display indicates a malfunction in the engine management system




This condition occurs ONLY while the engine running.
Contact as soon as possible an authorized Betamotor.

Vehicle battery voltage displaying
When the vehicle is running, the vehicle battery voltage is displayed.
WARNING:
If the voltage value blinks turn off the engine and disconnect the battery as described at page 68.
Contact authorised BETAMOTOR customer service.







BATTERY REPLACEMENT


Follow this procedure for proper installation.
The meter includes an internal battery (CR2032). This battery shall be replaced only when power runs out.

For replacement remove the headlight mask. Remove the battery cover located behind the instrument and pull out the battery.

In order to install the battery properly, push the battery as shown on figure to make sure the battery is placed underneath the metal tab (**1**).

WARNING:
Not following this procedure could result in permanent damage to the meter.

2 ADJUST BUTTON FUNCTION INSTRUCTION




In main screen, press the **Adjust button** once to switch the function from odometer to trip.



In main screen, you could hold pressing the **Adjust button** for 3 seconds to change the speed and space unit, from **km / h** and **km** to **MPH** and **mile** and vice versa.






Press the **Adjust button** to switch from trip A to trip B.



Hold pressing the **Adjust button** for 3 seconds to reset the trip A.






Press the **Adjust button** to switch from trip B to total hour meter.




Hold pressing the **Adjust button** for 3 seconds to reset the trip B.





Press the **Adjust button** to switch from total hour meter to hour meter A.






Press the **Adjust button** to switch from hour meter A to hour meter B.



Press and hold the **Adjust button** for 3 seconds to reset the hour meter A.






Press the **Adjust button** to switch from Hour Meter B back to the main screen.




Press and hold the **Adjust button** for 3 seconds to reset the Hour Meter B.





The main screen.

SELECT BUTTON FUNCTION INSTRUCTION




Press the **Select button** during main screen to switch from Clock to Stopwatch.

Press and hold the **Select button** for 3 seconds to change between 12/24hour mode.




NOTE: If 24hour mode is chosen, then the AM/PM symbol will not be displayed.



Press the **Select button** to switch from Stopwatch to Speed Record.


Press and hold the **Select button** for 3 seconds to reset the Stopwatch.






Press the **Select button** to switch from Speed Record back to main screen.

Press and hold the **Select button** for 3 seconds to reset the Speed Record.



NOTE: If Engine Oil Light goes up, reset the Engine Oil Light in this screen to re-calculate the mileage.


NOTE: Average speed and the Max speed display in the 3 seconds rotation.




The main screen.

2 TO ENTER THE SETTING MODE

Adjust+SelectX3 function instruction



In main screen, press down the Adjust+SelectX3 to enter the tire circumference and sensing point setting (for changing different size tire.)



The tire circumference and sensor point setting.

Press the **Adjust button** to enter the tire circumference setting.

The tire circumference and sensing point setting



EX. The tire circumference is 2100 mm.


Press the **Select button** to change the setting.

NOTE: The tire circumference setting range 2100mm / 1811mm.



EX. The tire circumference setting is changed from 2100mm to 1811mm.

Press **Adjust button** to go back to tire circumferences value setting screen.




From **a 1** switch to **a 2** screen.


Press the **Adjust button** to enter the clock (Hour) setting.



Press the **Select button** to enter the clock (Hour) setting.

The clock (Hour) setting





EX: You want to set the hour at 14.

Press the **Select button** to choose the hour you want to set.

NOTE: Setting range: 0~23 H.

NOTE: The sequent of cursor movement:
Hour>Ten-Digit of Minute>Single Digit of Minute

EX. Now the setting is changed from 0:00 to 14:00.

Press the to enter the **Adjust button** minute setting.

The clock (minute) setting





EX. To change the setting to 14:05.


Press the **Select button** to choose the minute you want to set.

NOTE: Setting range: 0~59 minutes..

EX. Now the minute is changed from 14:00 to 14:05.

Press **Adjust button** to get back to Clock setting screen.





Switch from d2 to d3

Press **Select button** to switch to Stopwatch distance setup entering screen.


Press **Adjust button** to enter the distance setup for Stopwatch.

Distance setup for Stopwatch



Press the **Select button** to choose auto/ manual stopwatch function.

If Auto is chosen, press the **Adjust button** to exit the stopwatch setting function.



NOTE: Default:AUTO



Switch from d 3 to d 4

Press **Select button** to switch to Engine Oil Light Mileage setting screen.



Press **Adjust button** to enter the Engine Oil Light Mileage setting.

Maintenance Light Mileage Setting



Press the **Select button** to choose maintenance mileage ON or OFF.

NOTE: Default:OFF



If ON is chosen, press **Adjust button** to enter the maintenance mileage setting

Press the **Adjust button** to move the cursor to the digit that would like to set.



If OFF is chosen then press the **Adjust button** to exit the maintenance mileage setting.




Press Select button to switch the ODO setting. screen from d 4 to d 5



Press the **Adjust button** to enter the Backlight Brightness setting.

Backlight brightness



Press the **Select button** to adjust the brightness of the backlight

NOTE: Adjustable Range: 1 ~ 5

NOTE: Default: 5

Press the **Adjust button** to exist from the Backlight Brightness setting.

CHECKS BEFORE AND AFTER USE

For safe driving and long vehicle life you should:

1 Check all fluid levels.

2 Check the correct operation of the brakes and brake pad wear (page 58).

3 Check pressure, general condition and thickness of tread.

4 Check that the spokes are properly tightened.

5 Check the tensioning of the chain (page 65).

6 Check the adjustment and the operation of all the cable controls.

7 Inspect all the nuts and bolts.

8 With the engine running, check the operation of the headlight, the rear and brake lights, the indicators, the warning lights and the horn.

9 Wash the motorcycle thoroughly after off-road use (page 71)

RUNNING IN

The running-in period lasts approximately 15 hours, during which it is advisable to:

1 During the first 3 hours of operation the engine should only be used to approximately 50 percent of its power. In addition, the engine speed should not exceed 7,000 rpm.

2 For the next 12 hours of operation the engine should only be used to about 75 percent of its power.

WARNING
After the first 3 hours change the engine and gear oil.

This procedure should be followed each time piston, piston rings, cylinder, crankshaft or crankshaft bearings are replaced.

FUELLING

See page 13 for the fuel specifications.

Fuel tank capacity is shown on page 10.

To refuel open the tank cap (page 16).

After refuelling, screw the cap back and tighten securely.

WARNING:
The refuelling should be performed with the engine off.

When the operation is finished, reconnect the ventilation pipe.



WARNING:
Fire hazard. Fuel is highly flammable.



Always stop the engine when refuelling and keep open flames and lighted cigarettes away.



Do not top up fuel while using a mobile phone.

Refuel in an open well ventilated area.

Pay special attention so that the fuel does not come into contact with hot parts of the vehicle. Immediately clean up any spilled fuel.



WARNING: Risk of poisoning.

Fuel is poisonous liquid and a health hazard.



Fuel must not come into contact with the skin, eyes, and clothing. Do not breathe in the fuel vapours. If contact occurs with the eyes, rinse immediately with plenty of water and seek medical advice. If contact occurs with skin, immediately clean contaminated areas with soap and water If fuel is swallowed, contact a doctor immediately. Change clothing that is contaminated with fuel.

WARNING: Environmental pollution hazard.

The fuel must not contaminate the ground water, the ground, or the sewage system.

STARTING THE ENGINE

The bike starts ONLY with the battery mounted on the vehicle and connected to the electrical system.

Check that the gears are in neutral (page 17).

Close the side stand (page 18).

WARNING:
During start-up do not operate the throttle.

WHIT ELECTRIC STARTER (page 17):
Press the startup button for a max of 3 seconds. If the vehicle does not startup, wait 30 seconds before attempting a new startup.
NOTE
Pauses are needed to diffuse the generated heat and to avoid damaging the battery. If the battery is at a temperature below 15°C, the electric startup will be weak, not because the battery is deteriorated but because it needs to be warmed up. Therefore, with temperatures below 15°C, several startup attempts may be necessary to heat the battery and thereby increase the battery power provided by the battery.

Do not press the button while the engine is running.

NOTE: If the battery charge is not sufficient to allow the electric starter you can still start the bike with the start lever if the battery voltage is more than 8V.

ENGINE SHUT-DOWN

To shut-down the engine press the button  on the switch unit (page 16).

WARNING:
In case of fall the vehicle turns off after about 5 seconds.

VEHICLE PREPARATION FOR USE IN HEAVY-DUTY CONDITIONS

Using the vehicle in heavy-duty conditions, such as sand or wet or muddy soils, may require the corrective actions mentioned below.

The following are considered heavy-duty operating conditions:

- Dry sand
- Wet sand
- Particularly wet and muddy soils
- Driving in high temperature and low speed conditions
- Driving in low temperature and snow conditions

General actions:

- Verify filter and filter box cleaning (page 48)
- Verify tensioning and wear of the chain (page 73)
- Verify all electrical connectors, making sure they are well connected. Keep them dry and clean.

USE ON DRY SAND

- Apply specific protection against sand to the air filter
- Clean the chain
- Assemble a steel crown. For this operation contact the Betamotor service network. (Do not grease the chain!)
- Verify that the radiator fins are clean
- Verify that the radiator fins are not bent

USE ON WET SAND

- Apply an anti-water cap for the water filter
- Clean the chain
- Assemble a steel crown. For this operation, contact the Betamotor service network. (Do not grease the chain!)
- Verify that the radiator fins are clean
- Verify that the radiator fins are not bent

USE ON PARTICULARLY WET AND MUDDY SOILS

- Apply an anti-water cap for the water filter
- Assemble a steel crown. For this operation contact the Betamotor service network.
- Verify that the radiator fins are clean
- Verify that the radiator fins are not bent
- After use, proceed with washing (page 71)

DRIVING IN HIGH TEMPERATURE AND LOW SPEED CONDITIONS

- Adjust crown size based on the route.
  Note: The oil has a tendency to heat up quickly when there is frequent clutch use and when using a crown whose dimensions are excessive. For this operation contact the Betamotor service network.
- Clean the chain
- Verify that the radiator fins are clean
- Verify that the radiator fins are not bent
- Verify cooling liquid level (page 48)
- For this use it is recommended to use an electric fan (optional). For the code, refer to the Betamotor accessory catalogue.

DRIVING IN LOW TEMPERATURE AND SNOW CONDITIONS

- Apply water protection to the air filter
- After use, proceed with washing (page 71)

CHAPTER 3 ADJUSTMENTS

CONTENTS

Key to symbols 34
Brakes 34
- Front brake 34
- Rear brake 34

Clutch 35
Adjustment of gas clearance 35
Idle adjustment 35
Handlebar adjustment 35
- U-bolt position adjustment 35
- Adjustment of the handlebar position 36


Adjusting fork 37
- Adjusting the rebound damper 37
- Adjusting the spring preload 37
- Adjusting the compression damper 37
- Adjusting the suspensions 38

Shock absorber 39
- Adjusting the rebound damper 39
- Adjusting the hydraulic compression damper (high and low speeds) 39
- Adjusting the spring preload 40
- Static sag load test 40
- Suspensions settings according to the weight of the rider 41

KEY TO SYMBOLS

Tightening torque

Threadlocker Medium




M03_L0017

BRAKES

FRONT BRAKE

The front brake is disk type with hydraulic control.


The home position of brake lever **2** can be adjusted by means of screw **1**.



M03_L0018

Warning! Once the adjustment has been made, tighten the locknut **1A**.

Warning! Do not remove the locknut for any reason **1A**.




M03_L0014

REAR BRAKE

The home position of brake pedal **3** can be altered by turning adjusting screw **5** after loosening the counternut located under dust cap **4**. Loosen the counternut and turn the adjusting screw until the desired height is obtained. Retighten the counternut after completing the operation.


CLUTCH

The adjustment screw **6** allows adjustment of the distance of lever **7** from the knob. The empty run is recovered automatically.



ADJUSTMENT OF GAS CLEARANCE


The throttle control cable should always have a 3-5 mm play. In addition, the idle speed should not change when the handlebars are fully rotated to the left or right. Push back protective cap **1**. Loosen counternut **2** and turn adjusting screw **3**. Tighten the counternut and check that the throttle twist grip turns smoothly.



IDLE ADJUSTMENT

The minimum speed is controlled directly by the electronic control unit. Any manual adjustment is not allowed.


WARNING! Do not modify the indicated screw for any reason. Modifying the position of this screw may cause abnormal response behaviour and engine operation. Moving the indicated screw, in terms of the warranty, is considered tampering.




HANDLEBAR ADJUSTMENT

U-BOLT POSITION ADJUSTMENT


The lower bracket **1** can be mounted on the holes nr. **2**, **3** or **4** respectively.





To adjust the position of the u-bolt remove the screws shown in the figure.


Remove the handlebar.



Remove the screws **5**.

Position the U-bolt as required.


At the end refit the screws **5** after the application of thread lock fluid and tighten to the torque indicated.



Apply the handlebar.

Apply the top u-bolt.

Refit the screws **6**. Tighten to the torque indicated.



ADJUSTMENT OF THE HANDLEBAR POSITION

The handlebar can be adjusted by rotating it back and forth.

To adjust the handlebar loosen screws **1**.

Position the handlebar according to requirements.


Tighten to the torque indicated.

ADJUSTING FORK

ADJUSTING THE COMPRESSION DAMPER

Hydraulic compression adjuster **A** is used to manage the ability of the fork to absorb a shock. By turning clockwise the adjuster closes, thus increasing the braking effect; conversely by turning counterclockwise the conversely opens, thus decreasing the braking effect.


For standard calibration, refer to page 11.



ADJUSTING THE REBOUND DAMPER

The hydraulic rebound damper determines the behaviour of the telescopic fork during extension and can be adjusted by means of screw **C**. By screwing the screw the action of the rebound damper increases; by unscrewing the screw the action of the rebound damper decreases.


For standard calibration, refer to page 11.




ADJUSTING THE SUSPENSIONS

Suggestions for adjustment according to use:

• Increased comfort
To make it easier to follow the ground and its roughness, open (turn counterclockwise) the compression control **C**.
• Lack of grip






M03_L0055

ADJUSTING THE SUSPENSIONS

Suggestions for adjustment according to use

To make it easier to follow the ground and its roughness, open (turn counterclockwise) the compression control **C**.




M03_L0024

Dirt roads or not very challenging roads

To absorb even the smallest roughness, open (turn counterclockwise) the compression adjuster **C** by a few clicks.

Challenging terrain

For the use on challenging terrain it is necessary to intervene on the extension adjuster **A**. To find the right grip balance of the front wheel with respect to the terrain, open (turn counterclockwise) or close (turn clockwise) the adjuster.



M03_L0055

Potholes in sequence or strong compressions

In the presence of potholes or strong compressions, close (turn clockwise) the compression adjuster **C** by a few clicks. Balance out the extension adjuster **A** accordingly to keep the best contact with the ground.


SHOCK ABSORBER

ADJUSTING THE REBOUND DAMPER

Turn screw **A** to adjust the hydraulic rebound damper.

Turning the screw counterclockwise decreases the damping effect.

For standard setting, refer to page 11.



ADJUSTING THE HYDRAULIC COMPRESSION DAMPER (HIGH AND LOW SPEEDS)

Adjustment for low compression speed:

- Using a screwdriver, loosen screw **C** by turning it clockwise to increase the hydraulic compression damper.

For standard setting, refer to page 11.


Adjustment for high compression speed:


- Turn knob **D** counterclockwise to decrease the hydraulic compression damper.

For standard setting, refer to page 11.

WARNING:
Starting from the standard position, turn the knob counterclockwise (with a closing action), the center screw will have an integral movement, then will rotate with the knob.

For standard setting, refer to page 11.







ADJUSTING THE SPRING PRELOAD

Loosen counter-ring **E**, rotate ring **F** clockwise to increase the spring preload (and consequently the shock absorber preload) or anticlockwise to decrease it. After obtaining the desired preload, turn counter-ring **E** until it stops against adjusting ring **F**.

For standard setting, refer to page 11.





STATIC SAG LOAD TEST

To verify the static sag of the shock absorber proceed as follows:

- Place the motorcycle on the work stand.
- Measure the vertical distance between the rear wheel axle and a reference point on the rear fairings.
- Write down the dimension H_1.
- Remove the work stand.
- Keep the motorcycle in vertical position and measure again the distance between the wheel axle and the reference point previously established.
- Write down the dimension H_2.

Verify that the value of the static compression $X = H_1 - H_2$ matches the one shown on page 11. Otherwise, perform the adjustment of the spring preload as described above.

SUSPENSIONS SETTINGS ACCORDING TO THE WEIGHT OF THE RIDER

The table below shows the spring constant K of the suspensions (fork and shock absorber) depending on the weight of the driver.
Refer to the accessories catalogue Betamotor to obtain the spring codes.

Rider weight [kg]	K (Spring constant)	
	FORK [N/mm]	SHOCK ABSORBER [daN/mm]
<50	/	4,8
50 - 60	4,5	5
60 - 70	4,6	5,2
70 - 80	4,7	5,4
80 - 95	/	5,6
>95	4,9	5,8

Standard settings


CHAPTER 4 CHECKS AND MAINTENANCE

4

CONTENTS

Engine oil....44
Check the level....44
Replacement....44
Gearbox oil....46
Check the level....46
Replacement....46
Liquid coolant....47
Check the level....47
Replacement....48
Air filter....50
Air filter cleaning....51
Spark plug....53
Front brake....54
Check the level of the front brake fluid....54
Restoring the level of the front brake fluid....54
Bleeding the front brake....55
Front brake lining control....56
Brake disc thickness control....56
Rear brake....57
Check the level of the rear brake fluid....57
Restoring the level of the rear brake fluid....57
Bleeding the rear brake....58
Rear brake lining control....59
Brake disc thickness control....59
Clutch control....60
Check the level....60
Bleeding....61
Check and adjusting of steering play....62
Fork....63
Front wheel....63
Tightening....63
Tyres....64
Rear suspension leverage....64
Chain....65
Check and adjust tightening chain....65
Check for chain wear....66
Headlight....66
Replacing the headlight bulbs....67
Tail light....67
Battery....68
Battery removal....68
Battery assembly....69
Inactivity....69
Charging the battery....70
Fuses....70
Cleaning the vehicle....71
General precautions....71
Electrical connector maintenance....72
Control unit connector....72
Air pressure and temperature sensor....73
Prolonged inactivity....74
Scheduled maintenance vehicle....75
Tightening torque overview....77

EN




ENGINE OIL

CHECK THE LEVEL


1) Keep the vehicle in vertical position relative to the ground.
2) Position the drive on a flat base ensuring stability.
3) Start the engine and keep it running for about 2 minutes.
4) Keeping the engine idling, check that the oil level reach middle of the of the inspection window **1**.
5) If the level is below the edge of the window, switch off the engine and top up through the filler hole **2**. Load oil until it reaches the upper edge of the window.
6) Close the filling hole with the plug **2** and repeat steps 3, 4 and 5 until the condition in step 4 is satisfied.

Use the oil indicated on page 13 in the "Recommended lubricants and liquids" table.



REPLACEMENT


Always perform the replacement when engine is hot:
- Position the drive on a flat base ensuring stability.
- Remove the engine casing (page 84).
- Place a container under the engine.




WARNING:
Hot oil can cause severe burns!

- Unscrew filler plug **1** and drain plug **2**.
- Remove the wire mesh filter.
- Drain all the oil from the crankcase.
- Thoroughly clean the drain plug, the wire mesh filter and the sealing surfaces.
- Mount the wire mesh filter and the drain plug.
- Tighten to the torque indicated.


To change the paper filter, remove the oil tap form engine unscrewing the two screws **3**. Using special seeger ring pliers, pull the paper oil filter.





Mount the new paper filter, close the oil tap to engine, tighten the screws at 10 Nm.

Pour in the quantity of liquid indicated on page 10.
Use the oil indicated on page 13 in the "Recommended lubricants and liquids" table.





- Screw on filler cap **1** again.
- Check the oil level as described in paragraph "Check the level" (page 44).


WARNING:
Hot oil can cause severe burns!

ATTENTION:
Dispose of used oil in compliance with the regulations in force.

Refit the engine protection plate (page 84).







GEARBOX OIL

CHECK THE LEVEL

Hold the vehicle upright.
Position the drive on a flat base ensuring stability.

Remove the inspection cap **1**.

The oil level must arrive to the lower edge of check hole.

In contrary case restore the oil level through cap **2**.


The inspection cap is ONLY to check the oil level. For the oil drain, refer to the paragraph Replacement on page 46.

Use the oil indicated on page 13 in the "Recommended lubricants and liquids" table.

REPLACEMENT

Always perform the replacement when engine is hot:
- Position the drive on a flat base ensuring stability.
- Remove the engine casing (page 84).
- Place a container under the engine.

WARNING:
Hot oil can cause severe burns!



- Unscrew filler plug **2** and drain plug **3**.
- Drain all the oil from the crankcase.
- Apply the cap **3** and tighten up to the specified torque.

Pour in the quantity of liquid indicated on page 10.


Use the oil indicated on page 13 in the "Recommended lubricants and liquids" table.

Close plug **2**.

WARNING:
Hot oil can cause severe burns!

ATTENTION:
Dispose of used oil in compliance with the regulations in force.

Re-assemble the engine protection plate (page 84).




LIQUID COOLANT

CHECK THE LEVEL

WARNING: Never unscrew the filler cap of the radiator when the engine is hot. Danger of burning!

Keep the vehicle in vertical position relative to the ground.

The level of the coolant must be checked when the engine is cold. Use the following procedure:



- Unscrew cap **1** and ensure that the liquid is visible in the lower portion of the loading tube.
- In the case in which the liquid is not visible proceed topping up.
- At the end of operation refit the filler cap.

Use the liquid coolant indicated on page 13 in the "Recommended lubricants and liquids" table.

WARNING: Never unscrew the filler cap of the radiator when the engine is hot. Danger of burning!

WARNING:
Wear appropriate protective clothing and protection gloves.

Keep coolant out of reach of children.

Avoid any direct contact of the coolant with skin, eyes or clothing. If this happens:


- with the eyes, rinse immediately with plenty of water and seek medical advice;
- with skin, Immediately clean contaminated areas with soap and water Change clothing that is contaminated with coolant.

If coolant is swallowed, contact a doctor immediately.


REPLACEMENT

Keep the vehicle in vertical position relative to the ground.

Replacement of the coolant must take place when the engine is cold.



- Unscrew cap **1**.



- Place a container under screw **2**.
- Unscrew the screw **2**.
- Drain the liquid.
- Tighten screw **2** applying the specific washer.
- Top up.
- Reapply the loading cap.

The amounts of liquid are shown on page 10.

Use the liquid indicated on page 13 in the "Recommended lubricants and liquids" table.



WARNING:
Never unscrew the filler cap of the radiator when the engine is hot. Danger of burning!



WARNING:
Wear appropriate protective clothing and protection gloves.



Keep coolant out of reach of children.



Avoid any direct contact of the coolant with skin, eyes or clothing. If this happens:


- with the eyes, rinse immediately with plenty of water and seek medical advice.
- with skin, Immediately clean contaminated areas with soap and water Change clothing that is contaminated with coolant.

If coolant is swallowed, contact a doctor immediately.


AIR FILTER

Check after every ride.

To access the filter:
- Remove the filter cover panel (page 81).




- Release filter fastener **1**



- Pull out air filter **2**

Reassemble by performing the operations in reverse order.

WARNING:
After every intervention, check that nothing has been left inside the filter box.



WARNING!
When re-inserting the filter, be careful that the pin on the filter cage is properly engaged into the specific housing.

WARNING:
Do not clean the filter with gasoline or petrol.

NOTE:
If the filter is damaged, replace it immediately.
To replace, contact authorised Beta-motor customer service.

WARNING:
Never use the vehicle if the air filter is not in place. The infiltration of dust and dirt can cause damage and considerable wear.


WARNING:
After every intervention, check that nothing has been left inside the filter box.


AIR FILTER CLEANING

- Thoroughly wash the filter with water and soap.
- Dry the filter.
- Wet the filter with filter oil and then remove the excess oil to prevent it from dripping.
- If necessary also clean the interior of the filter box.


Apply the sponge filter element to the cage with care:

- to make to correspond the sign UP of the filter with the coding indicated on the cage.






• To completely insert the rungs **3** of the cage into the filter seats.



• To hook the inside edges of the filter with the correspondents grafts **4** found on the cage.




Note: before refitting the filter to the vehicle is recommended to apply a long-term grease in the area **A**.

SPARK PLUG

Keeping the spark plug in good condition will reduce fuel consumption and increase engine performance.

To accede to spark plug, is necessary to take off saddle (page 80) and the fuel tank (page 85).


Examine the distance between the electrodes with a feeler. This distance should be from 0,5÷0,6 mm. If it is not, it may be corrected by bending the earth electrode.



Check as well that there are no cracks in the insulation or corroded electrodes. If so, replace immediately.

When replacing the spark plug, screw it in by hand until it stops, then tighten with a wrench.


WARNING:
Do not check while the engine is hot.



FRONT BRAKE

CHECK THE LEVEL OF THE FRONT BRAKE FLUID

Check the level of the brake fluid through sight **A**. The level of the fluid should never fall below the mark in the sight.



RESTORING THE LEVEL OF THE FRONT BRAKE FLUID

To restore the level of the brake fluid, loosen the two screws **1**, lift cap **2** and add brake fluid until its level is 5 mm below the upper rim of the reservoir.

Use the liquid indicated on page 13 in the "Recommended lubricants and liquids" table.

WARNING:
The brake fluid is extremely corrosive. Take care not to spill it on the paintwork.

Wear appropriate protective clothing and protection gloves.


Keep coolant out of reach of children.

WARNING: Avoid any direct contact of the liquid with skin, eyes or clothing. If this happens:

- with the eyes, rinse immediately with plenty of water and seek medical advice.
- with skin, immediately clean contaminated areas with soap and water. Change clothing that is contaminated with liquid.

If liquid is swallowed, contact a doctor immediately.

BLEEDING THE FRONT BRAKE



To bleed air from the front brake circuit, proceed as follows:

- Remove the rubber cap **1** from the valve **2**.
- Open the sump cap.
- Place one end of a small transparent tube into the valve **2**, and the other end inside a container.
- Pump with the brake lever 2/3 times and keep the lever pressed.
- Unscrew the valve and let the oil drain.
- If are still visible in the tube repeat above operation until obtaining a continuous outflow of oil within no air bubbles.
- Close the valve and release the lever.

NOTE:
during this procedure, continuously top up the brake pump thank to replace the oil that is out flowing.

- Remove the tube.
- Replace the rubber cap.
- Close the oil reservoir cap.

Use the liquid indicated on page 13 in the "Recommended lubricants and liquids" table.

WARNING:
The brake fluid is extremely corrosive. Take care not to spill it on the paintwork.


Wear appropriate protective clothing and protection gloves.

Keep coolant out of reach of children.

WARNING: Avoid any direct contact of the liquid with skin, eyes or clothing. If this happens:

- with the eyes, rinse immediately with plenty of water and seek medical advice.
- with skin, immediately clean contaminated areas with soap and water. Change clothing that is contaminated with liquid.

If liquid is swallowed, contact a doctor immediately.




FRONT BRAKE LINING CONTROL

In order to verify the wear condition of front brake is enough to view the caliper from the bottom, where is possible to glimpse the brake lining tails which will have to show a brake of 2 mm in thickness. If the stratum is lesser let's start replacing them.

NOTE:
Perform the check according to the times shown in the table on page 75.

To replace, contact authorised Betamotor customer service.



BRAKE DISC THICKNESS CONTROL

Periodically verify disc condition. In case signs of damage , veins, or deformations are present, proceed with replacement.
Verify disc thickness. The minimum thickness is engraved on the disc.
Once the limit is in proximity or has been reached, proceed with brake disc replacement.
For replacement, contact an authorised Betamotor after-sales service centre.

REAR BRAKE

CHECK THE LEVEL OF THE REAR BRAKE FLUID

Check the level of the brake fluid through sight **A**. The level of the fluid should never fall below the mark in the sight.

RESTORING THE LEVEL OF THE REAR BRAKE FLUID

To restore the oil level, top up by means of oil filler cap **1**.

Use the liquid indicated on page 13 in the "Recommended lubricants and liquids" table.

WARNING:
The brake fluid is extremely corrosive. Take care not to spill it on the paintwork.


Wear appropriate protective clothing and protection gloves.


Keep coolant out of reach of children.

WARNING: Avoid any direct contact of the liquid with skin, eyes or clothing. If this happens:

- with the eyes, rinse immediately with plenty of water and seek medical advice.
- with skin, immediately clean contaminated areas with soap and water. Change clothing that is contaminated with liquid.

If liquid is swallowed, contact a doctor immediately.





BLEEDING THE REAR BRAKE

To bleed air from the rear brake circuit, proceed as follows:

- Remove the rubber cap **1** from the valve **2**.
- Open the sump cap.
- Place one end of a small transparent tube into the valve **2**, and the other end inside a container.
- Pump with the brake lever 2/3 times and keep the pedal pressed.
- Unscrew the valve and let the oil drain.
- If are still visible in the tube repeat above operation until obtaining a continuous outflow of oil within no air bubbles.
- Close the valve and release the lever.

NOTE:
During this procedure, continuously top up the brake pump thank to replace the oil that is out flowing.

- Remove the tube.
- Replace the rubber cap.
- Close the oil reservoir cap.

Use the liquid indicated on page 13 in the "Recommended lubricants and liquids" table.

WARNING:
The brake fluid is extremely corrosive. Take care not to spill it on the paintwork.

Wear appropriate protective clothing and protection gloves.

Keep coolant out of reach of children.

WARNING: Avoid any direct contact of the liquid with skin, eyes or clothing. If this happens:

- with the eyes, rinse immediately with plenty of water and seek medical advice.
- with skin, immediately clean contaminated areas with soap and water. Change clothing that is contaminated with liquid.


If liquid is swallowed, contact a doctor immediately.

REAR BRAKE LINING CONTROL

In order to verify the wear condition of front brake is enough to view the caliper from the bottom, where is possible to glimpse the brake lining tails which will have to show a brake of 2 mm in thickness. If the stratum is lesser let's start replacing them.


NOTE:
Perform the check according to the times shown in the table on page 75.


To replace, contact authorised Betamotor customer service.




BRAKE DISC THICKNESS CONTROL

Periodically verify disc condition. In case signs of damage , veins, or deformations are present, proceed with replacement.
Verify disc thickness. The minimum thickness is engraved on the disc.
Once the limit is in proximity or has been reached, proceed with brake disc replacement.
For replacement, contact an authorised Betamotor after-sales service centre.







CLUTCH CONTROL

CHECK THE LEVEL

To check the oil level in the clutch pump, first remove cover **2**.
Remove the two screws **1** and take off cover **2** together with the rubber bellows.
With the clutch pump in a horizontal position, the level of the oil should be 5 mm below the upper rim.
In the case where the level is lower than specified top up.

Use the liquid indicated on page 13 in the "Recommended lubricants and liquids" table.

WARNING:
The clutch fluid is extremely corrosive. Take care not to spill it on the paintwork.

Wear appropriate protective clothing and protection gloves.

Keep coolant out of reach of children.

WARNING: Avoid any direct contact of the liquid with skin, eyes or clothing. If this happens:


- with the eyes, rinse immediately with plenty of water and seek medical advice.
- with skin, immediately clean contaminated areas with soap and water. Change clothing that is contaminated with liquid.


If liquid is swallowed, contact a doctor immediately.

BLEEDING

To bleed air from the clutch pump, proceed as follows:

- Remove the rubber cap **1** from the valve **2**.
- Open the sump cap.
- Place one end of a small transparent tube into the valve **2**, and the other end inside a container.
- Pump with the clutch lever 2/3 times and keep the lever pressed.
- Unscrew the valve and let the oil drain.
- If are still visible in the tube repeat above operation until obtaining a continuous outflow of oil within no air bubbles.
- Close the valve and release the lever.





NOTE:
During this procedure, continuously top up the pump tank to replace the liquid that is out flowing.

- Remove the tube.
- Replace the rubber cap.

Use the liquid indicated on page 13 in the "Recommended lubricants and liquids" table.

WARNING:
The clutch fluid is extremely corrosive. Take care not to spill it on the paintwork.


Wear appropriate protective clothing and protection gloves.

Keep coolant out of reach of children.

WARNING: Avoid any direct contact of the liquid with skin, eyes or clothing. If this happens:


- with the eyes, rinse immediately with plenty of water and seek medical advice.
- with skin, immediately clean contaminated areas with soap and water. Change clothing that is contaminated with liquid.

If liquid is swallowed, contact a doctor immediately.



CHECK AND ADJUSTING OF STEERING PLAY

Periodically check the play in the steering sleeve by moving the fork back and forth as shown in the figure. Whenever you feel play, adjust as described below:



- Loosen the screws **1**
- Loosen the screw **2**
- Reduce the play by turning nut **3**

Tighten nut **3** to the indicated torque and make sure the steering wheel has no slack and moves freely, then proceed with tightening screws **1** and **2** to the indicated torque.


WARNING:
Tightening of the screws should be carried out by adjusting the torque wrench to the stability torque with repeated tightening until stability torque has been achieved.

FORK

To maintenance refer at an authorized service centre Betamotor.

To check the tightening torques see as shown in the figure.

WARNING:
Tightening of the screws should be carried out by adjusting the torque wrench to the stability torque with repeated tightening until stability torque has been achieved.




FRONT WHEEL

TIGHTENING


Following removal of the wheel:


Compress and release the fork 3-4 times.



Tighten the wheel bolt and the screws of the foot-legs.

WARNING:
Tightening of the screws should be carried out by adjusting the torque wrench to the stability torque with repeated tightening until stability torque has been achieved.





REAR SUSPENSION LEVERAGE

In order to guarantee optimal operation and duration over time of the progressive leverage of the rear suspension, it is recommended to periodically check correct tightness of nuts and bolts.

Verify that suspension nuts and bolts are at the indicated torque.

TYRES

Only fit tyres approved by BETAMOTOR.
Unsuitable tyres can adversely affect the road holding of the vehicle.

- To protect your safety, immediately replace any damaged tyres.
- Slick tyres adversely affect the road holding of the vehicle, especially on wet roads and in off-road riding.
- Insufficient pressure results in abnormal wear and overheating of the tyres.
- The front and rear tyres must have the same tread design.
- Always measure the inflating pressures when the tyres are cold.
- Keep the tyre pressures within the prescribed range.

CHAIN


Checking the drive chain periodically to ensure longer chain life. Always keep it lubricated and clean of deposited dirt.

Take special care in preventing the lubricant from coming into contact with the rear tyre or brake disc, otherwise the tyre grip and the action of the brake would be greatly reduced, making it very difficult to control the vehicle.


CHECK AND ADJUST TIGHTENING CHAIN

Hold the vehicle upright on the ground on a flat base ensuring stability.


The chain clearance must comply with the measure indicated. Tension the chain if the clearance exceeds the indicated value.




- Loosen the pin **1**.




- Loosen counternuts **A** on either side of the fork.
- Turn adjusting screws **B** on either side until the desired chain tension is obtained.
- Tighten counternuts **A** on either side of the fork.





• Tighten the pin **1** to the torque indicated.



CHECK FOR CHAIN WEAR

Shift into neutral, pull up the upper stretch of the chain with a force of 10 - 15 kg (see figure). Measure the length of 18 links on the lower stretch of the chain. If the length is ≥ 272 mm, replace the chain. Chains do not always wear evenly. For this reason it is important that the measurement is taken at different points along the chain.

When fitting a new chain, be sure to replace the chainring and sprocket as well. New chains wear more quickly if fitted on old and worn sprockets. After replacing the chain, adjust its tension as described on page 13.

HEADLIGHT


Keep the headlight glass clean at all times (see page 71).

Periodically check the correct angle of the light beam.

For disassembly and refitting see page 67.


REPLACING THE HEADLIGHT BULBS

To remove the headlamp mask (page 90).
For the replacement of the day light/ position light **1** remove the lamp from the lamp holder and replace it with a new one (page 13 for the lamp type).




For the replacement of high/low beam:

- remove the rubber cap **2**;
- disconnect the connector **3**;



- unhook the spring **4** and remove the light bulb.

Replace with a new lamp (page 13 for lamp data).
Warning: don't touch the bulb to avoid compromising the efficiency of the lamp.
For the reassembly proceed inversely as described above.




TAIL LIGHT

Keep the tail light glass clean at all times (see page 71).

The LED tail light is sealed. In the case of burnout of one or more LEDs it is necessary to replace the entire group.

To replace, contact authorised Betamotor customer service.



BATTERY

Battery is located under the saddle and requires no maintenance.

Keep the battery terminals clean. If necessary, protect them with a thin film of acid-free grease.

WARNING:
The battery contains hazardous substances:
- Keep the batterie out of the reach of children.


- Keep sparks and open flames away from the battery.

- Charge the battery only in well-ventilated areas, keeping it away from flammable materials. Use only chargers suitable for charging lithium-ion batteries.

- Do not attempt to charge fully exhausted batteries with a voltage lower than the minimum 9V. In this case, dispose of the battery according to applicable regulations.

- Do not remove the protections.

- When installing the battery, be sure to observe the polarity of the terminals.



BATTERY REMOVAL


Shut off all electrical users and stop the engine.
Remove the saddle (page 80).

FIRST remove the cap **1** of the negative pole and disconnect the negative lug **2** (black) from the negative pole.

THEN remove the cap of the positive pole **3** and disconnect the positive lug **4** (red) from the positive pole (+).

Release the rubber band **5**.

Remove the battery.



BATTERY ASSEMBLY


When fitting the battery, insert it with the terminals as shown in picture.


Reattach the rubber band **5**.

FIRST Connect the positive lug **4** (red) to the positive pole (+) of the battery by pushing the protective cap **3** in its position.

THEN secure the negative lug **2** (black) to the negative pole (-) of the battery by bringing the relative protective cap **1** in position.

Refit the saddle (page 80).





INACTIVITY

If the vehicle is not going to be used for a long time:
- remove the battery (page 68)
- charge with an adequate charger (page 70)
- store the battery in a dry place. The ideal temperature for storing the lithium-ion battery is 20°C.



CHARGING THE BATTERY

Check the battery charge using a multimeter or by pressing the "TEST" button on the battery (if it is present)

- **Voltage < 9V or "LOW"**:
  - Do NOT charge the battery
  - Replace the battery with a new equivalent one
- **Voltage <12.4V or "MED"**:
  - Charge the battery

Guidelines to charge the battery:


⚠ Use ONLY chargers suitable for charging lithium-ion batteries.

Recharge the battery with a specific battery charger when the vehicle is not used for more than 6 months.

FUSES

To access the fuse, remove the saddle (page 80).

Fuse **1**: in the event of a blown fuse, the services listed in the table are not operational:



Rear lights
Stop
Front lights
Tachometer and control lights
Turn lights
Klaxon
Electric fan (optional)

Fuse **2**: in the event of a blown fuse, the vehicle stops/does not start.

Fuse **3**: in the event of a blown fuse, the vehicle does not start.

Three spare fuses comes with the kit accompanying the vehicle.

A blown fuse should only be replaced with another of the same type. Should the new fuse also burn out when fitted, immediately contact a specialized BETAMOTOR dealer.

CLEANING THE VEHICLE

GENERAL PRECAUTIONS

WARNING: Do not clean your vehicle with a high-pressure device with a strong jet of water. Excessive pressure can reach electrical components, connectors, flexible cables, bearings, etc and can damage or destroy them.

WARNING: Wash motorbikes frequently with cold water that are used near the sea (salty air) and on roads subject to salt spreading in winter. Cover with a film of oil or silicone spray unpainted parts and the most exposed parts such as wheels, forks and swingarm. Do not treat rubber parts and brakes.

When cleaning, avoid direct exposure to sunlight.

Close off the exhaust system to prevent water from entering.

Avoid directing the jet of water onto the air filter box cover and the throttle body.

WASHING MODE

Use water jet to soften the dirt and mud accumulated on the paintwork, then remove them with a soft bodywork sponge soaked in water and shampoo. Subsequently rinse well with water, and dry with air and cloth or suede leather.

Detergents pollute water. Always wash the vehicle in areas equipped for collection and purification of the washing liquids.

AFTER WASHING

Proceed to the emptying of the filter box using the appropriate ventilation and drying.

After cleaning, ride a short distance until the engine reaches operating temperature.

WARNING: braking effect is reduced with wet brakes. Operate the brakes cautiously to allow them to dry.

Push back the handlebar control covers, so that water can evaporate.

When the bike is completely dry and cooled down, lubricate all moving parts.

Treat all plastic and painted components with non-aggressive detergents or products that are specific for the care of the motorcycle.


To prevent malfunction of the electrical system, treat electric contacts and switches with electrical contact spray.

ATTENTION: any oxidation of electrical contacts may result in serious malfunctioning to the power supply system.

Specifically, treat the battery poles as described on page 68 and pay particular attention to what is contained here below.


ELECTRICAL CONNECTOR MAINTENANCE

Disconnect the connectors listed below, blow compressed air on the connector both on the system and on the component side, and treat electrical contacts and switches with spray for electrical contacts.


M04_L0105

CONTROL UNIT CONNECTOR

To access the control unit connector it is necessary to remove the air filter cover panel (page 81).


M04_L0104


Then:
- press the lock device;
- rotate the safety device as shown;
- remove the connector;

For re-assembly, proceed opposite the above-mentioned order.


AIR PRESSURE AND TEMPERATURE SENSOR

Remove the tank (page 85).


The connector is positioned as indicated in figure.



1) press the lock device;
2) Pull the connector as shown.



For re-assembly, proceed opposite the above-mentioned order.
Attention: at the end of the operation ensure that the connector is blocked.



PROLONGED INACTIVITY

A few simple operations should be performed to keep the vehicle in good condition whenever it is to remain inactive for a long period (e.g. during the winter):

- Thoroughly clean the vehicle.
- Reduce the tyre pressures by approximately 30 percent, and if possible raise the tyres off the ground.
- Cover the unpainted parts, excepting the brakes and the rubber parts, with a film of oil or spray silicone.
- Remove the battery (page 68), and follow the instructions for inactivity (page 69) and recharging (page 70).
- Protect the vehicle with a non-waterproof sheet to protect from dust.

AFTER PROLONGED INACTIVITY

- Reinstall the battery.
- Restore the tyre inflating pressures.
- Check the tightening of all the screws having an important mechanical function.

SCHEDULED MAINTENANCE VEHICLE

WARNING! Register the maintenance operation on Betanet.

WARNING! After the first 100 Km (62 miles) of riding check the tightening of the following safety parts:

- Rear sprocket
- Brake calipers
- Brake pedal
- Brake discs
- Pinion

Key

C **Check** (Clean, adjust, lubricate, replace as necessary)
S **Replace/renew**
R **Adjust**
P **Clean**
T **Tighten**

		End of running-in - **3** hours or 90km	Coupon **1** - **30** hours or 900km	Coupon **2** - **60** hours or 1800km	Coupon **3** - **90** hours or 2700km	Coupon **4** - **120** hours or 3600km	Coupon **5** - **150** hours or 4500km	Coupon **6** - **180** hours or 5400km
Engine	Engine oil	S	S	S	S	S	S	S
	Paper filter oil	S	S	S	S	S	S	S
	Wire netting filter oil	P	P	P	P	P	P	P
	Gear and clutch oil	S	S	S	S	S	S	S
	Engine clamping screws	C	C	C	C	C	C	C
	Head screws	T						
	Kick start and gearchange lever screws	C	C	C	C	C	C	C
	Spark plug cap	P	P	P	S	P	P	S
	Spark plug	C		S		S		S
	Breather pipe	C	C	C	C	C	C	C
	Countershaft bearings				S			S
	Crankshaft bearings				S			S
	Connecting rod				S			S
	Piston and segments				S			S
	Cylinder				C			C
	Surface appearance of the cams				C			C
	Valve clearance	C	C	C	C	C	C	C
	Valves				C			S
	Valve guide wear				C			C
	Valve spring				C			S
	Clutch disc wear		C	C	S	C	C	S
	Clutch springs		C	C	S	C	C	S
	Clutch hub - basket wear		C	C	C	C	C	C
	Gearbox bearing (crankcase side)				S			S
	Surface appearance of the gearbox				C			C
	Water pump seals				S			S
	Oil pump control gears				S			S
	Noise-absorbing material of the silencer		S	S	S	S	S	S

The required engine maintenance is strongly depending on the level of use and on the accordingly done periodic checks and service.
The mentioned maintenance intervals are for the normal use of the vehicle, subject to the condition that the engine was never running under extraordinary conditions and the periodic service was done accurately.

		End of running-in - **3** hours or 90km	Coupon **1** - **30** hours or 900km	Coupon **2** - **60** hours or 1800km	Coupon **3** - **90** hours or 2700km	Coupon **4** - **120** hours or 3600km	Coupon **5** - **150** hours or 4500km	Coupon **6** - **180** hours or 5400km
Assembling groups	Coolant system tightness and coolant level	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Exhaust manifold tightness	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Drives sliding and regulation	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Liquid level clutch pump	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Airbox and air filter	**P**	**P**	**P**	**P**	**P**	**P**	**P**
	Chain, plate wheel and pinion	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Read the error memory with a BST diagnosis tester	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Operation of the electric system by blowing and greasing the main connections	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Check and recharge the 12V battery	**C**	**C**	**C**	**C**	**C**	**C**	**C**
Brake	Liquid level, pads thickness	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Disc thickness	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Pipe tightness	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Idle travel levers and drives sliding	**C**	**C**	**C**	**C**	**C**	**C**	**C**
Cycling	Chassis	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Swing arm	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Mobile parts	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Shock absorber and telescopic fork tightness	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Rear suspension linkage	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Dust seal	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Fuel lines	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Bearings of stearing	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Bolts	**T**	**T**	**T**	**T**	**T**	**T**	**T**
Wheels	Wheel spokes and rim coaxiality	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Tyres (wear and pressure)	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Bearings clearance	**C**	**C**	**C**	**C**	**C**	**C**	**C**

Key

C **Check** (Clean, adjust, lubricate, replace as necessary)
S **Replace/renew**
R **Adjust**
P **Clean**
T **Tighten**

WARNING:
For any service requirements, please contact Betamotor's Authorized Service Network.

TIGHTENING TORQUE OVERVIEW

Here below is an overview of the tightening torque of all pieces subject to adjustment or maintenance:

Forecarriage		
	Tightening torque [Nm]	Threadlock
Wheel pin	50	
Fork foots - wheel pin	10*	
Brake caliper - Fork	35	M
U-bolt fork tube protection	1,5	
Steering head base - fork legs	12*	
Steering head - fork legs	17*	
Stem pin on steering head	20	
Lower handlebar u-bolt - steering head	40	M
Upper handlebar u-bolt - lower handlebar u-bolt	25	
Steering head clearance adjustment nut	33	

Rear axle		
	Tightening torque [Nm]	Threadlock
Wheel pin	130	
Rear shock absorber - frame	50	
Rear shock absorber - rocker arm	50	
Connecting rod - frame	90	
Connecting rod - rocker arm	90	
Rocker arm - swinging arm	90	

Engine		
	Tightening torque [Nm]	Threadlock
Engine oil drain plug	15	
Paper oil filter plug	10	
Gearbox oil drain plug	20	

M Medium strength threadlock


* WARNING:
Tightening of the screws should be carried out by adjusting the torque wrench to the stability torque with repeated tightening until stability torque has been achieved.

Fairings		
	Tightening torque [Nm]	Notes
Fuel tank to the frame	10	Grease
Fuel tank fairings to the radiator	7	
Rear mudguard	5	M6
	20	M8
License plate	5	M6
	1,8	Self tapping
Small frame to frame	35	Medium strength threadlocker
Filter box arms to the frame	35	Medium strength threadlocker
Engine protection	7	

CHAPTER 5 REMOVING AND INSTALLING SUPERSTRUCTURES

CONTENTS

Removing and installing of the saddle 80
Removing and installing air filter cover panel 81
Removing and installing of the rear mudguard 82
Removing and installing of the engine protection 84
Removing and installing of the tank 85
Removing and installing the headlamp mask 90




REMOVING AND INSTALLING OF THE SADDLE


Press button **1**.



Remove the saddle towards the rear of the motorcycle.




To re-assemble:
Insert the cavity **1** of the saddle in slot **2**.



Press the saddle down in the middle and at the same time, push it forwards until the bayonet joint engages in its seat.

WARNING
Make sure the bayonet joint **3** is firmly inserted into the button lock.





REMOVING AND INSTALLING AIR FILTER COVER PANEL

Grab the side panel in the front side and pull out.

To refit insert the tabs **1** into their slots.

Slide the side panel toward the vehicle.






REMOVING AND INSTALLING OF THE REAR MUDGUARD


To remove the rear fender is necessary:


- remove the saddle (page 80);
- remove the screws **1** and **2** fixing the license plate holder to the vehicle;

Remove the saddle towards the rear of the motorcycle.




Remove the screws **3**, **4** and **5** (one for each side) fixing the mudguard to the vehicle.






Grasp the mudguard by the sides, spread the fender and slide out towards the rear.


For reassembly, proceed inversely compared to the previously-described disassembly procedures. Refer to the tightening torques, where indicated.





REMOVING AND INSTALLING OF THE ENGINE PROTECTION

To remove the engine protection plate, loosen the screws **1** and **2**.




For reassembly, proceed inversely compared to the previously-described disassembly procedures.

Tighten the screws to the specified torque.

REMOVING AND INSTALLING OF THE TANK

Disconnect the fuel tank vent pipe.

Disconnect the fuel hose **1** by pressing the appropriate button of the quick coupling.



WARNING:
Follow action on a cold engine and in a well ventilated area.


WARNING:
Fire hazard. Fuel is highly flammable.

Always stop the engine when refuelling and keep open flames and lighted cigarettes away.


Immediately clean up any spilled fuel.


Remove the saddle (page 80).


Remove the screw **2** fastening the tank to the frame and the screws **3** (one per side) securing the fairing to the radiator.




Disconnect the electrical connectors **4** and **5**.








Lift the tank slightly and:
• remove the tube **6**.




• disconnect the connector **7**.

Lift the tank backwards and remove the tank towards the rear.





To refit the tank proceed as follows:

- place the tank to the vehicle and connect the connector **7**.




Insert the hose **6** following the passage as shown in figure.






Push the tank towards the front of the vehicle and down.


Tighten the tank screws to the torques given.
When assembly is complete, lightly pull the tube **6** so that it is stretched correctly.




Connect the fuel connections by coupling them completely.




WARNING
For safety reason, the fuel flow is stopped when the connector is even partially engaged.
Make sure that the fuel quick release fittings are well inserted.



Reconnect connectors **4** and **5**.




Refit the saddle (page 80) and the vent pipe.




REMOVING AND INSTALLING THE HEADLAMP MASK


Remove the screw **1**.



Remove the jumper **2** by pulling the rear portion towards you and slide it towards the rear.



Unhook the elastics **3** (one on each side).



Pull the mask upwards and rotate it forward from the top.

Disconnect all the electric connector attaching the mask to the vehicle.

Remove the mask.

For reassembly, proceed inversely compared to the previously-described disassembly procedures.

CHAPTER 6 TROUBLESHOOTING

CONTENTS

Troubleshooting 92
Alphabetical index 93

6 TROUBLESHOOTING

PROBLEM	CAUSE	REMEDY
The engine starts but the telltale "MIL" lights on	Engine management system fault	Contact authorised BETAMOTOR customer service
The electric starter does not turn	Decompressor failure	Contact authorised BETAMOTOR customer service
	Flat battery	Check the battery
	Blown fuse	Replace
	Defective relay	Contact authorised BETAMOTOR customer service
	Defective starter motor	Contact authorised BETAMOTOR customer service
The engine rotates, but does not start	Fuel quick release fittings incorrectly inserted	Check that the fuel quick release fittings are properly inserted (page 85)
	Spark plug dirty	Clean or replace the spark plug
	Spark gap wrongly adjusted	Restore the spark gap
	Faulty ignition/injection system	Contact authorised BETAMOTOR customer service
"High Voltage" appears on the instrument	- Overcharging	Disconnect the battery (page 68). Contact authorised BETAMOTOR customer service
The motor stops or splutters	Lack of fuel	Refuel
Engine overheats	Radiator grill blocked	Remove and clean the grill
	Radiator (air side) blocked	Clean the radiator
	Insufficient air flow	Check that the cooling fan is working correctly
	Silencer partly clogged	Contact authorised BETAMOTOR customer service
Front braking poor	Brake pads worn	Contact authorised BETAMOTOR customer service
	Air or humidity in the hydraulic circuit	Contact authorised BETAMOTOR customer service
Rear braking poor	Brake pads worn	Contact authorised BETAMOTOR customer service
	Air or humidity in the hydraulic circuit	Contact authorised BETAMOTOR customer service

ALPHABETICAL INDEX

Adjusting fork 37
Adjustment of gas clearance 35
Air filter 50

Battery 68
Brakes 34
Bulbs 13

Chain 65
Check and adjusting of steering play 62
Checks before and after use 28
Cleaning the vehicle 71
Clutch 35
Clutch control 60

Dashboard operating instructions 19

Electrical connector maintenance 72
Engine oil 44
Engine shut-down 30

Familiarizing with the vehicle 9
Fork 63
Front brake 54
Front wheel 63
Fuelling 29
Fuses 13
Fuses 70

Gearbox oil 46

Handlebar adjustment 35
Headlight 66

Idle adjustment 35

Key to symbols 34

Liquid coolant 47

Main parts 16

Operating instructions 5

Prolonged inactivity 74

Rear brake 57
Rear suspension leverage 64
Recommended lubricants and liquid 13
Removing and installing air filter cover panel 81
Removing and installing of the engine protection 84
Removing and installing of the rear mudguard 82
Removing and installing of the saddle 80
Removing and installing of the tank 85
Removing and installing the headlamp mask 90
Riding safety 6
Running in 28

Scheduled maintenance vehicle 75
Shock absorber 39
Spark plug 53
Specifications 10
Starting the engine 30
Symbols 5

Tail light 67
Tightening torque overview 77
Tools kit 8
Troubleshooting 92
Tyres 64

Vehicle identification data 8
Vehicle preparation for use in heavy-duty conditions 31