SINCRO

2-STROKE

125 / 200 / 250 / 300



Rideability

Beta motorcycles

2026 OWNERS MANUAL

SINCRO 125-200-250-300/300SS

Thanks for you preference, and have a good time! This handbook contains the information you need to properly operate and maintain your motorcycle.

The data, specifications and images shown in this manual does not constitute an engagement on the part of BETAMOTOR S.p.A. BETAMOTOR reserves the right to make any changes and improvements to its models at any moment and without notice.

IMPORTANT

We recommend you to check all the tightenings after the first one or two hours' ride over rough ground. Special attention should be paid to the following parts:

- rear sprocket
- ensure that the footrests are properly fixed
- front/rear brake levers/calipers/discs
- check that the plastics are properly fastened
- engine bolts
- shock absorber bolts/swingarm
- wheel hubs/spokes
- rear frame
- pipe connections
- tensioning the chain

IMPORTANT

In the event of interventions on the vehicle, contact Betamotor after-sales service.

TABLE OF CONTENTS

Operating instructions 5
Symbols 5
Riding safety 6

CHAPTER 1 GENERAL INFORMATION 7
Vehicle identification data 8
Familiarizing with the vehicle 9
Specifications 10
Electrical system 14
Recommended lubricants and liquids 16

CHAPTER 2 OPERATION 17
Main parts 18
Checks before and after use 21
Breaking in 21
Fuelling 22
Startup 23
Engine shut-down 23

CHAPTER 3 ADJUSTMENTS 25
Key to symbols 26
Brakes 26
Clutch 27
Adjustment of gas clearance 27
Accelerator 28
Handlebar adjustment 28
Adjusting fork 29
Shock absorber 29
Suspension adjustment according to the motorcyclist's weight 30

CHAPTER 4 CHECKS AND MAINTENANCE 31
Key to symbols 32
Gear oil 32
Coolant 33
Air filter 35
Spark plug 37
Carburetor 38
Front Brake 40
Rear brake 43

CONTENTS

Clutch control 46
Check of steering gear 48
Oil fork 49
Tyres 52
Chain 53
Rear tail light 54
Headlight 54
Battery 55
Cleaning the vehicle 58
Prolonged inactivity 59
Scheduled maintenance vehicle 60
Tightening torque overview 61

CHAPTER 5 REMOVING AND INSTALLING SUPERSTRUCTURES 63
Removing and installing saddle-mudguard assembly 64

CHAPTER 6 TROUBLESHOOTING 65
Troubleshooting 66

CONTENTS

EN

OPERATING INSTRUCTIONS

- The vehicle must be accompanied by: number-plate, registration document, tax disc and insurance.
- Changes to the engine or other parts is punishable by law with severe penalties, including the confiscation of the vehicle.
- Do not sit on the vehicle stand.
- Do not start the engine in a closed place.

WARNING
Any modifications and tampering with the vehicle during the warranty period exempt the manufacturer from all responsibility and invalidate warranty.

SYMBOLS


SAFETY/ATTENTION
Failure to respect information marked with this symbol can entail a personal hazard.


INTEGRITY OF THE VEHICLE
Failure to respect information marked with this symbol can entail serious damage to the vehicle and termination of the warranty.


FLAMMABLE LIQUID HAZARD


Read the use and maintenance manual carefully.


MANDATORY TO WEAR PROTECTIVE CLOTHING
Use of the vehicle is subject to wearing specific protective clothing and safety footwear.


PROTECTIVE GLOVES MANDATORY
To perform the operations described, it is mandatory to wear protective gloves.


FORBIDDEN TO USE NAKED FLAMES OR POSSIBLE UNCONTROLLED IGNITION SOURCES


NO SMOKING


DO NOT USE MOBILE PHONE


CORROSIVE SUBSTANCES HAZARD
Liquids marked with this symbol are highly corrosive: handle with care


POISONING HAZARD

RIDING SAFETY

- Observe the Highway Code.
- Always wear approved personal safety equipment.
- Always ride with the low beam on.
- Always keep the crash helmet visor clean.
- Avoid wearing garments with hanging ends.
- Do not keep sharp or brittle objects in your pockets while riding.
- Properly adjust the rearview mirrors.
- Always ride in a seated position, with both hands on the handlebars and both feet on the footrests.
- Never ride abreast with other vehicles.
- Do not tow and avoid being towed by other vehicles.
- Always keep a safe distance from other vehicles.
- Do not start off while the vehicle is on its stand.
- Avoid swaying and wheelies as they are extremely dangerous for your own and other people's safety as well as for your vehicle.
- Always apply both brakes on dry roads with no gravel and sand. Using one brake may be dangerous and cause uncontrolled skidding.
- To reduce the braking distance, always apply both brakes.
- On wet roads and in off-road riding, drive with care and at moderate speed. Take special care in applying the brakes.

CHAPTER 1 GENERAL INFORMATION

CONTENTS


Vehicle identification data 8
- Frame identification 8
- Engine identification 8

Familiarizing with the vehicle 9
- Main parts 9

Specifications 10
- Weight 10
- Vehicle dimensions 10
- Tyres 10
- Wheels 10
- Capacities 10
- Front suspension 11
- Rear suspension 11
- Front brake 11
- Rear brake 11
- Engine 12
- Carburetor 12
- Gear box 13

Electrical system 14
- Electrical diagram 14
- Legend electrical diagram 15


Recommended lubricants and liquids 16



VEHICLE IDENTIFICATION DATA

FRAME IDENTIFICATION

Frame identification data **A** are stamped on the right side of the steering head tube.





ENGINE IDENTIFICATION

Engine identification data **B** are stamped in the area shown in the picture.

WARNING:
Tampering with the identification numbers is severely punished by law.

FAMILIARIZING WITH THE VEHICLE





MAIN PARTS

1 Fuel tank
2 Tank cap
3 Silencer
4 Rear shock absorber
5 Headlight
6 Rear light
7 Side stand
8 Fork
9 Rider's footrests
10 Lower bumper
11 Engine
12 Front mudguard
13 Rear mudguard
14 Kick-start
15 Gear lever
16 Rear brake lever
17 Front brake lever
18 Clutch lever
19 Throttle

SPECIFICATIONS

WEIGHT

Version	SINCRO 125	SINCRO 200	SINCRO 250	SINCRO 300/300SS
Weight in running order [kg]	68	68	70	70
Front [kg]	34	34	35	35
Rear [kg]	34	34	35	35

VEHICLE DIMENSIONS

maximum length ..... 1995 mm
maximum width ..... 810 mm
wheelbase ..... 1310 mm
maximum height ..... 1110 mm
ground clearance ..... 313 mm
saddle height ..... 685 mm

TYRES

Dimensions		Pressure [Bar]	
Front tyre	Rear tyre	Front tyre	Rear tyre
2.75 - 21	4.00 - 18	0.4 ÷ 0.5	0.3 ÷ 0.4

The use of GEOMAX TRIAL TL01 tyres is recommended.

WHEELS

Dimensions	
Front	**Rear**
J 21x1,6	**18x2,15**

CAPACITIES

fuel tank .....2.6 liters

coolant circuit:

Version	SINCRO 125	SINCRO 200/250/300/300SS
Coolant liquid with circuit emptied [ml]	550	500

Engine oil .....550 ml

FRONT SUSPENSION

Version	SINCRO 125		SINCRO 200/250		SINCRO 300/300SS	
Wheel excursion [mm]	166		166		166	
	right fork leg	left fork leg	right fork leg	left fork leg	right fork leg	left fork leg
K spring [N/mm]	7,65	X	7,65	X	7,65	X
Oil type	Sil power 5W					
Oil quantity [ml]	LH 360					
	RH 350					
Register spring preload	Full open	X	Full open	X	2 turns	X
Click in extension (from fully closed)	X	Full open	X	Full open	X	Full open

REAR SUSPENSION

Version	SINCRO 125	SINCRO 200/250	SINCRO 300/300SS
k spring	72N/mm	72N/mm	72N/mm
precharge (spring in its seat) [mm]	127	127	127
Oil type	Fuchs RENOLIN MR 520 5W		
Click in extension (from fully closed)	8	8	8
Spring preload	3	3	3

FRONT BRAKE

disk-type with hydraulic control Ø 185 mm

REAR BRAKE

disk-type with hydraulic control Ø 160 mm

ENGINE

Version	SINCRO 125	SINCRO 200	SINCRO 250	SINCRO 300	SINCRO 300SS
Type	Single-cylinder, 2-stroke				
Bore x stroke	54x54,5	65x60,5	72,5 x 60,5	79 x 60,5	79 x 60,5
Displacement [cm^3]	124,8	200,65	249,7	296,5	296,5
Pressure ratio	15,9:1	10,3:1	9:1	10,5:1	9,5:1
Fuel system	carburetor without mixer (1,2%)				

CARBURETOR

Version	SINCRO 125	SINCRO 200	SINCRO 250	SINCRO 300/300SS
Carburetor type	PWK 28	PWK 28	PWK 28	PWK 28
Main jet	130	125	125	125
Slow jet	55	48	48	48
Start jet	60	60	60	60
Needle	JJH	JJH	JJH	IJH
Needle position (from top)	4°	4°	4°	4°
Air screw turns (from all closed)	1,5	1,5	1,5	1,5


Cooling system ..... forced liquid circulation by pump
Spark plug ..... NGK CR7EB
Clutch ..... wet, multidisc

GEAR BOX

Version	SINCRO 125	SINCRO 200	SINCRO 250	SINCRO 300/300SS
Primary drive	25/69	25/69	25/69	25/69
Gear ratio 1st gear	11/38	11/38	11/38	11/38
Gear ratio 2nd gear	14/41	14/41	14/41	14/41
Gear ratio 3rd gear	15/37	15/37	15/37	15/37
Gear ratio 4th gear	15/29	15/29	15/29	15/29
Gear ratio 5th gear	21/26	21/26	21/26	21/26
Gear ratio 6th gear	27/22	27/22	27/22	27/22
Secondary drive	9/43	11/41	11/41	11/41

Ignition .....electronic Hidria 12V-110W

ELECTRICAL DIAGRAM



Key to colours

Bi = White
Ve = Green
Ma = Brown
Vi = Purple
Bl = Blue
Ne = Black
Gi = Yellow
Rs = Red
Ar = Orange
Az = Sky-blue
Ro = Pink
Gr = Grey

LEGEND ELECTRICAL DIAGRAM

1) Voltage regulator
2) Horn connector
3) Front headlight
4) Diagnostic connector
5) Main graound
6) Rear light
7) Kill switch
8) Map switch
9) Fan
10) Thermoswitch
11) Ignition coil
12) Stator
13) Pick-up sensor
14) ECU
15) Capacitor

RECOMMENDED LUBRICANTS AND LIQUIDS

For better operation and longer vehicle life, we advise you to use the products listed in the following chart:


PRODUCT TYPE	SPECIFICATIONS
OILMIXTURE	LIQUI MOLY RACING SYNTH 2T
GEAR AND CLUTCH OIL	LIQUI MOLY RACING 4T 10W-30
BRAKE OIL	LIQUI MOLY BRAKE FLUID DOT4
CLUTCH ACTUATOR OIL	LIQUI MOLY BRAKE FLUID DOT4
FORK OIL	SIL POWER 5W
TIE ROD GREASE	LIQUI MOLY SCHMIERFIXIX
LIQUID COOLANT	LIQUI MOLY COOLANT READY MIX RAF12 PLUS

CHAPTER 2 OPERATION

CONTENTS

Main parts 18
- Fuel tap 18
- Starter 18
- Clutch lever 18
- LH switch (Optional kit 200-250-300) 18
- RH switch 19
- Front brake lever and gas control 19
- Switch for change mapping 19
- Gearchange lever 20
- Brake pedal 20
- Kick-start 20

Checks before and after use 21
Breaking in 21
Fuelling 22
Startup 23
Engine shut-down 23




MAIN PARTS

FUEL TAP

The fuel tap has two positions:


OFF, pull outward: fuel supply closed. Fuel cannot flow from the tank to the carburetor.
ON push inward: fuel supply enabled. Fuel flows from the tank to the carburetor.
NOTE: the vehicle is not equipped with a reserve.



STARTER

The starter lever is located on the carburetor.

To operate it, push the choke lever downward.



CLUTCH LEVER


Clutch lever **1** is fitted to the left-hand side of the handlebars.

LH SWITCH (OPTIONAL KIT 200-250-300)

The button **2**, located on the left-hand side of the handlebar, allows the electric starting of the motorcycle.
For the starting procedure, refer to page 23.
Do not press button **2** while the engine is running.


RH SWITCH

The off switch is positioned on the right-hand side of the handlebar and consists of the following:
shutdowns engine : it is necessary to hold it until the engine stops.



FRONT BRAKE LEVER AND GAS CONTROL

The front brake lever **1** and the gas throttle **2** are located on the right side of the handlebar.




SWITCH FOR CHANGE MAPPING


The switch for change mapping is located on the tank cover.

By acting on the switch shown in the figure, it is possible to select one of two possible mappings for the ignition advance.

With the switch in position , "soft" mapping more suited to muddy terrain and for a gentler response of the bike is selected.


With the switch in position "hard" mapping that is more suitable for dry land and for a more aggressive response of the bike is selected.






GEARCHANGE LEVER

Gearchange lever is fitted to the left side of the engine.
The positions corresponding to the different gears are shown in the figure.




BRAKE PEDAL

Brake pedal is located in front of the right-hand footrest.



KICK-START

The kick-start pedal is located on the right side of the engine. The upper part is rotatable.



SIDE STAND

Press down side stand with the foot and lean the vehicle against it.
Ensure that the ground is solid and the vehicle stands steadily.

WARNING! The kickstand has an automatic closing device. When the vehicle weight on the kickstand is reduced, it closes automatically.

ATTENTION! Do not climb on the vehicle with the side stand lowered.

CHECKS BEFORE AND AFTER USE

For safe driving and long vehicle life you should:

- Check all fluid levels.
- Check the correct operation of the brakes and brake pad wear (page 42).
- Check pressure, general condition and thickness of tread (page 10).
- Check that the spokes are properly tightened.
- Check the chain tension (page 53).
- Check the adjustment and the operation of all the cable controls.
- Inspect all the nuts and bolts.
- With the engine running, check the operation of the headlight, the rear and brake lights, the indicators, the warning lights and the horn.
- Wash the motorcycle thoroughly after off-road use (page 58).

BREAKING IN

The breaking-in period lasts approximately 5 hours, during which it is advisable to:

- Avoid travelling at constant speed.
- Avoid turning the throttle more than 3/4 of the way.

WARNING:
After the first 5 hours to replace the gearbox oil.

This procedure should be followed each time piston, piston rings, cylinder, crankshaft or crankshaft bearings are replaced.

FUELLING



Use a blend of high-octane unleaded gasoline and synthetic oil at 1,2%.

Fuel tank capacity is shown on page 10.

To open the fuel tank's cap, turn it anti-clockwise.

To close the fuel tank's cap, set it on the tank and crew it clockwise.

For the type of oil mixture refer to the "Recommended fluids and lubricants" table.

WARNING:
The refuelling should be performed with the engine off.

WARNING:
Fire hazard. Fuel is highly flammable.

Always stop the engine when refuelling and keep open flames and lighted cigarettes away.

Do not top up fuel while using a mobile phone.

Refuel in an open well ventilated area.

Pay special attention so that the fuel does not come into contact with hot parts of the vehicle. Immediately clean up any spilled fuel.

WARNING: Risk of poisoning.

Fuel is poisonous liquid and a health hazard.

Fuel must not come into contact with the skin, eyes, and clothing. Do not breathe in the fuel vapours. If contact occurs with the eyes, rinse immediately with plenty of water and seek medical advice. If contact occurs with skin, immediately clean contaminated areas with soap and water If fuel is swallowed, contact a doctor immediately. Change clothing that is contaminated with fuel.

WARNING: Environmental pollution hazard.

The fuel must not contaminate the ground water, the ground, or the sewage system.

STARTUP

Set the fuel tank tap to ON (see page 18).

- Check that the gears are in neutral (page 20).
- Pull the clutch lever (page 18).

KICKSTART (page 20):
depress the kick-starter with a sharp movement of the foot

ATTENTION
Once the pedal has been depressed, release it immediately. This avoids jolts to the entire ignition group and to the foot.

COLD STARTING:
actuate the starter by pulling it upwards (page 18), start the engine, wait a few seconds, then return the lever to its original position.

WITH ELECTRIC STARTER (OPTIONAL KIT 200-250-300):
Press the starter button for a maximum of 3 seconds.
If the vehicle does not start, wait 30 seconds before attempting a new start.
NOTE
The pauses are necessary to allow the generated heat to dissipate and to prevent battery damage.
If the battery temperature is below 15°C, the electric start will be weak not because the battery is worn out, but because it needs to warm up.
Therefore, at temperatures below 15°C, several starting attempts may be required to warm up the battery and increase the available electrical energy.

Do not press the starter button with the engine running.

ENGINE SHUT-DOWN

To shut-down the engine:
- press the button on the right switch unit (see page 19).

NOTE:
With the engine stopped, always set the fuel tap to OFF (page 18).

CHAPTER 3 ADJUSTMENTS

CONTENTS


Key to symbols....26
Brakes....26
Front brake....26
Rear Brake....26
Clutch....27
Adjustment of gas clearance....27
Accelerator....28
Adjusting the idle speed....28
Air adjustment screw....28
Handlebar adjustment....28
Adjusting fork....29
Adjusting the rebound damper....29
Adjusting the spring preload....29
Shock absorber....29
Adjusting the rebound damper....29
Adjusting the spring preload....30
Suspension adjustment according to the motorcyclist's weight....30

KEY TO SYMBOLS

Tightening torque

Threadlocker Medium

Grease



M02_L0064


BRAKES

FRONT BRAKE

The front brake is disk type with hydraulic control.
The position of the lever is controlled through the use of register **1**.

Once the position of the lever has been changed, register **2** must be changed to restore the initial correct clearance.

WARNING: reduced play causes brake overheating leading to sudden lockup.



M02_L0066

REAR BRAKE


The rear brake is disk type with hydraulic control. You may adjust pedal height by means of register **1**.

Once you change the original pedal position you need to modify regulator **2** on the brake pump to allow you to reset the correct pump travel.

WARNING: reduced play causes brake overheating leading to sudden lockup.


CLUTCH

The position of the lever is controlled through the use of register **1**.
Once the position of the lever has been changed, register **2** must be changed to restore the initial correct clearance.



The idle stroke of push rod must not be less than 0.9 mm

ATTENTION: reduced clearance leads to premature wear of the discs and overheating of the entire clutch group.



ADJUSTMENT OF GAS CLEARANCE


The throttle control cable should always have a 3-5 mm play. In addition, the idle speed should not change when the handlebars are fully rotated to the left or right.


To adjust the clearance proceed as follows:

- Loosen ring **1**.

- Rotate register **2** with respect to sheath **3**.

- Tighten ring **1**.






ACCELERATOR

ADJUSTING THE IDLE SPEED

In order to perform this operation correctly, we advise you to do it when the engine is hot, connecting an electric revolution counter to the spark plug wire. Then use a screwdriver on register screw **A** to calibrate the minimum with 1.100÷1.200 rpm.

AIR ADJUSTMENT SCREW

To adjust the idle carburation, act on air screw **B**: turning it in enriches the mixture (richer), while turning it out increases the air supply (leaner).
The procedure must be carried out with the engine warm, starting from a standard position of approximately 1.5–2 turns from fully closed, then fine-tuning the adjustment until a smooth idle speed and a prompt throttle response are obtained.



HANDLEBAR ADJUSTMENT


The handlebar can be adjusted by rotating it back and forth.
- To adjust the handlebar loosen screws **1**.
- Position the handlebar according to requirements.
- Tighten to the torque indicated.

ADJUSTING FORK

ADJUSTING THE REBOUND DAMPER

The hydraulic brake unit in extension determines the behaviour in the extension phase of the fork and can be adjusted using screw **1**. Turning clockwise increases the action of the brake in extension, while rotating counter-clockwise decreases the action of the brake in extension.


For standard calibration, refer to page 11.



ADJUSTING THE SPRING PRELOAD

Spring preload is adjusted by means of screw **2**. Turning clockwise will increase the preload, while rotating counter- clockwise decreases the preload.

For standard calibration, refer to page 11.




SHOCK ABSORBER


ADJUSTING THE REBOUND DAMPER

The hydraulic brake unit in extension determines the behaviour in the extension phase of the shock absorber and can be adjusted using screw 1. Turning clockwise increases the action of the brake in extension, while rotating counter-clockwise decreases the action of the brake in extension.

For standard calibration, refer to page 11.

NOTE:
for adjustment use a T-handle wrenches with jointed hexagonal socket.





ADJUSTING THE SPRING PRELOAD

To adjust the spring preload, use the procedure described below.
Loosen counter-ring **1**, rotate ring **2** clockwise to increase the spring preload (and consequently the shock absorber preload) or anticlockwise to decrease it.
After obtaining the desired preload, turn counter-ring **1** until it stops against adjusting ring **2**.

For standard calibration, refer to page 11.

NOTE: for movement of the rings use a specific sector key with square pin.

SUSPENSION ADJUSTMENT ACCORDING TO THE MOTORCYCLIST'S WEIGHT

The following table shows the approximate calibration of the suspension adjustment according to the motorcyclist's weight.

p < 70 Kg		**70 Kg < p < 80 Kg**		**80 Kg < p**	
Adjustment		Adjustment		Adjustment	
Fork	Shock absorber	Fork	Shock absorber	Fork	Shock absorber
Standard	Standard	+2,5 turns preload	+1,5 turns preload	+5 turns preload	+1,5 turns preload

ATTENTION! Shock absorber pre-load max permitted = +6 turns.

CHAPTER 4 CHECKS AND MAINTENANCE

4

CONTENTS

Key to symbols 32
Gear oil 32
- Check the level 32
- Replacement 32

Coolant 33
- Check the level 33
- Replacement 34
- Radiator grill 35

Air filter 35
- Removing and fitting air filter 35
- Cleaning air filter 36

Spark plug 37
Carburetor 38
- Draining the carburetor float chamber 38
- Float level check 39

Front Brake 40
- Check the level of the front brake fluid 40
- Restoring the level of the front brake fluid 40
- Bleeding the front brake 41
- Brake disc thickness control 42
- Front brake lining control 42

Rear brake 43
- Check the level of the rear brake fluid 43
- Restoring the level of the rear brake fluid 43
- Bleeding the rear brake 44
- Rear brake lining control 45
- Brake disc thickness control 45

Clutch control 46
- Check oil level 46
- Bleeding clutch control 47

Check of steering gear 48
Oil fork 49
- Removing legs 49
- Oil replacement right leg 49
- Oil replacement left leg 50
- Legs assembly and parts 51

Tyres 52
- Linkage rear suspension 52

Chain 53
- Check and adjust tightening chain 53

Rear tail light 54
Headlight 54
Battery 55
- Battery removal 55
- Battery assembly 56
- Inactivity 57
- Charging the battery 57

Cleaning the vehicle 58
- General precautions 58


Prolonged inactivity 59
Scheduled maintenance vehicle 60
Tightening torque overview 61


EN


Tightening torque

Threadlocker Medium

Grease







GEAR OIL

CHECK THE LEVEL

Keep the vehicle in vertical position relative to the ground.

Start the engine and let it idle for a few minutes in order to bring the oil to operating temperature. Switch off the engine and wait one minute to allow the oil to settle. Unscrew screw **1** and check that oil flows out.
If no oil leakage is observed, the level is insufficient. In this case, top up through the filler plug **2** until the oil starts to flow out from the hole of screw **1**.
Use the liquid indicated on page 16 in the "Recommended lubricants and liquids" table.

REPLACEMENT

Always perform the replacement when engine is hot:
- Position the drive on a flat base ensuring stability
- Place a container under the engine
- Unscrew the filler cap **1** and the drain plug **2**
- Completely empty the crankcase
- Close the cap **2**
- Introducing the quantity of liquid shown at page 10.
  Use the liquid indicated on page 16 in the "Recommended lubricants and liquids" table.
- Close the filler cap **1**.

WARNING:
Hot oil can cause severe burns!


COOLANT

CHECK THE LEVEL


Keep the vehicle in vertical position relative to the ground.

The level of the coolant must be checked when the engine is cold. Use the following procedure:

- Remove the radiator retaining knob **1** and rotate it forward to access the cap. Unscrew cap **2** and ensure that the liquid is visible in the lower portion of the loading tube.



- Where the liquid is not visible in the lower part of the loading tube position the vehicle as in the figure and then top up.



- At the end of operation refit the filler cap and the vent screw.

- Rotate the radiator towards the frame and secure it with retainer **1**.

Use the liquid indicated on page 16 in the "Recommended lubricants and liquids" table.

WARNING: Never unscrew the filler cap of the radiator when the engine is hot. Danger of burning!

WARNING:
Wear appropriate protective clothing and protection gloves.


Keep coolant out of reach of children.


Avoid any direct contact of the coolant with skin, eyes or clothing. If this happens:


- with the eyes, rinse immediately with plenty of water and seek medical advice;


- with skin, Immediately clean contaminated areas with soap and water Change clothing that is contaminated with coolant.

If coolant is swallowed, contact a doctor immediately.









REPLACEMENT

Position the vehicle on a flat base and in a stable manner.

Replacement of the coolant must take place when the engine is cold.

1) Remove the radiator retaining knob **1** and rotate it forward to access the cap. Unscrew cap **2**.
2) Place a container under screw **3**.
3) Unscrew the screw **3**.
4) Drain the liquid.
5) Tighten screw **3** applying the specific washer.
6) Unscrew drain screw **4** and fill until the liquid starts to overflow the screw.
7) Tighten screw **4**.
8) Reapply the loading cap **2**.
9) Rotate the radiator towards the frame and secure it with retainer **1**.

The amounts of liquid are shown on page 10.

Use the liquid indicated on a page 16 in the "Recommended lubricants and liquids" table.

WARNING:
Never unscrew the filler cap of the radiator when the engine is hot. Danger of burning!

WARNING:
Wear appropriate protective clothing and protection gloves.

Keep coolant out of reach of children.

Avoid any direct contact of the coolant with skin, eyes or clothing. If this happens:

- with the eyes, rinse immediately with plenty of water and seek medical advice;

- with skin, Immediately clean contaminated areas with soap and water Change clothing that is contaminated with coolant.

If coolant is swallowed, contact a doctor immediately.


RADIATOR GRILL

Should the grill be obstructed proceed as follows:

Remove the grill by pulling it towards the front of the vehicle.

Shake and wash the grill.

Reapply the grill pushing it towards the radiator.



M04_L0150

AIR FILTER


Check after every ride.

REMOVING AND FITTING AIR FILTER

To access the filter:
- Loosen the fastening screw **1** of the cover.




M04_L0151



- Remove the filter frame and the filter by unscrewing the screw **2**.

WARNING:
After every intervention, check that nothing has been left inside the filter box.

- Reassemble by performing the operations in reverse order.



CLEANING AIR FILTER

- Thoroughly wash the filter with water and soap.

- Dry the filter.

- Wet the filter with specific oil and then remove the excess oil to prevent it from dripping.

- If necessary also clean the interior of the filter box.

WARNING:
Do not clean the filter with gasoline or petrol.

NOTE:
If the filter is damaged, replace it immediately.

Verify the integrity of water proofing gaskets on air box. Change them if these are damaged.

To replace, contact authorised Betamotor customer service.


WARNING:
Never use the vehicle if the air filter is not in place. The infiltration of dust and dirt can cause damage and considerable wear.

WARNING:
After each operation check that no object is left in the filter box.

SPARK PLUG


Keeping the spark plug in good condition will reduce fuel consumption and increase engine performance.

To perform the check, simply slide off the electrical connection tube and unscrew the spark plug. Examine the distance between the electrodes with a feeler. This distance should be from 0.7÷0.8 mm. If it is not, it may be corrected by bending the earth electrode.
Check as well that there are no cracks in the insulation or corroded electrodes. If so, replace immediately.



When replacing the spark plug, screw it in by hand until it stops, then tighten with a wrench.

WARNING:
Do not check while the engine is hot.



CARBURETOR

DRAINING THE CARBURETOR FLOAT CHAMBER

If the carburetor tank needs to be emptied, proceed as described. Perform the operation once the engine is cold.
Turn the fuel cock to OFF position (see page 18).
Place a cloth under the carburettor in order to collect the fuel that comes out.
Loosen screw **1** and drain the fuel until complete emptying of the tank.
Tighten screw **1**.

WARNING:
Follow action on a cold engine.

WARNING:
Fire hazard. Fuel is highly flammable.

Always stop the engine when refuelling and keep open flames and lighted cigarettes away.
Refuel in an open well ventilated area.

Immediately clean up any spilled fuel.

WARNING:
Risk of poisoning!
Fuel is poisonous liquid and a health hazard.

Wear appropriate protective clothing and protection gloves.

Fuel must not come into contact with the skin, eyes, and clothing. Do not breathe in the fuel vapours. If contact occurs with the eyes, rinse immediately with plenty of water and seek medical advice. If contact occurs with skin, immediately clean contaminated areas with soap and water If fuel is swallowed, contact a doctor immediately. Change clothing that is contaminated with fuel.

WARNING:
Environmental pollution hazard!
The fuel must not contaminate the ground water, the ground, or the sewage system.

FLOAT LEVEL CHECK

Remove the carburetor from the vehicle after following the procedure for emptying the carburetor bowl.

Remove the bowl and place the carburetor as in the figure.

Start turn it in anticlockwise direction and stop immediately when the float assy closes the fuel valve needle.


The float level is correct if the plan surface over the float assy is parallel to the float chamber division plan. See the two red lines in the picture.


ATTENTION: It's important to avoid putting carburetor in vertical position, otherwise the weight of the float assy compresses the spring into the fuel valve needle and the position will look incorrect.


Replace the bowl to the carburetor.


Reassemble the carburetor to the vehicle, making sure to tighten the metal clamps on the sleeves.

WARNING:
before starting the vehicle to check for play on the throttle (page 27).


M04_L0180


M04_L0181



M04_L0182



FRONT BRAKE

CHECK THE LEVEL OF THE FRONT BRAKE FLUID

Check the level of the brake fluid through sight **A**. The level of the fluid should never fall below the mark in the sight.



RESTORING THE LEVEL OF THE FRONT BRAKE FLUID

To restore the level, top up by loosening the two screws **1**, lifting the cover **2**, and adding brake fluid up to the upper edge of the sight glass.

Use the liquid indicated on page 16 in the "Recommended lubricants and liquids" table.

WARNING:
The clutch fluid is extremely corrosive. Take care not to spill it on the paintwork.

Wear appropriate protective clothing and protection gloves.

Keep coolant out of reach of children.

WARNING: Avoid any direct contact of the liquid with skin, eyes or clothing. If this happens:

- with the eyes, rinse immediately with plenty of water and seek medical advice.


- with skin, immediately clean contaminated areas with soap and water. Change clothing that is contaminated with liquid.

If liquid is swallowed, contact a doctor immediately.

BLEEDING THE FRONT BRAKE

To bleed air from the front brake circuit, proceed as follows:

- Remove the rubber cap **1** from the valve **2**.
- Open the sump cap.
- Insert one end of a transparent tube into a container.
- Pump with the brake lever 2/3 times and keep the lever pressed.
- Unscrew the valve and let the oil drain.
- If are still visible in the tube repeat above operation until obtaining a continuous outflow of oil within no air bubbles.
- Close the valve and release the lever.



NOTE:
During this procedure, continuously top up the brake pump thank to replace the oil that is out flowing.

- Remove the tube.
- Replace the rubber cap.

Close the oil reservoir cap.

Use the liquid indicated on page 16 in the "Recommended lubricants and liquids" table.

WARNING:
The brake fluid is extremely corrosive. Take care not to spill it on the paintwork.


Wear appropriate protective clothing and protection gloves.

Keep coolant out of reach of children.

WARNING: Avoid any direct contact of the liquid with skin, eyes or clothing. If this happens:

- with the eyes, rinse immediately with plenty of water and seek medical advice.
- with skin, immediately clean contaminated areas with soap and water. Change clothing that is contaminated with liquid.

If liquid is swallowed, contact a doctor immediately.




FRONT BRAKE LINING CONTROL

In order to verify the wear condition of front brake is enough to view the caliper from the bottom, where is possible to glimpse the brake lining tails which will have to show a brake of 2 mm in thickness. If the stratum is lesser let's start replacing them.

NOTE:
Perform the check according to the times shown in the table on page 60.

To replace, contact authorised Betamotor customer service.




BRAKE DISC THICKNESS CONTROL

Periodically verify disc condition. In case signs of damage , veins, or deformations are present, proceed with replacement.
Verify disc thickness. The minimum thickness is engraved on the disc.
Once the limit is in proximity or has been reached, proceed with brake disc replacement.
For replacement, contact an authorised Betamotor after-sales service centre.

REAR BRAKE

CHECK THE LEVEL OF THE REAR BRAKE FLUID

Check the level of the brake fluid through sight **A**. The level of the fluid should never fall below the mark in the sight glass.



RESTORING THE LEVEL OF THE REAR BRAKE FLUID

To restore the level of the brake fluid, loosen the two screws **1**, lift cap **2** and add brake fluid up to the upper edge of the sight glass.

Use the liquid indicated on page 16 in the "Recommended lubricants and liquids" table.

WARNING:
The brake fluid is extremely corrosive. Take care not to spill it on the paintwork.


Wear appropriate protective clothing and protection gloves.


Keep coolant out of reach of children.

WARNING: Avoid any direct contact of the liquid with skin, eyes or clothing. If this happens:

- with the eyes, rinse immediately with plenty of water and seek medical advice.
- with skin, immediately clean contaminated areas with soap and water. Change clothing that is contaminated with liquid.

If liquid is swallowed, contact a doctor immediately.





BLEEDING THE REAR BRAKE

To bleed air from the rear brake circuit, proceed as follows:

- Remove the rubber cap **1** from the valve **2**.
- Open the sump cap.
- Insert one end of a transparent tube into a container.
- Pump with the brake lever 2/3 times and keep the lever pressed.
- Unscrew the valve and let the oil drain.
- If are still visible in the tube repeat above operation until obtaining a continuous outflow of oil within no air bubbles.
- Close the valve and release the lever.

NOTE:
During this procedure, continuously top up the brake pump thank to replace the oil that is out flowing.

- Remove the tube.
- Replace the rubber cap.

Close the oil reservoir cap.

Use the liquid indicated on page 16 in the "Recommended lubricants and liquids" table.

WARNING:
The brake fluid is extremely corrosive. Take care not to spill it on the paintwork.

Wear appropriate protective clothing and protection gloves.


Keep coolant out of reach of children.

WARNING: Avoid any direct contact of the liquid with skin, eyes or clothing. If this happens:

- with the eyes, rinse immediately with plenty of water and seek medical advice.
- with skin, immediately clean contaminated areas with soap and water. Change clothing that is contaminated with liquid.

If liquid is swallowed, contact a doctor immediately.

REAR BRAKE LINING CONTROL




In order to verify the wear condition of rear brake is enough to view the caliper from the back side, where is possible to glimpse the brake lining tails which will have to show a brake of 2 mm in thickness. If the stratum is lesser let's start replacing them.


NOTE:
Perform the check according to the times shown in the table on page 60.

To replace, contact authorised Betamotor customer service.

BRAKE DISC THICKNESS CONTROL



Periodically verify disc condition. In case signs of damage , veins, or deformations are present, proceed with replacement.
Verify disc thickness. The minimum thickness is engraved on the disc.
Once the limit is in proximity or has been reached, proceed with brake disc replacement.
For replacement, contact an authorised Betamotor after-sales service centre.



CLUTCH CONTROL

CHECK OIL LEVEL

To check the oil level in the clutch pump, first remove cover **1**.
Remove the two screws **2** and take off cover **1** together with the rubber bellows. With the clutch pump in a horizontal position, the level of the oil should be 5 mm below the upper rim.

Use the liquid indicated on page 16 in the "Recommended lubricants and liquids" table.

WARNING:
The brake fluid is extremely corrosive. Take care not to spill it on the paintwork.

Wear appropriate protective clothing and protection gloves.

Keep coolant out of reach of children.


WARNING: Avoid any direct contact of the liquid with skin, eyes or clothing. If this happens:

- with the eyes, rinse immediately with plenty of water and seek medical advice.

- with skin, immediately clean contaminated areas with soap and water. Change clothing that is contaminated with liquid.

If liquid is swallowed, contact a doctor immediately.

BLEEDING CLUTCH CONTROL



- Remove the rubber cap **1** from the valve **2**.
- Open the sump cap.
- Insert one end of a trasparent tube into a container.
- Place one end of a small transparent tube into the valve **2**, and the other end inside a container.
- Unscrew the valve and let the oil drain.
- If are still visible in the tube repeat above operation until obtaining a continuous outflow of oil within no air bubles.
- Close the valve and release the lever.

NOTE:
During this procedure, continuosly top up the brake pump thank to replace the oil that is out flowing.

- Remove the tube.
- Replace the rubber cap.

Use the liquid indicated on page 16 in the "Recommended lubricants and liquids" table.

WARNING:
The clutch fluid is extremely corrosive. Take care not to spill it on the paintwork.


Wear appropriate protective clothing and protection gloves.

Keep coolant out of reach of children.

WARNING: Avoid any direct contact of the liquid with skin, eyes or clothing. If this happens:


- with the eyes, rinse immediately with plenty of water and seek medical advice.
- with skin, immediately clean contaminated areas with soap and water. Change clothing that is contaminated with liquid.

If liquid is swallowed, contact a doctor immediately.




CHECK OF STEERING GEAR

Periodically check the play in the steering sleeve by moving the fork back and forth as shown in the figure. Whenever you feel play, adjust as described below:



Loosen the screws **1**.



Loosen the screw **2**.

Take up the play by means of nut **3**.

Tighten the screws to the specified torque values.

OIL FORK

The procedure for changing the oil in the forks is provided only for information.
We recommend having the operation performed by a BETAMOTOR authorized workshop.

REMOVING LEGS


To replace, proceed as follows:

Position the vehicle on the central bike stand.

Remove the front wheel.

Remove the mudguard, the brake caliper and brake disc cover.

Loosen the screws **1** and pull off the stems.




OIL REPLACEMENT RIGHT LEG

Unscrew upper plug **2**.

Unscrew fixing lock nut and take off the plug.

Unscrew the fixing screw of the cartridge positioned under the fork leg, and extract the cartridge.




Empty the fork leg and the cartridge, draining all the oil inside.

Reassemble the cartridge on the fork leg tightening the fixing screw, then refill oil in the cartridge.

Pour in the quantity of liquid indicated on page 11.

Use the liquid indicated on page 16 in the "Recommended lubricants and liquids" table.

Reassemble the plug on the rod, tighten the lock nut and, extending the fork leg.



M03_L0062

OIL REPLACEMENT LEFT LEG

Unscrew upper plug **3**.

Remove the spring and totally empty the oil.

Pour in the quantity of liquid indicated on page 11.

Reassemble the spring and extend fork leg.

Apply and tighten cap **3**.

LEGS ASSEMBLY AND PARTS

Apply the legs to the vehicle and tighten the screws **1** to the torque indicated.

ATTENTION: Tightening of the screws should be carried out by adjusting the torque wrench to to the stability torque with repeated tightening until stability torque has been achieved.

Grease the wheel bolt.

Apply wheel and wheel bolt.

Apply brake caliper, disc cover and fender.

Tighten to the torque indicated.


⚠ ATTENTION: Tightening of the screws should be carried out by adjusting the torque wrench to to the stability torque with repeated tightening until stability torque has been achieved.


Place the vehicle on the ground.


Compress and release the fork 3-4 times.


Tighten the wheel bolt and the screws of the foot.

⚠ ATTENTION: Tightening of the screws should be carried out by adjusting the torque wrench to to the stability torque with repeated tightening until stability torque has been achieved.









LINKAGE REAR SUSPENSION

To guarantee an optimal operation and the longest lifetime of the progressive linkage of the rear suspension, it is recommended to check after every race/run the correct tightening of the bolt.

Verify that the result of the suspension bolts to specified torque.

To access the upper fixing, remove the entire mudguard group (page 64).

NOTE: It is recommended not to wash with water jets at high pressure in the zone of the linkage.

Perform the check according to the times indicated in the table on page 60.

To verify device, contact authorised Beta-motor customer service.

TYRES


Only fit tyres approved by BETAMOTOR.
Unsuitable tyres can adversely affect the road holding of the vehicle.

- To protect your safety, immediately replace any damaged tyres.
- Slick tyres adversely affect the road holding of the vehicle, especially on wet roads and in off-road riding.
- Insufficient pressure results in abnormal wear and overheating of the tyres.
- The front and rear tyres must have the same tread design.
- Always measure the inflating pressures when the tyres are cold.
- Keep the tyre pressures within the prescribed range.

CHAIN


Checking the drive chain periodically to ensure longer chain life. Always keep it lubricated and clean of deposited dirt.

Take special care in preventing the lubricant from coming into contact with the rear tyre or brake disc, otherwise the tyre grip and the action of the brake would be greatly reduced, making it very difficult to control the vehicle.




CHECK AND ADJUST TIGHTENING CHAIN


Position the vehicle on the central bike stand.
If the distance between chain and swingarm is less than 10 mm proceed with adjustment.



Loosen the pin **1**.

Rotate register **2** until the distance between chain and swingarm is that recommended.







Rotate register **3** into the same position as register **2**.

Ensure the distance between chain and swingarm is that recommended.

If the distance between chain and swingarm is not that recommended proceed to readjustment.



Tighten the pin to the torque indicated.




HEADLIGHT

Keep the headlight glass clean at all times (page 58).

The LED headlight is sealed. In the case of burnout of one or more LEDs it is necessary to replace the entire group.

To replace, contact authorised Betamotor customer service.




REAR TAIL LIGHT

Keep the tail light glass clean at all times (see page 58).

The LED tail light is sealed. In the case of burnout of one or more LEDs it is necessary to replace the entire group.

To replace, contact authorised Betamotor customer service.

BATTERY


M04_L0190

The battery is secured to the rear of the front number plate and is maintenance-free.

Keep the battery terminals clean. If necessary, protect them with a thin film of acid-free grease.

WARNING: The battery contains hazardous substances:
- Keep the battery out of the reach of children.
- Keep sparks and open flames away from the battery.
- Charge the battery only in well-ventilated areas, keeping it away from flammable materials. Use only chargers suitable for charging lithium-ion batteries.
- Do not attempt to charge fully exhausted batteries with a voltage lower than the minimum 9V. In this case, dispose of the battery according to applicable regulations.
- Do not remove the protections.
- When installing the battery, be sure to observe the polarity of the terminals.


BATTERY REMOVAL

Shut off all electrical users and stop the engine.


FIRST remove the cap **1** of the negative pole and disconnect the negative lug **2** (black) from the negative pole (-).

THEN remove the cap of the positive pole **3** and disconnect the positive lug **4** (red) from the positive pole (+).


Remove the battery.




M04_V0002A




M04_V0002B



Remove the two screws **1** securing the front number plate to the frame.




Remove the two screws **2**, separate the plastic components and remove the battery.



BATTERY ASSEMBLY

When fitting the battery, insert it with the terminals as shown in picture.


FIRST Connect the positive lug **4** (red) to the positive pole (+) of the battery by pushing the protective cap **3** in its position.




THEN secure the negative lug **2** (black) to the negative pole (-) of the battery by bringing the relative protective cap **1** in position.

For reassembly, carry out the operations in reverse order.

During reassembly, ensure correct engagement of the retaining tabs **A** of the support.





INACTIVITY

If the vehicle is not going to be used for a long time:
- remove the battery (page 62)
- charge with an adequate charger (page 57)
- store the battery in a dry place. The ideal temperature for storing the lithium-ion battery is 20°C.

CHARGING THE BATTERY

Check the battery charge using a multimeter or by pressing the "TEST" button on the battery (if it is present)

- **Voltage < 9V or "LOW"**:
  - Do NOT charge the battery
  - Replace the battery with a new equivalent one

- **Voltage <12.4V or "MED"**:
  - Charge the battery

Guidelines to charge the battery:

⚠ Use ONLY chargers suitable for charging lithium-ion batteries.

Recharge the battery with a specific battery charger when the vehicle is not used for more than 6 months.

CLEANING THE VEHICLE

GENERAL PRECAUTIONS

WARNING: Do not clean your vehicle with a high-pressure device with a strong jet of water. Excessive pressure can reach electrical components, connectors, flexible cables, bearings, etc and can damage or destroy them.

WARNING: Wash motorbikes frequently with cold water that are used near the sea (salty air) and on roads subject to salt spreading in winter. Cover with a film of oil or silicone spray unpainted parts and the most exposed parts such as wheels, forks and swingarm. Do not treat rubber parts and brakes.

When cleaning, avoid direct exposure to sunlight.

Close off the exhaust system to prevent water from entering.

Avoid directing the jet of water onto the air filter box cover and the carburettor.

WASHING MODE

Use water jet to soften the dirt and mud accumulated on the paintwork, then remove them with a soft bodywork sponge soaked in water and shampoo. Subsequently rinse well with water, and dry with air and cloth or suede leather.

Detergents pollute water. Always wash the vehicle in areas equipped for collection and purification of the washing liquids.

AFTER WASHING

Proceed to the emptying of the filter box using the appropriate ventilation and drying.

After cleaning, ride a short distance until the engine reaches operating temperature.

WARNING: braking effect is reduced with wet brakes. Operate the brakes cautiously to allow them to dry.

Push back the handlebar control covers, so that water can evaporate.

When the bike is completely dry and cooled down, lubricate all moving parts.

Treat all plastic and painted components with non-aggressive detergents or products that are specific for the care of the motorcycle.

To prevent malfunction of the electrical system, treat electric contacts and switches with electrical contact spray.

ATTENTION: any oxidation of electrical contacts may result in serious malfunctioning.

PROLONGED INACTIVITY

A few simple operations should be performed to keep the vehicle in good condition whenever it is to remain inactive for a long period (e.g. during the winter):

- Thoroughly clean the vehicle.
- Reduce the tyre pressures by approximately 30 percent, and if possible raise the tyres off the ground.
- Remove the spark plug and pour a few drops of engine oil into the spark plug hole. Make the engine turn a few times by operating the kick-start (where available) and then replace the spark plug.
- Cover the unpainted parts, excepting the brakes and the rubber parts, with a film of oil or spray silicone.
- Protect the vehicle with a dust cover.
- Drain the carburetor tank as described at page 38.

AFTER PROLONGED INACTIVITY

- Restore the tyre inflating pressures.
- Check the tightening of all the screws having an important mechanical function.

		End of running-in **5** hours	Coupon **1** **40** hours or **1.000** Km	Coupon **2** **80** hours or **2.000** Km	Coupon **3** **120** hours or **3.000** Km	Coupon **4** **160** hours or **4.000** Km	Coupon **5** **200** hours or **5.000** Km	Coupon **6** **240** hours or **6.000** Km	Coupon **7** **280** hours or **7.000** Km	Coupon **8** **320** hours or **8.000** Km	Coupon **9** **360** hours or **9.000** Km
Engine	Spark plug	**P**		**S**			**S**			**S**	
	Clutch	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Reed valve		**C**	**S**	**C**	**C**	**S**	**C**	**C**	**S**	**C**
	Cylinder		**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Piston sealing rings		**C**	**S**	**C**	**C**	**S**	**C**	**C**	**S**	**C**
	Piston			**S**			**S**			**S**	
	Water pump fan		**C**	**S**	**C**	**S**	**C**	**S**	**C**	**S**	**C**
	Shim water pump fan		**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Gear water pump fan		**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Water pump shaft		**C**	**S**	**C**	**S**	**C**	**S**	**C**	**S**	**C**
	Water pump shaft sealing			**S**		**S**		**S**		**S**	
	Coolant	**C**	**C**	**S**	**C**	**C**	**S**	**C**	**C**	**S**	**C**
	Gear oil	**S**	**S**	**S**	**S**	**S**	**S**	**S**	**S**	**S**	**S**
	Connecting rod				**S**			**S**			**S**
	Crankshaft bearings				**S**			**S**			**S**
	Gear				**C**			**C**			**C**
Vehicle	Rear shock absorber	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Linkage rear suspension	**T**	**T**	**C**	**T**	**C**	**T**	**C**	**T**	**C**	**T**
	Fork oil		**S**		**S**		**S**		**S**		**S**
	Steering bearings and steering clearance	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Wheel bearings	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Spokes	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Air filter	**P**	**P**	**S**	**P**	**S**	**P**	**S**	**P**	**S**	**P**
	Throttle control	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Braking system	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Oil pumps brakes	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Oil clutch actuator	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Transmission chain	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	State and tire pressure	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**
	Electrical system	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**	**C**

Key

C **Check** (Clean, adjust, lubricate, replace as necessary)
S **Replace/renew**
R **Adjust**
P **Clean**
T **Tighten**

TIGHTENING TORQUE OVERVIEW

Here below is an overview of the tightening torque of all pieces subject to adjustment or maintenance:

Forecarriage		
	Tightening torque [Nm]	Threadlock
Wheel pin	40	
Fork foots - wheel pin	10*	
Brake caliper - Fork	25	M
Steering head base - fork legs	10*	
Steering head - fork legs	10	
Stem pin on steering head	10	
Upper handlebar u-bolt	20	

Rear axle		
	Tightening torque [Nm]	Threadlock
Wheel pin	65	
Rear shock absorber - frame	45	
Rear shock absorber - rocker arm	45	
Connecting rod - frame	30	
Connecting rod - rocker arm	45	
Rocker arm - swinging arm	45	

Engine		
	Tightening torque [Nm]	Threadlock
Gearbox oil drain plug	10	
Bleeding screw cooling system	10	

Superstructures		
	Tightening torque [Nm]	Grease
Front mudguard	10	
Rear mudguard	2,5	G

Headlamps		
	Tightening torque [Nm]	Threadlock
Headlight mask	1	
Tail light glass	0,5	


M Medium strength threadlock

* WARNING:
Tightening of the screws should be carried out by adjusting the torque wrench to the stability torque with repeated tightening until stability torque has been achieved.

CHAPTER 5 REMOVING AND INSTALLING SUPERSTRUCTURES

CONTENTS

Removing and installing saddle-mudguard assembly..... 64



REMOVING AND INSTALLING SADDLE-MUDGUARD ASSEMBLY

Remove the air filter box cover (page 35).
Remove screws **1** and **2** (two per side).
Remove the mudguard.

At the end refit the screws **1** and **2**.

Tighten to the torque indicated.

CHAPTER 6 TROUBLESHOOTING

CONTENTS

Troubleshooting 66
Alphabetical index 67

6 TROUBLESHOOTING

PROBLEM	CAUSE	REMEDY
The engine turns over but will not start	Fuel valve in OFF position	Move the fuel valve in ON or RES position
	Dirty carburettor jets	Contact authorised Betamotor customer service
	Spark plug dirty	Clean or replace the spark plug
	Spark gap wrongly adjusted	Restore the spark gap (page 37)
	Fault in the ignition system	Contact authorised Betamotor customer service
The power delivered by the engine is insufficient	Tank vent obstructed	Check the tank vent
	Fuel system dirty	Contact authorised Betamotor customer service
	Air filter dirty	Clean the air filter
	Defective ignition system	Contact authorised Betamotor customer service
The motor stops or splutters	Lack of fuel	Move the fuel cock to RES
		Refuel
	Poor carburettor seal	Make sure that the sleeve between carburetor and engine is intact
	Loose or oxidized connector or ignition coil	Check the connector. Clean and treat with specific spray
Engine overheats (liquid flows out/vapor from the vent radiator)	Radiator grill blocked	Remove and clean the grill (page 35)
	Radiator (air side) blocked	Clean the radiator
	Forced ventilation absent	Check that the cooling fan is working correctly
	Silencer partly clogged	Contact authorised Betamotor customer service
	Carburation too lean	Contact authorised Betamotor customer service
Front braking poor	Brake pads worn	Contact authorised Betamotor customer service
	Air or humidity in the hydraulic circuit	Contact authorised Betamotor customer service
Rear braking poor	Brake pads worn	Contact authorised Betamotor customer service
	Air or humidity in the hydraulic circuit	Contact authorised Betamotor customer service

ALPHABETICAL INDEX

Accelerator 28
Adjusting fork 29
Adjustment of gas clearance 27
Air filter 35

Battery 55
Brakes 26
Breaking in 21

Carburetor 38
Chain 53
Check of steering gear 48
Checks before and after use 21
Cleaning the vehicle 58
Clutch 27
Clutch control 46
Coolant 33

Electrical system 14
Engine shut-down 23

Familiarizing with the vehicle 9
Front Brake 40
Fuelling 22

Gear oil 32

Handlebar adjustment 28
Headlight 54

Key to symbols 26
Key to symbols 32

Main parts 18

Oil fork 49
Operating instructions 5

Prolonged inactivity 59

Rear brake 43
Rear tail light 54
Recommended lubricants and liquids 16
Removing and installing saddle-mudguard assembly 64
Riding safety 6

Scheduled maintenance vehicle 60
Shock absorber 29
Spark plug 37
Specifications 10
Startup 23
Suspension adjustment according to the motorcyclist's weight 30
Symbols 5

Tightening torque overview 61
Troubleshooting 66
Tyres 52

Vehicle identification data 8