Owner's manual 2027

EC 350F

Item no.: 3215293en



GASGAS

Dear GASGAS customer,

Congratulations on your decision to purchase a GASGAS motorcycle. You are now the owner of a state-of-the-art sports vehicle which, with proper care, will bring you pleasure for a long time to come.

We hope you enjoy your bike and have a safe journey at all times!

You can enter the serial numbers of your vehicle below to find the serial numbers more quickly if required:

Vehicle identification number (p. 16)	Stamp of the contractual partner
Engine number (p. 16)	

The owner's manual contained the latest information for this model series at the time of publication. Slight deviations resulting from continuing development and design of the motorcycles cannot, however, be completely excluded.
All specifications are non-binding. GASGAS GmbH specifically reserves the right to modify or delete technical specifications, prices, colors, forms, materials, services, designs, equipment, etc., without prior notice and without specifying reasons, to adapt these to local conditions, as well as to stop production of a particular model without prior notice. The models portrayed partly contain special equipment that does not belong to the regular scope of supply.

© 2026 GASGAS GmbH, Mattighofen Austria
All rights reserved. Figures: Visus Studios/INDG/GASGAS
Written permission from the copyright owner is required before any duplication or reproduction.

ISO 9001

GASGAS applies quality assurance processes that lead to the highest possible product quality as defined in the ISO 9001 international quality management standard.

12 100 6061

REG.NO. 12 100 6061

Issuing institution:
TÜV SÜD Management Service GmbH

GASGAS GmbH
Stallhofnerstraße 3
5230 Mattighofen, Austria

This document is valid for:
EC 350F EU (F0303927)

3215293en

06/08/2026

Table of contents

1 Means of representation ... 9

1.1 Conventions ... 9
1.1.1 Icons ... 9
1.1.2 Formatting ... 9
1.1.3 Abbreviations ... 9

2 Safety ... 10

2.1 Safety instructions ... 10
2.2 Warning against tampering with the machine ... 10
2.3 Safe use ... 10
2.4 Protective clothing ... 11
2.5 Work rules ... 11
2.6 Environment ... 12
2.7 Owner's manual ... 12
2.8 Use definition – intended use ... 12
2.9 Improper use ... 12

3 Important notes ... 13

3.1 Manufacturer's warranty, implied warranty ... 13
3.2 Auxiliary material, operating material ... 13
3.3 Spare parts, accessories ... 13
3.4 Service ... 13
3.5 Figures ... 13
3.6 Customer service ... 13

4 View of the vehicle ... 14

4.1 View of vehicle, rear right (example) ... 14
4.2 View of vehicle, front left (example) ... 15

5 Serial number ... 16

5.1 Vehicle identification number ... 16
5.2 Type approval label ... 16
5.3 Key number ... 16
5.4 Engine number ... 16
5.5 Fork part number ... 17
5.6 Shock absorber part number ... 17

6 Controls ... 18

6.1 Clutch lever ... 18
6.2 Handbrake lever ... 18
6.3 Throttle grip ... 18
6.4 Horn button ... 18
6.5 Light switch ... 19
6.6 Turn signal switch ... 19
6.7 Electric starter ... 19
6.8 Kill switch ... 19
6.9 Overview of indicator lights ... 20
6.10 Opening the fuel tank cap ... 20
6.11 Closing the fuel tank cap ... 21
6.12 Cold start button ... 21
6.13 Idle speed adjustment screw ... 22
6.14 Gear shift lever ... 22
6.15 Brake pedal ... 23
6.16 Side stand ... 23
6.17 Steering lock ... 23
6.18 Locking the steering ... 24
6.19 Unlocking the steering ... 24

7 Combination instrument ... 25

7.1 Dashboard ... 25
7.2 activation and testing ... 25
7.2.1 Activating the dashboard ... 25
7.2.2 Display test ... 25
7.3 indicator lamps ... 25
7.4 Speed display ... 26
7.5 Display mode average speed and maximum speed ... 26
7.6 Time display ... 27
7.7 Display mode **ODO** (odometer) ... 27
7.8 Display mode **Trip A** (tripmaster A) ... 27
7.9 Display mode **Trip B** (tripmaster B) ... 28
7.10 The display mode Accumulated Ride Time ... 28
7.11 Display mode Trip Time 1 ... 29
7.12 Display mode Trip Time 2 ... 29
7.13 Setup menu ... 30
7.14 Setting the clock ... 31
7.15 Adjusting the light ... 31
7.16 Adjusting the wheel circumference ... 32
7.17 Adjusting the unit of measurement ... 32
7.18 Table of functions ... 33
7.19 Table of conditions and menu activation ... 34

8 Preparing for use ... 35

8.1 Notes on preparing for first use ... 35
8.2 Running in the engine ... 36
8.3 Starting performance of lithium-ion batteries at low temperatures ... 36
8.4 Preparing the vehicle for difficult operating conditions ... 37
8.5 Preparing the vehicle for rides on dry sand ... 37
8.6 Preparing the vehicle for rides on wet sand ... 38
8.7 Preparing for rides on wet and muddy surfaces ... 38
8.8 Preparing vehicle for rides at high temperature or slow speed ... 39
8.9 Preparing the vehicle for low temperatures or snow ... 39

9 Riding instructions ... 40

9.1 Checks and maintenance measures when preparing for use ... 40
9.2 Starting the vehicle ... 40
9.3 Starting off ... 41
9.4 Shifting, riding. ... 41
9.5 Braking ... 42

9.6 Stop, park 42
9.7 Transportation 43
9.8 Refueling 43

10 Service schedule 45

10.1 Service schedule 45

11 Tuning the chassis 47

11.1 Checking the basic chassis setting with the rider's weight 47
11.2 Compression damping of the shock absorber 47
11.3 Adjusting the low-speed compression damping of the shock absorber 47
11.4 Adjusting the high-speed compression damping of the shock absorber 48
11.5 Adjusting the rebound damping of the shock absorber 48
11.6 Measuring the dimension of the unloaded rear wheel 49
11.7 Checking the static sag of the shock absorber 50
11.8 Checking the rider sag of the shock absorber 50
11.9 Adjusting the preload for the shock absorber 51
11.10 Adjusting the rider sag 52
11.11 Checking the basic setting of the fork 52
11.12 Adjusting the compression damping of the fork 53
11.13 Adjusting the rebound damping of the fork 53
11.14 Handlebar position 54
11.15 Adjusting the handlebar position 54

12 Service work on the chassis 56

12.1 Raising the motorcycle with a lift stand 56
12.2 Removing the motorcycle from the lift stand 56
12.3 Bleeding the fork legs 56
12.4 Cleaning the dust boots of the fork legs 57
12.5 Removing the fork protector 58
12.6 Installing the fork protector 58
12.7 Removing the frame protector 58
12.8 Installing the frame protector 59
12.9 Removing the fork legs 59
12.10 Installing the fork legs 60
12.11 Removing the lower triple clamp 60
12.12 Installing the lower triple clamp 61
12.13 Checking the steering head bearing play 63
12.14 Adjusting the steering head bearing play 64
12.15 Lubricating the steering head bearing 65
12.16 Removing the front top fender 65
12.17 Installing the front top fender 65
12.18 Removing the shock absorber 66
12.19 Installing the shock absorber 68
12.20 Removing the seat 69
12.21 Mounting the seat 70
12.22 Removing air filter box cover 70
12.23 Installing air filter box cover 71
12.24 Removing the air filter 72
12.25 Installing the air filter 72
12.26 Cleaning the air filter and air filter box 73
12.27 Preparing the air filter box cover for securing 74
12.28 Removing the muffler 74
12.29 Installing muffler 74
12.30 Changing the damping material on the main silencer 75
12.31 Removing the fuel tank 75
12.32 Installing the fuel tank 77
12.33 Checking the chain for dirt 79
12.34 Cleaning the chain 79
12.35 Checking the chain tension 80
12.36 Adjusting the chain tension 81
12.37 Checking the chain, rear sprocket, front sprocket, and chain guide 82
12.38 Checking the frame 84
12.39 Checking the swingarm 84
12.40 Checking the throttle cable routing 84
12.41 Checking the hand grip 85
12.42 Adjusting the basic position of the clutch lever 86
12.43 Checking/correcting the fluid level of hydraulic clutch 86
12.44 Changing the hydraulic clutch fluid 87

13 Brake system 89

13.1 Adjusting the basic position of the hand brake lever 89
13.2 Checking the brake discs 89
13.3 Checking the brake fluid level for the front brake 90
13.4 Adding brake fluid for the front brake 90
13.5 Checking that the brake pads of the front brake are secured 91
13.6 Changing the brake pads of the front brake 92
13.7 Checking the free travel of the brake pedal 94
13.8 Adjusting the basic position of the brake pedal 94
13.9 Checking the brake fluid level for the rear brake 95

Table of contents

13.10 Adding brake fluid for the rear brake ... 96
13.11 Checking that the brake pads of the rear brake are secured ... 97
13.12 Changing the rear brake pads ... 97

14 Wheels, tires ... 100

14.1 Removing the front wheel ... 100
14.2 Installing the front wheel ... 101
14.3 Removing the rear wheel ... 101
14.4 Installing the rear wheel ... 102
14.5 Checking the tire condition ... 103
14.6 Checking the tire pressure ... 104
14.7 Checking the spoke tension ... 105

15 Electrics ... 106

15.1 Removing the 12 V battery ... 106
15.2 Installing the 12 V battery ... 107
15.3 Charging the 12 V battery ... 108
15.4 Changing the main fuse ... 110
15.5 Removing the headlight mask with the headlight ... 111
15.6 Installing the headlight mask with the headlight ... 111
15.7 Changing the headlight bulb ... 112
15.8 Checking the headlight setting ... 112
15.9 Adjusting the headlight range ... 113
15.10 Changing the turn signal bulb ... 113
15.11 Changing the combination instrument battery ... 114
15.12 Diagnostic connector ... 115
15.13 OCU ... 115

16 Cooling system ... 116

16.1 Cooling system ... 116
16.2 Checking the frost protection and coolant level ... 116
16.3 Checking the coolant level ... 117
16.4 Draining the coolant ... 118
16.5 Refilling the coolant ... 118
16.6 Changing the coolant ... 119

17 Tuning the engine ... 121

17.1 Checking the play in the throttle cable ... 121
17.2 Adjusting the throttle cable play ... 121
17.3 Adjusting the characteristic map of the throttle response ... 122
17.4 Changing the mapping ... 124
17.5 adjusting the idle speed ... 124
17.6 Teaching the throttle valve position ... 125
17.7 Checking the basic position of the gear shift lever ... 126
17.8 Adjusting the basic position of the gear shift lever ... 126

18 Service work on the engine ... 127

18.1 Changing the fuel screen ... 127
18.2 Checking the engine oil level ... 128
18.3 Changing the engine oil and oil filter, cleaning the oil screens ... 129
18.4 Adding engine oil ... 131

19 Cleaning, care ... 133

19.1 Cleaning the motorcycle ... 133
19.2 Checks and maintenance steps for winter operation ... 134

20 Storage ... 136

20.1 Storage ... 136
20.2 Preparing for use after storage ... 137

21 Troubleshooting ... 138

21.1 troubleshooting ... 138

22 Flash code ... 140

22.1 Flash code ... 140

23 Technical specifications ... 142

23.1 Engine ... 142
23.1.1 Technical data - engine ... 142
23.1.2 Capacities - engine ... 143
23.2 Chassis ... 143
23.2.1 Technical data - chassis ... 143
23.2.2 Technical data - tires ... 144
23.2.3 Capacities - vehicle ... 144
23.3 Electrics ... 144
23.3.1 Battery ... 144
23.3.2 Fuses ... 144
23.3.3 Lamps ... 144
23.4 Fork ... 145
23.4.1 Technical data - fork ... 145
23.4.2 Capacities - fork ... 145
23.5 Shock absorber ... 145
23.5.1 Technical data - shock absorber ... 145
23.5.2 Capacities - shock absorber ... 146
23.6 Tightening torque ... 146
23.6.1 Engine tightening torques ... 146
23.6.2 Chassis tightening torques ... 150

24 Recycling ... 155

24.1 Recycling ... 155

Notes ... 157

A Technical terms ... 157

B Fuels ... 158

C Operating supplies ... 159

D Cleaning agents ... 162

E Icons 163

E.1 Symbol colors 163
E.1.1 Yellow and orange symbols 163
E.1.2 Green and blue symbols 163

Index 164

Table of contents

1.1 Conventions

1.1.1 Icons

✓	Indicates a desired result (e.g. of a work step or a function).
✗	Indicates an undesired result (e.g. of a work step or a function).
	All work marked with this symbol requires specialist knowledge and technical understanding. Ensure that this work is carried out or supervised by trained personnel from an authorized contractual partner, and that any special tools required are used.
	Indicates a page reference.
	Indicates information with more details.
	Indicates a tip, e.g. to simplify work.
»	Indicates the result from a test step.
◀	Indicates the end of an activity, including any rework.

1.1.2 Formatting

Proprietary name	Indicates a proprietary name.
Name ®	Indicates a protected name.
Brand ™	Indicates a brand available on the open market.
Underlined terms	Refer to technical details of the vehicle or indicate technical terms that are explained in the glossary.

1.1.3 Abbreviations

2-pc.	two-part
Part no.	Part number
or	respectively
approx.	circa
etc.	et cetera
poss.	possibly/possible
if necessary	if necessary
cmpl.	complete
min.	at least
no.	number
no fig.	no figure
s.	see
among others	among others/not limited to
and the like	and the like
etc.	et cetera
cf.	compare
e.g.	for example

2.1 Safety instructions

Function of the safety instruction

Safety instruction brings attention to dangers when handling the product. Hazards are classified, named, described, and supplemented with information on how to avoid them.

- If there is a safety instruction before a list of instructions, the danger exists throughout the entire activity.
- If there is a safety instruction immediately before an instruction, the next step presents a danger.

Safety instruction layout

All safety instructions are identified by a signal word and a warning symbol. The combination of signal word and warning symbol determines the degree of danger.



DANGER
Indicates an imminent danger that leads to serious injury or death.



WARNING
Indicates a potentially imminent danger that could lead to serious injury or death.



CAUTION
Indicates a potentially imminent danger that can lead to minor or slight injuries.



NOTE
Indicates a situation that can lead to damage to the product or the product environment.



NOTE
Indicates a situation that can lead to environmental damage.

2.2 Warning against tampering with the machine

Tampering with the noise control system is prohibited. Federal law prohibits the following acts or the causing thereof:

1. The removal or rendering inoperative by any person other than for purposes of servicing, repair, or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use, or
2. the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

Among those acts presumed to constitute tampering are the acts listed below:

1. Removing or drilling through rear mufflers, baffle plates, manifolds, or other components that conduct exhaust gases.
2. Removing or puncturing parts of the intake system.
3. Lack of proper maintenance.
4. Replacing moving parts of the vehicle, or parts of the exhaust system or intake system, with parts other than those specified by the manufacturer.

2.3 Safe use



DANGER
Danger of accidents A rider who is not fit to ride poses a danger to themself and to others.
– Do not operate the vehicle if you are not fit to ride due to alcohol, drugs, or medication.
– Do not operate the vehicle if you are physically or mentally incapable of doing so.

DANGER

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always ensure that there is sufficient ventilation when running the engine.
- Use suitable exhaust extraction when starting or running the engine in an enclosed space.

WARNING

Danger of burns Some vehicle components become hot when the vehicle is operated.

- Do not touch any parts such as the exhaust system, radiator, engine, damper, or brake system before the vehicle parts have cooled down.
- Allow the vehicle parts to cool down before performing any work on the vehicle.

The vehicle should only be used when it is in perfect technical condition, for its intended purpose, and in a safe and environmentally-friendly manner.

An appropriate driver's license is needed to drive the vehicle on public roads.

Have any faults that impair safety immediately remedied by an authorized contractual partner.

Observe the information and warning stickers on the vehicle.

2.4 Protective clothing

WARNING

Risk of injury Missing or inadequate protective clothing increases the risk of injury.

- Wear appropriate protective clothing such as helmet, boots, gloves as well as pants and a jacket with protectors on all rides.
- Always wear protective clothing that is in good condition and meets the legal regulations.

2.5 Work rules

Unless specified otherwise, the ignition must be switched off during all work (models with ignition lock, models with transponder key) or the engine must be at a standstill (models without ignition lock or transponder key).

Special tools are required for some work. The tools are not part of the vehicle, but can be ordered using the number in parentheses. Example: bearing puller (15112017000)

Unless otherwise noted, normal conditions apply to all tasks and descriptions.

Ambient temperature	20 °C (68.0 °F)
Ambient air pressure	1,013 mbar (14.69 psi)
Relative air humidity	60 ±5 %

During assembly, use new parts to replace parts which cannot be reused (e.g. self-locking screws and nuts, expansion screws, seals, sealing rings, O-rings, pins, and lock washers).

A thread lock (e.g. **Loctite®**) is required for some screw connections. Observe the manufacturer's specific instructions for use.

If thread lock (e.g. **Precote®**) has already been applied to a new part, do not apply any additional thread lock.

After disassembly, clean the parts that are to be reused and check them for damage and wear. Replace damaged or worn parts.

After completing a repair or service, check the operating safety of the vehicle.

2.6 Environment

Handling the vehicle responsibly reduces the risk of conflict with other road users and the surrounding area. The future of motorcycling also depends on using motorcycles legally, being environmentally conscious and respecting the rights of others.

When disposing of used oil, other operating and auxiliary fluids, and used components, the laws and regulations of the respective country must be observed.

As motorcycles are not subject to the EU regulations governing the disposal of end-of-life vehicles, there are no legal regulations that pertain to the disposal of an end-of-life motorcycle. More information is available from the authorized contractual partner.

2.7 Owner's manual

Read this owner's manual carefully and in full before riding off for the first time. The owner's manual contains information and tips on how to operate, handle, and service your vehicle, as well as advice on optimum tuning and how to avoid injuries.



Tip

Save this owner's manual on your smartphone, for example, so that you can access it at any time.

An authorized contractual partner will be happy to assist you if you are unsure.

The owner's manual is an important component of the vehicle. If the vehicle is sold, the owner's manual must be downloaded again by the new owner.

The owner's manual can be downloaded multiple times using the QR code or the link on the delivery certificate.

The owner's manual is also available for download from your authorized contractual partner and on the GASGAS website.

International GASGAS website: https://www.gasgas.com/

A printed copy can be ordered from the following address.

Website for printed copy: https://print.ktm.com

2.8 Use definition – intended use

This vehicle has been designed and built to withstand the typical stresses and strains of racing. This vehicle complies with the currently valid regulations and categories of the top international motorsports organizations.



Note

This vehicle is only authorized for operation on public roads in the homologated (restricted) version.

The derestricted version of this vehicle must only be operated in closed off areas away from public highway traffic.

This vehicle is designed for use in offroad endurance competition, and not primarily for use in motocross.

2.9 Improper use

The vehicle may only be used as intended.

Improper use can result in danger to people, property and the environment.

Any use of the vehicle beyond the intended and defined use constitutes misuse.

Improper use includes the use of operating and auxiliary materials that do not meet the required specifications for the respective use.

3.1 Manufacturer's warranty, implied warranty

The work prescribed in the service schedule must only be carried out by an authorized contractual partner and then confirmed in the electronic proof of service, as otherwise all warranty claims will be void. Damage or secondary damage caused by tampering with and/or conversions on the vehicle are not covered by the manufacturer's warranty.

3.2 Auxiliary material, operating material

Use operating materials and auxiliary materials in accordance with the operating instructions and specifications.

3.3 Spare parts, accessories

For safety reasons, only spare parts and accessories approved by GASGAS may be used. They may only be installed by an authorized contractual partner. GASGAS accepts no liability for other products and any resulting damage or loss.

Certain spare parts and accessory products are specified in parentheses in the descriptions. Authorized contractual partners will be happy to help.

The current accessories for your vehicle are available from your authorized contractual partner and on the GASGAS website.

International GASGAS website: https://www.gasgas.com/

3.4 Service

A prerequisite for perfect operation and prevention of premature wear is that the service, care, and tuning work on the engine and chassis is properly carried out as described in the owner's manual. An incorrect suspension setting can lead to damage and breakage of chassis components.

Use of the vehicle under arduous conditions, such as on sand or on wet, dusty and muddy surfaces, can result in significantly increased wear of components, such as the powertrain, brake system, air filter, or suspension components. For this reason, it may be necessary to inspect or replace parts before the next scheduled service interval.

Please adhere to the prescribed run-in times and service intervals at all times. Strictly adhering to this will ensure a much longer service life for your motorcycle.

The relevant mileage or time interval is whichever occurs first.

A list of services that have already been carried out on the vehicle can be found in the Service area on the international GASGAS website:

International GASGAS website: https://www.gasgas.com/

Authorized contractual partners will be happy to answer any questions regarding the services performed.

A list of authorized contractual partners can be found on the GASGAS website.

3.5 Figures

Some of the figures in this document contain optional extras.

For clarity, some components may be shown disassembled or may not be shown at all. Disassembly is not always absolutely necessary in order to carry out the activities described. The textual information takes precedence.

3.6 Customer service

Authorized contractual partners will be happy to answer questions about the vehicle and GASGAS.

A list of authorized contractual partners can be found on the GASGAS website.

International GASGAS website: https://www.gasgas.com/

4 View of the vehicle

4.1 View of vehicle, rear right (example)



1 Horn button (p. 18)
1 Light switch (p. 19)
1 Turn signal switch (p. 19)
2 Kill switch (p. 19)
2 Electric starter (p. 19)
3 Throttle grip (p. 18)
4 Handbrake lever (p. 18)
5 Fork part number (p. 17)
6 Brake pedal (p. 23)
7 Level viewer for brake fluid, rear


4.2 View of vehicle, front left (example)



1. Clutch lever (p. 18)
2. Fuel tank cap
3. Air filter box cover
4. Side stand (p. 23)
5. Engine number (p. 16)
6. Gear shift lever (p. 22)


5 Serial number

5.1 Vehicle identification number




The vehicle identification number ❶ is stamped on the right-hand side of the steering head.

5.2 Type approval label




The type label ❶ is located on the front steering head.

5.3 Key number




The key number ❶ for the steering lock is stamped onto the key connector.

5.4 Engine number




The engine number ❶ is stamped on the left side of the engine above the front sprocket.

5.5 Fork part number




Fork part number ❶ is stamped on the inside of the fork shoe.

5.6 Shock absorber part number




Shock absorber part number ❶ is stamped on the top right of the shock absorber.

6.1 Clutch lever




Clutch lever ❶ is fitted on the left side of the handlebar.
The clutch is activated hydraulically and adjusts itself automatically.

6.2 Handbrake lever




Hand brake lever ❶ is fitted on the right side of the handlebar.
The front brake is engaged using the hand brake lever.

6.3 Throttle grip



The throttle twist grip ❶ is fitted on the right side of the handlebar.


6.4 Horn button



Horn button ❶ is fitted on the left side of the handlebar.

Condition	Meaning
Horn buttons in the basic position	No function
Horn buttons pressed	The horn is operated in this position.


6.5 Light switch



Light switch ❶ is fitted on the left side of the handlebar.

Condition		Meaning
	Light switch is in the central position.	In this position, the low beam and tail light are switched on.
	The light switch is turned counterclockwise.	In this position, the high beam and the tail light are switched on.

6.6 Turn signal switch



Turn signal switch ❶ is fitted on the left side of the handlebar.

Condition		Meaning
	Turn signal switch pressed to the left	Left turn signal, on
	Turn signal switch pressed to the right	Right turn signal, on

6.7 Electric starter



Electric starter ❶ is fitted on the right side of the handlebar.

Condition	Meaning
Electric starter in the basic position	No function
Electric starter pressed	In this position, the starter motor is actuated.


6.8 Kill switch



Kill switch ❶ is fitted on the right side of the handlebar.

Condition	Meaning
Kill button is not pressed.	In this position, the ignition circuit is closed, and the engine can be started.
The kill button is pressed and held.	In this position, the ignition circuit is interrupted, a running engine stops, and an engine at standstill will not start.

6.9 Overview of indicator lights



Condition		Meaning
	The high beam indicator lamp lights up blue	The high beam is switched on.
	Malfunction indicator lamp lights up/flashes yellow	The **OBD** has detected an error in the vehicle electronics. Come safely to a halt, and contact an authorized dealer.
	The fuel level warning lamp lights up yellow	The fuel level has reached the reserve mark.
	Turn signal indicator lamp flashes green	The turn signal is switched on.

6.10 Opening the fuel tank cap

DANGER

Fire hazard Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

- Do not refuel the vehicle in the vicinity of open flames, glowing, or smoldering objects.
- Make sure that nobody smokes in the vicinity of the vehicle during the refueling process.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it up immediately.
- Do not overfill the fuel tank.

WARNING


Danger of poisoning Fuel is harmful to health.

- Do not allow fuel to come into contact with skin, eyes, or clothing.
- Consult a doctor immediately if fuel has been ingested.
- Do not inhale fuel vapors.
- Rinse the affected area immediately with plenty of water in the event of contact with skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if fuel comes into contact with eyes.
- If fuel spills on to your clothing, change the clothing.
- Store fuel properly in a suitable container and keep out of the reach of children.

NOTE


Environmental hazard Improper handling of fuel is dangerous to the environment.

- Do not allow fuel to enter the groundwater, the soil, or the sewage system.



– Press release button ❶, turn the fuel tank cap counterclockwise, and lift it off.

6.11 Closing the fuel tank cap




– Mount the fuel tank filler cap and turn it clockwise until release button ❶ engages.

Route hose of fuel tank vent ❷ without kinks.

6.12 Cold start button

The electronic fuel injection extends the injection time when the engine is cold and the ambient temperature is low. To help the engine burn the increased amount of fuel, it must be supplied with additional oxygen by pushing the cold start button. After briefly opening up the throttle and then releasing the throttle grip again, or turning the throttle grip towards the front, the cold start button returns to its original position.


Note
Check whether the cold start button has returned to its basic position.



Cold start button ❶ is fitted to the bottom of the throttle body.

Condition	Meaning
The cold start button is pushed in all the way to the stop.	Cold start button activated
The cold start button is in the basic position.	Cold start button deactivated

6.13 Idle speed adjustment screw



The idle setting of the throttle body substantially influences the vehicle's starting behavior, a stable idle speed, and the vehicle's response when the throttle is opened.


An engine with a correctly set idle speed is easier to start than an engine with the idle speed set incorrectly.

The idle speed is adjusted using idle speed adjusting screw ❶.


Increase the idle speed by turning the idle speed adjustment screw clockwise.

Decrease the idle speed by turning the idle speed adjustment screw counterclockwise.

6.14 Gear shift lever




Gear shift lever ❶ is mounted on the left of the engine.



The gear positions can be seen in the figure.


The neutral or idle position is between the first and second gears.

6.15 Brake pedal




Brake pedal ❶ is located in front of the right footpeg.
The rear brake is operated with the brake pedal.

6.16 Side stand




The side stand ❶ is attached to the left side of the vehicle.



The side stand is used for parking the motorcycle.

Note
When you are riding, side stand ❶ must be folded up and secured with rubber band ❷.

6.17 Steering lock



Steering lock ❶ is fitted on the left side of the steering head.
The steering lock is used to lock the steering. Steering and riding is then no longer possible.

6.18 Locking the steering


NOTE

Material damage The vehicle may be damaged if parked incorrectly.

Damage can occur if the vehicle rolls away or falls over.

The components for parking the vehicle are designed only for the weight of the vehicle.

– Park the vehicle on a firm and level surface.
– Make sure that nobody sits on the vehicle when it is parked on a stand.




– Park the vehicle.
– Turn handlebar as far as possible to the right.
– Lubricate the steering lock regularly.

Universal oil spray (p. 159)

– Insert the key for the steering lock into the steering lock (p. 23), turn it to the left, press it in, turn it to the right and remove.

Never leave the key for the steering lock in the steering lock.

6.19 Unlocking the steering




– Insert the key for the steering lock into the steering lock (p. 23), turn it to the left, pull it out, turn it to the right and remove.

Never leave the key for the steering lock in the steering lock.

✓ The handlebar can now be moved again.


7.1 Dashboard



1. Indicator lamps (p. 25)
2. Display
3. Left button
4. Right button


7.2 activation and testing

7.2.1 Activating the dashboard




The dashboard is activated when one of the buttons is pressed or a pulse comes from the wheel speed sensor.

7.2.2 Display test




To enable you to check that the display is functioning properly, all display segments light up briefly.

7.3 indicator lamps



Condition		Meaning
	The high beam indicator light lights up blue.	The high beam is switched on.
	Malfunction indicator light lights up/flashes.	The **OBD** has detected an error in the vehicle electronics. Come safely to a halt, and contact an authorized dealer.
	Fuel level warning light lights up yellow.	The fuel level has reached the reserve mark.
	Turn signal indicator light flashes green.	The turn signal is switched on.

7.4 Speed display



– Briefly and repeatedly press **«Left button»** until the speed appears in the left of the display.

The current speed is displayed on the left in display mode **SPEED**.


The current speed can be displayed in **km/h** or **mph**.

Note

Make the setting according to the country.

When an impulse comes from the front wheel, the left side of the display changes to the **SPEED** mode and the current speed is shown.

7.5 Display mode average speed and maximum speed



– Briefly and repeatedly press **«Left button»** until indicator **MAX** appears in the left of the display.

AVG (average speed 1) shows the average speed calculated on the basis of **Trip A** (tripmaster A) and **HOURS A** (stopwatch A).


The calculation of this value is activated by the first impulse of the wheel speed sensor and ends 3 seconds after the last impulse.

Note

Average speed and max. speed are displayed alternately at intervals of 3 seconds.


– **«Right button»** Press for 2–3 seconds.	No function
– **«Right button»** Press briefly.	Next display mode
– Press **«Left button»** for 2–3 seconds.	No function
– Press **«Left button»** briefly.	Switches between **AVG** and the speedometer

7.6 Time display



The time is displayed at the top right.
The time can be displayed in 24-hour or 12-hour format in all languages.

7.7 Display mode ODO (odometer)




– **«Right button»** Briefly and repeatedly press until indicator **ODO** appears in the bottom right of the display.

The total traveled distance is shown in display mode **ODO**.

– **«Right button»** Press for 2–3 seconds.	No function
– **«Right button»** Press briefly.	Next display mode
– Press **«Left button»** for 2–3 seconds.	No function
– Press **«Left button»** briefly.	Switches between **AVG** and the speedometer

7.8 Display mode Trip A (tripmaster A)




– **«Right button»** Briefly and repeatedly press until **Trip A** appears in the top right of the display.

Trip A (tripmaster A) always runs and counts up to 999.9.
You can use it to measure trips or the distance between refueling stops.
Trip A is linked to **AVG** (average speed) and **HOURS A** (stopwatch A).


Note
If it exceeds 999.9, the values **Trip A** , **AVG** and **HOURS A** are automatically reset to 0.0.

– **«Right button»** Press for 2–3 seconds.	**Trip A** is set to 0.0.



– **«Right button»** Press briefly.	Next display mode
– Press **«Left button»** for 2–3 seconds.	No function
– Press **«Left button»** briefly.	Switches between **AVG** and the speedometer

7.9 Display mode Trip B (tripmaster B)




– **«Right button»** Briefly and repeatedly press until **Trip B** appears in the top right of the display.

Trip B (tripmaster B) always runs and counts up to 999.9.

– **«Right button»** Press for 2–3 seconds.	**Trip B** is set to 0.0.
– **«Right button»** Press briefly.	Next display mode
– Press **«Left button»** for 2–3 seconds.	No function
– Press **«Left button»** briefly.	Switches between **AVG** and the speedometer

7.10 The display mode Accumulated Ride Time



– **«Right button»** Briefly and repeatedly press until indicator **HOURS** appears in the right of the display.


HOURS shows the total trip time and runs until a pulse is received from the wheel speed sensor.

The calculation of this value starts with the first impulse from the wheel speed sensor and ends 3 seconds after the last impulse.

– **«Right button»** Press for 2–3 seconds.	No function
– **«Right button»** Press briefly.	Next display mode

– Press **«Left button»** for 2–3 seconds.	No function
– Press **«Left button»** briefly.	Switches between **AVG** and the speedometer

7.11 Display mode Trip Time 1




– **«Right button»** Briefly and repeatedly press until indicator **HOURS A** appears in the right of the display.

HOURS A (Trip Time A) displays the trip time on the basis of **Trip A** and continues to run until a pulse is received from the wheel speed sensor. The calculation of this value starts with the first impulse from the wheel speed sensor and ends 3 seconds after the last impulse.

– **«Right button»** Press for 2–3 seconds.	**HOURS A** is set to 0.0.
– **«Right button»** Press briefly.	Next display mode
– Press **«Left button»** for 2–3 seconds.	No function
– Press **«Left button»** briefly.	Switches between **AVG** and the speedometer


7.12 Display mode Trip Time 2



– **«Right button»** Briefly and repeatedly press until indicator **HOURS B** appears in the top right of the display.


HOURS B (Trip Time B) displays the trip time on the basis of **Trip B** and continues to run until a pulse is received from the wheel speed sensor. The calculation of this value starts with the first impulse from the wheel speed sensor and ends 3 seconds after the last impulse.

– **«Right button»** Press for 2–3 seconds.	**HOURS B** is set to 0.0.
– **«Right button»** Press briefly.	Next display mode



– Press **«Left button»** for 2–3 seconds.	No function
– Press **«Left button»** briefly.	No function

7.13 Setup menu



Condition: Motorcycle is stationary

– Press both buttons for 2–3 seconds.

The Setup menu displays the active functions.


Note

Briefly and repeatedly press the **Right button** until the desired function is reached.

If no button is pressed for 20 seconds, the settings are automatically saved.

– **«Right button»** Press briefly.	Introduction to the selection process
– **«Right button»** Press for 2–3 seconds.	Closes the Setup menu
– Press **«Left button»** briefly.	Changes to the next display
– Press **«Left button»** for 2–3 seconds.	No function
– Wait 10–12 seconds.	Closes the Setup menu

7.14 Setting the clock




Condition: Motorcycle is stationary

– Press both buttons for 2–3 seconds.
– **«Right button»** Briefly and repeatedly press until indicator **Clock** appears in the display.
– Set the hours display using the **Right button**.
– **«Right button»** Press briefly.
  ✓ The next segment of the display flashes and can be set.
– By pressing the **Right button**, the following segments can be set in the same way as for the hour display.

Note
If no button is pressed for 15–20 seconds, or if a pulse comes from the wheel speed sensor, the settings are automatically saved and the setup menu is closed.

– **«Right button»** Press briefly.	Changes to the next value
– **«Right button»** Press for 2–3 seconds.	No function
– Press **«Left button»** briefly.	Increases the value
– Press **«Left button»** for 2–3 seconds.	Closes the Setup menu
– Wait 10–12 seconds.	Closes the Setup menu

7.15 Adjusting the light




Condition: Motorcycle is stationary

– Press both buttons for 2–3 seconds.
– **«Right button»** Briefly and repeatedly press until indicator **Light** appears in the display.
– The brightness of the light can be adjusted by pressing the **Right button**.


Note
There are 5 possible settings.
If no button is pressed for 15–20 seconds, or if a pulse comes from the wheel speed sensor, the settings are automatically saved and the setup menu is closed.

– **«Right button»** Press briefly.	Changes to the next value



– **«Right button»** Press for 2–3 seconds.	No function
– Press **«Left button»** briefly.	Increases the value
– Press **«Left button»** for 2–3 seconds.	Closes the Setup menu
– Wait 10–12 seconds.	Closes the Setup menu

7.16 Adjusting the wheel circumference




Condition: Motorcycle is stationary

– Press both buttons for 2–3 seconds.
– **«Right button»** Briefly and repeatedly press until indicator **Speed** appears in the display.

– **«Right button»** Press briefly.	Changes to the next value
– **«Right button»** Press for 2–3 seconds.	No function
– Press **«Left button»** briefly.	Increases the value
– Press **«Left button»** for 2–3 seconds.	Closes the Setup menu
– Wait 10–12 seconds.	Closes the Setup menu

7.17 Adjusting the unit of measurement



Condition: Motorcycle is stationary

– Press both buttons for 2–3 seconds.
– **«Right button»** Briefly and repeatedly press until indicator **Unit** appears in the display.

In the measurement unit menu, you can change the unit of measurement.

Note
If no button is pressed for 5 seconds, the settings are automatically saved.

– **«Right button»** Press briefly.	Changes to the next value
– **«Right button»** Press for 2–3 seconds.	No function
– Press **«Left button»** briefly.	Increases the value
– Press **«Left button»** for 2–3 seconds.	Closes the Setup menu
– Wait 10–12 seconds.	Closes the Setup menu

7.18 Table of functions

Display	**«Right button» Press for 2–3 seconds.**	**«Right button» Press briefly.**	**Press «Left button» for 2–3 seconds.**	**Press «Left button» briefly.**	**Wait 10–12 seconds.**
Adjusting the unit of measurement	No function	Changes to the next value	Closes the Setup menu	Increases the value	Closes the Setup menu
Adjusting the wheel circumference	No function	Changes to the next value	Closes the Setup menu	Increases the value	Closes the Setup menu
Adjusting the light	No function	Changes to the next value	Closes the Setup menu	Increases the value	Closes the Setup menu
Setting the clock	No function	Changes to the next value	Closes the Setup menu	Increases the value	Closes the Setup menu
Setup menu	Closes the Setup menu	Introduction to the selection process	No function	Changes to the next display	Closes the Setup menu
Display mode Trip Time 2	**HOURS B** is set to 0.0.	Next display mode	No function	No function	
Display mode Trip Time 1	**HOURS A** is set to 0.0.	Next display mode	No function	Switches between **AVG** and the speedometer	
The display mode Accumulated Ride Time	No function	Next display mode	No function	Switches between **AVG** and the speedometer	
Display mode **Trip B** (tripmaster B)	**Trip B** is set to 0.0.	Next display mode	No function	Switches between **AVG** and the speedometer	
Display mode **Trip A** (tripmaster A)	**Trip A** is set to 0.0.	Next display mode	No function	Switches between **AVG** and the speedometer	

Display	«Right button» Press for 2–3 seconds.	«Right button» Press briefly.	Press «Left button» for 2–3 seconds.	Press «Left button» briefly.	Wait 10–12 seconds.
Display mode **ODO** (odometer)	No function	Next display mode	No function	Switches between **AVG** and the speedometer	
Display mode average speed and maximum speed	No function	Next display mode	No function	Switches between **AVG** and the speedometer	

7.19 Table of conditions and menu activation

Display	Motorcycle is stationary	Menu can be activated
Adjusting the unit of measurement	●	
Adjusting the wheel circumference	●	
Adjusting the light	●	
Setting the clock	●	
Setup menu	●	
Display mode Trip Time 2		●
Display mode Trip Time 1		●
The display mode Accumulated Ride Time		●
Display mode **Trip B** (tripmaster B)		●
Display mode **Trip A** (tripmaster A)		●
Display mode **ODO** (odometer)		
Display mode average speed and maximum speed		●
Speed display		

8.1 Notes on preparing for first use

DANGER
Danger of accidents A rider who is not fit to ride poses a danger to themself and to others.
– Do not operate the vehicle if you are not fit to ride due to alcohol, drugs, or medication.
– Do not operate the vehicle if you are physically or mentally incapable of doing so.

WARNING
Danger of accidents The vehicle is not designed to carry passengers.
– Do not ride with a passenger.

WARNING
Danger of accidents The brake system fails in the event of overheating.
If the brake pedal is not released, the brake pads grind continuously.
– Take your foot off the brake pedal when you are not braking.

WARNING
Danger of accidents Not adapting the riding style constitutes a major risk.
– Adapt the vehicle speed to the road conditions and your riding ability.

WARNING
Danger of accidents Total weight and axle loads influence the handling characteristic.
– Do not exceed the maximum permissible total weight or the axle loads.

WARNING
Risk of injury People who act without authorization endanger themselves and others.
– Never leave the vehicle unattended while the engine is running.
– Secure the vehicle against unauthorized access.

WARNING
Danger of accidents Different tire profiles on the front and rear wheels can make it more difficult to control the vehicle.
– Make sure that only tires of the same tread type are mounted to the front and rear wheel.

WARNING
Risk of injury Missing or inadequate protective clothing increases the risk of injury.
– Wear appropriate protective clothing such as helmet, boots, gloves as well as pants and a jacket with protectors on all rides.
– Always wear protective clothing that is in good condition and meets the legal regulations.

Note
When using the motorcycle, remember that others may be disturbed by excessive noise.

– Ensure that the pre-delivery inspection has been carried out by an authorized contractual partner.
  ✓ The delivery certificate is transferred upon vehicle handover.
– Read the entire owner's manual before riding for the first time.
– Get to know the controls.
– Adjust the basic position of the clutch lever. (p. 86)
– Adjust the basic position of the hand brake lever. (p. 89)
– Adjust the basic position of the brake pedal. (p. 94)
– Adjust the basic position of the gear shift lever. (p. 126)
– Get used to the handling characteristics of the motorcycle on suitable terrain before undertaking a more challenging ride.

Note
When off-road, it is recommended that you be accompanied by another person with another vehicle so that you can help each other.

- Also, ride as slowly as possible and in a standing position to get a better feel for the motorcycle.
- Do not make any off-road trips that exceed your ability and experience.
- Hold the handlebar firmly with both hands and keep your feet on the footpegs when riding.
- If luggage is carried, ensure it is fixed firmly as close as possible to the center of the vehicle and ensure even weight distribution between the front and rear wheels.

The maximum permissible total weight and the maximum permissible axle loads must not be exceeded.	
Maximum permissible total weight	335 kg (738.5 lb)
Maximum permissible front axle load	145 kg (319.7 lb)
Maximum permissible rear axle load	190 kg (418.9 lb)

Note
Motorcycles react sensitively to any changes of weight distribution.

- Check the spoke tension. (p. 105)

The spoke tension must be checked after half an hour of operation.

- Run in the engine. (p. 36)

8.2 Running in the engine


- Do not exceed the specified engine speed and load during the running-in time.

Maximum engine speed	
During the first operating hour	7,000 rpm (116.67 Hz)

Maximum engine power	
during the first 3 operating hours	≤ 75 %

Avoid fully opening the throttle.

8.3 Starting performance of lithium-ion batteries at low temperatures



Lithium-ion batteries are far lighter than lead batteries, have a low self-discharge rate, and have more starting power at temperatures over 6 °C (43 °F).

Several attempts to start may be required. Press the start button for 5 seconds, and wait 15 seconds between attempts. At low temperatures, wait for 30 seconds. The pauses are necessary so that the heat created can be distributed through the lithium-ion battery without damaging the lithium-ion battery.

The starting power increases as the battery warms up.

Always make sure the lithium-ion battery is charged to that there is enough power to spare for starting at low temperatures.

After 6 unsuccessful starting attempts, do not try again, and check the vehicle for other faults instead.

8.4 Preparing the vehicle for difficult operating conditions

Note

Use of the vehicle under difficult conditions, such as on sand or on wet and muddy surfaces, can result in significantly increased wear of components, such as the drive train, brake system, or suspension components. For this reason, it may be necessary to inspect or replace parts before the next scheduled service interval.

– Clean the air filter and air filter box. (p. 73)

Check the air filter approx. every 30 minutes.

– Check the connector for humidity and corrosion and to ensure it is firmly seated.
  » If moisture, corrosion, or damage is found:
    – Clean and dry the socket connector, or change it if necessary.
– Riding on dry sand. (p. 37)
– Riding on wet sand. (p. 38)
– Rides on wet and muddy surfaces. (p. 38)
– Riding at high temperatures or slow speed. (p. 39)
– Riding at low temperatures and in snow. (p. 39)

8.5 Preparing the vehicle for rides on dry sand



– Mount the air filter dust protection.

Read the accompanying mounting instructions.
Air filter dust protection cover (A46009620000)



– Mount the air filter sand protection.

Read the accompanying mounting instructions.
Air filter sand protection (A46006922000)


600868-01

– Clean the chain.

Chain cleaner (p. 162)

– Mount the steel sprocket.
– Grease the chain.

Universal oil spray (p. 159)

– Clean the radiator fins.
– Straighten the bent radiator fins carefully.

8.6 Preparing the vehicle for rides on wet sand



102137-01

– Mount the air filter water protection.

Read the accompanying mounting instructions.

Air filter water protection (A46006921000)


600868-01

– Clean the chain.

Chain cleaner (p. 162)

– Mount the steel sprocket.
– Grease the chain.

Universal oil spray (p. 159)

– Clean the radiator fins.
– Straighten the bent radiator fins carefully.

8.7 Preparing for rides on wet and muddy surfaces



102137-01

– Mount the air filter water protection.

Read the accompanying mounting instructions.

Air filter water protection (A46006921000)



– Mount the steel sprocket.
– Clean the motorcycle. (p. 133)
– Straighten the bent radiator fins carefully.

8.8 Preparing vehicle for rides at high temperature or slow speed



– Adjust the secondary transmission to the road conditions.

Note
The engine oil heats up quickly when the clutch is operated frequently due to an excessively high secondary ratio.

– Clean the chain.

Chain cleaner (p. 162)

– Clean the radiator fins.
– Straighten the bent radiator fins carefully.
– Check the coolant level. (p. 117)

8.9 Preparing the vehicle for low temperatures or snow




– Mount the air filter water protection.

Read the accompanying mounting instructions.

Air filter water protection (A46006921000)

9.1 Checks and maintenance measures when preparing for use

Note
Before every trip, check the condition of the vehicle and ensure that it is safe to operate.
The vehicle must be in perfect technical condition when it is being operated.


H02217-01

- Check the engine oil level. (p. 128)
- Check the electrical system.
- Check the brake fluid level for the front brake. (p. 90)
- Check the brake fluid level for the rear brake. (p. 95)
- Check that the brake pads of the front brake are secured. (p. 91)
- Check that the brake pads of the rear brake are secured. (p. 97)
- Check that the brake system is functioning properly.
- Check the coolant level. (p. 117)
- Check the chain for dirt. (p. 79)
- Check the chain, rear sprocket, engine sprocket, and chain guide. (p. 82)
- Check the chain tension. (p. 80)
- Check the tire condition. (p. 103)
- Check the tire pressure. (p. 104)

Condition: Offroad use


- Make sure that the rim locks are installed.
- Check the spoke tension. (p. 105)

  The spoke tension must be checked regularly as incorrect spoke tension will severely impair riding safety.
- Clean the dust boots of the fork legs. (p. 57)
- Bleed the fork legs. (p. 56)
- Check the air filter.
- Check the settings of all controls and ensure that they can be operated smoothly.
- Check all screws, nuts, and hose clamps regularly for tightness.
- Check the fuel level.

9.2 Starting the vehicle

DANGER
Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.
- Always ensure that there is sufficient ventilation when running the engine.
- Use suitable exhaust extraction when starting or running the engine in an enclosed space.


NOTE
Engine failure Running a cold engine at high engine speeds negatively impacts the service life of the engine.
- Always warm up the engine at low engine speeds.



– Take the motorcycle off side stand ❶ and secure the side stand with rubber band ❷.
– Shift the transmission into the neutral position.
– Turn the ignition key in the ignition lock to position ◯.

Condition: Ambient temperature: < 20 °C (< 68.0 °F)

– Press the cold start button in all the way to the stop.



– Press the electric starter.

Note

Press the electric starter for a maximum of 5 seconds. Wait for 15 seconds before making another attempt at starting.

At low temperatures, wait for 30 seconds.

At temperatures below 6 °C (43 °F), several attempts at starting may be necessary to warm-up the lithium-ion battery and thereby increase the starting power.

After 6 unsuccessful starting attempts, do not try again, and check the vehicle for other faults instead.

The malfunction indicator light lights up during the starting process.

9.3 Starting off

Note

When you are riding, the side stand must be folded up and secured with the rubber band.

– Pull the clutch lever, shift into first gear, release the clutch lever slowly and at the same time carefully open the throttle.

9.4 Shifting, riding.

WARNING

Danger of accidents If you downshift at high engine speed, the rear wheel blocks and the engine races.

– Do not downshift to a lower gear at high engine speeds.

Note

If you hear unusual noises while riding, stop immediately, switch off the engine, and contact an authorized contractual partner.

First gear is used for starting off or for steep inclines.

– Shift into a higher gear when conditions allow (incline, riding situation, etc.). To do so, release the throttle while simultaneously pulling the clutch lever, shift into the next gear, release the clutch lever and open the throttle.
– After reaching maximum speed by fully opening the throttle twist grip, turn the throttle back so that it is ¾ open. This will reduce the speed slightly, but the fuel consumption will be considerably lower.
– Only open the throttle as much as the engine can handle. Abruptly opening the throttle increases fuel consumption.
– To shift down, apply the brakes and close the throttle at the same time.

– Pull the clutch lever and shift into a lower gear, release the clutch lever slowly, and either open the throttle or shift again.
– Switch off the engine if you are likely to be running at idle speed or stationary for a long time.

≥ 2 min

– Avoid frequent and lengthy slipping of the clutch. This causes the engine oil, engine and cooling system to heat up.
– Ride at a low engine speed instead of at a high engine speed when riding the clutch.

9.5 Braking

WARNING
Danger of accidents A spongy pressure point on the front or rear brake reduces the brake action.
– Do not drive the vehicle if the brake system has a spongy pressure point.

WARNING
Danger of accidents Braking with excessive force locks the wheels.
– Adapt your braking to the riding situation and the road conditions.

WARNING
Danger of accidents Moisture and dirt impair the brake system.
– Brake carefully several times to dry out and remove dirt from the brake pads and the brake discs.

– On sandy, wet, or slippery surfaces, use the rear brake.
– Always finish braking before you go into a bend. Shift into a lower gear that suits the speed.
– Use the brake action of the engine on long downhill stretches. To do so, shift back one or two gears, but do not overrev the engine. This means that significantly less braking is required and means the brake system does not overheat.

9.6 Stop, park

WARNING
Danger of burns Some vehicle components become hot when the vehicle is operated.
– Do not touch any parts such as the exhaust system, radiator, engine, damper, or brake system before the vehicle parts have cooled down.
– Allow the vehicle parts to cool down before performing any work on the vehicle.

WARNING
Risk of injury People who act without authorization endanger themselves and others.
– Never leave the vehicle unattended while the engine is running.
– Secure the vehicle against unauthorized access.

NOTE
Fire hazard Hot vehicle components pose a fire hazard and explosion risk.
– Do not park the vehicle near materials which are highly flammable or explosive.
– Allow the vehicle to cool down before covering it.

NOTE
Material damage The vehicle may be damaged if parked incorrectly.
Damage can occur if the vehicle rolls away or falls over.
The components for parking the vehicle are designed only for the weight of the vehicle.
– Park the vehicle on a firm and level surface.
– Make sure that nobody sits on the vehicle when it is parked on a stand.

– Brake the motorcycle.

– Shift the transmission into the neutral position.
– Press kill switch when the engine is at idle speed until the engine stops.
– Park the motorcycle on firm ground.

9.7 Transportation

NOTE

Fire hazard Hot vehicle components pose a fire hazard and explosion risk.

– Do not park the vehicle near materials which are highly flammable or explosive.
– Allow the vehicle to cool down before covering it.


NOTE

Material damage The vehicle may be damaged if parked incorrectly.

Damage can occur if the vehicle rolls away or falls over.

The components for parking the vehicle are designed only for the weight of the vehicle.

– Park the vehicle on a firm and level surface.
– Make sure that nobody sits on the vehicle when it is parked on a stand.



– Switch off the engine.
– Use tension belts or other suitable devices to secure the motorcycle against falling over or rolling away.

9.8 Refueling

DANGER

Fire hazard Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

– Do not refuel the vehicle in the vicinity of open flames, glowing, or smoldering objects.
– Make sure that nobody smokes in the vicinity of the vehicle during the refueling process.
– Switch off the engine for refueling.
– Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
– If any fuel is spilled, wipe it up immediately.
– Do not overfill the fuel tank.

WARNING

Danger of poisoning Fuel is harmful to health.

– Do not allow fuel to come into contact with skin, eyes, or clothing.
– Consult a doctor immediately if fuel has been ingested.
– Do not inhale fuel vapors.
– Rinse the affected area immediately with plenty of water in the event of contact with skin.
– Rinse eyes thoroughly with water and consult a doctor immediately if fuel comes into contact with eyes.
– If fuel spills on to your clothing, change the clothing.
– Store fuel properly in a suitable container and keep out of the reach of children.

NOTE


Material damage Inadequate fuel quality can lead to losses in performance and consequential damage.

– Refuel only with clean fuel that meets the specified standards.

NOTE

Environmental hazard Improper handling of fuel is dangerous to the environment.

– Do not allow fuel to enter the groundwater, the soil, or the sewage system.



– Switch off the engine.
– Open the fuel tank cap. (p. 20)
– Fill the fuel tank with fuel no higher than A.

Level A	35 mm (1.38 in)

Total fuel tank capacity, approx.	
Super unleaded (ROZ 95) (p. 158)	9 l (2.4 liq. gal_{US})

– Close the fuel tank cap. (p. 21)

10.1 Service schedule

Any further work that results from the service work must be ordered separately and invoiced separately.

Different service intervals may apply in your country, depending on the local operating conditions.

Individual service intervals and scopes may change in the course of technical developments. The most up-to-date service schedule is available for authorized contractual partners for the electronic proof of service. Your authorized contractual partner will be happy to advise you.

	After one operating hour	Every 15 operating hours	Every 45 operating hours	Every 90 operating hours	Every 24 months
Read out the fault memory using the diagnostics tool.	○	●	●	●	●
Program the gear position sensor.		●	●	●	
Check that the electrical equipment is functioning properly.	○	●	●	●	
Check and charge the 12 V battery.		●	●	●	●
Check that the brake pads of the front brake are secured. (p. 91)		●	●	●	●
Check that the brake pads of the rear brake are secured. (p. 97)		●	●	●	●
Check the brake discs. (p. 89)		●	●	●	●
Check the brake lines for damage and tightness.		●	●	●	●
Check the brake fluid level for the front brake. (p. 90)		●	●		
Change the brake fluid for the front brake.				●	●
Check the brake fluid level for the rear brake. (p. 95)		●	●		
Change the brake fluid for the rear brake.				●	●
Check/correct the fluid level of the hydraulic clutch. (p. 86)			●		
Change the hydraulic clutch fluid. (p. 87)				●	●
Check the free travel on the hand brake lever.	○	●	●	●	●
Check the free travel of the brake pedal. (p. 94)		●	●	●	●
Check the idle speed.	○	●	●	●	●
Change the engine oil and the oil filter, clean the oil screens. (p. 129)	○	●	●	●	●
Check all hoses (e.g. fuel, cooling, bleeder, drainage, etc.) and boots for cracking, leaks, and correct routing.	○	●	●	●	●
Check the cables for damage and that there are no kinks in the routing.		●	●	●	●
Check that the clutch cables are undamaged, routed without kinks, and set correctly.		●	●	●	
Check the frame. (p. 84)		●	●	●	
Check the swingarm. (p. 84)		●	●	●	
Check the swingarm bearing for play.			●	●	
Check the heim joint on the shock absorber for play.			●	●	
Check the shock absorber linkage.		●	●	●	
Check the tire condition. (p. 103)		●	●	●	●
Check the tire pressure. (p. 104)		●	●	●	●
Check the wheel bearing for play.		●	●	●	


	After one operating hour	Every 15 operating hours	Every 45 operating hours	Every 90 operating hours	Every 24 months
Check the hubs.		●	●	●	
Check the rim run-out.	○	●	●	●	
Check the spoke tension. (p. 105)	○	●	●	●	
Check the chain, rear sprocket, engine sprocket, and chain guide. (p. 82)	○	●	●	●	
Check the chain tension. (p. 80)	○	●	●	●	●
Grease all moving parts (e.g. side stand, hand lever, chain, etc.) and check for smooth operation.	○	●	●	●	●
Check the valve clearance.	○		●	●	
Change the fuel filter.				●	●
Check the clutch.			●	●	
Clean the air filter and air filter box. (p. 73)		●	●	●	●
Check the funnel in the inlet sleeve in the air filter box.		●	●	●	●
Change the damping material on the main silencer. (p. 75)			●	●	
Carry out fork service.			●	●	
Service the shock absorber.			●	●	
Check all screws, nuts, and hose clamps for a tight fit.	○	●	●	●	●
Change the fuel screen. (p. 127)	○	●	●	●	●
Check the fuel pressure.	○		●	●	●
Check the frost protection and coolant level. (p. 116)			●	●	
Check the coolant level. (p. 117)	○	●			
Change the coolant. (p. 119)					●
Check that the radiator fan is functioning properly.	○	●	●	●	
Check the steering head bearing play. (p. 63)	○	●			
Lubricate the steering head bearing. (p. 65)			●	●	●
Check the headlight setting. (p. 112)		●	●	●	
Perform engine service including removing and installing the engine. (Change the spark plug and spark plug connector. Change the piston. Check/measure the cylinder. Check the cylinder head. Change the valves, valve springs, valve spring retainers and valve spring seats. Check the camshaft and cam lever. Change the connecting rod, conrod bearing and crank pin. Check the transmission and shift mechanism. Check the oil pressure control valve. Change the suction pump. Check the force pump and lubrication system. Check the timing assembly. Change the timing chain. Change all engine bearings and all gaskets. Change the freewheel.)				●	
Final check: Check the vehicle is roadworthy and take a test ride.	○	●	●	●	●
Read out the fault memory after the test ride using the diagnostics tool.	○	●	●	●	●
Enter the electronic proof of service in the contractual partner portal.	○	●	●	●	●

○ One-time interval

● Periodic interval

11.1 Checking the basic chassis setting with the rider's weight

Note
When adjusting the basic chassis setting, first adjust the shock absorber and then the fork.



- For optimal motorcycle riding characteristics and to avoid damage to forks, shock absorbers, swingarm, and frame, the basic settings of the suspension components must match the rider's weight.
- As delivered, GASGAS offroad motorcycles are adjusted for an average rider's weight (with full protective clothing).

Standard rider weight	75 kg ... 85 kg (165.3 lb ... 187.4 lb)

- If the rider's weight is above or below this range, the basic setting of the suspension components must be adjusted accordingly.
- Small weight differences can be compensated for by adjusting the preload, but in the case of large weight differences, the springs must be replaced.


11.2 Compression damping of the shock absorber

The compression damping of the shock absorber is divided into two ranges: high-speed and low-speed.
High-speed and low-speed refer to the compression speed of the rear wheel suspension and not to the vehicle speed.
The high-speed compression has an effect, for example, when landing after a jump: the rear wheel suspension compresses quickly.
The low-speed compression has an effect, for example, when riding over long bumps: the rear wheel suspension compresses slowly.
These two ranges can be adjusted separately, although the transition between high-speed and low-speed is floating. As a result, changes in the high-speed range affect the compression damping in the low-speed range and vice versa.

11.3 Adjusting the low-speed compression damping of the shock absorber

CAUTION
Risk of injury Parts of the shock absorber will move erratically if the shock absorber is detached incorrectly.
The shock absorber is filled with highly compressed nitrogen.
- Please follow the description provided.

Note
The effect of the low-speed compression adjustment can be seen in slow to normal compression of the shock absorber.



– Turn adjusters ❶ clockwise up to the last perceptible click.
– Turn counterclockwise by the number of clicks corresponding to the shock absorber type.


Comfort	18 clicks
Standard	15 clicks
Sport	12 clicks

Note
Turning clockwise increases damping; turning counterclockwise reduces damping during compression.

11.4 Adjusting the high-speed compression damping of the shock absorber

CAUTION
Risk of injury Parts of the shock absorber will move erratically if the shock absorber is detached incorrectly. The shock absorber is filled with highly compressed nitrogen.
– Please follow the description provided.

Note
The effect of the high-speed compression adjustment can be seen in the fast compression of the shock absorber.




– Turn adjusters ❶ clockwise all the way to the stop.
– Turn counterclockwise by the number of turns corresponding to the shock absorber type.

Comfort	2.5 turns (900°)
Standard	2 turns (720°)
Sport	1.5 turns (540°)

Note
Turning clockwise increases damping; turning counterclockwise reduces damping during compression.

11.5 Adjusting the rebound damping of the shock absorber

CAUTION
Risk of injury Parts of the shock absorber will move erratically if the shock absorber is detached incorrectly. The shock absorber is filled with highly compressed nitrogen.
– Please follow the description provided.



– Turn adjusters ❶ clockwise up to the last perceptible click.
– Turn counterclockwise by the number of clicks corresponding to the shock absorber type.

Comfort	18 clicks
Standard	15 clicks
Sport	12 clicks


Note
Turning clockwise increases damping; turning anticlockwise reduces damping on rebound.

11.6 Measuring the dimension of the unloaded rear wheel

Preparatory work

– Raise the motorcycle with a lift stand. (p. 56)

Main work



– Position the sag gage in the rear axle and measure the distance to marking **SAG** on the rear fender.


Sag scale (00029090200)

– Note the value as dimension Ⓐ.

Reworking

– Remove the motorcycle from the lift stand. (p. 56)

11.7 Checking the static sag of the shock absorber



– Measure the dimension of the unloaded rear wheel. (p. 49)
– Hold the motorcycle upright with aid of an assistant.
– Measure the distance again between the rear axle and marking **SAG** on the rear fender using the sag scale.
– Note the value as dimension **B**.

Note


The static sag is the difference between measurements **A** and **B**.

– Check the static sag.

Static sag	40 mm (1.57 in)

» If the static sag is more or less than the specified value:
– Adjust the preload for the shock absorber. (p. 51)

11.8 Checking the rider sag of the shock absorber



– Measure the dimension of the unloaded rear wheel. (p. 49)
– With another person holding the motorcycle, sit on the saddle with full protective clothing in a normal sitting position (feet on footrests) and bounce up and down a few times.
✓ The rear wheel suspension levels out.
– With the help of another person, remeasure the distance between the rear axle and marking **SAG** on the rear fender using the sag scale.
– Note the value as dimension **C**.

Note

The rider sag is the difference between measurements **A** and **C**.

– Check the rider sag.

Rider sag	110 mm (4.33 in)

» If the rider sag differs from the specified measurement:
– Adjust the rider sag. (p. 52)


11.9 Adjusting the preload for the shock absorber

CAUTION
Risk of injury Parts of the shock absorber will move erratically if the shock absorber is detached incorrectly.
The shock absorber is filled with highly compressed nitrogen.
– Please follow the description provided.

Note
Note the current adjustment before changing the spring preload - e.g. measure the spring length.

Preparatory work
– Raise the motorcycle with a lift stand. (p. 56)
– Remove the frame protector. (p. 58)
– Remove the shock absorber. (p. 66)
– After removing the shock absorber, clean it thoroughly.

Main work



– Loosen screw 1.
– Turn adjusting ring 2 until the spring is no longer under tension.

Hook wrench (90129051000)

Note
If the spring cannot be fully released, the spring must be removed to accurately measure the spring length.

– Measure the total spring length while the spring is not under tension.
– Tension the spring by turning adjusting ring 2 to the specified degree A.

Preload	7 mm (0.28 in)

Note
Depending on the static sag and/or the riding sag, it may be necessary to increase or decrease the spring preload.

– Tighten screw 1.

Screw, shock absorber adjusting ring	
M5	5 Nm (3.7 ft·lb$_f$)

Make sure that the adjusting ring does not touch any other components when installed.

Reworking
– Install the shock absorber. (p. 68)
– Check the free travel of the brake pedal. (p. 94)


– Install the frame protector. (p. 59)
– Remove the motorcycle from the lift stand. (p. 56)

11.10 Adjusting the rider sag

Preparatory work

– Raise the motorcycle with a lift stand. (p. 56)
– Remove the frame protector. (p. 58)
– Remove the shock absorber. (p. 66)
– After removing the shock absorber, clean it thoroughly.

Main work



– Select and mount a suitable spring.

Weight of rider: 65 kg … 75 kg (143.3 lb … 165.3 lb)	42 N/mm (239.8 lb_f/in)
Weight of rider: 75 kg … 85 kg (165.3 lb … 187.4 lb)	45 N/mm (257.0 lb_f/in)
Weight of rider: 85 kg … 95 kg (187.4 lb … 209.4 lb)	48 N/mm (274.1 lb_f/in)


Note
The spring rate is shown on the outside of the spring.
Smaller weight differences can be compensated by changing the spring preload.

Reworking

– Install the shock absorber. (p. 68)
– Check the free travel of the brake pedal. (p. 94)
– Install the frame protector. (p. 59)
– Remove the motorcycle from the lift stand. (p. 56)
– Check the static sag of the shock absorber. (p. 50)
– Check the rider sag of the shock absorber. (p. 50)
– Adjust the rebound damping of the shock absorber. (p. 48)

11.11 Checking the basic setting of the fork

Note
For various reasons, no exact rider sag can be determined for the fork.



- As with the shock absorber, smaller differences in the rider's weight can be compensated by the spring preload.
- However, if the fork frequently bottoms out (hard end stop on compression), harder springs must be fitted to avoid damage to the fork and frame.
- If the fork feels unusually hard after extended periods of operation, the fork legs need to be bled.

11.12 Adjusting the compression damping of the fork

Note
The hydraulic compression damping determines the fork suspension behavior.



- Turn white adjuster ❶ clockwise as far as it will go.

Note
Adjuster ❶ **COMP** is located at the upper end of the left fork leg.


- Turn counterclockwise by the number of clicks corresponding to the fork type.

Compression damping	
Comfort	18 clicks
Standard	15 clicks
Sport	12 clicks

Note
Turning clockwise increases damping; turning counterclockwise reduces damping during compression.

11.13 Adjusting the rebound damping of the fork

Note
The hydraulic rebound damping determines the fork suspension behavior.



- Turn red adjuster ❶ clockwise as far as it will go.


Note
Adjuster ❶ **REB** is located at the upper end of the right fork leg.

- Turn counterclockwise by the number of clicks corresponding to the fork type.

Rebound damping	
Comfort	18 clicks
Standard	15 clicks
Sport	12 clicks

Note
Turning clockwise increases damping; turning anticlockwise reduces damping on rebound.

11.14 Handlebar position



The holes on the handlebar support are placed at a distance of Ⓐ from the center.


Hole distance Ⓐ	3.5 mm (0.138 in)

The handlebar support can be mounted in two different positions. This allows the handlebar to be mounted in the most comfortable position for the rider.

11.15 Adjusting the handlebar position

WARNING
Danger of accidents A repaired handlebar poses a safety risk.
If the handlebar is bent or straightened, the material becomes fatigued. The handlebar may break as a result.
– Change the handlebar if the handlebar is damaged or bent.

Preparatory work
– Remove the handlebar pad.



Main work

– Remove ❶ screws. Take off the handlebar clamp. Remove the handlebar and lay it to one side.

Protect the components against damage by covering them.
Do not kink the cables or lines.

– Remove ❷ screws. Take off the handlebar support.

– Place the handlebar mount in the required position. Mount and tighten screws ❷.

Screw, handlebar mount	
M10	40 Nm (29.5 ft·lb$_f$) **Loctite® 243**

Position the handlebar support so that it is even.

– Position the handlebar.

Make sure the cables and wiring are positioned correctly.

– Position the handlebar clamp. Mount screws ❶ and tighten evenly.


Handlebar clamp screw	
M8	20 Nm (14.8 ft·lb$_f$)

Make sure the installed gap widths are even.

Reworking

– Mount the handlebar pad.

12.1 Raising the motorcycle with a lift stand


401942-01

NOTE

Material damage The vehicle may be damaged if parked incorrectly.

Damage can occur if the vehicle rolls away or falls over.

The components for parking the vehicle are designed only for the weight of the vehicle.

– Park the vehicle on a firm and level surface.
– Make sure that nobody sits on the vehicle when it is parked on a stand.

– Raise the motorcycle at the frame underneath the engine.

Lift stand (78129955100)

✓ Neither wheel is in contact with the ground.

– Secure the motorcycle against falling over.

12.2 Removing the motorcycle from the lift stand


NOTE

Material damage The vehicle may be damaged if parked incorrectly.

Damage can occur if the vehicle rolls away or falls over.

The components for parking the vehicle are designed only for the weight of the vehicle.

– Park the vehicle on a firm and level surface.
– Make sure that nobody sits on the vehicle when it is parked on a stand.



401943-10


– Remove the motorcycle from the lift stand.
– Remove the lift stand.
– To park the motorcycle, press side stand ❶ to the ground with your foot and lean the motorcycle on it.

When you are riding, the side stand must be folded up and secured with the rubber band.

12.3 Bleeding the fork legs

Preparatory work

– Raise the motorcycle with a lift stand. (p. 56)



Main work

– Loosen bleeder screw 1.
  ✓ Any excess pressure escapes from the inner fork.
– Tighten the bleeder screw.


Reworking

– Remove the motorcycle from the lift stand. (p. 56)

12.4 Cleaning the dust boots of the fork legs

Preparatory work

– Raise the motorcycle with a lift stand. (p. 56)
– Remove the fork protector. (p. 58)



Main work

– Push dust boot 1 downward on both fork legs.

Note
The dust boots should remove dust and coarse dirt particles from the inner fork tubes. Over time, dirt can accumulate behind the dust boots. If this dirt is not removed, the oil seals behind can start to leak.

WARNING
Danger of accidents Oil, grease or wax on the brake discs reduces the brake action.
– Always keep the brake discs free of oil, fat and wax.
– Clean the brake discs with brake cleaner when necessary.

– Clean and oil the dust boots and the inner fork tube of both fork legs.


Universal oil spray (p. 159)

– Press the dust boots back into their installation position.
– Remove excess oil.

Reworking


– Install the fork protector. (p. 58)
– Remove the motorcycle from the lift stand. (p. 56)

12.5 Removing the fork protector



– Remove screw ❶ and take off the clamp.
– Remove screws ❷ on the left fork leg and take off the left fork protector.
– Remove screws ❸ on the right fork leg and take off the right fork protector.

12.6 Installing the fork protector



– Position the fork protector on the left fork leg. Mount and tighten screws ❶.

Remaining screws on chassis	
M6	10 Nm (7.4 ft·lb$_f$)


– Position the brake line, the wiring harness, and the clamp. Mount and tighten screws ❷.

Remaining screws on chassis	
EJOT PT® – K60×25 – Z	2 Nm (1.5 ft·lb$_f$)

– Position the fork protector on the right fork leg. Mount and tighten screws ❸.


Remaining screws on chassis	
M6	10 Nm (7.4 ft·lb$_f$)

12.7 Removing the frame protector



– Remove the cable ties.
– Remove screws ❶ and bushings.
– Take off the left frame protector.
– Push the right frame protector to the front and take off at the bottom.

12.8 Installing the frame protector



– Position the left frame protector.
– Insert the right frame protector from below and push it to the rear.
– Mount screw ❶ and bushing and tighten.

Screw, frame protector	
M5	3 Nm (2.2 ft·lb$_f$)

– Secure the frame protector with cable ties.


Turn the head of the cable tie so far back that it does not touch any other components.

12.9 Removing the fork legs


Preparatory work

– Raise the motorcycle with a lift stand. (p. 56)
– Remove the front wheel. (p. 100)

Main work





– Remove screw ❶ and take off the clamp.
– Remove the cable ties.
– Remove screws ❷ and take off the brake caliper.
– Allow the brake caliper and the brake line to hang loosely to the side.




– Loosen screws ❸.
– Remove the left fork leg.
– Loosen screws ❹.
– Remove the right fork leg.

12.10 Installing the fork legs







Main work

– Position the fork legs.

✓ Bleeder screws ❶ are positioned toward the front.

Note

Grooves are milled into the side of the upper end of the fork legs. The second milled groove (from the top) must be flush with the upper edge of the upper triple clamp.

The pressure and rebound damping is located in the left and right fork leg.

– Tighten screws ❷.

Screw, top triple clamp	
M8	20 Nm (14.8 ft·lb$_f$)

– Tighten screws ❸.

Screw, bottom triple clamp	
M8	15 Nm (11.1 ft·lb$_f$)

– Position the brake caliper, and mount and tighten screws ❹.

Screw, front brake caliper	
M8	25 Nm (18.4 ft·lb$_f$) **Loctite® 243**

– Mount cable ties.

– Position the brake line, the wiring harness, and the clamp. Mount and tighten screws ❺.

Remaining screws on chassis	
EJOT PT® – K60×25 – Z	2 Nm (1.5 ft·lb$_f$)

Reworking

– Install the front wheel. (p. 101)

12.11 Removing the lower triple clamp

Preparatory work

– Raise the motorcycle with a lift stand. (p. 56)

– Remove the front wheel. (p. 100)


– Remove the fork legs. (p. 59)

– Remove the headlight mask with the headlight. (p. 111)

– Remove the front top fender. (p. 65)


– Remove the handlebar pad.

Main work



- Loosen screw ❶.
- Remove screw ❷.
- Take off the upper triple clamp with the handlebar and hang them to the side.


Protect the components against damage by covering them.
Do not kink the cables or lines.



- Remove protective ring ❸.
- Take off the lower triple clamp with the steering stem.
- Remove the upper steering head bearing.

12.12 Installing the lower triple clamp


Main work




- Clean the bearing and sealing elements, check for damage, and grease.

High viscosity grease (p. 160)

- Insert the lower triple clamp with the steering stem. Mount the upper steering head bearing.
- Push on protective ring ❶.




– Make sure the steering lock in area Ⓐ is positioned correctly.
  ✓ The catch on the steering lock engages in the notch on the triple clamp.



– Position the upper triple clamp and handlebar.
– Mount screw ❷, but do not tighten it yet.

Screw, top steering head	
M20×1.5	12 Nm (8.9 ft·lb$_f$)




– Position the fork legs.
  ✓ Bleeder screws ❸ are positioned toward the front.

Note


Grooves are milled into the side of the upper end of the fork legs. The second milled groove (from the top) must be flush with the upper edge of the upper triple clamp.

The pressure and rebound damping is located in the left and right fork leg.



– Tighten screws ❹.

Screw, bottom triple clamp	
M8	15 Nm (11.1 ft·lb$_f$)




– Tighten screw ❷.

Screw, top steering head	
M20×1.5	12 Nm (8.9 ft·lb$_f$)


– Tighten screw ❺.

Screw, upper steering stem	
M8	20 Nm (14.8 ft·lb$_f$) **Loctite® 243**



– Tighten screws ❻.

Screw, top triple clamp	
M8	20 Nm (14.8 ft·lb$_f$)



– Position the brake caliper, and mount and tighten screws ❼.

Screw, front brake caliper	
M8	25 Nm (18.4 ft·lb$_f$) **Loctite® 243**

– Mount the cable tie.
– Position the brake line, the wiring harness, and the clamp. Mount and tighten screws ❽.

Remaining screws on chassis	
EJOT PT® – K60×25 – Z	2 Nm (1.5 ft·lb$_f$)

Reworking

– Mount the handlebar pad.
– Install the front top fender. 📖 (p. 65)
– Install the front wheel. 🔧 📖 (p. 101)
– Install the headlight mask with the headlight. 📖 (p. 111)
– Check the wiring harness, cables, and brake and clutch lines for freedom of movement and correct routing.
– Check the steering head bearing play. 📖 (p. 63)
– Remove the motorcycle from the lift stand. 📖 (p. 56)
– Check the headlight setting. 📖 (p. 112)


12.13 Checking the steering head bearing play

WARNING
Danger of accidents Incorrect steering head bearing play can impair the handling characteristic and damage components.
– Correct incorrect steering head bearing play immediately.

Note
If the vehicle is operated for a lengthy period with play in the steering head bearing, the bearings and the bearing seats in the frame can become damaged.

Preparatory work

– Raise the motorcycle with a lift stand. 📖 (p. 56)



Main work

– Move the handlebar to the straight-ahead position. Move the fork legs to and fro in the direction of travel.

Play should not be detectable on the steering head bearing.

» If there is detectable play:

– Adjust the steering head bearing play. (p. 64)

– Move the handlebar back and forth over the entire steering range.

It must be possible to move the handlebar easily over the entire steering range. There should be no detectable detent positions.

» If detent positions are detected:

– Adjust the steering head bearing play. (p. 64)

– Check the steering head bearing and replace if necessary.


Reworking

– Remove the motorcycle from the lift stand. (p. 56)

12.14 Adjusting the steering head bearing play

Preparatory work

– Raise the motorcycle with a lift stand. (p. 56)



Main work

– Loosen screws ❶ and ❷.

– Loosen and retighten screw ❸.

Screw, top steering head	
M20×1.5	12 Nm (8.9 ft·lb$_f$)

– Using a plastic hammer, tap lightly on the upper triple clamp to avoid stresses.

– Tighten screws ❶.

Screw, top triple clamp	
M8	20 Nm (14.8 ft·lb$_f$)

– Remove screw ❷.

– Mount and tighten screw ❷.


Screw, upper steering stem	
M8	20 Nm (14.8 ft·lb$_f$) **Loctite® 243**

Reworking

– Check the steering head bearing play. (p. 63)

– Remove the motorcycle from the lift stand. (p. 56)

12.15 Lubricating the steering head bearing



– Remove the lower triple clamp. (p. 60)
– Install the lower triple clamp. (p. 61)


Note
The steering head bearing is cleaned and lubricated in the course of removal and installation of the lower triple clamp.

12.16 Removing the front top fender


Preparatory work

– Remove the headlight mask with the headlight. (p. 111)

Main work




– Remove ❶ screws.



– Remove screws ❷ and take off the fender at the front.


12.17 Installing the front top fender

Main work



– Position the front fender, install screws ❶ and tighten.

Remaining screws on chassis	
M6	10 Nm (7.4 ft·lb$_f$)



– Mount and tighten screws 2.

Remaining screws on chassis	
M6	10 Nm (7.4 ft·lb$_f$)

Reworking


– Install the headlight mask with the headlight. (p. 111)
– Check the headlight setting. (p. 112)

12.18 Removing the shock absorber

Preparatory work

– Raise the motorcycle with a lift stand. (p. 56)
– Remove the frame protector. (p. 58)

Main work




– Remove 1 screws.
– Remove screw connection 2.

Tip
Raise the link fork slightly to be able to remove the screws more easily.



– Disconnect the plug-in connector of the brake light switch.




– Remove ❸ screws.
– Pull off rear brake cylinder from the push rod.




– Remove the connecting link on the chain.

Protect the components against damage by covering them.

– Take off the chain.




– Remove nut ❹ and pull out the swingarm pivot.
– Push the swingarm back and secure it against falling over.



– Hold the shock absorber and remove screw ❺.
– Remove the shock absorber carefully at the bottom.

12.19 Installing the shock absorber




Main work

– Carefully position the shock absorber into the vehicle from the bottom.

– Mount and tighten screw ❶.

Top shock absorber screw	
M10	60 Nm (44.3 ft·lb$_f$) **Loctite® 2701**




– Position the swingarm and fit the swingarm pivot.

Pay attention to flat area Ⓐ.

– Mount and tighten nut ❷.

Nut, swingarm pivot	
M16×1.5	100 Nm (73.8 ft·lb$_f$)




– Mount the chain.

– Connect the chain with connecting link ❸.

The closed side of the master link clip must face in the direction of travel.




– Join plug-in connector of the brake light switch.



– Position the rear brake cylinder.
  ✓ Push rod ❹ engages in the rear brake cylinder.
  ✓ The dust boot is correctly positioned.
– Mount and tighten screws ❺.

Remaining screws on chassis	
M6	10 Nm (7.4 ft·lb$_f$)



– Position the power valve control lever and linkage lever.
– Mount and tighten screw connection ❻.

Nut, linkage lever on angle lever	
M14x1,5	60 Nm (44.3 ft·lb$_f$)

Pay attention to flat area Ⓑ.

– Mount and tighten screw ❼.

Bottom shock absorber screw	
M10	60 Nm (44.3 ft·lb$_f$) **Loctite® 2701**


Tip
Raise the link fork slightly to be able to mount the screw more easily.


Reworking
– Check the free travel of the brake pedal. (p. 94)
– Install the frame protector. (p. 59)
– Remove the motorcycle from the lift stand. (p. 56)

12.20 Removing the seat

Preparatory work
– Remove air filter box cover. (p. 70)


Main work
– Remove screw ❶ with the pair of wedge lock washers.






– Raise the rear of the seat, pull the seat back and lift it off.

12.21 Mounting the seat



Main work

– Mount the front of the seat on the collar bushings of the fuel tank, lower the seat at the rear, and push the seat to the rear.
  ✓ The holding lugs engage in the recesses at the back.
– Make sure the seat is latched in place correctly.



– Mount and tighten the screw and the pair of wedge lock washers ❶.

Remaining screws on chassis	
M6	10 Nm (7.4 ft·lb$_f$)

Reworking


– Install the air filter box cover. (p. 71)

12.22 Removing air filter box cover

Condition: Air filter box cover secured




– Remove screw ❶.



– Detach air filter box cover in areas Ⓐ and slide it in areas Ⓑ to the rear.
– Take off the air filter box cover.


Condition: Air filter box cover not secured



– Detach air filter box cover in areas Ⓐ and slide it in areas Ⓑ to the rear.
– Take off the air filter box cover.

12.23 Installing air filter box cover

Condition: Air filter box cover secured




– Attach the air filter box cover in areas Ⓑ and clip in areas Ⓐ.



– Mount and tighten screw ❶.

Screw, air filter box cover	
EJOT PT® – MK60×20 – Z	3 Nm (2.2 ft·lb$_f$)

Condition: Air filter box cover not secured



– Attach the air filter box cover in areas B and clip in areas A.

12.24 Removing the air filter

NOTE

Engine failure Unfiltered intake air has a negative effect on the service life of the engine.

Dust and dirt can enter the engine if there is no air filter or if the air filter is mounted incorrectly.

– Only operate the vehicle if an air filter is correctly fitted.

NOTE

Environmental hazard Hazardous substances cause environmental damage.

– Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.

Preparatory work

– Remove air filter box cover. (p. 70)


Main work



– Detach tab 1.
– Remove air filter with air filter support.
– Remove the air filter with the air filter support.


12.25 Installing the air filter

Main work



– Mount the clean air filter on the air filter support.
– Grease the air filter in area A.

Long-life grease (p. 159)



– Insert air filter and position retaining pin ❶ in bushing Ⓑ.
  ✓ The air filter is correctly positioned.
– Attach tab ❷.
  ✓ Retaining pin ❸ is secured by retaining tab ❷.

Reworking

– Install the air filter box cover. 📖 (p. 71)

12.26 Cleaning the air filter and air filter box


NOTE

Environmental hazard Hazardous substances cause environmental damage.

– Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.

Preparatory work

– Remove air filter box cover. 📖 (p. 70)
– Remove the air filter. 🔧 📖 (p. 72)



Main work

– Wash the air filter thoroughly in special cleaning liquid and allow it to dry properly.

Do not clean the air filter with fuel or petroleum as these substances will damage the foam rubber.
Only press the air filter to dry it, do not wring it out.

Air filter cleaning agent 📖 (p. 162)

– Oil the dry air filter with a high-grade air filter oil.

Oil for foam air filter 📖 (p. 160)

– Clean the air filter box.
– Clean the intake flange and check it for damage and that it is firmly seated.

Reworking


– Install the air filter. 🔧 📖 (p. 72)
– Install the air filter box cover. 📖 (p. 71)

12.27 Preparing the air filter box cover for securing

Preparatory work

– Remove air filter box cover. (p. 70)

Main work



– Drill a hole at marking A.


Diameter	6 mm (0.24 in)

Reworking

– Install the air filter box cover. (p. 71)

12.28 Removing the muffler

WARNING
Danger of burns The exhaust system gets hot when the vehicle is driven.
– Allow the exhaust system to cool down before performing any work on the vehicle.




– Detach spring 1.

Spring hook (50305017000C1)

– Remove screws 2 with washers and take off main silencer with catalytic converter.

12.29 Installing muffler



– Position the main silencer. Mount screws 1 with washers, but do not tighten yet.
– Attach spring 2.

Spring hook (50305017000C1)


– Tighten screws 1.

Remaining screws on chassis	
M6	10 Nm (7.4 ft·lb$_f$)

12.30 Changing the damping material on the main silencer

WARNING
Danger of burns The exhaust system gets hot when the vehicle is driven.
– Allow the exhaust system to cool down before performing any work on the vehicle.

Note
Over time, the damping material fibers disappear, and the main silencer “burns out”.
Not only does this make the noise level higher, but the performance characteristics also change.



Preparatory work
– Remove the muffler. (p. 74)

Main work
– Remove screws ❶.
– Take off silencer cap ❷ with O-ring ❸.
– Remove old damping material.
– Clean the parts that need to be reinstalled and check for damage.
– Mount new damping material ❹ in the silencer.
– Mount the O-ring on the silencer cap.
– Position the silencer cap.
– Mount and tighten the screws.

Screws on muffler	
M5	7 Nm (5.2 ft·lb$_f$)

Reworking
– Install the muffler. (p. 74)

12.31 Removing the fuel tank

DANGER
Fire hazard Fuel is highly flammable.
The fuel in the fuel tank expands when warm and can escape if overfilled.
– Do not refuel the vehicle in the vicinity of open flames, glowing, or smoldering objects.
– Make sure that nobody smokes in the vicinity of the vehicle during the refueling process.
– Switch off the engine for refueling.
– Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
– If any fuel is spilled, wipe it up immediately.
– Do not overfill the fuel tank.

WARNING

Danger of poisoning Fuel is harmful to health.

- Do not allow fuel to come into contact with skin, eyes, or clothing.
- Consult a doctor immediately if fuel has been ingested.
- Do not inhale fuel vapors.
- Rinse the affected area immediately with plenty of water in the event of contact with skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if fuel comes into contact with eyes.
- If fuel spills on to your clothing, change the clothing.
- Store fuel properly in a suitable container and keep out of the reach of children.

NOTE


Environmental hazard Improper handling of fuel is dangerous to the environment.

- Do not allow fuel to enter the groundwater, the soil, or the sewage system.


Preparatory work

- Remove air filter box cover. (p. 70)
- Remove the seat. (p. 69)

Main work



- Remove protection cap ❶ of the fuel line.



- Clean quick-lock coupling ❷ thoroughly with compressed air.


  Dirt must not enter into the fuel line. Dirt in the fuel line clogs the injector!

- Disconnect the quick-lock coupling.

  Note
  Remaining fuel may flow out of the fuel line.

- Mount wash cap set ❸.

  Wash cap set (81212016100)



- Unplug socket connector ❹ of the fuel pump.
- Remove screw ❺ with the rubber bushing.
- Remove the hose from the fuel tank breather.



– Remove screws 6.
– Hang the horn and horn bracket to one side.



– Pull both spoilers laterally off the radiator and lift off the fuel tank.


12.32 Installing the fuel tank

DANGER
Fire hazard Fuel is highly flammable.
The fuel in the fuel tank expands when warm and can escape if overfilled.
– Do not refuel the vehicle in the vicinity of open flames, glowing, or smoldering objects.
– Make sure that nobody smokes in the vicinity of the vehicle during the refueling process.
– Switch off the engine for refueling.
– Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
– If any fuel is spilled, wipe it up immediately.
– Do not overfill the fuel tank.

WARNING
Danger of poisoning Fuel is harmful to health.
– Do not allow fuel to come into contact with skin, eyes, or clothing.
– Consult a doctor immediately if fuel has been ingested.
– Do not inhale fuel vapors.
– Rinse the affected area immediately with plenty of water in the event of contact with skin.
– Rinse eyes thoroughly with water and consult a doctor immediately if fuel comes into contact with eyes.
– If fuel spills on to your clothing, change the clothing.
– Store fuel properly in a suitable container and keep out of the reach of children.


NOTE
Environmental hazard Improper handling of fuel is dangerous to the environment.
– Do not allow fuel to enter the groundwater, the soil, or the sewage system.

Main work
– Check the throttle cable routing. (p. 84)



– Position the fuel tank and fit the two spoilers to the sides in front of the radiator bracket.

Make sure that no wires or cables are trapped or damaged.



– Attach the fuel tank breather hose.
– Mount and tighten screw ❶ with the rubber bushing.


Remaining screws on chassis	
M6	10 Nm (7.4 ft·lb$_f$)

– Plug in fuel pump socket connector ❷.



– Position the horn with the horn bracket.
– Mount and tighten screws ❸.

Remaining screws on chassis	
M6	10 Nm (7.4 ft·lb$_f$)



– Remove the wash cap set.
– Clean the quick release coupling thoroughly with compressed air.


Dirt must not enter into the fuel line. Dirt in the fuel line clogs the injector!

– Spray silicone spray onto a lint-free cleaning cloth and lightly lubricate the O-ring of the quick-lock coupling.

Silicone spray 📖 (p. 160)

– Join quick release coupling ❹.

Route the wire and fuel line at a safe distance from the exhaust system.




– Mount protection cap ❺ of the fuel line.

Reworking

– Mount the seat. (p. 70)
– Install the air filter box cover. (p. 71)

12.33 Checking the chain for dirt



– Check the chain for coarse dirt accumulation.
  » If the chain is very dirty:
    – Clean the chain. (p. 79)

12.34 Cleaning the chain

WARNING
Danger of accidents Oil, grease or wax on the brake discs reduces the brake action.
– Always keep the brake discs free of oil, fat and wax.
– Clean the brake discs with brake cleaner when necessary.

WARNING
Danger of accidents Lubricants on the tires reduces the road grip.
– Remove lubricants from the tires using a suitable cleaning agent.


NOTE
Environmental hazard Hazardous substances cause environmental damage.
– Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.

Note
The service life of the chain depends largely on its maintenance.

Preparatory work

– Raise the motorcycle with a lift stand. (p. 56)

Main work



– Rinse off the loose dirt with a gentle jet of water.
– Remove old grease residues with a chain cleaner.

Chain cleaner (p. 162)

– After drying, apply chain spray.

Off-road chain spray (p. 159)

Reworking

– Remove the motorcycle from the lift stand. (p. 56)

12.35 Checking the chain tension

WARNING

Danger of accidents Incorrect chain tension can damage components and result in an accident.

If the chain is tension is too high, the chain, front sprocket, rear sprocket, transmission, and rear wheel bearings wear more quickly. Some components may break if overloaded.


If the chain is too loose, the chain may fall off the front sprocket or the rear sprocket. This can damage the rear wheel or the engine.

– Check the chain tension regularly.
– Set the chain tension in accordance with the specification.

Preparatory work

– Raise the motorcycle with a lift stand. (p. 56)

Main work



– Pull the chain at the end of the chain slider upward to measure chain tension A.

Chain tension	58 mm … 61 mm (2.28 in … 2.40 in)
Lower chain section 1 must be taut.	
When the chain guard is mounted, it must be possible to pull up the chain at least to the point where it makes contact with chain guard B.	
Chain wear is not always even, so repeat this measurement at different positions on the chain.	

» If the chain tension does not meet the specification:
– Adjust the chain tension. (p. 81)

Reworking

– Remove the motorcycle from the lift stand. (p. 56)

12.36 Adjusting the chain tension

WARNING

Danger of accidents Incorrect chain tension can damage components and result in an accident.

If the chain is tension is too high, the chain, front sprocket, rear sprocket, transmission, and rear wheel bearings wear more quickly. Some components may break if overloaded.


If the chain is too loose, the chain may fall off the front sprocket or the rear sprocket. This can damage the rear wheel or the engine.

– Check the chain tension regularly.
– Set the chain tension in accordance with the specification.

Preparatory work

– Raise the motorcycle with a lift stand. (p. 56)
– Check the chain tension. (p. 80)

Main work



– Loosen nut ❶.
– Loosen nuts ❷.
– Adjust the chain tension by turning adjusting screws ❸ left and right.

Chain tension	58 mm … 61 mm (2.28 in … 2.40 in)
Turn adjusting screws ❸ on the left and right so that the markings on the left and right chain adjusters are in the same position relative to reference marks Ⓐ. The rear wheel is then correctly aligned.	

– Tighten nuts ❷.
– Make sure that chain adjusters ❹ are fitted correctly on adjusting screws ❸.
– Tighten nut ❶.

Nut, wheel spindle, rear	
M22	80 Nm (59.0 ft·lb$_f$)

Note


The wide adjustment range of the chain adjusters enables different secondary ratios with the same chain length.

Chain adjusters ❹ can be turned by 180°.

Reworking

– Check the chain tension. (p. 80)
– Remove the motorcycle from the lift stand. (p. 56)

12.37 Checking the chain, rear sprocket, front sprocket, and chain guide


400227-01


Preparatory work

– Raise the motorcycle with a lift stand. (p. 56)

Main work

– Shift the transmission into the neutral position.
– Check the chain, rear sprocket, and front sprocket for wear.
  » If the chain, rear sprocket, or front sprocket is worn:
    – Change the drivetrain kit.

Always replace the front sprocket, rear sprocket, and chain together.



400987-10

– Pull on the top section of the chain with the specified weight A.

Weight, chain wear measurement	10 kg … 15 kg (22.0 lb … 33.1 lb)


– Measure distance B of chain rollers in the lower chain section.

Maximum distance B of chain rollers at the longest chain section	272 mm (10.71 in)
Chain wear is not always even, so repeat this measurement at different positions on the chain.	

  » If distance B is greater than the specified measurement:
    – Change the drivetrain kit.


When installing a new chain, also replace the rear sprocket and front sprocket.

Note
New chains wear out faster on old, worn sprockets.




– Check the chain slider at the top for wear.
  » If the lower edge of the chain pins is in line with, or below, the chain slider:
    – Change the chain slider.
– Check that the chain slider is firmly seated.
  » If the chain slider is loose:
    – Tighten the screws of the chain slider.

Screw, chain slider guard	
M6	6 Nm (4.4 ft·lb$_f$) **Loctite® 243**



– Check the chain slider for wear.
  » If the lower edge of the chain pins is in line with or below the chain slider:
    – Change the chain slider.
– Check that the chain slider is firmly seated.
  » If the chain slider is loose:
    – Tighten the screw of the chain sliding piece.


Screw, chain slider	
M8	15 Nm (11.1 ft·lb$_f$)



– Check the chain guide for wear.

Note
Wear can be seen on the front of the chain guide.

  » If the light part of the chain guide is worn:
    – Change the chain guide.




– Check that the chain guide is firmly seated.
  » If the chain guide is loose:
    – Tighten the screws on the chain guide.

Remaining screws on chassis	
M6	10 Nm (7.4 ft·lb$_f$)
Remaining nuts on chassis	
M6	10 Nm (7.4 ft·lb$_f$)

Reworking

– Remove the motorcycle from the lift stand. (p. 56)

12.38 Checking the frame



– Check the frame for damage, cracks, and deformation.
  » If the frame shows signs of damage, cracks, or deformation:
    – Change the frame.

Repairs on the frame are not permitted.

12.39 Checking the swingarm



– Check the swingarm for damage, cracks, and deformation.
  » If the swingarm shows signs of damage, cracks, or deformation:
    – Change the swingarm.


Always replace a damaged link fork.
Repairing the swingarm is not authorized by GASGAS.

12.40 Checking the throttle cable routing

WARNING
Danger of accidents The throttle cable can become kinked, jammed, or blocked if it has been routed incorrectly. If the throttle cable is kinked, jammed or blocked, the speed can no longer be controlled.
– Make sure that the throttle cable routing and the play in the throttle cable complies with the specification.

Preparatory work

– Remove air filter box cover. (p. 70)
– Remove the seat. (p. 69)
– Remove the fuel tank. (p. 75)



Main work

– Check the throttle cable routing.


Both throttle cables must be routed, side by side, on the back of the handlebars and above the fuel tank bracket, to the throttle valve body. Both throttle cables must be secured behind the rubber strap of the fuel tank support.

» If the throttle cable routing is not as specified:
  – Correct the throttle cable routing.

Reworking

– Install the fuel tank. (p. 77)
– Mount the seat. (p. 70)
– Install the air filter box cover. (p. 71)


12.41 Checking the hand grip



– Check the hand grips on the handlebar for damage, wear, and that they are firmly seated.

Note
The hand grips are vulcanized onto a sleeve on the left and onto the grip tube of the throttle grip on the right. The left sleeve is clamped onto the handlebar.
The hand grip can only be replaced with the sleeve or the gas pipe.

» If a rubber grip is damaged, worn, or loose:
  – Replace the hand grip.




– Check that screw 1 is firmly seated.

Screw, fixed grip	
M4	5 Nm (3.7 ft·lb$_f$) **Loctite® 243**

Diamond A must be located at the top.

12.42 Adjusting the basic position of the clutch lever



– Adjust the basic position of the clutch lever to your hand size by turning adjusting screw 1.

Only turn the adjusting screw by hand, and do not use force.
Do not make any adjustments while riding.

Note

When the adjusting screw is turned clockwise, the clutch lever moves away from the handlebar.

When the adjusting screw is turned counterclockwise, the clutch lever moves closer to the handlebar.

The range of adjustment is limited.

12.43 Checking/correcting the fluid level of hydraulic clutch

WARNING

Health hazard Brake fluid is a harmful substance.

– Keep brake fluid out of the reach of children.
– Wear suitable protective clothing and safety glasses.
– Do not allow brake fluid to come into contact with the skin, the eyes, or clothing.
– Consult a doctor immediately if brake fluid has been ingested.
– Rinse the affected area with plenty of water in the event of contact with the skin.
– Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
– If brake fluid spills on to your clothing, change the clothing.

NOTE


Environmental hazard Hazardous substances cause environmental damage.

– Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.

Note

The fluid level rises with increasing wear of the friction plates.

Avoid contact between brake fluid and painted parts. Brake fluid corrodes paint.



– Move the hydraulic clutch fluid reservoir mounted on the handlebar into a horizontal position.
– Remove 1 screws.
– Take off cover 2 with diaphragm 3.
– Check the fluid level.

Fluid level below reservoir rim	4 mm (0.16 in)

» If the fluid level does not meet the specifications:
– Correct the fluid level of the hydraulic clutch.

Brake fluid DOT 5.1 (p. 160)

– Position the cover with diaphragm.

– Mount and tighten the screws.


Immediately clean up any brake fluid that has overflowed or spilled with water.

12.44 Changing the hydraulic clutch fluid


WARNING
Health hazard Brake fluid is a harmful substance.
– Keep brake fluid out of the reach of children.
– Wear suitable protective clothing and safety glasses.
– Do not allow brake fluid to come into contact with the skin, the eyes, or clothing.
– Consult a doctor immediately if brake fluid has been ingested.
– Rinse the affected area with plenty of water in the event of contact with the skin.
– Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
– If brake fluid spills on to your clothing, change the clothing.

NOTE
Environmental hazard Hazardous substances cause environmental damage.
– Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.

Note
Avoid contact between brake fluid and painted parts. Brake fluid corrodes paint.




– Move the hydraulic clutch fluid reservoir mounted on the handlebar into a horizontal position.
– Remove ❶ screws.
– Take off cover ❷ with diaphragm ❸.



– Fill bleeding syringe ❹ with the appropriate hydraulic fluid.

Syringe (50329050000)
Brake fluid DOT 5.1 (p. 160)

– On the clutch slave cylinder, remove the protection cap, remove bleeder screw ❺ and mount bleeding syringe ❹.




– Keep pumping the fluid into the system until it comes out of openings ❻ of the master cylinder without bubbles.
– Occasionally extract the fluid from the master cylinder reservoir to prevent overflowing.
– Remove the bleeding syringe.
– Mount and tighten the bleeder screw.
– Mount the protection cap.
– Correct the fluid level of the hydraulic clutch.

Fluid level below reservoir rim	4 mm (0.16 in)

– Position the cover with diaphragm.
– Mount and tighten the screws.

Immediately clean up any brake fluid that has overflowed or spilled with water.

13.1 Adjusting the basic position of the hand brake lever



– Adjust the basic position of the hand brake lever to your hand size by turning adjusting screw ❶.

The range of adjustment is limited.
Only turn the adjusting screw by hand, and do not use force.
Do not make any adjustments while riding.

Note

Turn the adjusting screw clockwise to increase the distance between the hand brake lever and the handlebar.


Turn the adjusting screw counterclockwise to decrease the distance between the hand brake lever and the handlebar.

13.2 Checking the brake discs

WARNING

Danger of accidents Worn-out brake discs reduce the braking action.

– Make sure that worn-out brake discs are replaced immediately.



– Check the brake disc thickness of the front and rear brake disc at several places on the disc to see if they conform to measurement Ⓐ.

Brake disc wear limit	
front	2.5 mm (0.098 in)
rear	3.5 mm (0.138 in)

Note

Wear reduces the thickness of the brake discs at the contact surface of the brake pads.

» If the brake disc thickness is less than the specified value:

– Change the brake discs of the front brake.

– Change the brake discs on the rear brake.

– Check the front and rear brake discs for damage, cracks, and deformation.

» If the brake disc shows signs of damage, cracks, or deformation:


– Change the brake discs of the front brake.

– Change the brake discs on the rear brake.

13.3 Checking the brake fluid level for the front brake

WARNING
Danger of accidents Brake fluid which is too old or of the wrong type impairs the function of the brake system.
– Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule.
– Make sure that only clean, approved brake fluid from a tightly sealed container is used.

WARNING
Danger of accidents An insufficient brake fluid level will cause the brake system to fail.
If the brake fluid level drops below the specified marking or the specified value, the brake system has a leak or the brake pads are worn down.
– Have the brake system checked and make sure that the problem has been eliminated before the vehicle is used again.



– Move the brake reservoir mounted on the handlebar to a horizontal position.
– Check the brake fluid level in sight glass 1.
  » If the brake fluid level has fallen below marking A:
    – Add brake fluid for the front brake. (p. 90)

13.4 Adding brake fluid for the front brake

WARNING
Danger of accidents Brake fluid which is too old or of the wrong type impairs the function of the brake system.
– Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule.
– Make sure that only clean, approved brake fluid from a tightly sealed container is used.

WARNING
Danger of accidents An insufficient brake fluid level will cause the brake system to fail.
If the brake fluid level drops below the specified marking or the specified value, the brake system has a leak or the brake pads are worn down.
– Have the brake system checked and make sure that the problem has been eliminated before the vehicle is used again.


WARNING
Health hazard Brake fluid is a harmful substance.
– Keep brake fluid out of the reach of children.
– Wear suitable protective clothing and safety glasses.
– Do not allow brake fluid to come into contact with the skin, the eyes, or clothing.
– Consult a doctor immediately if brake fluid has been ingested.
– Rinse the affected area with plenty of water in the event of contact with the skin.
– Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
– If brake fluid spills on to your clothing, change the clothing.

NOTE
Environmental hazard Hazardous substances cause environmental damage.
– Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.

Note
Avoid contact between brake fluid and painted parts. Brake fluid corrodes paint.

Preparatory work
– Check that the brake pads of the front brake are secured.
(p. 91)

Main work



– Move the brake reservoir mounted on the handlebar to a horizontal position.
– Remove 1 screws.
– Take off cover 2 with diaphragm 3.
– Add brake fluid up to level A.

Level A (brake fluid level below reservoir rim)	5 mm (0.20 in)


Brake fluid DOT 5.1 (p. 160)

– Position the cover with diaphragm.
– Mount and tighten the screws.

Immediately clean up any brake fluid that has overflowed or spilled with water.

13.5 Checking that the brake pads of the front brake are secured

WARNING
Danger of accidents Worn brake pads reduce the brake action.
– Make sure that worn brake pads are replaced immediately.



– Check all brake pads on both brake calipers for their lining thickness A.

Minimum pad thickness A	≥ 1 mm (≥ 0.04 in)

» If it is less than the minimum thickness:
– Change the front brake pads. (p. 92)
– Check the brake linings for damage and cracking.
» If there is damage or cracking:
– Change the front brake pads. (p. 92)
– Check that the brake pads are secured.
» If the brake pads are not secured correctly:
– Secure brake pads, replace with new parts if necessary.

13.6 Changing the brake pads of the front brake

WARNING
Danger of accidents Brake pads which have not been approved alter the braking action.
– Only use brake pads approved and recommended by the vehicle manufacturer.

WARNING
Danger of accidents Incorrect servicing will cause the brake system to fail.
– Ensure that service work and repairs are performed professionally.


WARNING
Danger of accidents Brake fluid which is too old or of the wrong type impairs the function of the brake system.
– Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule.
– Make sure that only clean, approved brake fluid from a tightly sealed container is used.

WARNING
Danger of accidents Oil, grease or wax on the brake discs reduces the brake action.
– Always keep the brake discs free of oil, fat and wax.
– Clean the brake discs with brake cleaner when necessary.


WARNING
Health hazard Brake fluid is a harmful substance.
– Keep brake fluid out of the reach of children.
– Wear suitable protective clothing and safety glasses.
– Do not allow brake fluid to come into contact with the skin, the eyes, or clothing.
– Consult a doctor immediately if brake fluid has been ingested.
– Rinse the affected area with plenty of water in the event of contact with the skin.
– Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
– If brake fluid spills on to your clothing, change the clothing.

NOTE
Environmental hazard Hazardous substances cause environmental damage.
– Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.


Note
Avoid contact between brake fluid and painted parts. Brake fluid corrodes paint.




– Move the brake reservoir mounted on the handlebar to a horizontal position.
– Remove screws ❶.
– Take off cover ❷ with diaphragm ❸.



– Manually press the brake caliper toward the brake disc to push back the brake pistons. Ensure that brake fluid does not flow out of the brake fluid reservoir; extract some if necessary.
– Remove cotter pin ❹, pull out pin ❺, and remove the brake linings.
– Clean brake caliper and brake caliper support.



– Check that spring steel clip ❻ in the brake caliper and brake pad guide plate ❼ in the brake caliper support are properly seated.




– Insert the new brake linings, insert pin ❺, and mount cotter pin ❹.

Always replace brake pads in sets.
Make sure the brake pads and retaining spring are properly seated.
Mount the inner cotter pins from the rear to the front.
Mount the outer cotter pins from the front to the rear.

Tip
To make it easier to mount the stud, push the brake pads upward against the retaining spring.

– Operate the hand brake lever repeatedly until the brake pads are in contact with the brake disc and a pressure point is reached.



– Correct the brake fluid level to level Ⓐ.

Level Ⓐ (brake fluid level below reservoir rim)	5 mm (0.20 in)


Brake fluid DOT 5.1 (p. 160)

– Position cover ❷ with diaphragm ❸. Mount and tighten screws ❶.

Immediately clean up any brake fluid that has overflowed or spilled with water.

13.7 Checking the free travel of the brake pedal

WARNING
Danger of accidents The brake system fails in the event of overheating.
If there is no free travel on the brake lever, pressure builds up in the brake system.
– Set the free travel on the brake lever as specified.



– Detach spring ❶.
– Move the brake pedal back and forth between the end stop and the brake pedal cylinder piston actuation and check free travel Ⓐ.


Free travel of brake pedal	3 mm … 5 mm (0.12 in … 0.20 in)

» If the free travel does not meet the specifications:
– Adjust the basic position of the brake pedal. (p. 94)

– Attach spring ❶.

13.8 Adjusting the basic position of the brake pedal

WARNING
Danger of accidents The brake system fails in the event of overheating.
If there is no free travel on the brake lever, pressure builds up in the brake system.
– Set the free travel on the brake lever as specified.



– Detach spring ❶.
– Loosen nut ❹ and unscrew it with push rod ❺ until you have maximum free travel.
– To adjust the basic position of the brake pedal to individual requirements, loosen nut ❷ and turn screw ❸ accordingly.

Note
The range of adjustment is limited.

– Turn push rod ❺ accordingly until you have free travel Ⓐ. If necessary, adjust the basic position of the brake pedal.

Free travel of brake pedal	3 mm … 5 mm (0.12 in … 0.20 in)

– Hold screw ❸ and tighten nut ❷.

Brake pedal stop nut	
M10	45 Nm (33.2 ft·lb$_f$)

– Hold push rod ❺ and tighten nut ❹.


Remaining nuts on chassis	
M6	10 Nm (7.4 ft·lb$_f$)

– Attach spring ❶.

13.9 Checking the brake fluid level for the rear brake

WARNING
Danger of accidents Brake fluid which is too old or of the wrong type impairs the function of the brake system.
– Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule.
– Make sure that only clean, approved brake fluid from a tightly sealed container is used.

WARNING
Danger of accidents An insufficient brake fluid level will cause the brake system to fail.
If the brake fluid level drops below the specified marking or the specified value, the brake system has a leak or the brake pads are worn down.
– Have the brake system checked and make sure that the problem has been eliminated before the vehicle is used again.



– Stand the vehicle upright.
– Check the brake fluid level in sight glass ❶.
» If the brake fluid level has fallen below marking Ⓐ:
– Add brake fluid for the rear brake. (p. 96)

13.10 Adding brake fluid for the rear brake

WARNING
Danger of accidents Brake fluid which is too old or of the wrong type impairs the function of the brake system.
– Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule.
– Make sure that only clean, approved brake fluid from a tightly sealed container is used.


WARNING
Danger of accidents An insufficient brake fluid level will cause the brake system to fail.
If the brake fluid level drops below the specified marking or the specified value, the brake system has a leak or the brake pads are worn down.
– Have the brake system checked and make sure that the problem has been eliminated before the vehicle is used again.

WARNING
Health hazard Brake fluid is a harmful substance.
– Keep brake fluid out of the reach of children.
– Wear suitable protective clothing and safety glasses.
– Do not allow brake fluid to come into contact with the skin, the eyes, or clothing.
– Consult a doctor immediately if brake fluid has been ingested.
– Rinse the affected area with plenty of water in the event of contact with the skin.
– Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
– If brake fluid spills on to your clothing, change the clothing.

NOTE
Environmental hazard Hazardous substances cause environmental damage.
– Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.

Note
Avoid contact between brake fluid and painted parts. Brake fluid corrodes paint.

Preparatory work
– Check that the brake pads of the rear brake are secured. (p. 97)
– Remove the frame protector. (p. 58)



Main work
– Stand the vehicle upright.
– Remove screw cap 1 with diaphragm 2 and the O-ring.
– Add brake fluid to mark A.

Brake fluid DOT 5.1 (p. 160)

– Mount and tighten screw cap 1 with diaphragm 2 and the O-ring.


Immediately clean up any brake fluid that has overflowed or spilled using water.

Reworking

– Install the frame protector. (p. 59)

13.11 Checking that the brake pads of the rear brake are secured

WARNING
Danger of accidents Worn brake pads reduce the brake action.
– Make sure that worn brake pads are replaced immediately.



– Check all brake pads on both brake calipers for their lining thickness A.

Minimum pad thickness A	≥ 1 mm (≥ 0.04 in)

» If it is less than the minimum thickness:
– Change the rear brake pads. (p. 97)

– Check the brake linings for damage and cracking.
» If there is damage or cracking:
– Change the rear brake pads. (p. 97)

– Check that the brake pads are secured.
» If the brake pads are not secured correctly:
– Secure brake pads, replace with new parts if necessary.

13.12 Changing the rear brake pads

WARNING
Danger of accidents Brake pads which have not been approved alter the braking action.
– Only use brake pads approved and recommended by the vehicle manufacturer.

WARNING
Danger of accidents Incorrect servicing will cause the brake system to fail.
– Ensure that service work and repairs are performed professionally.

WARNING
Danger of accidents Brake fluid which is too old or of the wrong type impairs the function of the brake system.
– Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule.
– Make sure that only clean, approved brake fluid from a tightly sealed container is used.

WARNING
Danger of accidents Oil, grease or wax on the brake discs reduces the brake action.
– Always keep the brake discs free of oil, fat and wax.
– Clean the brake discs with brake cleaner when necessary.

WARNING
Health hazard Brake fluid is a harmful substance.
– Keep brake fluid out of the reach of children.
– Wear suitable protective clothing and safety glasses.
– Do not allow brake fluid to come into contact with the skin, the eyes, or clothing.
– Consult a doctor immediately if brake fluid has been ingested.
– Rinse the affected area with plenty of water in the event of contact with the skin.

– Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
– If brake fluid spills on to your clothing, change the clothing.

NOTE

Environmental hazard Hazardous substances cause environmental damage.

– Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.


Note

Avoid contact between brake fluid and painted parts. Brake fluid corrodes paint.


Preparatory work

– Remove the frame protector. (p. 58)


Main work




– Cover the painted parts.
– Remove screw cap ❶ with the membrane and the O-ring.
– Press the brake piston back to its basic position and make sure that no brake fluid overflows from the brake reservoir, extract some brake fluid if necessary.




– Remove cotter pin ❷, pull out pin ❸, and remove the brake linings.
– Clean brake caliper and brake caliper support.



– Check that spring steel clip ❹ in the brake caliper and brake pad guide plate ❺ in the brake caliper support are properly seated.



– Insert the new brake linings, insert the pin, and mount the cotter pins.
– Actuate the brake disc repeatedly until the brake pads are in contact with the brake disc and a pressure point is achieved.



– Correct the brake fluid level to mark Ⓐ.

Brake fluid DOT 5.1 (p. 160)

– Mount and tighten screw cap ❶ with the membrane and O-ring.

Immediately clean up any brake fluid that has overflowed or spilled with water.

Reworking


– Install the frame protector. (p. 59)

14.1 Removing the front wheel


Preparatory work

– Raise the motorcycle with a lift stand. (p. 56)


Main work



– Manually press the brake caliper toward the brake disc to push back the brake pistons.



– Loosen screw ❶ by four turns.
– Loosen screws ❷.
– Press on screw ❶ to push the wheel spindle out of the fork shoe.
– Remove screw ❶.




WARNING

Danger of accidents Damaged brake discs reduce the braking action.

– Always lay the wheel down in such a way that the brake disc is not damaged.

– Hold front wheel and remove wheel spindle. Take the front wheel out of the fork.


Do not actuate the hand brake lever when the front wheel is removed.



– Remove spacers ❸.

14.2 Installing the front wheel

WARNING
Danger of accidents Oil, grease or wax on the brake discs reduces the brake action.
– Always keep the brake discs free of oil, fat and wax.
– Clean the brake discs with brake cleaner when necessary.




– Check the wheel bearing for damage and wear.
  » If the wheel bearing is damaged or worn:
    – Change the front wheel bearing.
– Clean and grease radial shaft seal 1 and contact surfaces A on the spacers.

Long-life grease (p. 159)

– Insert spacers.
– Clean and lightly grease the wheel spindle.

Long-life grease (p. 159)

– Position the front wheel and insert the wheel spindle.
  ✓ The brake pads are positioned correctly.



– Mount and tighten screw 2.


Screw, wheel spindle, front	
M20×1.5	35 Nm (25.8 ft·lb$_f$)


– Operate the hand brake lever several times until the brake pads are in contact with the brake disc.
– Remove the motorcycle from the lift stand. (p. 56)
– Operate the hand brake lever and compress the fork a few times firmly.
  ✓ The fork legs straighten.
– Tighten screws 3.

Screw, fork shoe	
M8	15 Nm (11.1 ft·lb$_f$)

14.3 Removing the rear wheel

Preparatory work
– Raise the motorcycle with a lift stand. (p. 56)





Main work


– Manually press the brake caliper toward the brake disc to push back the brake pistons.
– Remove nut ❶.
– Remove chain tension adjuster ❷. Pull out wheel spindle ❸ far enough to allow the rear wheel to be pushed forward.
– Push the rear wheel forward as far as possible. Remove the chain from the rear sprocket.

Protect the components against damage by covering them.

WARNING
Danger of accidents Damaged brake discs reduce the braking action.
– Always lay the wheel down in such a way that the brake disc is not damaged.

– Hold the rear wheel and remove wheel spindle. Take the rear wheel out of the swingarm.


Do not actuate the brake pedal when the rear wheel is removed.



– Remove spacers ❹.

14.4 Installing the rear wheel

WARNING
Danger of accidents Oil, grease or wax on the brake discs reduces the brake action.
– Always keep the brake discs free of oil, fat and wax.
– Clean the brake discs with brake cleaner when necessary.




Main work

– Check the wheel bearing for damage and wear.
  » If the wheel bearings are damaged or worn:
    – Change the rear wheel bearing.
– Clean and grease radial shaft seal ❶ and contact surfaces Ⓐ on the spacers.

Long-life grease (p. 159)


– Insert spacers.



– Clean and lightly grease the wheel spindle.

Long-life grease (p. 159)

– Position the rear wheel and insert wheel spindle ❷.
  ✓ The brake pads are positioned correctly.
– Attach the chain.



– Position chain tension adjuster ❸. Mount nut ❹ but do not tighten yet.
– Make sure that chain tension adjusters ❸ are fitted correctly on adjusting screws ❺.
– Check the chain tension. (p. 80)
– Tighten nut ❹.

Nut, wheel spindle, rear	
M22	80 Nm (59.0 ft·lb$_f$)

Note
The wide adjustment range of the chain adjusters enables different secondary ratios with the same chain length.
Chain tension adjusters ❸ can be turned by 180°.


– Actuate the brake disc repeatedly until the brake pads are in contact with the brake disc and a pressure point is achieved.

Reworking

– Remove the motorcycle from the lift stand. (p. 56)

14.5 Checking the tire condition

Note
Only fit tires approved and/or recommended by GASGAS.
Other tires could have a negative effect on handling characteristics.
The type, condition, and pressure of the tires all have a major impact on the handling of the motorcycle.
The tires mounted on the front and rear wheels must have a similar profile.
Worn tires have a negative effect on handling characteristics, especially on wet surfaces.




– Check the front and rear tires for cuts, embedded objects, and other damage.
  » If the tires have cuts, run-in objects, or other damage:
    – Change the tires.
– Check the tread depth.

Minimum tread depth	≥ 2 mm (≥ 0.08 in)

Note
Adhere to the legally required minimum tread depth specific to the country concerned.

  » If the tread depth is less than the minimum tread depth:
    – Change the tires.




– Check the tire age.

Note
The tire date of manufacture is usually contained in the tire label and is indicated by the last four digits of the **DOT** number. The first two digits indicate the week of manufacture and the last two digits the year of manufacture.
GASGAS recommends that the tires be changed after five years at the latest, regardless of the actual wear.

  » If the tires are older than five years:
    – Change the tires.

14.6 Checking the tire pressure

Note
Low tire pressure leads to abnormal wear and the tire overheating.
Correct tire pressure ensures optimal riding comfort and maximum tire service life.



– Remove the protection cap.
– Check the tire pressure when the tires are cold.

Off-road tire pressure	
front	1.0 bar (14.5 psi)
rear	1.0 bar (14.5 psi)

Street tire pressure	
front	2.0 bar (29.0 psi)
rear	2.0 bar (29.0 psi)

  » If the tire pressure does not meet specifications:
    – Correct the tire air pressure.
– Mount the protection cap.

14.7 Checking the spoke tension


WARNING

Danger of accidents Incorrectly tensioned spokes impair the handling characteristic and can result in secondary damage.

If the spokes are too tight, they can break due to being overloaded.

Loose spokes can cause lateral or radial run-out in the wheel and other spokes will loosen as a result.

– Check the spoke tension regularly, especially on a new vehicle.



– Briefly tap each spoke with a screwdriver.

You should hear a high-pitched sound.

Note

The frequency of the sound depends on the spoke length and spoke diameter.

If spokes of the same length and diameter vibrate with a different tone, this is an indication that the spoke tensions differ.

» If the spoke tension differs:

– Correct the spoke tension.

– Check the spoke torque.

Spoke nipple, front wheel	
M4,5	6 Nm (4.4 ft·lb$_f$)
Spoke nipple, rear wheel	
M4,5	6 Nm (4.4 ft·lb$_f$)

Torque wrench kit (58429094000)

15.1 Removing the 12 V battery

WARNING

Risk of injury 12-V batteries contain harmful substances.

- Keep 12-V batteries out of the reach of children.
- Keep the battery away from sparks or open flames.
- Only charge batteries in well-ventilated rooms.
- Maintain a minimum distance from flammable materials when charging 12-V batteries.

Minimum distance	1 m (3 ft – 3 in)

- Do not charge deeply discharged 12- V batteries if the charge is already below the minimum voltage.

Minimum voltage before starting charging	9 V

- Dispose of 12 V batteries correctly if they have less than the minimum voltage.

NOTE

Environmental hazard 12-V batteries contain environmentally-hazardous materials.

- Do not dispose of 12-V batteries as household waste.
- Dispose of 12-V batteries at a collection point for used batteries.

NOTE


Environmental hazard Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.


Preparatory work

- Remove air filter box cover. (p. 70)
- Remove the seat. (p. 69)

Main work




- Disconnect negative cable ❶ from the 12 V battery.
- Pull back positive terminal cover and disconnect positive cable ❷ from the 12-V battery.
- Pull off starter relay ❸ and OCU ❹ and hang to the side.
- Unscrew battery holding bracket screw ❺.



– Push battery holding bracket to the side and detach.
– Lift out the 12-V battery.


15.2 Installing the 12 V battery

Main work



– Insert the 12 V battery into the battery compartment with the terminals facing forward and secure with holding bracket.

12-V battery (HJTZ5S-FP-C)



– Screw battery holding bracket screw ❶ tight.

Screw, battery holding bracket	
M6	6 Nm (4.4 ft·lb$_f$)

– Attach the OCU ❷ and the starter relay ❸ to the holding bracket.
– Connect positive cable ❹ to the 12-V battery and install the positive terminal cover.

Screw, battery terminal	
M5	2.5 Nm (1.84 ft·lb$_f$)

– Connect negative cable ❺ to the 12 V battery.

Screw, battery terminal	
M5	2.5 Nm (1.84 ft·lb$_f$)

Reworking

– Mount the seat. (p. 70)
– Install the air filter box cover. (p. 71)

15.3 Charging the 12 V battery

WARNING

Risk of injury 12-V batteries contain harmful substances.

– Keep 12-V batteries out of the reach of children.
– Keep the battery away from sparks or open flames.
– Only charge batteries in well-ventilated rooms.
– Maintain a minimum distance from flammable materials when charging 12-V batteries.

Minimum distance	1 m (3 ft – 3 in)

– Do not charge deeply discharged 12- V batteries if the charge is already below the minimum voltage.

Minimum voltage before starting charging	9 V

– Dispose of 12 V batteries correctly if they have less than the minimum voltage.

NOTE

Danger of damage An incorrectly selected charging mode will damage the 12-V battery.

– Always select a charging mode that is compatible with the type of battery.

NOTE

Environmental hazard 12-V batteries contain environmentally-hazardous materials.

– Do not dispose of 12-V batteries as household waste.
– Dispose of 12-V batteries at a collection point for used batteries.

NOTE

Environmental hazard Hazardous substances cause environmental damage.


– Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.

Note

Even when there is no load on the 12 V battery, it discharges steadily each day.
The state of charge and the method of charging are very important for the service life of the 12 V battery.
Rapid recharging with a high charging current shortens the service life of the battery.
If the charging current, charging voltage, or charging time is exceeded, the 12 V battery will be destroyed.
If the 12 V battery is left in a discharged state for an extended period, it will become deeply discharged and suffer a loss of capacity, destroying the battery.
The 12 V battery is maintenance-free.

Preparatory work

– Remove air filter box cover. (p. 70)
– Remove the seat. (p. 69)
– Remove the 12 V battery. (p. 106)



Main work

– Do not open the cover ❶.
– Check the battery voltage.
  » Battery voltage:
    • < 9 V
    – Do not charge the 12 V battery.
    – Replace the 12 V battery and dispose of the old 12 V battery properly.
  » If the specifications have been met:
    Battery voltage:
    • ≥ 9 V
    – Connect a charger to the 12 V battery. Switch the charger on.

Read the accompanying instructions.	
Maximum charging voltage	14.4 V
Minimum charging voltage	3.0 A
Maximum charging time	12 h
The charging current, charging voltage, and charging time must not be exceeded.	
Recharge the 12 V battery regularly when the motorcycle is not being used.	6 months
If the 12 V battery is depleted from starting the vehicle repeatedly, the battery must be charged immediately.	
Ideal charging and storage temperature of the lithium-ion battery	10 °C … 20 °C (50.0 °F … 68.0 °F)

Battery charger (79629974000)

Note
This battery charger tests whether the 12 V battery retains its voltage. It is also impossible to overcharge the 12 V battery with this battery charger. The charging time may be longer at low temperatures.

Note
This battery charger is only suitable for lithium iron phosphate batteries.

– Switch off the charger after charging and disconnect from the 12 V battery.

Reworking

– Install the 12 V battery. (p. 107)
– Mount the seat. (p. 70)
– Install the air filter box cover. (p. 71)

15.4 Changing the main fuse


WARNING

Fire hazard Incorrect fuses overload the electrical system.

– Use only fuses with the prescribed amperage.
– Do not bypass or repair fuses.

Note

The main fuse protects all electrical power loads of the vehicle. It is located in the starter relay housing under the seat.



Preparatory work

– Remove air filter box cover. (p. 70)
– Remove the seat. (p. 69)
– Remove the fuel tank. (p. 75)

Main work

– Pull the starter relay off the holder and hang to the side.
– Remove protection caps 1.
– Remove faulty main fuse 2.

Note

A faulty fuse has a burned-out fuse wire A.

A spare fuse 3 is located in the starter relay.

– Insert the main fuse.

Fuse (58011109120)

– Check that the electrical equipment is functioning properly.

Tip


Insert a new spare fuse so that it is available if needed.

– Mount the protection caps.
– Mount the starter relay onto the holder and route the cable.


Reworking

– Install the fuel tank. (p. 77)
– Mount the seat. (p. 70)
– Install the air filter box cover. (p. 71)

15.5 Removing the headlight mask with the headlight




– Loosen screws ❶.
– Slide the headlight mask up and swing it forward.
– Detach the brake line and wiring harness from the headlight mask.




– Detach plug-in connectors ❷ and take off the headlight mask with the headlight.

15.6 Installing the headlight mask with the headlight

Main work



– Join plug-in connectors ❶.



– Position the brake line and wiring harness in the brake line guide.
– Position the headlight mask.
  ✓ The holding lugs engage in the fender.
– Tighten screws ❷.

Remaining screws on chassis	
M6	10 Nm (7.4 ft·lb$_f$)

Reworking


– Check the headlight setting. (p. 112)

15.7 Changing the headlight bulb


Preparatory work

– Remove the headlight mask with the headlight. (p. 111)

Main work



– Turn LED unit ❶ counterclockwise all the way and take it out of the reflector.




– Insert the LED unit into the reflector and turn it clockwise all the way.

Ensure that O-ring ❷ is seated properly.
Low beam (LED)

Reworking

– Install the headlight mask with the headlight. (p. 111)
– Check the headlight setting. (p. 112)

15.8 Checking the headlight setting



– Park the vehicle on a horizontal surface in front of a light-colored wall and make a mark at the height of the center of the low beam headlight.
– Make another mark at a distance Ⓑ under the first marking.

Distance Ⓑ	5 cm (2.0 in)

– Position the vehicle vertically at a distance Ⓐ away from the wall.

Distance Ⓐ	5 m (16 ft – 5 in)

– Sit on the motorcycle.
– Switch on the low beam.
– Check the headlight setting.

The boundary between light and dark must be exactly on the lower mark for a motorcycle with rider.


» If the boundary between light and dark does not meet specifications:
  – Adjust headlight range. (p. 113)

15.9 Adjusting the headlight range

Preparatory work

– Check the headlight setting. (p. 112)

Main work



– Loosen screw 1.
– Adjust the headlight range by pivoting the headlight.

The boundary between light and dark must be exactly on the lower mark for a motorcycle with rider (instructions on how to apply the mark: Checking the headlight setting).

Note
A change in weight may require a correction of the headlight range.

– Tighten screw 1.

Reworking


– Check the headlight setting. (p. 112)

15.10 Changing the turn signal bulb

NOTE

Impairments to reflectors and lamps Grease on the reflector reduces the emitted light.
Grease on the bulb will evaporate due to the heat and be deposited on the reflector.
Grease residue on the bulb reduces heat dissipation and increases the heat of the bulb, thus reducing its service life.

– Clean and degrease the bulbs before mounting.
– Do not touch the bulbs with your bare hands.



Main work

– Remove the screw on the rear of the turn signal housing.
– Carefully remove turn signal glass ❶.
– Lightly squeeze orange cap ❷ in the area of the holding lugs and take it off.
– Press the turn signal bulb lightly into the socket, turn it counter-clockwise by about 30°, and pull it out of the socket.
– Press the new turn signal bulb carefully into the socket and turn it clockwise until it stops.

Turn signal (R10W / Sockel BA15s)

– Mount the orange cap.
– Position the turn signal glass.
– Insert the screw and first turn counterclockwise until it engages in the thread with a small jerk. Tighten the screw lightly.

Reworking

– Check that the turn signal system is functioning properly.

15.11 Changing the combination instrument battery


Preparatory work

– Remove the headlight mask with the headlight. (p. 111)

Main work




– Remove screws ❶ with the washers.
– Pull the combination instrument upward out of the holder.



– Using a coin, turn protection cap ❷ all the way counterclockwise and take it off.
– Remove combination instrument battery ❸.
– Insert the combination instrument with the label facing upward.

Button cell (CR 2430)

– Check the O-ring of the protection cap for correct seating.




– Position protection cap ❷ and turn all the way clockwise using a coin.
– Press any button on the combination instrument.
  ✓ The combination instrument is activated.
– Position the combination instrument in the holder.
– Mount and tighten the screws with washers.

Reworking


– Install the headlight mask with the headlight. (p. 111)
– Check the headlight setting. (p. 112)
– Setting the clock (p. 31)
– Adjusting the unit of measurement (p. 32)

15.12 Diagnostic connector



Diagnostics connector ❶ is located under the seat.

15.13 OCU




OCU ❶ is located under the seat.
The OCU replaces the electronic fuses and relays.
All outputs are switched independently of the signals of the voltage regulator and ECU.
The outputs are deactivated individually in the event of overcurrent.
This enables easy error detection because the status of each output is indicated via LED lights.
The OCU monitors the electronics system completely independently.
As soon as an indicated error is rectified, the status light of the OCU changes from red to green.
overview (p. 115)

overview

A	Ignition
B	Light
C	Brake light + horn
D	Fuel pump
E	Radiator fan

16.1 Cooling system



Water pump ❶ in the engine circulates the coolant.

The pressure resulting from the warming of the cooling system is regulated by a valve in radiator cap ❷.

The coolant is cooled by the air stream.

The lower the vehicle speed, the lower the cooling effect. Dirty cooling fins also reduce the cooling effect.

Additional cooling is provided by the radiator fan, which is activated at high temperature.

16.2 Checking the frost protection and coolant level

WARNING

Health hazard Coolant is harmful to health.


- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with skin, eyes, or clothing.
- Consult a doctor immediately if coolant has been ingested.
- Rinse the affected area immediately with plenty of water in the event of contact with skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant comes into contact with eyes.
- If coolant spills on to your clothing, change the clothing.
- Store coolant properly in a suitable container and keep out of the reach of children.

WARNING

Danger of scalding The coolant heats up and is under high pressure when the vehicle is operated.

- Do not open the radiator, the radiator hoses, or other cooling system components if the engine or the cooling system are at operating temperature.
- Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses, or other components of the cooling system.
- In the event of scalding, rinse the area affected immediately with lukewarm water.

Condition: The engine is cold



- Stand the motorcycle upright on a level surface.
- Take off the radiator cap.
- Check the frost protection in the coolant.

−45 °C … −25 °C (−49.0 °F … −13.0 °F)

  » If the frost protection in the coolant does not match the specified value:
    - Correct the frost protection in the coolant.
- Check the coolant level in the radiator.

Coolant level ❹ above the radiator fins	10 mm (0.39 in)

» If the coolant level does not meet the specifications:
– Correct the coolant level.

coolant	
Coolant (p. 160) Antifreeze protection to at least: −25 °C (−13.0 °F)	0.95 l (0.251 liq. gal_{US})


– Mount the radiator cap.

16.3 Checking the coolant level

WARNING
Health hazard Coolant is harmful to health.
– Keep coolant out of the reach of children.
– Do not allow coolant to come into contact with skin, eyes, or clothing.
– Consult a doctor immediately if coolant has been ingested.
– Rinse the affected area immediately with plenty of water in the event of contact with skin.
– Rinse eyes thoroughly with water and consult a doctor immediately if coolant comes into contact with eyes.
– If coolant spills on to your clothing, change the clothing.
– Store coolant properly in a suitable container and keep out of the reach of children.

WARNING
Danger of scalding The coolant heats up and is under high pressure when the vehicle is operated.
– Do not open the radiator, the radiator hoses, or other cooling system components if the engine or the cooling system are at operating temperature.
– Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses, or other components of the cooling system.
– In the event of scalding, rinse the area affected immediately with lukewarm water.

Condition: The engine is cold



– Stand the motorcycle upright on a level surface.
– Take off the radiator cap.
– Check the coolant level in the radiator.

Coolant level A above the radiator fins	10 mm (0.39 in)

» If the coolant level does not meet the specifications:
– Correct the coolant level.

coolant	
Coolant (p. 160) Antifreeze protection to at least: −25 °C (−13.0 °F)	0.95 l (0.251 liq. gal_{US})


– Mount the radiator cap.

16.4 Draining the coolant

WARNING
Health hazard Coolant is harmful to health.
- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with skin, eyes, or clothing.
- Consult a doctor immediately if coolant has been ingested.
- Rinse the affected area immediately with plenty of water in the event of contact with skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant comes into contact with eyes.
- If coolant spills on to your clothing, change the clothing.
- Store coolant properly in a suitable container and keep out of the reach of children.

WARNING
Danger of scalding The coolant heats up and is under high pressure when the vehicle is operated.
- Do not open the radiator, the radiator hoses, or other cooling system components if the engine or the cooling system are at operating temperature.
- Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses, or other components of the cooling system.
- In the event of scalding, rinse the area affected immediately with lukewarm water.

Condition: The engine is cold




Main work
- Stand the motorcycle upright.
- Place an appropriate container under the water pump cover.
- Remove screw ❶ and take off radiator cap ❷.
- Completely drain the coolant.
- Mount screw ❶ with the new sealing ring and tighten.

Screw, water pump cover	
M6	10 Nm (7.4 ft·lb$_f$)

16.5 Refilling the coolant

WARNING
Health hazard Coolant is harmful to health.
- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with skin, eyes, or clothing.
- Consult a doctor immediately if coolant has been ingested.
- Rinse the affected area immediately with plenty of water in the event of contact with skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant comes into contact with eyes.
- If coolant spills on to your clothing, change the clothing.
- Store coolant properly in a suitable container and keep out of the reach of children.



Main work

– Make sure that screw ❶ is tightened.
– Stand the motorcycle upright.
– Pour coolant in up to level Ⓐ above the radiator fins.

10 mm (0.39 in)

coolant	
Coolant (p. 160) Antifreeze protection to at least: −25 °C (−13.0 °F)	0.95 l (0.251 liq. gal_{US})

– Mount the radiator cap.

Reworking


– Go for a short test ride.
– Check the coolant level. (p. 117)

16.6 Changing the coolant

WARNING
Health hazard Coolant is harmful to health.
– Keep coolant out of the reach of children.
– Do not allow coolant to come into contact with skin, eyes, or clothing.
– Consult a doctor immediately if coolant has been ingested.
– Rinse the affected area immediately with plenty of water in the event of contact with skin.
– Rinse eyes thoroughly with water and consult a doctor immediately if coolant comes into contact with eyes.
– If coolant spills on to your clothing, change the clothing.
– Store coolant properly in a suitable container and keep out of the reach of children.


WARNING
Danger of scalding The coolant heats up and is under high pressure when the vehicle is operated.
– Do not open the radiator, the radiator hoses, or other cooling system components if the engine or the cooling system are at operating temperature.
– Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses, or other components of the cooling system.
– In the event of scalding, rinse the area affected immediately with lukewarm water.

Condition: The engine is cold



Main work

– Stand the motorcycle upright.
– Place an appropriate container under the water pump cover.
– Remove screw ❶ and take off radiator cap ❷.
– Completely drain the coolant.



– Mount screw ❶ with the new sealing ring and tighten.

Screw, water pump cover	
M6	10 Nm (7.4 ft·lb$_f$)

– Pour coolant in up to level Ⓐ above the radiator fins.

10 mm (0.39 in)


coolant	
Coolant 📖 (p. 160) Antifreeze protection to at least: −25 °C (−13.0 °F)	0.95 l (0.251 liq. gal$_{US}$)

– Mount radiator cap ❷.

Reworking

– Go for a short test ride.
– Check the coolant level. 📖 (p. 117)

17.1 Checking the play in the throttle cable



– Check the throttle grip for smooth operation.
– Move the handlebar to the straight-ahead position. Turn the throttle twist grip back and forth slightly and determine the play in throttle cable Ⓐ.

Throttle cable play	3 mm … 5 mm (0.12 in … 0.20 in)

» If the throttle cable play does not meet the specified value:
– Adjust the throttle cable play. (p. 121)

– Press the cold start button in all the way to the stop.
✓ When the throttle twist grip is turned forward, the cold start button jumps back to the start position.
» If the cold start button does not return to its original position:
– Adjust the throttle cable play. (p. 121)

DANGER
Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.
– Always ensure that there is sufficient ventilation when running the engine.
– Use suitable exhaust extraction when starting or running the engine in an enclosed space.

– Start the engine and let it run at idle speed. Move the handlebar back and forth over the entire steering range.


The idle speed must not change.

» If the idle speed changes:
– Adjust the throttle cable play. (p. 121)

17.2 Adjusting the throttle cable play

Note
If the correct routing of the throttle cables has already been secured, the fuel tank does not need to be removed.

Preparatory work
– Remove air filter box cover. (p. 70)
– Remove the seat. (p. 69)
– Remove the fuel tank. (p. 75)
– Check the throttle cable routing. (p. 84)



Main work

– Move the handlebar to the straight-ahead position.
– Push back boot ❶.
– Loosen nut ❷.
– Screw adjusting screw ❸ in as far as possible.
– Loosen nut ❹.
– Press cold start button ❻ all the way to the stop.
– Turn adjusting screw ❺ so that the cold start button moves to the basic position when the throttle twist grip is turned forward.
– Tighten nut ❹.
– Turn adjusting screw ❸ so that there is play in the throttle cable at the throttle twist grip.

Throttle cable play	3 mm … 5 mm (0.12 in … 0.20 in)


– Tighten nut ❷.
– Slide on boot ❶.
– Check the throttle grip for smooth operation.

Reworking

– Check the play in the throttle cable. (p. 121)


17.3 Adjusting the characteristic map of the throttle response

Note
On the throttle grip, the characteristic map of the throttle response is changed by changing the guide plate.
A guide plate with a different characteristic map is supplied.



Main work

– Push back sleeve ❶.
– Remove screws ❷ and half-shells ❸.
– Detach the throttle cables and take off the grip tube.




– Remove guide plate ❹ from handle tube ❺.
– Position the required guide plate on the grip tube.


The label **OUTSIDE** must be visible. Marking Ⓐ must be positioned at marking Ⓑ.

Gray guide plate (A48002014000)
Work material (Alternative 1 / 1)
Black guide plate (A46002014000)

Note
The gray guide plate opens the throttle valve more slowly.
The black guide plate opens the throttle valve more quickly.
The gray guide plate is mounted upon delivery.



– Clean the outside of the handlebar and the inside of the grip tube. Mount the grip tube on the handlebar.
– Attach the throttle cables to the guide plate and route correctly.



– Position half-shells ❸, mount and tighten screws ❷.

Screw, throttle twist grip	
M6	5 Nm (3.7 ft·lb$_f$)

– Slide on sleeve ❶ and check the throttle grip for ease of movement.

Reworking

– Check the play in the throttle cable. (p. 121)

17.4 Changing the mapping

Note


If the combination switch is mounted, the vehicle's road permit, if any, expires.

The vehicle may only be operated in closed-off areas away from public road traffic if the combination switch is installed.

The traction control can be activated with the **TC**-button.

The mapping can also be changed during the ride.

– Select one of the following alternatives.



Activating STANDARD mapping:

– Press button ❶.


Engine speed	< 4,000 rpm (< 66.67 Hz)

✓ Indicator light Ⓐ lights up.

✓ STANDARD: balanced response

Note

Traction control can be activated additionally using TC button ❸.



Activating ADVANCED mapping:

– Press button ❷.

Engine speed	< 4,000 rpm (< 66.67 Hz)

✓ Indicator light Ⓑ lights up.

✓ ADVANCED: direct response

Note


Traction control can be activated additionally using TC button ❸.

17.5 adjusting the idle speed

WARNING

Danger of accidents The engine may suddenly come to a halt if the idle speed is set too low.

– Set the idle speed to the specified value.



– Run the engine until warm.
– Check whether the cold start button has returned to its basic position.

DANGER
Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.
– Always ensure that there is sufficient ventilation when running the engine.
– Use suitable exhaust extraction when starting or running the engine in an enclosed space.

– Adjust the idle speed by turning idle speed adjusting screw 1.


Idle speed	1,950 rpm … 2,050 rpm (32.50 Hz … 34.17 Hz)

Service hour counter with revolution counter (A54012920100)

Note
Turning counterclockwise lowers the idle speed.
Turning clockwise increases the idle speed.

17.6 Teaching the throttle valve position

Note
If the control unit detects that the throttle valve position at idle speed needs to be retaught, then the malfunction indicator lamp flashes 2x per second.




DANGER
Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.
– Always ensure that there is sufficient ventilation when running the engine.
– Use suitable exhaust extraction when starting or running the engine in an enclosed space.

– Allow the vehicle to run at idle speed.
✓ The malfunction indicator lamp stops flashing once teaching is completed.

Note
If the engine becomes too warm, perform a cool-down ride at medium speed.
Then do not switch off the engine after this, but leave it running at idle speed until teaching is completed.

17.7 Checking the basic position of the gear shift lever

Note
When driving, the gear shift lever must not touch the rider's boot when in the basic position.
When the gear shift lever keeps touching the boot, the transmission will be subject to an excessive load.




– Sit on the vehicle in the riding position and measure the distance A between the upper edge of your boot and the shift lever.


Distance between the gear shift lever and upper edge of boot	10 mm ... 20 mm (0.39 in ... 0.79 in)

» If the distance does not meet the specifications:
– Adjust the basic position of the gear shift lever. (p. 126)

17.8 Adjusting the basic position of the gear shift lever



– Remove screw 1 with the washers and take off shift lever 2.



– Clean gear teeth A of the shift lever and shift shaft.
– Mount shift lever 2 on the shift shaft in the required position and engage the gearing.

The gear shift lever must not come into contact with any other vehicle components during the shift procedure.

Note
The range of adjustment is limited.

– Mount and tighten screw 1 with washers.

Screw, shift lever	
M6	14 Nm (10.3 ft·lb$_f$) **Loctite® 243**

18.1 Changing the fuel screen

DANGER

Fire hazard Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

– Do not refuel the vehicle in the vicinity of open flames, glowing, or smoldering objects.
– Make sure that nobody smokes in the vicinity of the vehicle during the refueling process.
– Switch off the engine for refueling.
– Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
– If any fuel is spilled, wipe it up immediately.
– Do not overfill the fuel tank.

WARNING


Danger of poisoning Fuel is harmful to health.

– Do not allow fuel to come into contact with skin, eyes, or clothing.
– Consult a doctor immediately if fuel has been ingested.
– Do not inhale fuel vapors.
– Rinse the affected area immediately with plenty of water in the event of contact with skin.
– Rinse eyes thoroughly with water and consult a doctor immediately if fuel comes into contact with eyes.
– If fuel spills on to your clothing, change the clothing.
– Store fuel properly in a suitable container and keep out of the reach of children.


NOTE

Environmental hazard Improper handling of fuel is dangerous to the environment.

– Do not allow fuel to enter the groundwater, the soil, or the sewage system.



– Remove protection cap ❶ of the fuel line.



– Clean quick-lock coupling ❷ thoroughly with compressed air.

Dirt must not enter into the fuel line. Dirt in the fuel line clogs the injector!

– Disconnect the quick-lock coupling.

Note
Remaining fuel may flow out of the fuel hose.


– Pull fuel screen ❸ out of the connecting piece.
– Slide the new fuel screen all the way into the connecting piece.
– Spray silicone spray onto a lint-free cleaning cloth and lightly lubricate the O-ring of the quick-lock coupling.

Silicone spray (p. 160)

– Join quick-lock couplings.

DANGER
Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.
– Always ensure that there is sufficient ventilation when running the engine.
– Use suitable exhaust extraction when starting or running the engine in an enclosed space.

– Start the engine and check the response.




– Mount protection cap ❶ of the fuel line.

18.2 Checking the engine oil level

Condition: Engine is at operating temperature

Preparatory work
– Stand the motorcycle upright on a level surface.

Main work



– Check the engine oil level.

The engine oil is at a level between lower edge Ⓐ and the middle of level viewer Ⓑ.
After switching off the engine, wait one minute before checking the level.

» If the engine oil is not up to lower edge Ⓐ of the level viewer:
– Add engine oil. (p. 131)

18.3 Changing the engine oil and oil filter, cleaning the oil screens

WARNING

Danger of scalding Engine and gear oil heat up when the motorcycle is operated.

– Wear suitable protective clothing and safety gloves.
– In the event of scalding, rinse the area affected immediately with lukewarm water.

NOTE

Environmental hazard Hazardous substances cause environmental damage.


– Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.

Condition: The engine is at operating temperature


Preparatory work

– Park the motorcycle on a level surface.

Main work



– Position an appropriate container under the engine.
– Remove screw plug ❶ with oil screen and the O-rings.
– Remove oil drain plug ❷ with the magnet and seal ring.




– Remove screw plug ❸ with O-ring.


Do not remove screw ❹.

– Allow the engine oil to drain completely.
– Thoroughly clean the parts and the sealing surfaces.
– Mount and tighten screw plug ❸ with new O-ring.

Oil drain plug	
M14×1.5	15 Nm (11.1 ft·lb$_f$)



– Position oil screen ❺ with the O-rings on a pin wrench.
– Position the pin wrench through the drill hole of the screw plug in the opposite section of the engine case.
– Push the oil screen all the way into the engine case.




– Mount and tighten screw plug ❶ with O-ring.


Plug, oil screen	
M20×1.5	15 Nm (11.1 ft·lb$_f$)

– Mount and tighten oil drain plug ❷ with the magnet and a new seal ring.

Oil drain plug with magnet	
M12×1.5	20 Nm (14.8 ft·lb$_f$)




– Remove screws ❻. Take off the oil filter cover with the O-ring.



– Pull oil filter ❼ out of the oil filter housing.

Lock ring plier (51012011000)


– Allow the engine oil to drain completely.
– Thoroughly clean the parts and the sealing surface.



– Lay the motorcycle on its side and fill the oil filter housing to about ⅓ full with engine oil.
– Insert the new oil filter into the oil filter housing.
– Oil the O-ring of the oil filter cover and mount it together with oil filter cover ❽.
– Mount and tighten the screws.

Screw, oil filter cover	
M6	10 Nm (7.4 ft·lb$_f$)

– Stand the motorcycle upright.



– Remove filler plug ❾ with the O-ring, and fill up with engine oil.

engine oil	
Engine oil (10W/50) (p. 159) fully synthetic	1.0 l (0.26 liq. gal$_{US}$)

Note
Too little engine oil or poor-quality engine oil will result in premature wear of the engine.

– Mount and tighten the oil plug together with the O-ring.

DANGER
Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.
– Always ensure that there is sufficient ventilation when running the engine.
– Use suitable exhaust extraction when starting or running the engine in an enclosed space.


– Start the engine and check it for leaks.

Reworking

– Check the engine oil level. (p. 128)

18.4 Adding engine oil

Note
Too little engine oil or poor-quality engine oil will result in premature wear of the engine.



Main work

– Remove oil filler plug 1 with the O-ring from the clutch cover.
– Fill engine oil to the middle A of the level viewer.

engine oil	
Engine oil (10W/50) (p. 159) fully synthetic	1.0 l (0.26 liq. gal_{US})

Note
In order to achieve optimal engine oil performance, it is not advisable to mix different engine oils.
GASGAS recommends changing the engine oil, if necessary.

– Mount and tighten the oil plug together with the O-ring.

DANGER
Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.
– Always ensure that there is sufficient ventilation when running the engine.
– Use suitable exhaust extraction when starting or running the engine in an enclosed space.

– Start the engine and check it for leaks.

Reworking

– Check the engine oil level. (p. 128)

19.1 Cleaning the motorcycle

NOTE

Material damage Components can be damaged or destroyed if a high-pressure cleaner is used incorrectly.

The high pressure forces water into the electrical components, socket connectors, clutch cables, and bearings, etc.

Too high a pressure can cause malfunctions and destroy components.

– Do not direct the water jet directly on to electrical components, socket connectors, clutch cables, or bearings.
– Maintain a minimum distance between the nozzle of the high-pressure cleaner and the component.

Minimum distance	60 cm (23.6 in)

NOTE


Environmental hazard Hazardous substances cause environmental damage.

– Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc. correctly and in accordance with the applicable regulations.

Note

Clean the motorcycle regularly to maintain its value and appearance over a long period.

Avoid direct sunshine when cleaning the motorcycle.



– Close off the exhaust system to keep water from entering.
– Remove the coarse dirt particles with a gentle water jet.
– Spray the heavily soiled parts with a standard commercial motorcycle cleaner and clean using a brush.

Never apply motorcycle cleaner to a dry vehicle; always rinse the vehicle with water first.

Environmentally neutral universal cleaning agent (p. 162)

Note

Use warm water containing standard motorcycle cleaner and a soft sponge.

– Clean the motorcycle thoroughly with a soft water jet, then allow to dry.
– Remove the cover from the exhaust system.

WARNING

Danger of accidents Moisture and dirt impair the brake system.

– Brake carefully several times to dry out and remove dirt from the brake pads and the brake discs.

– After cleaning, ride the vehicle a short distance until the engine warms up.

Note

The heat produced causes water to evaporate at inaccessible locations in the engine and on the brake system.

– After the motorcycle has cooled off, lubricate all moving parts and pivot points.
– Clean the chain. (p. 79)

WARNING
Danger of accidents Oil, grease or wax on the brake discs reduces the brake action.
– Always keep the brake discs free of oil, fat and wax.
– Clean the brake discs with brake cleaner when necessary.

– Treat bare metal (except for brake discs and the exhaust system) with an anticorrosive.

Preserving materials (p. 162)

– Treat all plastic parts and powder-coated parts with a mild cleaning and care product.

Cleaning agents for plastics, glass, lacquers, metals, windshields and visors (p. 162)

– Lubricate the steering lock.


Universal oil spray (p. 159)

19.2 Checks and maintenance steps for winter operation

WARNING
Danger of accidents Salt on the roads impairs the brake system.
– Brake carefully several times to remove salt from the brake linings and the brake discs.

WARNING
Danger of accidents Oil, grease or wax on the brake discs reduces the brake action.
– Always keep the brake discs free of oil, fat and wax.
– Clean the brake discs with brake cleaner when necessary.

Note
If you use the vehicle in winter, you must expect salt on the roads. You should therefore take precautions against aggressive road salt.


401060-01

– Clean the motorcycle. (p. 133)
– Clean brake system.

After every trip on salted roads, thoroughly wash the brake calipers and brake pads with cold water and dry carefully. This should be done after the parts are cooled down and while they are installed.

After riding on salted roads, thoroughly clean the vehicle with cold water and dry it well.

Note
Warm water enhances the corrosive effects of salt.

– Treat the engine, swingarm, and all other bare or zinc-plated parts (except the brake discs) with a wax-based anticorrosive.

Corrosion inhibitor must not come into contact with the brake discs. This would severely lower the braking effect.

– Clean the chain. (p. 79)

20.1 Storage

WARNING


Danger of poisoning Fuel is harmful to health.

- Do not allow fuel to come into contact with skin, eyes, or clothing.
- Consult a doctor immediately if fuel has been ingested.
- Do not inhale fuel vapors.
- Rinse the affected area immediately with plenty of water in the event of contact with skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if fuel comes into contact with eyes.
- If fuel spills on to your clothing, change the clothing.
- Store fuel properly in a suitable container and keep out of the reach of children.

Note

If you plan to garage the motorcycle for a longer period, perform the following steps or have them performed.

Before storing the motorcycle, check all parts for function and wear. If service, repairs, or replacements are necessary, you should do this during the storage period (workshops less busy). In this way, you can avoid long workshop waiting times at the start of the new season.



- When refueling for the last time before taking the motorcycle out of service, add fuel additive.

Fuel additive (p. 158)

- Refuel. (p. 43)

Tip

Fill the fuel tank completely as specified, using fuel with the lowest possible ethanol content.

- Clean the motorcycle. (p. 133)
- Change the engine oil and the oil filter, clean the oil screens. (p. 129)
- Check the frost protection and coolant level. (p. 116)
- Check the tire pressure. (p. 104)
- Remove the 12 V battery. (p. 106)
- Charge the 12 V battery. (p. 108)

Storage temperature of the 12 V battery without direct sunlight	0 °C … 35 °C (32.0 °F … 95.0 °F)

- Store the vehicle in a dry location that is not subject to large fluctuations in temperature.

Note

GASGAS recommends putting the motorcycle on a stand or lift.


- Raise the motorcycle with a lift stand. (p. 56)

Preferably cover the motorcycle with a tarp or similar cover that is permeable to air. Do not use any non-porous materials, as moisture cannot escape and corrosion can occur.

Note

Avoid running the engine of a motorcycle in storage for a short time only. Since the engine cannot warm up properly, the water vapor produced during combustion condenses and causes valves and the exhaust system to rust.

20.2 Preparing for use after storage



- Remove the motorcycle from the lift stand. (p. 56)
- Install the 12 V battery. (p. 107)
- Perform checks and maintenance measures when preparing for use. (p. 40)
- Take a test ride.

21.1 troubleshooting

Cause	Finding	Remedy
The engine does not turn over (starter motor)	Operating error 12 V battery discharged Main fuse blown Starter relay defective Starter motor defective	– Carry out the starting procedure. (p. 40) – Charge the 12 V battery. (p. 108) – Check the charging voltage. – Check the open-circuit current. – Check the stator winding of the alternator. – Change the main fuse. (p. 110) – Check the starter relay. – Check the starter motor.
The engine turns but does not start	Operating error Quick-lock coupling not joined Error in the circuit, OCU LED **A** and **D** lights up. Idle speed is not set correctly Spark plug sooty or wet Plug gap of spark plug too wide Faulty ignition Short-circuit cable in wiring harness frayed, stop button or emergency OFF switch faulty Error in the electronic fuel injection	– Carry out the starting procedure. (p. 40) – Join quick-lock couplings. – Check the electrical system. – Adjust the idle speed. (p. 124) – Clean and dry the spark plug and spark plug connector, or change if necessary. – Adjust plug gap. Plug gap of spark plug: 1.0 mm (0.039 in) – Check the ignition system. – Check the wiring harness. (Visual check). – Check the electrical system. – Read out the fault memory using the diagnostics tool.
Engine does not speed up	Error in the electronic fuel injection Faulty ignition	– Read out the fault memory using the diagnostics tool. – Ignition coil - check the secondary winding. – Check the spark plug connector. – Check the stator winding of the alternator.
Engine has too little power	Air filter is very dirty Fuel filter is very dirty Fuel screen is very dirty Error in the electronic fuel injection Exhaust system leaks, deformed or too little damping material in the silencer Valve clearance too little Faulty ignition	– Clean the air filter and air filter box. (p. 73) – Change the fuel filter. – Change the fuel screen. (p. 127) – Read out the fault memory using the diagnostics tool. – Check exhaust system for damage. – Change the damping material on the main silencer. (p. 75) – Adjust the valve clearance. – Ignition coil - check the secondary winding. – Check the spark plug connector.

Cause	Finding	Remedy
		– Check the stator winding of the alternator.
The engine dies during the trip	Lack of fuel Error in the circuit, OCU LED **A** and **D** lights up.	– Refuel. (p. 43) – Check the electrical system.
Engine overheats	Too little coolant in cooling system Too little air stream Radiator fins very dirty Foam formation in the cooling system Bent radiator hose Thermostat defective Defect in the radiator fan system, OCU LED **E** lights up.	– Check the transmission and cooling system for leaks. – Check the coolant level. (p. 117) – Switch off the engine when standing. – Clean the radiator fins. – Drain the coolant. (p. 118) – Refill the coolant. (p. 118) – Change the radiator hose. – Check the thermostat. Opening temperature: 70 °C (158.0 °F) – Check the radiator fan. – Check the electrical system.
Malfunction indicator lamp lights up or flashes	Error in the electronic fuel injection	– Check wiring for damage and electrical plug-in connectors for corrosion and damage. – Read out the fault memory using the diagnostics tool.
High oil consumption	Engine vent hose bent The engine oil level is too high The engine oil is too thin (low viscosity) Piston and cylinder worn	– Route the vent hose without bends or change it if necessary. – Check the engine oil level. (p. 128) – Change the engine oil and the oil filter, clean the oil screens. (p. 129) – Measure the piston/cylinder mounting clearance.
12 V battery discharged	The 12-V battery is not being charged by the alternator unwanted electrical load	– Check the charging voltage. – Check the stator winding of the alternator. – Check the open-circuit current.
Values in combination instrument deleted (time, stop watch, lap times)	The combination instrument battery is empty	– Change the combination instrument battery. (p. 114)
Fault with the lighting system or horn.	Error in the circuit, OCU LED **B** or **C** lights up.	– Check the electrical system.

22.1 Flash code

Note
The blink codes are only displayed by the derestricted version of the vehicle.

Blink code for malfunction indicator light	 02: Malfunction indicator light flashes 2x short
Error level condition	Time: **≥** 2.0 s The induction manifold pressure sensor delivers a normal signal (engine running), while the crankshaft speed sensor does not generate any signal at all.

Blink code for malfunction indicator light	 02a: Malfunction indicator lamp flashes 2x per second
Error level condition	Throttle valve position programming necessary Throttle valve position programming necessary

Blink code for malfunction indicator light	 06: Malfunction indicator light flashes 6x short
Error level condition	Throttle valve position sensor circuit A voltage **«THAD»**: **≤** 0.352 V Time: **≥** 3 s Throttle valve position sensor circuit A voltage **«THAD»**: **≥** 4.785 V Time: **≥** 3 s

Blink code for malfunction indicator light	 09: Malfunction indicator light flashes 9x short
Error level condition	Induction manifold pressure sensor, voltage **«PM1AD»**: **≤** 0.215 V Time: **≥** 3 s Induction manifold pressure sensor, voltage **«PM1AD»**: **≥** 4.121 V Time: **≥** 3 s

Blink code for malfunction indicator light	 12: Malfunction indicator light flashes 1x long, 2x short
Error level condition	Coolant temperature sensor voltage **«TWAD»**: **≤** 0.137 V Time: **≥** 3 s Coolant temperature sensor voltage **«TWAD»**: **≥** 4.785 V Time: **≥** 3 s

Blink code for malfunction indicator light	 13: Malfunction indicator light flashes 1x long, 3x short
Error level condition	Intake air temperature sensor voltage **«TAAD»**: **≤** 0.195 V Time: **≥** 3 s Intake air temperature sensor voltage **«TAAD»**: **≥** 4.824 V

	Time: ≥ 3 s

Blink code for malfunction indicator light	 15: Failure indicator light flashes 1x long, 5x short
Error level condition	Signal voltage **«(A/D type)»**: ≤ 0.176 V Time: ≥ 25.5 s Voltage **«(A/D type)»**: ≥ 4.57 V Time: ≥ 25.5 s

Blink code for malfunction indicator light	 21: Malfunction indicator light flashes 2x long, 1x short
Error level condition	EFI control unit power supply: ≥ 15.98 V Time: ≥ 2 s Circuit fault.

Blink code for malfunction indicator light	 22: Failure indicator light flashes 2x long, 2x short
Error level condition	

Blink code for malfunction indicator light	 33: Malfunction indicator lamp flashes 3x long, 3x short
Error level condition	Circuit fault: ≥ 2.0 s

Blink code for malfunction indicator light	 37: Malfunction indicator light flashes 3x long, 7x short
Error level condition	Time: ≥ 2.0 s Circuit fault.

Blink code for malfunction indicator light	 41: Malfunction indicator light flashes 4x long, 1x short
Error level condition	The engine is switched off: ≥ 3 s Circuit fault. The engine is switched off: ≥ 3 s Circuit fault.

23.1 Engine

23.1.1 Technical data - engine

Design	1-cylinder 4-stroke engine, water-cooled
Displacement	349.7 cm³ (21.340 in³)
Stroke	57.5 mm (2.264 in)
Bore	88 mm (3.46 in)
Compression ratio	13.7:1
Control	DOHC, four valves controlled via cam lever, drive via timing chain
Valve diameter, intake	29.10 mm (1.1457 in)
Valve diameter, exhaust	36.30 mm (1.4291 in)
Valve clearance	
Intake at: 20 °C (68.0 °F)	0.08 mm … 0.15 mm (0.0031 in … 0.0059 in)
Exhaust at: 20 °C (68.0 °F)	0.10 mm … 0.19 mm (0.0039 in … 0.0075 in)
Crankshaft bearing	2-cylinder roller bearing
Big (bottom) end bearing	Plain bearing
Wrist pin bearing	Bearing bush
Piston	Forged light alloy
Piston rings	1 compression ring, 1 oil scraper ring
Engine lubrication	Pressure circulation lubrication with 2 trochoidal pumps
Primary transmission	24:72
Clutch	Multidisc clutch in oil bath/hydraulically activated/damped
Transmission	6 speed transmission, claw shift
Gear ratios	
1st gear	13:33
2nd Gear	16:30
3rd Gear	18:26
4th Gear	22:26
5th Gear	23:23
6th Gear	26:22
Alternator	• 14 V • 200 W (0.268 hp)
Ignition system	Contactless controlled fully electronic ignition with digital ignition adjustment
Spark plug	NGK LMAR9AI-10
Plug gap of spark plug	1.0 mm (0.039 in)
Cooling	Liquid cooling, permanent circulation of coolant by water pump

Starting aid	Starter motor
Idle speed	1,950 rpm … 2,050 rpm (32.50 Hz … 34.17 Hz)

23.1.2 Capacities - engine

engine oil	
Engine oil (10W/50) 📖 (p. 159) fully synthetic	1.0 l (0.26 liq. gal_{US})
coolant	
Coolant 📖 (p. 160) Antifreeze protection to at least: −25 °C (−13.0 °F)	0.95 l (0.251 liq. gal_{US})

23.2 Chassis

23.2.1 Technical data - chassis

Frame	Central tube frame made of chrome molybdenum steel tubing
Fork	**WP XPLOR**
Suspension travel:	
front	291.2 mm (11.465 in)
rear	300 mm (11.81 in)
Triple clamp offset	22 mm (0.87 in)
Shock absorber	**WP XACT LDS**
Brake system	Disc brakes, floating brake calipers
Brake discs diameter	
front	260 mm (10.24 in)
rear	220 mm (8.66 in)
Brake disc wear limit	
front	2.5 mm (0.098 in)
rear	3.5 mm (0.138 in)
Street tire pressure	
front	2.0 bar (29.0 psi)
rear	2.0 bar (29.0 psi)
Final drive	14:46 (13:46)
Chain	520
Rear sprockets available	46 teeth

Steering head angle	63.9° (1.115 rad)
Wheelbase	1,489 ±10 mm (58.62 ±0.39 in)
Seat Height unloaded	957 mm (37.68 in)
Ground clearance unloaded	344 mm (13.54 in)
Weight without fuel approx.	110.2 kg (242.95 lb)
Maximum permissible front axle load	145 kg (319.7 lb)
Maximum permissible rear axle load	190 kg (418.9 lb)
Maximum permissible total weight	335 kg (738.5 lb)

23.2.2 Technical data - tires

Tire front	Rear tire
90/90 - 21 M/C 51R M+S TT MAXXIS Maxx Enduro	**140/80 - 18 M/C 70R M+S TT** MAXXIS Maxx Enduro
The tires specified represent one of the possible series production tires. For alternative manufacturers, if any, contact an authorized manufacturer or qualified tire dealership. If local road approval regulations apply, these and the respective technical specifications must be observed.	

23.2.3 Capacities - vehicle

Total fuel tank capacity, approx.	
Super unleaded (ROZ 95) (p. 158)	9 l (2.4 liq. gal_{US})

23.3 Electrics

23.3.1 Battery

12-V battery	HJTZ5S-FP-C	Lithium-ion battery Battery voltage: 12 V Nominal capacity: 2.0 Ah Maintenance-free
Button cell	CR 2430	Battery voltage: 3 V

23.3.2 Fuses

Fuse	58011109120	20 A

23.3.3 Lamps

Dashboard illumination and indicator lights	LED
Low beam	LED

Parking light	LED	
high beam	LED	
Turn signal	RY10W / Sockel BAU15s	12 V 10 W (0.013 hp)
Brake light	LED	
Tail light	LED	
License plate lighting	LED	

23.4 Fork

23.4.1 Technical data - fork

Fork part number	A590C163Z401000

Compression damping	
Comfort	18 clicks
Standard	15 clicks
Sport	12 clicks
Rebound damping	
Comfort	18 clicks
Standard	15 clicks
Sport	12 clicks
Spring length with preload spacer(s)	474 mm (18.66 in)
Spring rate	
Weight of rider: 65 kg … 75 kg (143.3 lb … 165.3 lb)	4.4 N/mm (25.12 lb_f/in)
Weight of rider: 75 kg … 85 kg (165.3 lb … 187.4 lb)	4.6 N/mm (26.27 lb_f/in)
Weight of rider: 85 kg … 95 kg (187.4 lb … 209.4 lb)	4.8 N/mm (27.41 lb_f/in)
Fork length	940 mm (37.01 in)

23.4.2 Capacities - fork

Fork oil per fork leg	
Fork oil (48601166S1) (SAE 4) (p. 159)	635 ±10 ml (21.47 ±0.34 fl. oz_{US})

23.5 Shock absorber

23.5.1 Technical data - shock absorber

Shock absorber part number	A390C463Z408000

Low-speed compression damping	
Comfort	18 clicks
Standard	15 clicks
Sport	12 clicks

High-speed compression damping	
Comfort	2.5 turns (900°)
Standard	2 turns (720°)
Sport	1.5 turns (540°)
Rebound damping	
Comfort	18 clicks
Standard	15 clicks
Sport	12 clicks
Preload	7 mm (0.28 in)
Spring rate	
Weight of rider: 65 kg ... 75 kg (143.3 lb ... 165.3 lb)	42 N/mm (239.8 lb_f/in)
Weight of rider: 75 kg ... 85 kg (165.3 lb ... 187.4 lb)	45 N/mm (257.0 lb_f/in)
Weight of rider: 85 kg ... 95 kg (187.4 lb ... 209.4 lb)	48 N/mm (274.1 lb_f/in)
Spring length	240 mm (9.45 in)
Gas assisted	10 bar (145 psi)
Static sag	40 mm (1.57 in)
Rider sag	110 mm (4.33 in)
Installation position	456.3 mm (17.965 in)

23.5.2 Capacities - shock absorber

Oil capacity, shock absorber	
Shock absorber oil (50180751S1) (SAE 2.5) (p. 160)	Fill to the maximum mark

23.6 Tightening torque

23.6.1 Engine tightening torques

Oil nozzle for main bearing lubrication	M4	0.8 Nm (0.59 ft·lb_f) **Loctite® 243**
Oil nozzle for clutch lubrication	M4	0.8 Nm (0.59 ft·lb_f) **Loctite® 243**
Screw, oil nozzle bent for piston cooling	M4	2.5 Nm (1.84 ft·lb_f) **Loctite® 243**

Jet, crank chamber ventilation M4	0.8 Nm (0.59 ft·lb$_f$) **Loctite® 243**
Hose clip, intake flange M4	3 Nm (2.2 ft·lb$_f$)
Detent arm screw M5	6 Nm (4.4 ft·lb$_f$) **Loctite® 243**
Screw, gear position sensor M5	5 Nm (3.7 ft·lb$_f$) **Loctite® 243**
Screw, clutch spring M5	6 Nm (4.4 ft·lb$_f$)
Oil pump cover screw for the suction/pressure pump M5	6 Nm (4.4 ft·lb$_f$) **Loctite® 243**
Oil pump idler gear fuse screw M5	6 Nm (4.4 ft·lb$_f$) **Loctite® 243**
Oil nozzle for piston cooling M5	2 Nm (1.5 ft·lb$_f$) **Loctite® 243**
Screw, bearing retainer M5	6 Nm (4.4 ft·lb$_f$) **Loctite® 243**
Stator screw M5	6 Nm (4.4 ft·lb$_f$) **Loctite® 2701**
Screw, crankshaft position sensor M5	6 Nm (4.4 ft·lb$_f$) **Loctite® 243**
Alternator cover grub screw M5	2 Nm (1.5 ft·lb$_f$) **Loctite® 243**
Shift star screw M6	10 Nm (7.4 ft·lb$_f$) **Loctite® 243**
Exhaust flange screw M6	10 Nm (7.4 ft·lb$_f$) **Loctite® 243**
Screw, guide rail M6	10 Nm (7.4 ft·lb$_f$) **Loctite® 243**
Screw, timing chain failure protection M6	10 Nm (7.4 ft·lb$_f$) **Loctite® 243**
Screw, starter motor M6	10 Nm (7.4 ft·lb$_f$)
Screw, outer clutch cover M6	10 Nm (7.4 ft·lb$_f$)

Screw, inner clutch cover M6		10 Nm (7.4 ft·lb$_f$)
Screw, clutch slave cylinder M6		10 Nm (7.4 ft·lb$_f$)
Screw, engine case M6		10 Nm (7.4 ft·lb$_f$)
Screw, oil filter cover M6		10 Nm (7.4 ft·lb$_f$)
Screw, shift lever M6		14 Nm (10.3 ft·lb$_f$) **Loctite® 243**
Screw, starter motor - intermediate gear M6		10 Nm (7.4 ft·lb$_f$) **Loctite® 243**
Screw, valve cover M6		8 Nm (5.9 ft·lb$_f$)
Stud, cylinder head M6		6 Nm (4.4 ft·lb$_f$) **Loctite® 243**
Nut, cylinder head M6		10 Nm (7.4 ft·lb$_f$)
Screw, water pump cover M6		10 Nm (7.4 ft·lb$_f$)
Nut, water pump impeller M6		6 Nm (4.4 ft·lb$_f$) **Loctite® 243**
Screw, outer clutch cover M6		10 Nm (7.4 ft·lb$_f$)
Screw, engine case M6×70		10 Nm (7.4 ft·lb$_f$)
Screw, water pump cover M6×40		10 Nm (7.4 ft·lb$_f$)
Screw, water pump cover M6		10 Nm (7.4 ft·lb$_f$)
Screw, ignition cover M6		10 Nm (7.4 ft·lb$_f$)
Fuel vapor retention system connection screw M6		5 Nm (3.7 ft·lb$_f$) **Loctite® 243**
Screw, fuel vapor retention system lock M6		5 Nm (3.7 ft·lb$_f$) **Loctite® 243**
Autodecompressor screw plug M7×1		15 Nm (11.1 ft·lb$_f$) **Loctite® 243**
Screw, camshaft bearing bridge M7×1 Engine oil	1.	5 Nm (3.7 ft·lb$_f$)
	2.	14 Nm (10.3 ft·lb$_f$)

Slide rail screw M8		15 Nm (11.1 ft·lb$_f$) **Loctite® 243**
Crankshaft clamp screw plug M8		10 Nm (7.4 ft·lb$_f$)
Crankshaft fixing screw M8		hand-tight
Screw plug, cam lever shaft M10×1		8 Nm (5.9 ft·lb$_f$)
Front sprocket screw M10		60 Nm (44.3 ft·lb$_f$) **Loctite® 243**
Chain tension adjuster finger follower shaft plug M10×1		8 Nm (5.9 ft·lb$_f$)
Screw, rotor M10×1		70 Nm (51.6 ft·lb$_f$) Engine oil
Coolant temperature sensor M10×1.25		12 Nm (8.9 ft·lb$_f$)
Oil channel screw plug M10×1		15 Nm (11.1 ft·lb$_f$) **Loctite® 243**
Stud, cylinder head M10×1.25		20 Nm (14.8 ft·lb$_f$) **Loctite® 243**
Nut, cylinder head M10×1.25 Engine oil	1.	10 Nm (7.4 ft·lb$_f$)
	2.	30 Nm (22.1 ft·lb$_f$)
	3.	180° (3.14 rad)
Screw, release for timing chain tensioner M10×1		8 Nm (5.9 ft·lb$_f$)
Spark plug M10×1		12 Nm (8.9 ft·lb$_f$)
Oil drain plug with magnet M12×1.5		20 Nm (14.8 ft·lb$_f$)
Pressure control valve plug M12×1.5		20 Nm (14.8 ft·lb$_f$)
Oil drain plug M14×1.5		15 Nm (11.1 ft·lb$_f$)
Nut, inner clutch hub M18×1.5		100 Nm (73.8 ft·lb$_f$)
Nut, primary gear wheel M18LH×1.5		120 Nm (88.5 ft·lb$_f$) **Loctite® 243**
Plug, oil screen M20×1.5		15 Nm (11.1 ft·lb$_f$)

Screw plug, timing chain tensioner M24×1.5	40 Nm (29.5 ft·lb$_f$)
Oil plug M24×3	hand-tight
Screw, ignition cover M24×1.5	18 Nm (13.3 ft·lb$_f$)
Screw plug, alternator cover M24×1.5	18 Nm (13.3 ft·lb$_f$)

23.6.2 Chassis tightening torques

Hose connector, active carbon filter	3.8 Nm (2.80 ft·lb$_f$)
Mushroom head screw for spoiler and seat	2.5 Nm (1.84 ft·lb$_f$)
Screw, radiator hoses clip	2.4 Nm (1.77 ft·lb$_f$)
Air boot on throttle body	2.8 Nm (2.07 ft·lb$_f$)
Screw, fixed grip M4	5 Nm (3.7 ft·lb$_f$) **Loctite® 243**
Screw, hose clamp, throttle body M4	5 Nm (3.7 ft·lb$_f$)
Remaining nuts on chassis M5	5 Nm (3.7 ft·lb$_f$)
Remaining screws on chassis M5	5 Nm (3.7 ft·lb$_f$)
Screw, battery terminal M5	2.5 Nm (1.84 ft·lb$_f$)
Screw, light switch M5	1 Nm (0.7 ft·lb$_f$)
Screw, turn signal switch M5	1 Nm (0.7 ft·lb$_f$)
Screw, frame protector M5	3 Nm (2.2 ft·lb$_f$)
Screw, throttle body cover M5	2.6 Nm (1.92 ft·lb$_f$)
Screw, shock absorber adjusting ring M5	5 Nm (3.7 ft·lb$_f$)
Screws on muffler M5	7 Nm (5.2 ft·lb$_f$)
Nut, starter motor M6	4 Nm (3.0 ft·lb$_f$)
Remaining nuts on chassis M6	10 Nm (7.4 ft·lb$_f$)
Remaining screws on chassis M6	10 Nm (7.4 ft·lb$_f$)
Screw, throttle twist grip M6	5 Nm (3.7 ft·lb$_f$)


Screw, rear brake disc M6	14 Nm (10.3 ft·lb$_f$) **Loctite® 243**
Screw, front brake disc M6	14 Nm (10.3 ft·lb$_f$) **Loctite® 243**
Screw, chain slider guard M6	6 Nm (4.4 ft·lb$_f$) **Loctite® 243**
Screw, ball joint of push rod on brake cylinder M6	10 Nm (7.4 ft·lb$_f$) **Loctite® 243**
Fender screw M6	12 Nm (8.9 ft·lb$_f$)
Screw, seat installation M6	8 Nm (5.9 ft·lb$_f$)
Brake line guide screw on swingarm M6	4.5 Nm (3.32 ft·lb$_f$) **Loctite® 243**
Screw, connector support incl. dashboard M6	5 Nm (3.7 ft·lb$_f$)
Screw, ground wire on frame M6	10 Nm (7.4 ft·lb$_f$)
Screw, starter cable to starter relay M6	6 Nm (4.4 ft·lb$_f$)
Screw, hand lever M6	5 Nm (3.7 ft·lb$_f$)
Screw, battery holding bracket M6	6 Nm (4.4 ft·lb$_f$)
Screw, fuel tank spoiler on radiator M6	6 Nm (4.4 ft·lb$_f$)
Nut, throttle cable on throttle body M6	3 Nm (2.2 ft·lb$_f$)
Screw, rear chain guide M6	10 Nm (7.4 ft·lb$_f$) **Loctite® 243**
Screw, front chain guide M6	10 Nm (7.4 ft·lb$_f$)
Nut, rear sprocket screw M8	35 Nm (25.8 ft·lb$_f$) **Loctite® 2701**
Nut, rim lock M8	12 Nm (8.9 ft·lb$_f$)
Remaining nuts on chassis M8	25 Nm (18.4 ft·lb$_f$)
Remaining screws on chassis M8	25 Nm (18.4 ft·lb$_f$)

Screw, front brake caliper M8	25 Nm (18.4 ft·lb$_f$) **Loctite® 243**
Screw, top triple clamp M8	20 Nm (14.8 ft·lb$_f$)
Screw, bottom triple clamp M8	15 Nm (11.1 ft·lb$_f$)
Screw, fork shoe M8	15 Nm (11.1 ft·lb$_f$)
Screw, upper steering stem M8	20 Nm (14.8 ft·lb$_f$) **Loctite® 243**
Screw, manifold M8	15 Nm (11.1 ft·lb$_f$)
Handlebar clamp screw M8	20 Nm (14.8 ft·lb$_f$)
Screw, chain slider M8	15 Nm (11.1 ft·lb$_f$)
Screw, engine brace on engine M8×20	25 Nm (18.4 ft·lb$_f$) **Loctite® 243**
Screw, subframe, top M8	40 Nm (29.5 ft·lb$_f$) **Loctite® 243**
Screw, side stand attachment M8	33 Nm (24.3 ft·lb$_f$) **Loctite® 2701**
Screw, subframe, bottom M8	35 Nm (25.8 ft·lb$_f$) **Loctite® 2701**
Screw, engine brace on frame M8×15	25 Nm (18.4 ft·lb$_f$) **Loctite® 2701**
Screw, front sprocket cover M8	15 Nm (11.1 ft·lb$_f$)
Screw, wheel speed sensor, fork shoe M8	4.5 Nm (3.32 ft·lb$_f$)
Brake pedal stop nut M10	45 Nm (33.2 ft·lb$_f$)
Screw, brake caliper on brake caliper bracket M10	45 Nm (33.2 ft·lb$_f$) **Loctite® 243**
Engine bracket screw M10	60 Nm (44.3 ft·lb$_f$)
Remaining nuts on chassis M10	45 Nm (33.2 ft·lb$_f$)
Remaining screws on chassis M10	45 Nm (33.2 ft·lb$_f$)

Screw, handlebar mount M10	40 Nm (29.5 ft·lb$_f$) **Loctite® 243**
Top shock absorber screw M10	60 Nm (44.3 ft·lb$_f$) **Loctite® 2701**
Bottom shock absorber screw M10	60 Nm (44.3 ft·lb$_f$) **Loctite® 2701**
Screw, sprocket M10	60 Nm (44.3 ft·lb$_f$) **Loctite® 2701**
Screw connection, pull rod on frame M14	60 Nm (44.3 ft·lb$_f$)
Nut, swingarm pivot M16×1.5	100 Nm (73.8 ft·lb$_f$)
Screw, top steering head M20×1.5	12 Nm (8.9 ft·lb$_f$)
Screw, wheel spindle, front M20×1.5	35 Nm (25.8 ft·lb$_f$)
Nut, wheel spindle, rear M22	80 Nm (59.0 ft·lb$_f$)
Screw-in nozzle, cooling system M24×1.5	7.5 Nm (5.53 ft·lb$_f$) **Loctite® 243**
Outer diaphragm fitting **EJOT PT® –** 35×25	0.8 Nm (0.59 ft·lb$_f$)
Inner diaphragm fitting **EJOT PT® –** 35×25	1 Nm (0.7 ft·lb$_f$)
Spoke nipple, front wheel M4,5	6 Nm (4.4 ft·lb$_f$)
Spoke nipple, rear wheel M4,5	6 Nm (4.4 ft·lb$_f$)
Screw, intake air temperature sensor **EJOT PT® –** 50×18	0.7 Nm (0.52 ft·lb$_f$)
Screw, emergency OFF switch **EJOT PT® –** K50×18	2 Nm (1.5 ft·lb$_f$)
Screw, pressure regulator **EJOT PT® –** K60×25 – Z	2.3 Nm (1.70 ft·lb$_f$)
Screw, seat installation **EJOT EJOFORM® –** K60×23/18	2.5 Nm (1.84 ft·lb$_f$)
Remaining screws on chassis **EJOT PT® –** K60×25 – Z	2 Nm (1.5 ft·lb$_f$)
Screw, fuel pump **EJOT PT® –** M60×30	2.5 Nm (1.84 ft·lb$_f$)
Screw, air filter box on subframe **EJOT PT® –** 60×20	5 Nm (3.7 ft·lb$_f$)
Screw, air filter box cover **EJOT PT® –** MK60×20 – Z	3 Nm (2.2 ft·lb$_f$)

Nut, linkage lever on angle lever M14x1,5	60 Nm (44.3 ft·lb$_f$)

24.1 Recycling



Further information is available at the following website.
Recycling information website: https://www.quefairedemesdechets.fr

24 Recycling

A Technical terms

OBD	On-board diagnosis	Vehicle system, which monitors the specified parameters of the vehicle electronics

B Fuels

Super unleaded

Standards

• ROZ 95	→ DIN EN 228

Fuel additive

Recommended supplier

MOTOREX®

- **FUEL STABILIZER**

C Operating supplies

Off-road chain spray

Recommended supplier

MOTOREX®

- **CHAINLUBE OFF ROAD**

Fork oil

Order details

- 48601166S1

Standards

- SAE 4 → SAE

Universal oil spray

Recommended supplier

MOTOREX®

- **JOKER 440 SYNTHETIC**

Long-life grease

Recommended supplier

MOTOREX®

- **Bike Grease 2000**

Engine oil

Recommended supplier

MOTOREX®

- **CROSS POWER 4T**

Standards

→ JASO T903 MA2

- 10W/50 → SAE

Properties

- fully synthetic

Engine oil

Recommended supplier

MOTOREX®

- **TOP SPEED 4T**

Standards

→ JASO T903 MA2

- 15W/50 → SAE

Properties

- Partially synthetic

High viscosity grease

Recommended supplier

SKF®

- **LGHB 2**

Silicone spray

Recommended supplier

MOTOREX®

- **SILICONE SPRAY**

Shock absorber oil

Order details

- 50180751S1

Standards

- SAE 2.5 → SAE

Oil for foam air filter

Recommended supplier

MOTOREX®

- **RACING BIO AIR FILTER OIL**

Brake fluid DOT 5.1

Recommended supplier

MOTOREX®

- **BRAKE FLUID DOT 5.1**

Standards

→ DOT

Coolant

Recommended supplier

MOTOREX®

- **COOLANT M3.0**

Properties	
• Antifreeze protection to at least	−25 °C (−13.0 °F)

D Cleaning agents

Chain cleaner

Recommended supplier

MOTOREX®

- **CHAIN CLEAN**

Preserving materials

Recommended supplier

MOTOREX®

- **MOTO PROTECT**

Air filter cleaning agent

Recommended supplier

MOTOREX®

- **RACING BIO AIR FILTER CLEANER**

Cleaning agents for plastics, glass, lacquers, metals, windshields and visors

Recommended supplier

MOTOREX®

- **QUICK CLEANER**

Environmentally neutral universal cleaning agent

Recommended supplier

MOTOREX®

- **MOTO CLEAN UNIVERSAL**

E Icons

E.1 Symbol colors

E.1.1 Yellow and orange symbols

Yellow and orange symbols indicate a malfunction status that requires prompt intervention. Active driving aids are also represented by yellow or orange symbols.

	Malfunction indicator light lights up/flashes.
	Fuel level warning light lights up yellow.
	Malfunction indicator lamp lights up/flashes yellow
	The fuel level warning lamp lights up yellow

E.1.2 Green and blue symbols

Green and blue symbols convey information.

	Turn signal indicator light flashes green.
	The high beam indicator light lights up blue.
	Turn signal indicator lamp flashes green
	The high beam indicator lamp lights up blue

1

12 V battery
- charging . . . 108
- installation . . . 107
- removing . . . 106

12 V battery
- starting power . . . 36

A

Accessories . . . 13

Air filter
- cleaning . . . 73
- installing . . . 72
- removing . . . 72

Air filter box
- cleaning . . . 73

Air filter box cover
- installing . . . 71
- preparing for securing . . . 74
- removing . . . 70

Auxiliary substances . . . 13

B

Battery . . . 144

Brake discs
- checking . . . 89

Brake fluid
- adding front brake . . . 90
- adding to rear brake . . . 96

Brake fluid level
- checking on front brake . . . 90
- checking on rear brake . . . 95

Brake lining retainers
- checking on front brake . . . 91
- checking on rear brake . . . 97

Brake pad
- checking on front brake . . . 91

Brake pads
- changing on the rear brake . . . 97
- checking on rear brake . . . 97
- of the front brake, changing . . . 92

Brake pedal
- adjusting the basic position . . . 94
- checking the free travel . . . 94

C

Chain
- checking . . . 82
- cleaning . . . 79

Chain guide
- checking . . . 82

Chain tension
- adjusting . . . 81
- checking . . . 80

Characteristic map of the throttle response
- adjusting . . . 122

Checking basic chassis setting with
- rider's weight . . . 47

Clothing . . . 11

Clutch
- changing fluid . . . 87
- checking/correcting fluid level . . . 86

Clutch lever
- adjusting the basic position . . . 86

Combination instrument
- Changing the combination instrument battery . . . 114

Compression damping
- adjusting the fork . . . 53

Coolant
- antifreeze and coolant level, checking . . . 116
- changing . . . 119
- draining . . . 118
- level, checking . . . 117
- refilling . . . 118

Customer service . . . 13

D

Dashboard
- overview . . . 25
- time . . . 27

Defined use . . . 12

Diagnostic connector . . . 115

Difficult operating conditions . . . 37
- dry sand . . . 37
- high temperatures . . . 39
- low temperature . . . 39
- muddy surfaces . . . 38
- slow speed . . . 39
- snow . . . 39
- wet sand . . . 38
- wet surfaces . . . 38

E

Engine
- running in . . . 36

Engine oil
- adding . . . 131
- changing . . . 129

Engine oil level
- checking . . . 128

Environment . . . 12

F

Figures . . . 13

Fork legs
bleeding . . . 56
checking basic setting . . . 52
cleaning the dust boots . . . 57
installing . . . 60
removing . . . 59
Fork protector
installation . . . 58
removing . . . 58
Frame
checking . . . 84
Frame protector
installation . . . 59
removing . . . 58
Front fender
installation . . . 65
removing . . . 65
Front sprocket
checking . . . 82
Front wheel
installing . . . 101
removing . . . 100
Frost protection
checking . . . 116
Fuel screen
changing . . . 127
Fuel tank
installation . . . 77
removing . . . 75
Fuel tank cap
closing . . . 21
opening . . . 20
Fuse
changing the main fuse . . . 110
Fuses . . . 144

G

Gear shift lever
adjusting the basic position . . . 126
checking the basic position . . . 126

H

Hand grip
checking . . . 85
Handbrake lever
adjusting the basic position . . . 89
Handlebar position . . . 54
adjusting . . . 54
Headlight
adjusting headlight range . . . 113
Headlight bulb
changing . . . 112
Headlight mask with headlight
installation . . . 111
removing . . . 111
Headlight setting
checking . . . 112
High-speed compression damping
adjusting the shock absorber . . . 48

I

idle speed
adjusting . . . 124
Idle speed adjustment screw . . . 22
implied warranty . . . 13
Improper use . . . 12
Intended use . . . 12

L

Lamps . . . 144
Lower triple clamp
installation . . . 61
removing . . . 60
Low-speed compression damping
adjusting the shock absorber . . . 47

M

Main fuse
changing . . . 110
Manufacturer's warranty . . . 13
Mapping
changing . . . 124
Motorcycle
cleaning . . . 133
raising with lift stand . . . 56
removing from lift stand . . . 56
Muffler
changing damping material . . . 75
installation . . . 74
removing . . . 74

O

OCU . . . 115
Oil filter
changing . . . 129
Oil screens
cleaning . . . 129
Owner's manual . . . 12

P

Preparing for use
after storage . . . 137
checks and maintenance measures when preparing for use . . . 40
Notes on preparing for first use . . . 35
Protective clothing . . . 11

R

Rear sprocket
checking . . . 82

Rear wheel
installation . . . 102
removing . . . 101

Rebound damping
adjusting the fork . . . 53
adjusting the shock absorber . . . 48

Recycling . . . 155

Refueling
fuel . . . 43

Resources . . . 13

Rider sag
adjusting . . . 52

S

Safe use . . . 10

Seat
mounting . . . 70
removing . . . 69

Service . . . 13

Shock absorber
adjusting the spring preload . . . 51
checking static sag . . . 50
checking the rider sag . . . 50
installation . . . 68
removing . . . 66

spare parts . . . 13

Spoke tension
checking . . . 105

Starting . . . 40

Starting performance of lithium-ion batteries at low temperatures . . . 36

Steering
locking . . . 24
unlocking . . . 24

Steering head bearing
lubricating . . . 65

Steering head bearing play
adjusting . . . 64
checking . . . 63

Storage . . . 136

Swingarm
checking . . . 84

T

Technical specifications
tires . . . 144

Throttle cable play
adjusting . . . 121
checking . . . 121

Throttle cable routing
checking . . . 84

Throttle valve position
programming . . . 125

Tire condition
checking . . . 103

Tire pressure
checking . . . 104

Transportation . . . 43

Turn signal bulb
changing . . . 113

V

Vehicle identification number . . . 16

VIN . . . 16

W

Winter operation
checks and maintenance steps . . . 134

Work rules . . . 11

3215293en

06/08/2026



GASGAS

Stallhofnerstraße 3 / 5230 Mattighofen / Austria / https://www.gasgas.com/