OWNER'S MANUAL **2024**



FE 501s

Art. no. 3402722en

Husqvarna MOTORCYCLES

DEAR HUSQVARNA MOTORCYCLES CUSTOMER

Congratulations on your decision to purchase a Husqvarna motorcycle. You are now the owner of a state-of-the-art sports vehicle which, with appropriate care, will bring you pleasure for a long time to come.

We wish you good and safe riding at all times!

Please enter the serial number of your vehicle below.

Vehicle identification number (📖 p. 17)	Stamp of dealer
Engine number (📖 p. 17)	
Key number (📖 p. 17)	

The Owner's Manual contained the latest information for this model series at the time of publication. However, minor differences due to further developments in design cannot be ruled out completely.

All specifications contained herein are non-binding. Husqvarna Motorcycles GmbH specifically reserves the right to modify or delete technical specifications, prices, colors, forms, materials, services, designs, equipment, etc., without prior notice and without specifying reasons, to adapt these to local conditions, as well as to stop production of a particular model without prior notice. Husqvarna Motorcycles accepts no liability for delivery options, deviations from illustrations and descriptions, as well as misprints and other errors. The models portrayed partly contain special equipment that does not belong to the regular scope of supply.

© 2023 Husqvarna Motorcycles GmbH, Mattighofen Austria

All rights reserved

Reproduction, even in part, as well as copying of all kinds, is permitted only with the express written permission of the copyright owner.

ISO 9001(12 100 6061)
Husqvarna Motorcycles applies quality assurance processes that lead to the highest possible product quality as defined in the ISO 9001 international quality management standard.
Issued by: TÜV Management Service

REG.NO. 12 100 6061

Husqvarna Motorcycles GmbH
Stallhofnerstraße 3
5230 Mattighofen, Austria

This document is valid for the following models:

FE 501s US (F2475X4)

3402722en

30.11.2023

TABLE OF CONTENTS

1 MEANS OF REPRESENTATION 6

1.1 Symbols used 6
1.2 Formats used 6

2 SAFETY ADVICE 7

2.1 Use definition – intended use 7
2.2 Misuse 7
2.3 Safety advice 7
2.4 Degrees of risk and symbols 7
2.5 Overview of labels 8
2.6 Reporting safety defects 10
2.7 Noise emission warranty 10
2.8 Manufacturer warranty for the exhaust monitoring system 10
2.9 Operating noise warning 11
2.10 Consumer rights 11
2.11 Tampering warning 11
2.12 Safe operation 11
2.13 Protective clothing 12
2.14 Work rules 12
2.15 Environment 13
2.16 Owner's Manual 13

3 IMPORTANT NOTES 14

3.1 Manufacturer warranty, implied warranty 14
3.2 Fuel, auxiliary substances 14
3.3 Spare parts, accessories 14
3.4 Service 14
3.5 Figures 14
3.6 Customer service 14

4 VIEW OF VEHICLE 15

4.1 View of vehicle, front left (example) 15
4.2 View of vehicle, rear right (example) 16

5 SERIAL NUMBERS 17

5.1 Vehicle identification number 17
5.2 Type label 17
5.3 Key number 17
5.4 Engine number 17
5.5 Fork part number 18
5.6 Shock absorber article number 18

6 CONTROLS 19

6.1 Clutch lever 19
6.2 Hand brake lever 19
6.3 Throttle grip 19
6.4 Ignition lock 19
6.5 Start button 20
6.6 Stop button 20
6.7 Horn button 20
6.8 Light switch 20
6.9 Turn signal switch 21
6.10 Overview of indicator lights 21
6.11 Opening fuel tank filler cap 21
6.12 Closing the fuel tank filler cap 22
6.13 Cold start button 22
6.14 Idle speed adjusting screw 23
6.15 Shift lever 23
6.16 Foot brake lever 24
6.17 Side stand 24
6.18 Steering lock 24
6.19 Locking the steering 25
6.20 Unlocking the steering 25

7 COMBINATION INSTRUMENT 26

7.1 Combination instrument overview 26
7.2 Activation and test 26
7.3 Setting kilometers or miles 26
7.4 Setting the combination instrument 27
7.5 Setting the clock 28
7.6 Viewing the lap time 28
7.7 Display mode SPEED (speed) 29
7.8 Display mode SPEED/H (operating hours) 29
7.9 Setup menu 29
7.10 Adjusting the unit of measurement 30
7.11 Display mode SPEED/CLK (time) 31
7.12 Setting the clock 31
7.13 Display mode SPEED/LAP (lap time) 31
7.14 Viewing the lap time 32
7.15 Display mode SPEED/ODO (odometer) 32
7.16 Display mode SPEED/TR1 (trip master 1) 33
7.17 Display mode SPEED/TR2 (trip master 2) 33
7.18 Adjusting TR2 (trip master 2) 33
7.19 Display mode SPEED/A1 (average speed 1) 34
7.20 Display mode SPEED/A2 (average speed 2) 34
7.21 Display mode SPEED/S1 (stop watch 1) 35
7.22 Display mode SPEED/S2 (stop watch 2) 35
7.23 Table of functions 36
7.24 Table of conditions and menu activation 37

8 PREPARING FOR USE 38

8.1 Advice on preparing for first use 38

8.2 Running in the engine 39
8.3 Starting power of lithium-ion batteries at low temperatures 40
8.4 Preparing the vehicle for difficult operating conditions 40
8.5 Preparing the vehicle for riding on dry sand 40
8.6 Preparing the vehicle for riding on wet sand 41
8.7 Preparing the vehicle for riding on wet and muddy circuits 41
8.8 Preparing vehicle for high temperatures or slow riding 42
8.9 Preparing the vehicle for low temperatures or snow 42

9 RIDING INSTRUCTIONS 43

9.1 Checks and maintenance measures when preparing for use 43
9.2 Starting the vehicle 43
9.3 Starting off 44
9.4 Shifting, riding 44
9.5 Braking 45
9.6 Stopping, parking 45
9.7 Transporting 46
9.8 Refueling 47

10 SERVICE SCHEDULE 48

10.1 Additional information 48
10.2 Service schedule 48

11 TUNING THE CHASSIS 50

11.1 Checking the basic chassis setting with rider's weight 50
11.2 Compression damping of the shock absorber 50
11.3 Adjusting the low-speed compression damping of the shock absorber 50
11.4 Adjusting the high-speed compression damping of the shock absorber 51
11.5 Adjusting the rebound damping of the shock absorber 52
11.6 Measuring the dimension of the rear wheel unloaded 52
11.7 Checking the static sag of the shock absorber 53
11.8 Checking the riding sag of the shock absorber 53
11.9 Adjusting the spring preload of the shock absorber 54
11.10 Adjusting the riding sag 55
11.11 Checking the basic setting of the fork 55
11.12 Adjusting the compression damping of the fork 56
11.13 Adjusting the rebound damping of the fork 56
11.14 Handlebar position 57
11.15 Adjusting the handlebar position 57

12 SERVICE WORK ON THE CHASSIS 59

12.1 Raising the motorcycle with a lift stand 59
12.2 Removing the motorcycle from the lift stand 59
12.3 Bleeding the fork legs 59
12.4 Cleaning the dust boots of the fork legs 60
12.5 Removing the fork protector 60
12.6 Installing the fork protector 61
12.7 Removing the fork legs 61
12.8 Installing the fork legs 62
12.9 Removing the frame protector 62
12.10 Installing the frame protector 63
12.11 Removing the lower triple clamp 63
12.12 Installing the lower triple clamp 64
12.13 Checking the steering head bearing play 66
12.14 Adjusting the steering head bearing play 66
12.15 Lubricating the steering head bearing 67
12.16 Removing front fender 67
12.17 Installing front fender 68
12.18 Removing the shock absorber 68
12.19 Installing the shock absorber 69
12.20 Removing the seat 71
12.21 Mounting the seat 72
12.22 Removing the air filter box cover 72
12.23 Installing the air filter box cover 72
12.24 Removing the air filter 73
12.25 Installing the air filter 73
12.26 Cleaning the air filter and air filter box 74
12.27 Removing the right side cover 74
12.28 Installing the right side cover 75
12.29 Removing the main silencer 75
12.30 Installing the main silencer 75
12.31 Cleaning spark arrestor 76
12.32 Changing the glass fiber yarn filling in the main silencer 77
12.33 Removing the fuel tank 78
12.34 Installing the fuel tank 79
12.35 Checking for chain dirt accumulation 81
12.36 Cleaning the chain 81
12.37 Checking the chain tension 82

TABLE OF CONTENTS

12.38 Adjusting the chain tension 82
12.39 Checking the chain, rear sprocket, engine sprocket, and chain guide 83
12.40 Checking the frame 86
12.41 Checking the link fork 86
12.42 Checking the throttle cable routing 86
12.43 Checking the rubber grip 87
12.44 Adjusting the basic position of the clutch lever 88
12.45 Checking/correcting the fluid level of hydraulic clutch 88
12.46 Changing the hydraulic clutch fluid 89
12.47 Removing the engine guard 90
12.48 Installing the engine guard 90

13 BRAKE SYSTEM 91

13.1 Adjusting the basic position of the hand brake lever 91
13.2 Checking the brake discs 91
13.3 Checking the front brake fluid level 92
13.4 Adding front brake fluid 92
13.5 Checking that the brake linings of the front brake are secured 93
13.6 Changing the brake linings of the front brake 94
13.7 Checking the free travel of foot brake lever 96
13.8 Adjusting the basic position of the foot brake lever 97
13.9 Checking the rear brake fluid level 98
13.10 Adding rear brake fluid 98
13.11 Checking that the brake linings of the rear brake are secured 99
13.12 Changing the rear brake linings 100

14 WHEELS, TIRES 103

14.1 Removing the front wheel 103
14.2 Installing the front wheel 104
14.3 Removing the rear wheel 104
14.4 Installing the rear wheel 105
14.5 Checking the tire condition 107
14.6 Checking tire pressure 107
14.7 Checking spoke tension 108

15 ELECTRICAL SYSTEM 109

15.1 Removing the 12-V battery 109
15.2 Installing the 12-V battery 110
15.3 Charging the 12-V battery 111
15.4 Changing the main fuse 113
15.5 Removing the headlight mask with the headlight 113
15.6 Installing the headlight mask with the headlight 114
15.7 Changing the headlight bulb 114
15.8 Changing the turn signal bulb 115
15.9 Checking the headlight setting 116
15.10 Adjusting the headlight range 116
15.11 Changing the combination instrument battery 116
15.12 Diagnostics connector 117
15.13 OCU 118

16 COOLING SYSTEM 119

16.1 Cooling system 119
16.2 Checking the antifreeze and coolant level 119
16.3 Checking the coolant level 120
16.4 Draining the coolant 120
16.5 Refilling with coolant 121
16.6 Changing the coolant 122

17 TUNING THE ENGINE 123

17.1 Checking the play in the throttle cable 123
17.2 Adjusting the play in the throttle cable 123
17.3 Adjusting the characteristic map of the throttle response 124
17.4 Adjusting the idle speed 126
17.5 Programming the throttle valve position 126
17.6 Checking the basic position of the shift lever 127
17.7 Adjusting the basic position of the shift lever 127

18 SERVICE WORK ON THE ENGINE 129

18.1 Changing the fuel screen 129
18.2 Checking the engine oil level 130
18.3 Changing the engine oil and oil filter, cleaning the oil screens 130
18.4 Adding engine oil 133

19 CLEANING, CARE 135

19.1 Cleaning the motorcycle 135
19.2 Checks and maintenance steps for winter operation 136

20 STORAGE 137

20.1 Storage 137
20.2 Preparing for use after storage 138

21 TROUBLESHOOTING 139

22 TECHNICAL SPECIFICATIONS 142

22.1 Engine 142
22.2 Engine tightening torques 143

22.3 Capacities 145
22.3.1 Engine oil 145
22.3.2 Coolant 145
22.3.3 Fuel 145
22.4 Chassis 145
22.5 Electrical system 146
22.6 Tires 146
22.7 Fork 146
22.8 Shock absorber 147
22.9 Chassis tightening torques 148

23 SUBSTANCES 151

24 AUXILIARY SUBSTANCES 153

25 STANDARDS 155

26 INDEX OF SPECIAL TERMS 156

27 LIST OF ABBREVIATIONS 157

28 LIST OF SYMBOLS 158

28.1 Yellow and orange symbols 158
28.2 Green and blue symbols 158

INDEX 159

1 MEANS OF REPRESENTATION

1.1 Symbols used

The meaning of specific symbols is described below.

✓	Indicates an expected reaction (e.g. of a work step or a function).
✗	Indicates an unexpected reaction (e.g. of a work step or a function).
	Indicates work that requires expert knowledge and technical understanding. In the interests of your own safety, have these jobs performed by an authorized Husqvarna Motorcycles workshop. Your motorcycle will be cared for there to the highest degree by specially trained experts using the special tools required.
	Indicates a page reference (more information is provided on the specified page).
	Indicates information with more details or tips.
»	Indicates the result of a testing step.
V	Indicates a voltage measurement.
A	Indicates a current measurement.
	Indicates the end of an activity, including potential rework.

1.2 Formats used

The typographical formats used in this document are explained below.

Proprietary name	Indicates a proprietary name.
Name®	Indicates a protected name.
Brand™	Indicates a brand available on the open market.
Underlined terms	Refer to technical details of the vehicle or indicate technical terms, which are explained in the glossary.

2.1 Use definition – intended use

This vehicle has been designed and built to withstand the normal stresses and strains of offroad leisure use.

Info
This vehicle is only authorized for operation on public roads in the homologated (restricted) version.
This vehicle is designed for use in offroad endurance competition, and not primarily for use in motocross.

2.2 Misuse

The vehicle must only be used as intended.
Dangers can arise for people, property and the environment through use not as intended.
Any use of the vehicle beyond the intended and defined use constitutes misuse.
Misuse also includes the use of operating and auxiliary fluids which do not meet the required specification for the respective use.

2.3 Safety advice

A number of safety instructions need to be followed to operate the product described safely. Therefore read this instruction and all further instructions included carefully. The safety instructions are highlighted in the text and are referred to at the relevant passages.

Info
Various information and warning labels are attached in prominent locations on the product described. Do not remove any information or warning labels. If they are missing, you or others may not recognize dangers and may therefore be injured.

2.4 Degrees of risk and symbols

Danger
Identifies a danger that will immediately and invariably lead to fatal or serious permanent injury if the appropriate measures are not taken.


Warning
Identifies a danger that is likely to lead to fatal or serious injury if the appropriate measures are not taken.

Caution
Identifies a danger that may lead to minor injuries if the appropriate measures are not taken.

Note
Identifies a danger that will lead to considerable machine and material damage if the appropriate measures are not taken.

Note
Indicates a danger that will lead to environmental damage if the appropriate measures are not taken.

2.5 Overview of labels



1	Canada type label
1	USA type label
2	Information on noise emission
3	Information on chain tension
4	Information on starting up
5	Information on emissions control

MANUFACTURED BY/FABRIQUÈ PAR:			**KTM AG**			
GVPR/PNBV:	**335**	KG	DATE:	**07/23**		
V.I.N./N.I.V.:	**DUMMY***					
TYPE:	**MC**					
GAWR/PNBE			TIRE/PNEU-DIMENSION-RIM/JANTE		COLD INFL. PRESS PRESS. DE GONFL. À FROID PSI/LPC	KPA
1st	**145**	KG	**90/90-21**	**1.6-21**	**26**	**180**
2nd	**190**	KG	**140/80-18**	**2.15-18**	**26**	**180**

THIS VEHICLE CONFORMS TO ALL APPLICABLE STANDARDS PRESCRIBED UNDER THE CANADIAN MOTOR VEHICLE SAFETY REGULATIONS IN EFFECT ON THE DATE OF MANUFACTURE - CE VÉHICULE EST CONFORME Á TOUTES LES NORMES QUI LUI SONT APPLICABLES ES VERTU DU RÉGLEMENT SUR LA SÉCURITÉ DES VÉHICLES AUTOMOBILES DU CANADA EN VIGUEUR Á LA DATE DE SA FABRICATION

S05815-01

Canada type label

Husqvarna MOTORCYCLES MFD. BY KTM AG AUSTRIA

MOTORCYCLE DATE 07/23

GVWR	**739** lbs		**335** kg				
GAWR FRONT	**320** lbs		**145** kg	WITH	**90/90-21**	TIRE,	**54S** TYPE,
	1.6-21 RIM,	AT	**26** psi	**1.8** bar COLD			
GAWR REAR	**419** lbs		**190** kg	WITH	**140/80-18**	TIRE,	**70R** TYPE,
	2.15-18 RIM,	AT	**26** psi	**1.8** bar COLD			

THIS VEHICLE CONFORMS TO ALL APPLICABLE U.S. FEDERAL MOTOR VEHICLE SAFETY STANDARDS IN EFFECT ON THE DATE OF MANUFACTURER SHOWN ABOVE.

DUMMY*

S05817-01

USA type label


MOTORCYCLE NOISE EMISSION CONTROL INFORMATION
KTM AG, AUSTRIA

THIS 2024 KTMA490510 MOTORCYCLE, A390.05.182.000 MEETS EPA NOISE EMISSION REQUIREMENTS OF 80 dBA AT 5400 RPM BY THE FEDERAL TEST PROCEDURE. MODIFICATIONS WHICH CAUSE THIS MOTORCYCLE TO EXCEED FEDERAL NOISE STANDARDS ARE PROHIBITED BY U.S. FEDERAL LAW. SEE OWNER´S MANUAL.

Motorcycle Type : FE 501s

S05816-01

Information on noise emission




S05806-01

Information on chain tension



S05805-01

Information on starting up



VEHICLE EMISSION CONTROL INFORMATION

Husqvarna MOTORCYCLES **MANUFACTURER: KTM AG, Mattighofen, Austria**
IMPORTER: KTM NORTH AMERICA, INC.

ENGINE DISPLACEMENT	**511 cc**	ENGINE EXHAUST EMISSION CONTROL SYSTEM:	**TBI, HO2S**
ENGINE FAMILY	**RKTXC.511ESF**		
EVAPORATIVE FAMILY	**RKTXU0014SLE**		
PERMEATION FAMILY	**RKTXPP504RP7**	MODEL NAME	**FE 501s**

THIS VEHICLE CONFORMS WITH US EPA AND CALIFORNIA REGULATIONS APPLICABLE TO 2024 MODEL YEAR NEW MOTORCYCLES AND IS CERTIFIED TO 0.8 G/KM HC+NOX, 12 G/KM CO EXHAUST EMISSON STANDARDS IN CALIFORNIA.

ENGINE TUNEUP SPECIFICATIONS:

IGNITION TIMING:	**NON ADJUSTABLE**
IDLE SPEED:	**1850 +/- 50 RPM IN NEUTRAL**
IDLE MIXTURE:	**NON ADJUSTABLE**
VALVE CLEARANCE:	**0.10 - 0.15 mm INTAKE 0.12 - 0.17 mm EXHAUST**
SPARK PLUG:	**NGK LZMAR8BI-10**
SPARK PLUG GAP:	**1.0 mm**
FUEL:	**UNLEADED GASOLINE ONLY - 91 (R+M)/2 OCTANE OR HIGHER**
OIL:	**SAE 10 W 50**

S05814-01

Information on emissions control

2.6 Reporting safety defects

If you believe that your vehicle has a defect which could cause an accident resulting in injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Husqvarna Motorcycles North America, Inc.

If the NHTSA receives multiple similar complaints, it may open an investigation. and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Husqvarna Motorcycles North America, Inc.

You can contact the NHTSA via the toll-free “Auto Safety Hotline” on 1–888–327–4236, visit the www.nhtsa.dot.gov website, or write to: NHTSA Headquarters, 1200 New Jersey Avenue, SE, West Building, Washington, DC 20590, USA. You can also obtain other information about motor vehicle safety from the hotline.

2.7 Noise emission warranty

Husqvarna Motorcycles North America, Inc. guarantees that this exhaust system satisfies all U.S. EPA Federal noise emission standards applicable at the time of sale.

This manufacturer’s warranty extends to the first person who purchases this exhaust system for purposes other than resale, and to all subsequent buyers.

Warranty claims should be directed to:

Husqvarna Motorcycles North America, Inc., c/o KTM North America, Inc., Customer Support, 1119 Milan Ave., Amherst, OH 44001, USA

Phone: (440) 985–3553

www.husqvarna-motorcycles.com

Husqvarna Motorcycles North America, Inc., c/o KTM Canada, Inc., 8701 Rue Samuel-Hatt, Chambly, QC J3L 6V4, Canada

Phone: (450) 441-4451

www.husqvarna-motorcycles.com

2.8 Manufacturer warranty for the exhaust monitoring system

Husqvarna Motorcycles North America, Inc. guarantees that, at the time of sale, the exhaust monitoring system complies with all the standards of the US Environmental Protection Agency (EPA) and the California Air Resources Board (CARB).

This manufacturer warranty applies in respect of the first owner of the motorcycle and all subsequent owners.

Your exhaust monitoring system may include parts, such as the fuel injection system, ignition, catalytic converter, control units, hoses, connectors and other emission related assemblies, fuel tank, crankcase breather, fuel tank lid for vehicles with fuel evaporation monitoring, oil filler cap, pressure control valve, fuel/vapor separator, canister, ignition coils, ignition wire, capacitors and spark plugs, if a fault occurs before the first scheduled replacement; it may also include the hoses, fittings, and pipes that are used directly in these components.

If the warranty conditions are met, Husqvarna Motorcycles will repair your motorcycle for you free of charge, including diagnosis, parts and labor.

As the owner of the motorcycle, you are responsible for the required maintenance specified in the Owner's Manual.

Please note that Husqvarna Motorcycles is entitled to reject warranty claims if your motorcycle or a part fails due to misuse, negligence, an accident, participation in racing or similar events, improper service work, or unauthorized modifications.

Scope of the manufacturer’s warranty

– Five (5) years or 30,000 kilometers (18,641 miles), whichever occurs first.

If you have any questions regarding the manufacturer warranty for the exhaust monitoring system, please address these to:

Husqvarna Motorcycles North America, Inc., c/o KTM North America, Inc., Customer Support, 1119 Milan Ave., Amherst, OH 44001, USA

Phone: (888) 985-6090

U.S. Environmental Protection Agency, 2000 Traverwood Drive, Ann Arbor, MI 48105, USA

California Air Resources Board, 1001 "I" Street, Sacramento, CA 95814, USA

2.9 Operating noise warning

This product should be checked for necessary repair or replacement parts if the motorcycle noise has increased significantly through use. Otherwise, the owner may become subject to penalties under the applicable ordinances.

2.10 Consumer rights

Warranty claims should be submitted to a Husqvarna Motorcycles workshop. If you are not satisfied, please contact:
Husqvarna Motorcycles North America, Inc., c/o KTM North America, Inc., Customer Support, 1119 Milan Ave., Amherst, OH 44001, USA
Phone: (440) 985–3553
www.husqvarna-motorcycles.com
Husqvarna Motorcycles North America, Inc., c/o KTM Canada, Inc., 8701 Rue Samuel-Hatt, Chambly, QC J3L 6V4, Canada
Phone: (450) 441-4451
www.husqvarna-motorcycles.com
Different rights may apply, according to national or regional legislation.

2.11 Tampering warning

Tampering with the noise control system is prohibited. Federal law prohibits the following acts or the causing thereof:

1 The removal or rendering inoperative by any person other than for purposes of servicing, repair, or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use, or
2 the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

Among those acts presumed to constitute tampering are the acts listed below:

1 Removal or puncturing of the main silencers, baffles, manifolds or any other components which conduct emissions.
2 Removal or puncturing of parts of the intake system.
3 Lack of proper maintenance.
4 Replacing moving parts of the vehicle, or parts of the exhaust system or intake system, with parts other than those specified by the manufacturer.

2.12 Safe operation

Danger
Danger of accidents A rider who is not fit to ride poses a danger to him or herself and others.
– Do not operate the vehicle if you are not fit to ride due to alcohol, drugs or medication.
– Do not operate the vehicle if you are physically or mentally impaired.

Danger
Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.
– Always make sure there is sufficient ventilation when running the engine.
– Use effective exhaust extraction when starting or running the engine in an enclosed space.

Warning

Danger of burns Some vehicle components become hot when the vehicle is operated.

– Do not touch any parts such as the exhaust system, radiator, engine, damper, or brake system before the vehicle parts have cooled down.
– Let the vehicle parts cool down before you perform any work on the vehicle.

Only operate the vehicle when it is in perfect technical condition, in accordance with its intended use, and in a safe and environmentally compatible manner.
The vehicle should only be used by trained persons. An appropriate driver's license is needed to drive the vehicle on public roads.
Have malfunctions that impair safety immediately eliminated by an authorized Husqvarna Motorcycles workshop.
Adhere to the information and warning labels on the vehicle.

2.13 Protective clothing

Warning

Risk of injury Missing or poor protective clothing presents an increased safety risk.

– Wear appropriate protective clothing such as helmet, boots, gloves as well as trousers and a jacket with protectors on all rides.
– Always wear protective clothing that is in good condition and meets the legal regulations.

In the interest of your own safety, Husqvarna Motorcycles recommends that you only operate the vehicle while wearing protective clothing.

2.14 Work rules

Unless specified otherwise, the ignition must be turned off during all work (models with ignition lock, models with transponder key) or the motor must be at a standstill (models without ignition lock or transponder key).
Special tools are necessary for certain tasks. The tools are not a component of the vehicle, but can be ordered using the number in parentheses. Example: bearing puller (15112017000)
Unless otherwise noted, normal conditions apply to all tasks and descriptions.

Ambient temperature	20 °C (68 °F)
Ambient air pressure	1,013 mbar (14.69 psi)
Relative air humidity	60 ± 5 %

During assembly, use new parts to replace parts which cannot be reused (e.g. self-locking screws and nuts, expansion screws, seals, sealing rings, O-rings, pins, and lock washers).
In the case of certain screws, a screw adhesive (e.g. **Loctite®**) is required. Observe the manufacturer's instructions.
If thread locker (e.g., **Precote®**) has already been applied to a new part, do not apply any additional thread locker.
After disassembly, clean the parts that are to be reused and check them for damage and wear. Change damaged or worn parts.
After completing a repair or service work, check the operating safety of the vehicle.

2.15 Environment

If you use your motorcycle responsibly, you can ensure that problems and conflicts do not occur. To protect the future of the motorcycle sport, make sure that you use your motorcycle legally, display environmental consciousness, and respect the rights of others.
When disposing of used oil, other operating and auxiliary fluids, and used components, comply with the laws and regulations of the respective country.
Because motorcycles are not subject to the EU regulations governing the disposal of used vehicles, there are no legal regulations that pertain to the disposal of an end-of-life motorcycle. Your authorized Husqvarna Motorcycles dealer will be glad to advise you.

2.16 Owner's Manual

It is important that you read this Owner's Manual carefully and completely before making your first trip. The Owner's Manual contains useful information and many tips on how to operate, handle, and service your motorcycle. This is the only way to find out how best to customize the vehicle for your own use and how you can protect yourself from injury.

Tip
Store the Owner's Manual on your terminal device, for example, so that you can read it whenever you need to.

If you would like to know more about the vehicle or have questions on the material you read, please contact an authorized Husqvarna Motorcycles dealer.
The Owner's Manual is an important component of the vehicle. If the vehicle is sold, the Owner's Manual must be downloaded again by the new owner.
The Owner's Manual can be downloaded several times using the QR code or the link on the delivery certificate.

The Owner's Manual is also available for download from your authorized Husqvarna Motorcycles dealer and on the Husqvarna Motorcycles website. A printed copy can also be ordered from your authorized Husqvarna Motorcycles dealer.
International Husqvarna Motorcycles website: www.husqvarna-motorcycles.com

3 IMPORTANT NOTES

3.1 Manufacturer warranty, implied warranty

The work prescribed in the service schedule must only be carried out in an authorized Husqvarna Motorcycles workshop and confirmed in the **Husqvarna Motorcycles Dealer.net**, as otherwise all warranty claims will be void. Damage or secondary damage caused by tampering with and/or conversions on the vehicle are not covered by the manufacturer warranty.

3.2 Fuel, auxiliary substances



Note

Environmental hazard Improper handling of fuel is a danger to the environment.

– Do not allow fuel to enter the groundwater, the soil, or the sewage system.

Use fuels and auxiliary substances in accordance with the Owner's Manual and specification.

3.3 Spare parts, accessories

For your own safety, only use spare parts and accessory products that are approved and/or recommended by Husqvarna Motorcycles, and have them installed by an authorized Husqvarna Motorcycles workshop. Husqvarna Motorcycles accepts no liability for other products and any resulting damage or loss.

The article numbers of some spare parts and accessory products are specified in parentheses in the descriptions. Your authorized Husqvarna Motorcycles dealer will be glad to advise you.

The current **Husqvarna Motorcycles** accessories for your vehicle are available from your authorized Husqvarna Motorcycles dealer and on the Husqvarna Motorcycles website.

International Husqvarna Motorcycles website: www.husqvarna-motorcycles.com

3.4 Service

A prerequisite for perfect operation and prevention of premature wear is that the service, care, and tuning work on the engine and chassis is properly carried out as described in the Owner's Manual. An incorrect suspension setting can lead to damage and breakage of chassis components.

Use of the vehicle under difficult conditions, such as on sand or on wet, dusty and muddy surfaces, can result in significantly increased wear of components, such as the drive train, brake system, air filter or suspension components. For this reason, it may be necessary to inspect or replace parts before the next scheduled service.

It is imperative that you adhere to the stipulated run-in times and service intervals. If you observe these exactly, you will ensure a much longer service life for your motorcycle.

The relevant mileage or time interval is whichever occurs first.

3.5 Figures

The figures contained in the manual may depict special equipment.

In the interest of clarity, some components may be shown disassembled or may not be shown at all. It is not always necessary to disassemble the component to perform the activity in question. Please follow the instructions in the text.


3.6 Customer service

Your authorized Husqvarna Motorcycles dealer will be happy to answer any questions you may have regarding your vehicle and Husqvarna Motorcycles.

A list of authorized Husqvarna Motorcycles dealers can be found on the Husqvarna Motorcycles website.


International Husqvarna Motorcycles website: www.husqvarna-motorcycles.com

4.1 View of vehicle, front left (example)




1. Hand brake lever (p. 19)
2. Clutch lever (p. 19)
3. Fuel tank filler cap
4. Air filter box cover
5. Side stand (p. 24)
6. Engine number (p. 17)
7. Shift lever (p. 23)

4.2 View of vehicle, rear right (example)




1. Horn button (p. 20)
1. Light switch (p. 20)
1. Turn signal switch (p. 21)
2. Start button (p. 20)
2. Stop button (p. 20)
3. Throttle grip (p. 19)
4. Fork compression adjuster
5. Fork rebound adjustment
6. Foot brake lever (p. 24)
7. Level viewer, engine oil
8. Shock absorber compression adjuster
9. Shock absorber rebound adjuster
10. Level viewer for brake fluid, rear

5.1 Vehicle identification number




The vehicle identification number ❶ is stamped on the right side of the steering head.

5.2 Type label



The type label ❶ is fixed to the front of the chest tube.


5.3 Key number



Key number ❶ for the ignition and steering lock is indicated on the **KEYCODECARD**.


Info
You need the key number to order a spare key. Keep the **KEYCODECARD** in a safe place.

5.4 Engine number




Engine number ❶ is embossed on the left side of the engine behind the shift lever.

5.5 Fork part number




The fork part number ❶ is stamped on the inner side of the fork stub.

5.6 Shock absorber article number




Shock absorber article number ❶ is stamped on the top of the shock absorber above the adjusting ring towards the engine side.

6.1 Clutch lever




Clutch lever ❶ is fitted on the handlebar on the left.
The clutch is activated hydraulically and adjusts itself automatically.

6.2 Hand brake lever




The hand brake lever ❶ is fitted on the right side of the handlebar.
The hand brake lever is used to activate the front brake.

6.3 Throttle grip



The throttle grip ❶ is fitted on the right side of the handlebar.

6.4 Ignition lock



Ignition lock ❶ is located to the right of the combination instrument.

Possible states

	Ignition off – In this position, the ignition circuit is interrupted, a running engine stops, and a non-running engine will not start.
	Ignition on – In this position, the ignition circuit is closed and the engine can be started.

6.5 Start button



Start button ❶ is fitted on the right side of the handlebar.

Possible states

- The start button ⓢ is in the basic position
- The start button ⓢ is pressed – The starter motor is actuated in this position.

6.6 Stop button




The stop button ❶ is located on the right side of the handlebar.

Possible states

- The stop button ⊠ is in the basic position – In this position, the ignition circuit is closed and the engine can be started.
- Stop button ⊠ pressed – In this position, the ignition circuit is interrupted, a running engine stops, and a non-running engine will not start.

6.7 Horn button




Horn button ❶ is fitted on the left side of the handlebar.

Possible states

- The horn button is in the basic position
- The horn button is pressed – The horn is operated in this position.

6.8 Light switch




The light switch ❶ is fitted on the left side of the handlebar.

Possible states

	Low beam on – The light switch is turned downward. In this position, the low beam and tail light are switched on.
	High beam on – The light switch is turned upward. In this position, the high beam and the tail light are switched on.

6.9 Turn signal switch



Turn signal switch ❶ is fitted on the left side of the handlebar.

Possible states

	Turn signal light off
⇦	Turn signal light, left, on – The turn signal switch is pressed to the left. The turn signal switch returns to the middle position after activation.
⇨	Turn signal light, right, on – The turn signal switch is pressed to the right. The turn signal switch returns to the middle position after activation.

To switch off the turn signal, press the turn signal switch toward the switch housing.

6.10 Overview of indicator lights



Possible states

	The high beam indicator lamp lights up blue – The high beam is switched on.
	Malfunction indicator lamp lights up/flashes yellow – The OBD has detected an error in the vehicle electronics. Come safely to a halt, and contact an authorized Husqvarna Motorcycles workshop.
	The fuel level warning lamp lights up yellow – The fuel level has reached the reserve mark.
	Turn signal indicator lamp flashes green – The turn signal is switched on.

6.11 Opening fuel tank filler cap

Danger

Fire hazard Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

- Do not fuel the vehicle in the vicinity of open flames or lit cigarettes.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it off immediately.
- Observe the specifications for refueling.

Warning


Danger of poisoning Fuel is harmful to health.

- Avoid skin, eye and clothing contact with fuel.
- Immediately consult a doctor if you swallow fuel.
- Do not inhale fuel vapors.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse the eyes thoroughly with water, and consult a doctor in case of fuel contact with the eyes.
- Change your clothing if fuel spills on them.
- Keep fuels correctly in a suitable canister, and out of the reach of children.

Note


Environmental hazard Improper handling of fuel is a danger to the environment.

– Do not allow fuel to enter the groundwater, the soil, or the sewage system.



– Press release button 1, turn the fuel tank filler cap counter-clockwise, and lift it off.

6.12 Closing the fuel tank filler cap




– Mount fuel tank filler cap and turn it clockwise until the release button 1 engages.

Info

Route fuel tank breather hose 2 without kinks.

6.13 Cold start button



The cold start button 1 is fitted to the bottom of the throttle valve body.

The electronic fuel injection system extends the injection time if the engine is cold and the ambient temperature is low. To help the engine burn the increased fuel quantity, it must be supplied with additional oxygen by pushing the cold start button.

After briefly opening up the throttle and then releasing the throttle grip again, or turning the throttle grip towards the front, the cold start button returns to its original position.


Info

Check whether the cold start button has returned to its basic position.

Possible states

- The cold start button is activated – The cold start button is pushed in all the way.
- The cold start button is deactivated – The cold start button is in its basic position.

6.14 Idle speed adjusting screw



The idle speed is adjusted using the idle speed adjusting screw ❶.


Increase the idle speed by turning the idle speed adjusting screw clockwise.

Decrease the idle speed by turning the idle speed adjusting screw counterclockwise.


The idle setting of the throttle valve body substantially influences the vehicle's starting behavior, a stable idle speed, and the vehicle's response when the throttle is opened.

An engine with a correctly set idle speed is easier to start than an engine with the idle speed set incorrectly.

6.15 Shift lever




Shift lever ❶ is mounted on the left of the engine.



The gear positions can be seen in the figure.


The neutral or idle position is between the first and second gears.

6.16 Foot brake lever




Foot brake lever ❶ is located in front of the right footrest.
The rear brake is engaged with the foot brake lever.

6.17 Side stand




The side stand ❶ is attached to the left side of the vehicle.



The side stand is used for parking the motorcycle.

Info
When you are riding, side stand ❶ must be folded up and secured with rubber strap ❷.

6.18 Steering lock




Steering lock ❶ is fitted on the left side of the steering head.
The steering lock is used to lock the steering. Steering, and therefore riding, is no longer possible.

6.19 Locking the steering

Note

Danger of damage The parked vehicle can roll away or fall over.

– Park the vehicle on a firm and level surface.



– Park the vehicle.
– Turn handlebar as far as possible to the right.
– Lubricate the steering lock regularly.


Universal oil spray (📖 p. 154)

– Insert the key for the steering lock into the steering lock (📖 p. 24), turn it to the left, push it in, and turn it to the right. Pull out the key for the steering lock.

✓ Steering is no longer possible.

Info
Never leave the key for the steering lock in the steering lock.

6.20 Unlocking the steering




– Insert the key for the steering lock into the steering lock (📖 p. 24), turn it to the left, pull it out, and turn it to the right. Pull out the key for the steering lock.

✓ The handlebar can now be moved again.

Info
Never leave the key for the steering lock in the steering lock.

7.1 Combination instrument overview




V00799-01

– Press the button + to control different functions.
– Press the button − to control different functions.

Info
When the vehicle is delivered, only the **SPEED/H** and **SPEED/ODO** display modes are activated.

7.2 Activation and test



400313-01

Activating combination instrument
The combination instrument is activated when one of the buttons is pressed or an impulse comes from the wheel speed sensor.

Display test
To enable you to check that the display is functioning properly, all display segments light up briefly.



400314-01


WS (wheel size)
After the display function check, the wheel circumference **WS** is displayed briefly.

Info
The number 2205 equals the circumference of the 21" front wheel with standard tires.

The display then changes to the last selected mode.

7.3 Setting kilometers or miles

Info
If you change the unit, the value **ODO** is retained and converted accordingly.
The values **TR1**, **TR2**, **A1**, **A2** and **S1** are cleared when the unit of measure is changed.



400329-01

Condition
The motorcycle is stationary.

– Repeatedly press the button + briefly until **H** appears at the bottom right of the display.
– Press the button + for 2–3 seconds.
  ✓ The Setup menu is displayed and the active functions are shown.
– Repeatedly press the button + briefly until **Km/h** / **Mph** flashes.

Adjusting the Km/h
  – Press the button +.

Adjusting the Mph

– Press the button −.

– Wait 3 - 5 seconds.

✓ The settings are stored.


Info

If no button is pressed for 10–12 seconds, or if an impulse comes from the wheel speed sensor, the settings are automatically saved and the setup menu is closed.

7.4 Setting the combination instrument

Info

When the vehicle is delivered, only the **SPEED/H** and **SPEED/ODO** display modes are activated.



Condition

The motorcycle is stationary.

– Repeatedly press the button + briefly until **H** appears at the bottom right of the display.

– Press the button + for 2–3 seconds.

✓ The Setup menu is displayed and the active functions are shown.

Info

If no button is pressed for 10–12 seconds, the settings are automatically saved.

If no button is pressed for 20 seconds, or if an impulse comes from the wheel speed sensor, the settings are automatically saved and the setup menu is closed.

– Repeatedly press the button + briefly until the desired function flashes.

✓ The selected function flashes.

Activating the function

– Press the button +.


✓ The symbol continues to appear in the display and the next function appears.

Deactivating a function

– Press the button −.

✓ The symbol disappears in the display and the next function appears.

7.5 Setting the clock




Condition
The motorcycle is stationary.

– Repeatedly press the button + briefly until **CLK** appears at the bottom right of the display.
– Press the button + for 2–3 seconds.
  ✓ The hour display flashes.
– Adjust the hour display with button + and/or button −.
– Wait 3 - 5 seconds.
  ✓ The next segment of the display flashes and can be set.
– You can set the following segments in the same way as the hours by pressing the button + and the button −.

Info
The seconds can only be set to zero.
If no button is pressed for 15–20 seconds, or if an impulse comes from the wheel speed sensor, the settings are automatically saved and the setup menu is closed.

7.6 Viewing the lap time

Info
This function can only be opened if lap times have actually been timed.



Condition
The motorcycle is stationary.

– Repeatedly press the button + briefly until **LAP** appears at the bottom right of the display.
– Briefly press the button +.
  ✓ **LAP 1** appears on the left side of the display.
– The laps 1–10 can be viewed with the button −.
– Press and hold the button + for 3-5 seconds.
  ✓ The lap times are deleted.
– Briefly press the button +.
  ✓ Next display mode

Info
When an impulse is received from the wheel speed sensor, the left side of the display changes back to the **SPEED** mode.

7.7 Display mode SPEED (speed)



– Repeatedly press the button + briefly until **SPEED** appears on the left side of the display.

The current speed is displayed in the **SPEED** display mode.
The current speed can be displayed in **Km/h** or **Mph**.

Info
Make the setting according to the country.
When an impulse comes from the front wheel, the left side of the display changes to the **SPEED** mode and the current speed is shown.

7.8 Display mode SPEED/H (operating hours)



Condition
- The motorcycle is stationary.


– Repeatedly press the button + briefly until **H** appears at the bottom right of the display.

In display mode **H**, the operating hours of the engine are displayed.
The operating hour counter stores the total traveling time.

Info
The operating hour counter is necessary for ensuring that service work is carried out at the right intervals.
If the combination instrument is in **H** display mode when starting off, it automatically changes to the **ODO** display mode.
The **H** display mode is suppressed during the journey.

Press the button + for 2–3 seconds.	The display changes to the functions setup menu.
Briefly press the button +.	Next display mode
Press the button − for 2–3 seconds.	No function
Briefly press the button −.	No function

7.9 Setup menu



Condition
- The motorcycle is stationary.


– Repeatedly press the button + briefly until **H** appears at the bottom right of the display.
– Press the button + for 2–3 seconds.

The Setup menu displays the active functions.

Info
Repeatedly press the button + briefly until the desired function is reached.
If no button is pressed for 20 seconds, the settings are automatically saved.

Briefly press the button +.	Activates the flashing display and changes to the next display
Press the button + for 2–3 seconds.	No function
Briefly press the button −.	Deactivates the flashing display and changes to the next display
Press the button − for 2–3 seconds.	No function
Wait 3 - 5 seconds.	Changes to the next display without changes
Wait 10 - 12 seconds.	Setup menu starts, stores the settings, and changes to **H** or **ODO**.

7.10 Adjusting the unit of measurement



Condition

- The motorcycle is stationary.


– Repeatedly press the button + briefly until **H** appears at the bottom right of the display.
– Press the button + for 2–3 seconds.
– Repeatedly press the button + briefly until **Km/h** / **Mph** flashes.

In measurement unit mode, you can change the unit of measurement.

Info
If no button is pressed for 5 seconds, the settings are automatically saved.

Briefly press the button +.	Starts selection, activates **Km/h** display
Press the button + for 2–3 seconds.	No function
Briefly press the button −.	Activates **Mph** display
Press the button − for 2–3 seconds.	No function
Wait 3 - 5 seconds.	Changes to the next display, changes from selection to the Setup menu
Wait 10 - 12 seconds.	Stores and closes the Setup menu

7.11 Display mode SPEED/CLK (time)



– Repeatedly press the button + briefly until **CLK** appears at the bottom right of the display.

The time is shown in display mode **CLK**.

Press the button + for 2–3 seconds.	The display changes to the Setup menu of the clock.
Briefly press the button +.	Next display mode
Press the button − for 2–3 seconds.	No function
Briefly press the button −.	No function

7.12 Setting the clock



Condition

- The motorcycle is stationary.

– Repeatedly press the button + briefly until **CLK** appears at the bottom right of the display.

– Press the button + for 2–3 seconds.

Press the button + for 2–3 seconds.	Increases the value
Briefly press the button +.	Increases the value
Press the button − for 2–3 seconds.	Reduces the value
Briefly press the button −.	Reduces the value
Wait 3 - 5 seconds.	Changes to the next value
Wait 10 - 12 seconds.	Exit the Setup menu

7.13 Display mode SPEED/LAP (lap time)



– Repeatedly press the button + briefly until **LAP** appears at the bottom right of the display.

In the **LAP** display mode, up to 10 lap times can be timed with the stop watch.

Info
If the lap time continues running after the button − is pressed, 9 memory locations are occupied.
Lap 10 must be timed using the button +.

Press the button + for 2–3 seconds.	The stop watch and the lap time are reset.

Briefly press the button +.	Next display mode
Press the button − for 2–3 seconds.	Stops the clock.
Briefly press the button −.	Starts the stop watch or stop the current lap time measurement, stores it and the stop watch starts the next lap.

7.14 Viewing the lap time



400321-01

Condition

- The motorcycle is stationary.

– Repeatedly press the button + briefly until **LAP** appears at the bottom right of the display.

– Briefly press the button +.

Press the button + for 2–3 seconds.	The stop watch and the lap time are reset.
Briefly press the button +.	Select a lap from 1–10
Press the button − for 2–3 seconds.	No function
Briefly press the button −.	View the next lap time.

7.15 Display mode SPEED/ODO (odometer)




400317-01

– Repeatedly press the button + briefly until **ODO** appears at the bottom right of the display.

The total traveled distance is shown in display mode **ODO**.

Press the button + for 2–3 seconds.	No function
Briefly press the button +.	Next display mode
Press the button − for 2–3 seconds.	No function
Briefly press the button −.	No function

7.16 Display mode SPEED/TR1 (trip master 1)




– Repeatedly press the button + briefly until **TR1** appears at the top right of the display.

TR1 (trip master 1) runs constantly and counts up to 999.9.
You can use it to measure trips or the distance between refueling stops.
TR1 is coupled with **A1** (average speed 1) and **S1** (stop watch 1).

Info
If 999.9 is exceeded, the values of **TR1**, **A1** and **S1** are automatically reset to 0.0.

Press the button + for 2–3 seconds.	Displays of **TR1**, **A1** and **S1** are reset to 0.0.
Briefly press the button +.	Next display mode
Press the button − for 2–3 seconds.	No function
Briefly press the button −.	No function

7.17 Display mode SPEED/TR2 (trip master 2)




– Repeatedly press the button + briefly until **TR2** appears at the top right of the display.

TR2 (trip master 2) runs constantly and counts up to 999.9.

Press the button + for 2–3 seconds.	Clears the values **TR2** and **A2**.
Briefly press the button +.	Next display mode
Press the button − for 2–3 seconds.	Reduces value of **TR2**.
Briefly press the button −.	Reduces value of **TR2**.

7.18 Adjusting TR2 (trip master 2)



Condition
- The motorcycle is stationary.

– Repeatedly press the button + briefly until **TR2** appears at the top right of the display.
– Press the button − for 2–3 seconds until **TR2** flashes.

The displayed value can be set manually with the button + and the button −. This is a very practical function when riding using the road book.

Info
The **TR2** value can also be corrected manually during the journey with the button + and the button −.
If 999.9 is exceeded, the value of **TR2** is automatically reset to 0.0.

Press the button + for 2–3 seconds.	Increases value of **TR2**.
Briefly press the button +.	Increases value of **TR2**.
Press the button − for 2–3 seconds.	Reduces value of **TR2**.
Briefly press the button −.	Reduces value of **TR2**.
Wait 10 - 12 seconds.	Stores and closes the Setup menu.

7.19 Display mode SPEED/A1 (average speed 1)



400325-01

– Repeatedly press the button + briefly until **A1** appears at the top right of the display.

A1 (average speed 1) shows the average speed calculated using **TR1** (trip master 1) and **S1** (stop watch 1).
The calculation of this value is activated by the first impulse of the wheel speed sensor and ends 3 seconds after the last impulse.

Press the button + for 2–3 seconds.	Displays of **TR1**, **A1** and **S1** are reset to 0.0.
Briefly press the button +.	Next display mode
Press the button − for 2–3 seconds.	No function
Briefly press the button −.	No function

7.20 Display mode SPEED/A2 (average speed 2)



400326-01

– Repeatedly press the button + briefly until **A2** appears at the top right of the display.


A2 (average speed 2) shows the average speed on the basis of the current speed if the stop watch **S2** (stop watch 2) is running.

Info
The displayed value can differ from the actual average speed if **S2** was not stopped after the ride.

Briefly press the button +.	Next display mode

Press the button + for 2–3 seconds.	No function
Press the button − for 2–3 seconds.	No function
Briefly press the button −.	No function

7.21 Display mode SPEED/S1 (stop watch 1)




– Repeatedly press the button + briefly until **S1** appears at the top right of the display.

S1 (Stop watch 1) shows the riding time based on **TR1** and continues running as soon as an impulse arrives from the wheel speed sensor.
The calculation of this value starts with the first impulse from the wheel speed sensor and ends 3 seconds after the last impulse.

Press the button + for 2–3 seconds.	Displays of **TR1**, **A1** and **S1** are reset to 0.0.
Briefly press the button +.	Next display mode
Press the button − for 2–3 seconds.	No function
Briefly press the button −.	No function

7.22 Display mode SPEED/S2 (stop watch 2)



– Repeatedly press the button + briefly until **S2** appears at the top right of the display.

S2 (Stop watch 2) is a manual stop watch.
If **S2** is running in the background, the display **S2** flashes.

Press the button + for 2–3 seconds.	The displays of **S2** and **A2** are set to 0,0.
Briefly press the button +.	Next display mode
Press the button − for 2–3 seconds.	No function
Briefly press the button −.	Starts or stops **S2**.

7.23 Table of functions

Display	Press the button + for 2–3 seconds.	Briefly press the button +.	Press the button − for 2–3 seconds.	Briefly press the button −.	Wait 3 - 5 seconds.	Wait 10 - 12 seconds.
Display mode **SPEED/H** (operating hours)	The display changes to the functions setup menu.	Next display mode	No function	No function		
Setup menu	No function	Activates the flashing display and changes to the next display	No function	Deactivates the flashing display and changes to the next display	Changes to the next display without changes	Setup menu starts, stores the settings, and changes to **H** or **ODO**.
Adjusting the unit of measurement	No function	Starts selection, activates **Km/h** display	No function	Activates **Mph** display	Changes to the next display, changes from selection to the Setup menu	Stores and closes the Setup menu
Display mode **SPEED/CLK** (time)	The display changes to the Setup menu of the clock.	Next display mode	No function	No function		
Setting the clock	Increases the value	Increases the value	Reduces the value	Reduces the value	Changes to the next value	Exit the Setup menu
Display mode **SPEED/LAP** (lap time)	The stop watch and the lap time are reset.	Next display mode	Stops the clock.	Starts the stop watch or stop the current lap time measurement, stores it and the stop watch starts the next lap.		
Viewing the lap time	The stop watch and the lap time are reset.	Select a lap from 1–10	No function	View the next lap time.		
Display mode **SPEED/ODO** (odometer)	No function	Next display mode	No function	No function		
Display mode **SPEED/TR1** (trip master 1)	Displays of **TR1**, **A1** and **S1** are reset to 0.0.	Next display mode	No function	No function		
Display mode **SPEED/TR2** (trip master 2)	Clears the values **TR2** and **A2**.	Next display mode	Reduces value of **TR2**.	Reduces value of **TR2**.		

Display	Press the button + for 2–3 seconds.	Briefly press the button +.	Press the button − for 2–3 seconds.	Briefly press the button −.	Wait 3 - 5 seconds.	Wait 10 - 12 seconds.
Adjusting **TR2** (trip master 2)	Increases value of **TR2**.	Increases value of **TR2**.	Reduces value of **TR2**.	Reduces value of **TR2**.		Stores and closes the Setup menu.
Display mode **SPEED/A1** (average speed 1)	Displays of **TR1**, **A1** and **S1** are reset to 0.0.	Next display mode	No function	No function		
Display mode **SPEED/A2** (average speed 2)	No function	Next display mode	No function	No function		
Display mode **SPEED/S1** (stop watch 1)	Displays of **TR1**, **A1** and **S1** are reset to 0.0.	Next display mode	No function	No function		
Display mode **SPEED/S2** (stop watch 2)	The displays of **S2** and **A2** are set to 0,0.	Next display mode	No function	Starts or stops **S2**.		

7.24 Table of conditions and menu activation

Display	The motorcycle is stationary.	Menu can be activated
Display mode **SPEED/H** (operating hours)	•	
Setup menu	•	
Adjusting the unit of measurement	•	
Setting the clock	•	
Display mode **SPEED/LAP** (lap time)		•
Viewing the lap time	•	
Display mode **SPEED/TR1** (trip master 1)		•
Display mode **SPEED/TR2** (trip master 2)		•
Adjusting **TR2** (trip master 2)	•	
Display mode **SPEED/A1** (average speed 1)		•
Display mode **SPEED/A2** (average speed 2)		•
Display mode **SPEED/S1** (stop watch 1)		•
Display mode **SPEED/S2** (stop watch 2)		•

8.1 Advice on preparing for first use

Danger

Danger of accidents A rider who is not fit to ride poses a danger to him or herself and others.

– Do not operate the vehicle if you are not fit to ride due to alcohol, drugs or medication.
– Do not operate the vehicle if you are physically or mentally impaired.

Warning

Risk of injury Missing or poor protective clothing presents an increased safety risk.

– Wear appropriate protective clothing such as helmet, boots, gloves as well as trousers and a jacket with protectors on all rides.
– Always wear protective clothing that is in good condition and meets the legal regulations.

Warning

Danger of crashing Different tire tread patterns on the front and rear wheel impair the handling characteristic.

Different tire tread patterns can make the vehicle significantly more difficult to control.

– Make sure that only tires with a similar tire tread pattern are fitted to the front and rear wheel.

Warning

Danger of accidents An unadapted riding style impairs the handling characteristic.

– Adapt your riding speed to the road conditions and your riding ability.

Warning

Danger of accidents The vehicle is not designed to carry passengers.

– Do not ride with a passenger.

Warning

Danger of accidents The brake system fails in the event of overheating.

If the foot brake lever is not released, the brake linings drag continuously.

– Take your foot off the foot brake lever if you do not want to brake.

Warning

Danger of accidents Total weight and axle loads influence the handling characteristic.

– Do not exceed the maximum permissible overall weight or the axle loads.

Warning

Risk of injury People who act without authorization may not be familiar with the vehicle.

– Do not leave the vehicle unattended if the engine is running.
– Protect the vehicle against access by unauthorized persons.

Info

When using your motorcycle, remember that others may feel disturbed by excessive noise.

– Make sure that the pre-sale inspection work has been carried out by an authorized Husqvarna Motorcycles workshop.
  ✓ You will receive a delivery certificate when the vehicle is handed over.
– Before riding for the first time, read the entire Owner's Manual carefully.
– Get to know the controls.
– Adjust basic position of the clutch lever. (📖 p. 88)

– Adjust basic position of the hand brake lever. (📖 p. 91)
– Adjust the basic position of the foot brake lever. 🔧 (📖 p. 97)
– Adjust the basic position of the shift lever. 🔧 (📖 p. 127)
– Get used to the handling characteristics of the motorcycle on a suitable surface before undertaking more challenging trips.

Info
When offroad, it is recommended that you are accompanied by another person on another vehicle so that you can help each other.

– Try also to ride as slowly as possible and in a standing position to get a better feel for the motorcycle.
– Do not make any off-road trips that exceed your ability and experience.
– Hold the handlebar firmly with both hands and keep your feet on the footrests when riding.
– If you carry any luggage, make sure you fix it firmly as close as possible to the center of the vehicle and ensure even weight distribution between the front and rear wheels.

Info
Motorcycles react sensitively to any changes of weight distribution.

– The maximum permissible overall weight and the maximum permissible axle loads must not be exceeded.
Guideline

Maximum permissible overall weight	335 kg (739 lb.)
Maximum permissible front axle load	145 kg (320 lb.)
Maximum permissible rear axle load	190 kg (419 lb.)

Info
The spoke tension must be checked after half an hour of operation.

– Run the engine in. (📖 p. 39)


8.2 Running in the engine

– Do not exceed the specified engine speed and load during the running-in time.
Guideline

Maximum engine speed	
During the first operating hour	7,000 rpm
Maximum engine performance	
During the first 3 operating hours	≤ 75 %

– Avoid fully opening the throttle.

8.3 Starting power of lithium-ion batteries at low temperatures



Lithium-ion batteries are far lighter than lead batteries, have a low self-discharge rate, and have more starting power at temperatures over 6 °C (43 °F).

Several attempts to start may be required. Press the start button for 5 seconds, and wait 15 seconds between attempts. At low temperatures, wait for 30 seconds. The pauses are necessary so that the heat created can distribute through the lithium-ion battery and the lithium-ion battery is not damaged.

The starting power increases as the battery warms up.

Always make sure the lithium-ion battery is charged to that there is enough power to spare for starting at low temperatures.

After 6 unsuccessful starting attempts, do not try again, and check the vehicle for other errors instead.

8.4 Preparing the vehicle for difficult operating conditions

Info
Use of the vehicle under difficult conditions, such as on sand or on wet and muddy surfaces, can result in significantly increased wear of components, such as the drive train, brake system, or suspension components. For this reason, it may be necessary to inspect or replace parts before the next scheduled service.

– Clean the air filter and air filter box. (p. 74)

Info
Check the air filter approx. every 30 minutes.

– Check the electrical connector for humidity and corrosion and to ensure it is firmly seated.
  » If humidity, corrosion, or damage is found:
    – Clean and dry the connector, or change it if necessary.

Difficult operating conditions are:
- Rides on dry sand. (p. 40)
- Rides on wet sand. (p. 41)
- Rides on wet and muddy circuits. (p. 41)
- Rides at high temperatures or slow riding. (p. 42)
- Riding at low temperatures and in snow. (p. 42)

8.5 Preparing the vehicle for riding on dry sand



– Mount the air filter dust cover.

Air filter dust cover (79006920000)

Info
Read the fitting instructions for **Husqvarna Motorcycles** accessories.



– Mount the air filter sand cover.

Air filter sand cover (79006922000)

Info
Read the fitting instructions for **Husqvarna Motorcycles** accessories.




– Clean the chain.
– Mount the steel sprocket.
– Grease the chain.

Universal oil spray (📖 p. 154)

– Clean the radiator fins.
– Straighten the bent radiator fins carefully.

8.6 Preparing the vehicle for riding on wet sand



– Mount the air filter rain cover.

Air filter rain cover (79006921000)

Info
Read the fitting instructions for **Husqvarna Motorcycles** accessories.



– Clean the chain.
– Mount the steel sprocket.
– Grease the chain.

Universal oil spray (📖 p. 154)

– Clean the radiator fins.
– Straighten the bent radiator fins carefully.

8.7 Preparing the vehicle for riding on wet and muddy circuits



– Mount the air filter rain cover.

Air filter rain cover (79006921000)

Info
Read the fitting instructions for **Husqvarna Motorcycles** accessories.


600868-01

– Mount the steel sprocket.
– Clean the motorcycle. (📖 p. 135)
– Straighten the bent radiator fins carefully.

8.8 Preparing vehicle for high temperatures or slow riding


600868-01

– Adjust the secondary drive to the road conditions.


Info
The engine oil heats up quickly when the clutch is operated frequently due to an excessively high secondary ratio.

– Clean the chain.

Chain cleaner (📖 p. 153)

– Clean the radiator fins.
– Straighten bent radiator fins carefully.
– Check the coolant level. (📖 p. 120)

8.9 Preparing the vehicle for low temperatures or snow



102137-01


– Mount the air filter rain cover.

Air filter rain cover (79006921000)

Info
Read the fitting instructions for **Husqvarna Motorcycles** accessories.

9.1 Checks and maintenance measures when preparing for use

Info
Before every trip, check the condition of the vehicle and ensure that it is safe to operate.
The vehicle must be in perfect technical condition when it is being operated.


H02217-01

- Check the engine oil level. (📖 p. 130)
- Check the electrical system.
- Check the front brake fluid level. (📖 p. 92)
- Check the rear brake fluid level. (📖 p. 98)
- Check that the brake linings of the front brake are secured. (📖 p. 93)
- Check that the brake linings of the rear brake are secured. (📖 p. 99)
- Check that the brake system is functioning properly.
- Check the coolant level. (📖 p. 120)
- Check for chain dirt accumulation. (📖 p. 81)
- Check the chain, rear sprocket, engine sprocket, and chain guide. (📖 p. 83)
- Check the chain tension. (📖 p. 82)
- Check the tire condition. (📖 p. 107)
- Check the tire pressure. (📖 p. 107)

Condition

Offroad use

  - Make sure that the rim locks are installed.

- Check the spoke tension. (📖 p. 108)

Info
The spoke tension must be checked regularly as incorrect spoke tension will strongly impair riding safety.

- Clean the dust boots of the fork legs. (📖 p. 60)
- Bleed the fork legs. (📖 p. 59)
- Check the air filter.
- Check the settings of all controls and ensure that they can be operated smoothly.
- Check all screws, nuts, and hose clips regularly for tightness.
- Check the fuel level.

9.2 Starting the vehicle


Danger
Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always make sure there is sufficient ventilation when running the engine.
- Use effective exhaust extraction when starting or running the engine in an enclosed space.

Note

Engine damage High revving speed with a cold engine negatively impacts the lifespan of the engine.

– Always run the engine warm at a low speed.




– Take the motorcycle off side stand ❶ and secure the side stand with rubber strap ❷.
– Shift the transmission into neutral.
– Turn the ignition key in the ignition lock to the position ❍.

Condition

Ambient temperature: < 20 °C (< 68 °F)

– Push the cold start button in all the way.



– Press the start button.

Info

Press the start button for a maximum of 5 seconds.
Wait for 15 seconds before a further attempt at starting.
At low temperatures, wait for 30 seconds.
At temperatures below 6 °C (43 °F), several attempts at starting may be necessary to warm-up the lithium-ion battery and thereby increase the starting power.
After 6 unsuccessful starting attempts, do not try again, and check the vehicle for other errors instead.
During the starting process, the malfunction indicator lamp lights up.

9.3 Starting off

Info

When you are riding, the side stand must be folded up and secured with the rubber strap.

– Pull the clutch lever, shift into first gear, release the clutch lever slowly and at the same time open the throttle carefully.

9.4 Shifting, riding

Warning

Danger of accidents If you change down at high engine speed, the rear wheel blocks and the engine races.

– Do not change into a low gear at high engine speed.

Info

If unusual noises occur while riding, stop immediately, switch off the engine, and contact an authorized Husqvarna Motorcycles workshop.
First-gear is used for starting off and for steep inclines.

– Shift into a higher gear when conditions allow (incline, road situation, etc.). To do so, release the throttle while simultaneously pulling the clutch lever, shift into the next gear, release the clutch lever and open the throttle.
– After reaching maximum speed by fully opening the throttle grip, turn the throttle back so it is ¾ open. This will barely reduce the speed, but fuel consumption will be considerably lower.
– Always open the throttle only as much as the engine can handle – abrupt throttle opening increases fuel consumption.
– To shift down, apply the brakes and close the throttle at the same time.
– Pull the clutch lever and shift into a lower gear, release the clutch lever slowly, and either open the throttle or shift again.
– Switch off the engine if running at idle speed or stationary for a long time.

  Guideline

≥ 2 min

– Avoid frequent and lengthy slipping of the clutch. This causes the engine oil, engine and cooling system to heat up.
– Ride at a low engine speed instead of at a high engine speed with a slipping clutch.

9.5 Braking

Warning
Danger of accidents Excessively forceful application of the brakes blocks the wheels.
– Adjust application of the brakes to the respective riding situation and riding surface conditions.

Warning
Danger of accidents A spongy pressure point on the front or rear brake reduces braking efficiency.
– Check the brake system and do not continue riding until the problem is eliminated. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

Warning
Danger of accidents Moisture and dirt impair the brake system.
– Brake carefully several times to dry out and remove dirt from the brake linings and the brake discs.

– On sandy, wet, or slippery surfaces, use the rear brake.
– Always finish braking before you go into a bend. Change down to a lower gear appropriate to your road speed.
– Use the braking effect of the engine on long downhill stretches. Change down one or two gears, but do not over-rev the engine. You will have to apply the brakes far less frequently as a result and the brake system will not overheat.

9.6 Stopping, parking

Warning
Risk of injury People who act without authorization may not be familiar with the vehicle.
– Do not leave the vehicle unattended if the engine is running.
– Protect the vehicle against access by unauthorized persons.

Warning

Danger of burns Some vehicle components become hot when the vehicle is operated.

– Do not touch any parts such as the exhaust system, radiator, engine, damper, or brake system before the vehicle parts have cooled down.
– Let the vehicle parts cool down before you perform any work on the vehicle.

Note

Material damage The vehicle may be damaged by incorrect procedure when parking.

Significant damage may be caused if the vehicle rolls away or falls over.

The components for parking the vehicle are designed only for the weight of the vehicle.

– Park the vehicle on a firm and level surface.
– Ensure that nobody sits on the vehicle when the vehicle is parked on a stand.

Note

Fire hazard Hot vehicle components pose a fire hazard and explosion risk.

– Do not park the vehicle near to materials which are highly flammable or explosive.
– Allow the vehicle to cool down before covering it.

– Apply the brakes on the motorcycle.
– Shift the transmission into neutral.
– Press and hold the stop button ⊠ while the engine is idling until the engine stops.
– Turn the ignition key in the ignition lock to the position ⊠ while the engine is idling.
– Park the motorcycle on firm ground.

9.7 Transporting

Note

Material damage The vehicle may be damaged by incorrect procedure when parking.

Significant damage may be caused if the vehicle rolls away or falls over.


The components for parking the vehicle are designed only for the weight of the vehicle.

– Park the vehicle on a firm and level surface.
– Ensure that nobody sits on the vehicle when the vehicle is parked on a stand.

Note

Fire hazard Hot vehicle components pose a fire hazard and explosion risk.

– Do not park the vehicle near to materials which are highly flammable or explosive.
– Allow the vehicle to cool down before covering it.


401475-01

– Switch off the engine.
– Use tension belts or other suitable devices to secure the motorcycle against falling over or rolling away.

9.8 Refueling

Danger

Fire hazard Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

- Do not fuel the vehicle in the vicinity of open flames or lit cigarettes.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it off immediately.
- Observe the specifications for refueling.

Warning

Danger of poisoning Fuel is harmful to health.

- Avoid skin, eye and clothing contact with fuel.
- Immediately consult a doctor if you swallow fuel.
- Do not inhale fuel vapors.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse the eyes thoroughly with water, and consult a doctor in case of fuel contact with the eyes.
- Change your clothing if fuel spills on them.

Note

Material damage Inadequate fuel quality causes the fuel filter to quickly become clogged.


In some countries and regions, the available fuel quality and cleanliness may not be sufficient. This will result in problems with the fuel system.

- Refuel only with clean fuel that meets the specified standards. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

Note

Environmental hazard Improper handling of fuel is a danger to the environment.

- Do not allow fuel to enter the groundwater, the soil, or the sewage system.



- Switch off engine.
- Open fuel tank filler cap. (p. 21)
- Fill the fuel tank with fuel up to measurement A.

  Guideline

Measurement of A	35 mm (1.38 in)

Total fuel tank capacity, approx.	8.0 l (2.11 US gal)	Super unleaded (ROZ 95) (p. 152)

- Close the fuel tank filler cap. (p. 22)

10.1 Additional information

Any further work that results from the service work must be ordered separately and invoiced separately.
Different service intervals may apply in your country, depending on the local operating conditions.
Individual service intervals and scopes may change in the course of technical developments. The most up-to-date service schedule can always be found on Husqvarna Motorcycles Dealer.net. Your authorized Husqvarna Motorcycles dealer will be glad to advise you.

10.2 Service schedule

	after 70 km (43.4 mi)	every 1,000 km (620 mi)	every 3,000 km (1,860 mi)	every 6,000 km (3,720 mi)	every 24 months
Read out the fault memory using the Husqvarna Motorcycles diagnostics tool. 🔧	○	●	●	●	●
Program the gear position sensor. 🔧		●	●	●	
Check that the electrical system is functioning properly.	○	●	●	●	
Check and charge the 12-V battery. 🔧		●	●	●	●
Check that the brake linings of the front brake are secured. (📖 p. 93)		●	●	●	●
Check that the brake linings of the rear brake are secured. (📖 p. 99)		●	●	●	●
Check the brake discs. (📖 p. 91)		●	●	●	●
Check the brake lines for damage and tightness.		●	●	●	●
Check the front brake fluid level. (📖 p. 92)		●	●		
Change the front brake fluid. 🔧				●	●
Check the rear brake fluid level. (📖 p. 98)		●	●		
Change the rear brake fluid. 🔧				●	●
Check/correct the fluid level of hydraulic clutch. (📖 p. 88)			●		
Change the hydraulic clutch fluid. 🔧 (📖 p. 89)				●	●
Check the free travel of the hand brake lever. 🔧	○	●	●	●	●
Check the free travel of the foot brake lever. (📖 p. 96)		●	●	●	●
Check the idle speed. 🔧 ** *see footnotes below*	○	●	●	●	●
Change the engine oil and the oil filter, clean the oil screens. 🔧 (📖 p. 130)	○	●	●	●	●
Check all hoses (e.g. fuel, cooling, bleeder, drainage hoses, etc.) and sleeves for cracking, tightness, and correct routing. 🔧	○	●	●	●	●
Check the cables for damage and that there are no kinks in the routing. 🔧		●	●	●	●
Check that the throttle cables are undamaged, routed without kinks, and set correctly.		●	●	●	
Check the frame. 🔧 (📖 p. 86)		●	●	●	
Check the link fork. 🔧 (📖 p. 86)		●	●	●	
Check the fork bearing for play. 🔧			●	●	
Check the shock absorber heim joint for play.			●	●	
Check the shock absorber linkage. 🔧		●	●	●	
Check the tire condition. (📖 p. 107)		●	●	●	●
Check the tire pressure. (📖 p. 107)		●	●	●	●
Check the wheel bearing for play. 🔧		●	●	●	
Check the wheel hubs. 🔧		●	●	●	
Check the rim run-out. 🔧	○	●	●	●	
Check the spoke tension. (📖 p. 108)	○	●	●	●	

** For California residents only: Inspection and Adjustment provided free-of-charge up to 5 years or 30,000 km, whichever occurs first.

	after 70 km (43.4 mi)	every 1,000 km (620 mi)	every 3,000 km (1,860 mi)	every 6,000 km (3,720 mi)	every 24 months
Check the chain, rear sprocket, engine sprocket, and chain guide. (📖 p. 83)	○	●	●	●	
Check the chain tension. (📖 p. 82)	○	●	●	●	●
Grease all moving parts (e.g. side stand, hand lever, chain, etc.) and check for smooth operation. 🔧	○	●	●	●	●
Check the valve clearance. 🔧 *** see footnotes below*	○		●	●	
Change the fuel filter. 🔧				●	●
Check the clutch. 🔧			●	●	
Clean the air filter and air filter box. 🔧 (📖 p. 74)		●	●	●	●
Check the inlet membrane. 🔧			●	●	
Change the glass fiber yarn filling in the main silencer. 🔧 (📖 p. 77)			●	●	
Service the fork. 🔧			●	●	
Perform the shock absorber service. 🔧			●	●	
Check all screws, nuts, and hose clips for a tight fit. 🔧	○	●	●	●	●
Change the fuel screen. 🔧 (📖 p. 129)	○	●	●	●	●
Check the fuel pressure. 🔧	○		●	●	●
Check the antifreeze and coolant level. (📖 p. 119)			●	●	
Check the coolant level. (📖 p. 120)	○	●			
Change the coolant. 🔧 (📖 p. 122)					●
Check that the radiator fan is functioning properly. 🔧	○	●	●	●	
Check the steering head bearing for play. (📖 p. 66)	○	●			
Lubricate the steering head bearing. 🔧 (📖 p. 67)			●	●	●
Check the headlight setting. (📖 p. 116)		●	●	●	
Clean spark arrestor. 🔧 (📖 p. 76)				●	●
Perform engine service including removing and installing the engine. (Change the spark plug and spark plug connector. Change the piston. Check/measure the cylinder. Check the cylinder head. Change the valves, valve springs, valve spring retainers and valve spring seats. Check the camshaft, rocker arm and rocker arm shafts. Change the connecting rod, conrod bearing and crank pin. Check the transmission and the shift mechanism. Check the oil pressure control valve. Change the suction pump. Check the force pump and lubrication system. Check the timing assembly. Change the timing chain. Change all engine bearings and all gaskets. Change the freewheel.) 🔧				●	
Final check: Check the vehicle is roadworthy and take a test ride. 🔧	○	●	●	●	●
Read out the fault memory after the test ride using the Husqvarna Motorcycles diagnostics tool. 🔧	○	●	●	●	●
Make a service entry in **Husqvarna Motorcycles Dealer.net**. 🔧	○	●	●	●	●


○ One-time interval

● Periodic interval

** For California residents only: Inspection and Adjustment provided free-of-charge up to 5 years or 30,000 km, whichever occurs first.

11.1 Checking the basic chassis setting with rider's weight

Info
When adjusting the basic chassis setting, first adjust the shock absorber and then the fork.



- For optimal motorcycle riding characteristics and to avoid damage to forks, shock absorbers, link fork and frame, the basic settings of the suspension components must match the rider's weight.
- As delivered, Husqvarna motorcycles are adjusted for an average rider's weight (with full protective clothing).

  Guideline

Standard rider weight	75 … 85 kg (165 … 187 lb.)

- If the rider's weight is above or below this range, the basic setting of the suspension components must be adjusted accordingly.
- Small weight differences can be compensated by adjusting the spring preload, but in the case of large weight differences, the springs must be replaced.

11.2 Compression damping of the shock absorber

The compression damping of the shock absorber is divided into two ranges: high-speed and low-speed.
High-speed and low-speed refer to the compression speed of the rear wheel suspension and not to the vehicle speed.
The high-speed compression adjuster has an effect, for example, when landing after a jump: the rear wheel suspension compresses quickly.
The low-speed compression adjuster has an effect, for example, when riding over long ground swells: the rear wheel suspension compresses slowly.
These two ranges can be adjusted separately, although the transition between high-speed and low-speed is gradual. Thus, modifications in the high-speed range affect the compression damping in the low-speed range and vice versa.


11.3 Adjusting the low-speed compression damping of the shock absorber

Caution
Risk of injury Parts of the shock absorber will move around if the shock absorber is detached incorrectly.

The shock absorber is filled with highly compressed nitrogen.

- Please follow the description provided. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

Info
The effect of the low-speed compression adjuster can be seen in slow to normal compression of the shock absorber.



– Turn adjuster 1 clockwise all the way to the stop.
– Turn counterclockwise by the number of clicks corresponding to the shock absorber type.

Guideline

Lowspeed compression damping	
Comfort	18 clicks
Standard	15 clicks
Sport	12 clicks

Info
Turn clockwise to increase damping; turn counterclockwise to reduce damping.


11.4 Adjusting the high-speed compression damping of the shock absorber

Caution
Risk of injury Parts of the shock absorber will move around if the shock absorber is detached incorrectly.

The shock absorber is filled with highly compressed nitrogen.

– Please follow the description provided. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

Info
The effect of the high speed compression adjuster can be seen in the fast compression of the shock absorber.



– Turn adjuster 1 clockwise all the way to the stop.
– Turn counterclockwise by the number of turns corresponding to the shock absorber type.

Guideline

Highspeed compression damping	
Comfort	2.5 turns
Standard	2 turns
Sport	1.5 turns

Info
Turn clockwise to increase damping; turn counterclockwise to reduce damping.


11.5 Adjusting the rebound damping of the shock absorber

Caution

Risk of injury Parts of the shock absorber will move around if the shock absorber is detached incorrectly.

The shock absorber is filled with highly compressed nitrogen.

– Please follow the description provided. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



– Turn adjusting screw ❶ clockwise up to the last perceptible click.
– Turn counterclockwise by the number of clicks corresponding to the shock absorber type.


Guideline

Rebound damping	
Comfort	18 clicks
Standard	15 clicks
Sport	12 clicks

Info

Turn clockwise to increase the damping; turn counterclockwise to reduce damping when the shock absorber rebounds.

11.6 Measuring the dimension of the rear wheel unloaded



Preparatory work

– Raise the motorcycle with a lift stand. (p. 59)

Main work

– Position the sag gage in the rear axle and measure the distance to marking **SAG** on the rear fender.


Sag gage (00029090200)

– Note the value as dimension Ⓐ.

Finishing work

– Remove the motorcycle from the lift stand. (p. 59)

11.7 Checking the static sag of the shock absorber



– Measure dimension Ⓐ of rear wheel unloaded. (📖 p. 52)
– Hold the motorcycle upright with aid of an assistant.
– Measure the distance again between the rear axle and marking **SAG** on the rear fender using the sag gage.
– Note the value as dimension Ⓑ.


Info
The static sag is the difference between measurements Ⓐ and Ⓑ.

– Check the static sag.

Static sag	40 mm (1.57 in)

» If the static sag is less or more than the specified value:
– Adjust the spring preload of the shock absorber. 🔧 (📖 p. 54)

11.8 Checking the riding sag of the shock absorber



– Measure dimension Ⓐ of rear wheel unloaded. (📖 p. 52)
– With another person holding the motorcycle, the rider, wearing full protective clothing, sits on the seat in a normal sitting position (feet on footrests) and bounces up and down a few times.
✔ The rear wheel suspension levels out.
– Another person again measures the distance between the rear axle and marking **SAG** on the rear fender using the sag gage.
– Note the value as dimension Ⓒ.

Info
The riding sag is the difference between measurements Ⓐ and Ⓒ.

– Check riding sag.
Guideline

Riding sag	110 mm (4.33 in)

» If the riding sag differs from the specified measurement:
– Adjust the riding sag. 🔧 (📖 p. 55)

11.9 Adjusting the spring preload of the shock absorber

Caution

Risk of injury Parts of the shock absorber will move around if the shock absorber is detached incorrectly.

The shock absorber is filled with highly compressed nitrogen.


– Please follow the description provided. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

Info

Before changing the spring preload, make a note of the present setting, e.g., by measuring the spring length.

Preparatory work

– Raise the motorcycle with a lift stand. (p. 59)
– Remove the right side cover. (p. 74)
– Remove the frame protector. (p. 62)
– Remove the shock absorber. (p. 68)
– After removing the shock absorber, clean it thoroughly.



Main work

– Loosen screw 1.
– Turn adjusting ring 2 until the spring is no longer under tension.

Hook wrench (90129051000)

Info

If the spring cannot be fully released, the spring must be removed to accurately measure the spring length.

– Measure the total spring length while the spring is not under tension.
– Tension the spring by turning adjusting ring 2 to specified dimension A.

Guideline

Spring preload	7 mm (0.28 in)

Info

Depending on the static sag and/or the riding sag, it may be necessary to increase or decrease the spring preload.

– Tighten bolt 1.

Guideline

Screw, shock absorber adjusting ring	M5	5 Nm (3.7 lbf ft)

Finishing work


– Install the shock absorber. (p. 69)
– Install the frame protector. (p. 63)
– Install the right side cover. (p. 75)

– Remove the motorcycle from the lift stand. (p. 59)

11.10 Adjusting the riding sag

Preparatory work

– Raise the motorcycle with a lift stand. (p. 59)
– Remove the right side cover. (p. 74)
– Remove the frame protector. (p. 62)
– Remove the shock absorber. (p. 68)
– After removing the shock absorber, clean it thoroughly.


B00292-10

Main work

– Select and mount a suitable spring.

Guideline

Spring rate	
Weight of rider: 65 … 75 kg (143 … 165 lb.)	42 N/mm (240 lb/in)
Weight of rider: 75 … 85 kg (165 … 187 lb.)	45 N/mm (257 lb/in)
Weight of rider: 85 … 95 kg (187 … 209 lb.)	48 N/mm (274 lb/in)


Info
The spring rate is shown on the outside of the spring. Smaller weight differences can be compensated by changing the spring preload.

Finishing work

– Install the shock absorber. (p. 69)
– Install the frame protector. (p. 63)
– Install the right side cover. (p. 75)
– Remove the motorcycle from the lift stand. (p. 59)
– Check the static sag of the shock absorber. (p. 53)
– Check the riding sag of the shock absorber. (p. 53)
– Adjust the rebound damping of the shock absorber. (p. 52)

11.11 Checking the basic setting of the fork


Info
For various reasons, no exact riding sag can be determined for the fork.


401000-01

– As with the shock absorber, smaller differences in the rider's weight can be compensated by the spring preload.
– However, if the fork frequently bottoms out (hard end stop on compression), harder springs must be fitted to avoid damage to the fork and frame.
– If the fork feels unusually hard after extended periods of operation, the fork legs need to be bled.

11.12 Adjusting the compression damping of the fork

Info
The hydraulic compression damping determines the fork suspension behavior.



– Turn white adjuster ❶ clockwise as far as it will go.

Info
Adjusters ❶ are located at the top end of the fork legs.

– Turn counterclockwise by the number of clicks corresponding to the fork type.


Guideline

Compression damping	
Comfort	17 clicks
Standard	15 clicks
Sport	7 clicks

Info
Turn clockwise to increase damping; turn counterclockwise to reduce damping during compression.

11.13 Adjusting the rebound damping of the fork

Info
The hydraulic rebound damping determines the fork suspension behavior.



– Turn red adjuster ❶ clockwise as far as it will go.

Info
Adjusters ❶ are located at the bottom end of the fork legs.


– Turn counterclockwise by the number of clicks corresponding to the fork type.

Guideline

Rebound damping	
Comfort	19 clicks
Standard	17 clicks
Sport	9 clicks

Info
Turn clockwise to increase the damping; turn counterclockwise to reduce damping when the shock absorber rebounds.

11.14 Handlebar position



The holes on the handlebar supports are placed at a distance of Ⓐ from the center.

Hole distance Ⓐ	3.5 mm (0.138 in)

The handlebar supports can be mounted in two different positions.


11.15 Adjusting the handlebar position

Warning

Danger of accidents A repaired handlebar poses a safety risk.

If the handlebar is bent or straightened, the material becomes fatigued. The handlebar may break as a result.

– Change the handlebar if the handlebar is damaged or bent.



– Remove screws ❶. Take off the handlebar clamps. Take off the handlebar and lay it to one side.

Info

Cover the components to protect them against damage.

Do not bend the cables and lines.

– Remove screws ❷. Take off the handlebar supports.

– Place the handlebar supports in the required position. Mount and tighten screws ❷.

Guideline

Screw, handlebar holder	M10	40 Nm (29.5 lbf ft) **Loctite®243™**

Info

Position the left and right handlebar holders evenly.

– Position the handlebar.

Info
Make sure the cables and wiring are positioned correctly.


– Position the handlebar clamps. Mount and tighten screws ❶ evenly.

Guideline

Screw, handlebar clamp	M8	20 Nm (14.8 lbf ft)

Info
Make sure the gap width is even.

12.1 Raising the motorcycle with a lift stand


401942-01

Note

Danger of damage The parked vehicle can roll away or fall over.

– Park the vehicle on a firm and level surface.

– Raise the motorcycle at the frame underneath the engine.

Lift stand (81329955100)

✔ Neither wheel is in contact with the ground.


– Secure the motorcycle against falling over.

12.2 Removing the motorcycle from the lift stand

Note

Danger of damage The parked vehicle can roll away or fall over.

– Park the vehicle on a firm and level surface.



401943-10

– Remove the motorcycle from the lift stand.
– Remove the lift stand.
– To park the motorcycle, press side stand ❶ to the ground with your foot and lean the motorcycle on it.


Info

When you are riding, the side stand must be folded up and secured with rubber strap.

12.3 Bleeding the fork legs

Preparatory work

– Raise the motorcycle with a lift stand. (📖 p. 59)



W00297-11

Main work

– Release bleeder screws ❶.


✔ Any excess pressure escapes from the interior of the fork.

– Tighten the bleeder screws.

Finishing work

– Remove the motorcycle from the lift stand. (📖 p. 59)

12.4 Cleaning the dust boots of the fork legs



Preparatory work

– Raise the motorcycle with a lift stand. (📖 p. 59)

– Remove the fork protector. (📖 p. 60)

Main work

– Push dust boots ❶ of both fork legs downward.

Info

The dust boots remove dust and coarse dirt particles from the inside fork tubes. Over time, dirt can accumulate behind the dust boots. If this dirt is not removed, the oil seals behind can start to leak.

Warning

Danger of accidents Oil or grease on the brake discs reduces the braking effect.

– Always keep the brake discs free of oil and grease.

– Clean the brake discs with brake cleaner when necessary.

– Clean and oil the dust boots and inner fork tubes of both fork legs.

Universal oil spray (📖 p. 154)

– Press the dust boots back into their installation position.


– Remove excess oil.

Finishing work

– Install the fork protector. (📖 p. 61)

– Remove the motorcycle from the lift stand. (📖 p. 59)

12.5 Removing the fork protector




– Remove screws ❶ and take off the clamp.

– Remove screws ❷ on the left fork leg and take off the left fork protector.

– Remove screws ❸ on the right fork leg and take off the right fork protector.

12.6 Installing the fork protector



– Position the fork protector on the left fork leg. Mount and tighten screws ❶.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)

– Position the brake line, wiring harness, and clamp. Mount and tighten screws ❷.
– Position the fork protector on the right fork leg. Mount and tighten screws ❸.


Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)

12.7 Removing the fork legs


Preparatory work

– Remove the headlight mask with the headlight. (📖 p. 113)
– Raise the motorcycle with a lift stand. (📖 p. 59)
– Remove the front wheel. (📖 p. 103)




Main work

– Remove screws ❶ and take off the clamp.
– Remove the cable tie.
– Remove screws ❷ and take off the brake caliper.
– Allow the brake caliper and brake line to hang loosely to the side.



– Loosen screws ❸. Remove the left fork leg.
– Loosen screws ❹. Remove the right fork leg.

12.8 Installing the fork legs



Main work


– Position the fork legs.

✓ Bleeder screws ❶ are positioned toward the front.

Info

Grooves are milled into the side of the upper end of the fork legs. The second milled groove (from the top) must be flush with the upper edge of the upper triple clamp.

The pressure and rebound damping is located in the left and right fork leg.



– Tighten screws ❷.


Guideline

Screw, top triple clamp	M8	17 Nm (12.5 lbf ft)

– Tighten screws ❸.

Guideline

Screw, bottom triple clamp	M8	12 Nm (8.9 lbf ft)



– Position the brake caliper, and mount and tighten screws ❹.

Guideline

Screw, front brake caliper	M8	25 Nm (18.4 lbf ft) **Loctite®243™**

– Mount the cable ties.

– Position the brake line, the wiring harness, and the clamp. Mount and tighten screws ❺.

Finishing work


– Install the front wheel. (p. 104)

– Remove the motorcycle from the lift stand. (p. 59)

12.9 Removing the frame protector

Preparatory work

– Remove the right side cover. (p. 74)



Main work


– Remove the cable ties.

– Remove screws ❶ with the bushings.

– Take off the left frame protector.

– Push the right frame protector to the front and take off at the bottom.

12.10 Installing the frame protector



Main work

– Position the left frame protector.
– Insert the right frame protector from below and push it to the rear.
– Mount screws ❶ with the bushings and tighten.

Guideline

Screw, frame protector	M5	3 Nm (2.2 lbf ft)

– Secure the frame protector with cable ties.


Finishing work

– Install the right side cover. (📖 p. 75)

12.11 Removing the lower triple clamp 🔧

Preparatory work

– Remove the headlight mask with the headlight. (📖 p. 113)
– Raise the motorcycle with a lift stand. (📖 p. 59)
– Remove the front wheel. 🔧 (📖 p. 103)
– Remove the fork legs. 🔧 (📖 p. 61)
– Remove front fender. (📖 p. 67)



Main work


– Loosen screw ❶.
– Remove screw ❷.
– Take off the upper triple clamp and handlebar and set it aside.

Info
Protect the components against damage by covering them.
Do not kink the cables or lines.



– Remove protective ring ❸.
– Remove the lower triple clamp with steering stem.
– Remove the upper steering head bearing.

12.12 Installing the lower triple clamp




Main work

– Clean the bearing and sealing elements, check for damage, and grease.

High viscosity grease (p. 153)


– Position the lower triple clamp with the steering stem. Mount upper steering head bearing.

– Mount protective ring ❶.




– Make sure the steering lock in area Ⓐ is positioned correctly.

✔ The catch on the steering lock engages in the notch on the triple clamp.



– Position the upper triple clamp and handlebar.

– Mount screw ❷, but do not tighten it yet.




– Position the fork legs.

✔ Bleeder screws ❸ are positioned toward the front.

Info


Grooves are milled into the side of the upper end of the fork legs. The second milled groove (from the top) must be flush with the upper edge of the upper triple clamp.



– Tighten screws ❹.

Guideline

Screw, bottom triple clamp	M8	12 Nm (8.9 lbf ft)



– Tighten screw ❷.


Guideline

Screw, top steering head	M20x1.5	12 Nm (8.9 lbf ft)

– Mount and tighten screw ❺.

Guideline


Screw, top steering stem	M8	20 Nm (14.8 lbf ft) **Loctite®243™**



– Tighten screws ❻.

Guideline

Screw, top triple clamp	M8	17 Nm (12.5 lbf ft)



– Position the brake caliper, and mount and tighten screws ❼.

Guideline

Screw, front brake caliper	M8	25 Nm (18.4 lbf ft) **Loctite®243™**

– Mount the cable ties.
– Position the brake line, the wiring harness, and the clamp. Mount and tighten screws ❽.

Finishing work

– Install front fender. (📖 p. 68)
– Install the front wheel. 🔧 (📖 p. 104)
– Install the headlight mask with the headlight. (📖 p. 114)
– Check the wiring harness, cables, and brake and clutch lines for freedom of movement and correct routing.
– Check the steering head bearing for play. (📖 p. 66)
– Check the headlight setting. (📖 p. 116)
– Remove the motorcycle from the lift stand. (📖 p. 59)

12.13 Checking the steering head bearing play


Warning

Danger of accidents Incorrect steering head bearing play impairs the handling characteristic and damages components.

– Correct incorrect steering head bearing play immediately. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

Info

If the vehicle is operated for a lengthy period with play in the steering head bearing, the bearings and the bearing seats in the frame can become damaged over time.



Preparatory work

– Raise the motorcycle with a lift stand. (p. 59)

Main work

– Move the handlebar to the straight-ahead position. Move the fork legs to and fro in the direction of travel.

Play should not be detectable on the steering head bearing.

» If there is detectable play:

– Adjust the steering head bearing play. (p. 66)

– Move the handlebar to and fro over the entire steering range.

It must be possible to move the handlebar easily over the entire steering range. There should be no detectable detent positions.

» If detent positions are detected:

– Adjust the steering head bearing play. (p. 66)


– Check the steering head bearing and replace if necessary.

– Check the steering stop bolts for correct adjustment and locking.

Finishing work

– Remove the motorcycle from the lift stand. (p. 59)

12.14 Adjusting the steering head bearing play



Preparatory work

– Raise the motorcycle with a lift stand. (p. 59)

Main work

– Loosen screws ❶.

– Remove screw ❷.

– Loosen and retighten screw ❸.

Guideline

Screw, top steering head	M20x1.5	12 Nm (8.9 lbf ft)

– Using a plastic hammer, tap lightly on the upper triple clamp to avoid stresses.

– Tighten screws ❶.

Guideline

Screw, top triple clamp	M8	17 Nm (12.5 lbf ft)

– Mount and tighten screw ❷.


Guideline

Screw, top steering stem	M8	20 Nm (14.8 lbf ft) **Loctite®243™**

Finishing work

– Check the steering head bearing for play. (📖 p. 66)
– Remove the motorcycle from the lift stand. (📖 p. 59)

12.15 Lubricating the steering head bearing




– Remove the lower triple clamp. (📖 p. 63)
– Install the lower triple clamp. (📖 p. 64)

Info
The steering head bearing is cleaned and lubricated in the course of removal and installation of the lower triple clamp.

12.16 Removing front fender

Preparatory work


– Remove the headlight mask with the headlight. (📖 p. 113)



Main work

– Remove screws ❶.
– Remove screws ❷. Take off the front fender.

12.17 Installing front fender



Main work

– Position front fender. Mount and tighten screws ❶.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)

– Mount and tighten screws ❷.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)


Finishing work

– Install the headlight mask with the headlight. (📖 p. 114)
– Check the headlight setting. (📖 p. 116)

12.18 Removing the shock absorber

Preparatory work

– Raise the motorcycle with a lift stand. (📖 p. 59)
– Remove the right side cover. (📖 p. 74)
– Remove the frame protector. (📖 p. 62)




Main work

– Remove screw ❶.
– Remove fitting ❷.


> **Info**
> Raise the link fork slightly to be able to remove the screws more easily.



– Disconnect the plug-in connector of the brake light switch.




– Remove screws ❸.
– Pull off foot brake cylinder from the push rod.




– Remove the connecting link of the chain.

Info
Cover the components to protect them against damage.

– Take off the chain.




– Remove nut ❹ and pull out the swingarm pivot.
– Push the link fork back and secure it against falling over.



– Hold the shock absorber and remove screw ❺.
– Remove the shock absorber carefully at the bottom.


12.19 Installing the shock absorber



Main work
– Carefully position the shock absorber into the vehicle from the bottom.
– Mount and tighten screw ❶.

Guideline

Screw, top shock absorber	M10	60 Nm (44.3 lbf ft) **Loctite®2701™**




– Position the link fork and mount the swingarm pivot.

Info
Pay attention to flat area Ⓐ.

– Mount and tighten nut ❷.

Guideline

Nut, fork pivot	M16x1.5	100 Nm (73.8 lbf ft)




– Mount the chain.
– Connect the chain with connecting link ❸.

Guideline

The closed side of the chain joint lock must face in the direction of travel.




– Join plug-in connector of the brake light switch.



– Position the foot brake cylinder.
  ✔ Push rod ❹ engages in the foot brake cylinder.
  ✔ The dust boot is correctly positioned.
– Mount and tighten screws ❺.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)



– Position the angle lever and linkage lever.
– Mount and tighten fitting ❻.

Guideline

Nut, linkage lever on angle lever	M16x1.5	80 Nm (59 lbf ft)

Info
Pay attention to flat area Ⓑ.

– Mount and tighten screw ❼.

Guideline

Screw, bottom shock absorber	M10	60 Nm (44.3 lbf ft) **Loctite®2701™**

Info
Raise the link fork slightly to be able to mount the screw more easily.


Finishing work
– Install the frame protector. (📖 p. 63)
– Install the right side cover. (📖 p. 75)
– Remove the motorcycle from the lift stand. (📖 p. 59)

12.20 Removing the seat



– Remove screw ❶.
– Push the seat forward and take it off in an upward direction.

12.21 Mounting the seat



– Mount the front of the seat on the collar bushings of the fuel tank, lower the seat at the rear, and push the seat to the rear.

✓ The holding lugs engage in the recesses at the back.

– Make sure the seat is latched in place correctly.

– Mount and tighten screw ❶.

Guideline


Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)

12.22 Removing the air filter box cover



– Pull off the air filter box cover sideways in areas Ⓐ and Ⓑ, and take off toward the front.

12.23 Installing the air filter box cover



– Attach the air filter box cover in area Ⓐ and slide it to the rear.

– Engage the air filter box cover in areas Ⓑ and Ⓒ.

12.24 Removing the air filter

Note

Engine damage Unfiltered intake air has a negative effect on the service life of the engine.

Dust and dirt will enter the engine without an air filter.

– Only operate the vehicle if it is equipped with an air filter.


Note

Environmental hazard Hazardous substances cause environmental damage.

– Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.

Preparatory work

– Remove the air filter box cover. (📖 p. 72)




Main work

– Detach retaining tab ❶. Remove air filter with air filter support.

– Remove air filter from air filter support.

12.25 Installing the air filter




Main work

– Mount the clean air filter on the air filter support.

– Grease the air filter in area Ⓐ.

Long-life grease (📖 p. 153)



– Insert air filter and position retaining pin ❶ in bushing Ⓑ.

✔ The air filter is correctly positioned.

– Insert retaining tab ❸.

✔ Retaining pin ❷ is secured with retaining tab ❸.

Info

If the air filter is not mounted correctly, dust and dirt may enter the engine and result in damage.

Finishing work

– Install the air filter box cover. (📖 p. 72)

12.26 Cleaning the air filter and air filter box

Note

Environmental hazard Hazardous substances cause environmental damage.

– Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.

Info

Do not clean the air filter with fuel or petroleum since these substances attack the foam.



Preparatory work

– Remove the air filter box cover. (p. 72)
– Remove the air filter. (p. 73)

Main work

– Wash the air filter thoroughly in special cleaning liquid and allow it to dry properly.

Air filter cleaner (p. 153)

Info

Only press the air filter to dry it, never wring it out.

– Oil the dry air filter with a high-grade air filter oil.


Oil for foam air filter (p. 153)

– Clean the air filter box.
– Check the intake flange for damage and looseness.

Finishing work


– Install the air filter. (p. 73)
– Install the air filter box cover. (p. 72)

12.27 Removing the right side cover



– Detach the side cover in area Ⓐ and take off to the rear.

12.28 Installing the right side cover



– Attach side cover with holding lug Ⓐ from below and push to the rear.
– Engage the side cover in areas Ⓑ and Ⓒ.

12.29 Removing the main silencer

Warning
Danger of burns The exhaust system gets hot when the vehicle is driven.
– Allow the exhaust system to cool down before performing any work on the vehicle.




– Detach spring ❶.

Spring hook (50305017000C1)

– Remove screws ❷ and take off the main silencer with the catalytic converter.

12.30 Installing the main silencer



– Position the catalytic converter in the main silencer.



– Position the main silencer.
– Mount screws ❶, but do not tighten yet.
– Attach spring ❷.

Spring hook (50305017000C1)

– Tighten screws ❶.

Guideline


Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)

12.31 Cleaning spark arrestor

Warning
Danger of burns The exhaust system gets hot when the vehicle is driven.
– Allow the exhaust system to cool down before performing any work on the vehicle.

Info
Soot particles accumulate on the screen of the spark arrestor over time.
This changes the performance characteristics.

Preparatory work
– Remove main silencer. (📖 p. 75)



Main work
– Remove all screws, take off silencer cap ❶ with O-ring ❷.

Info
Do not remove the glass fiber yarn filling.

Caution
Danger to health Soot particles irritate the eyes and mucuous membranes.
– Wear suitable breathing and eye protection when cleaning the main silencer and carbon screen.

– Clean main silencer sleeve ❸ and screen ❹ of the spark arrestor with compressed air.
– Position silencer cap ❶ with O-ring ❷.
– Mount and tighten all of the screws.

Guideline

Screws on main silencer	M5	7 Nm (5.2 lbf ft)

Finishing work

– Install the main silencer. (p. 75)

12.32 Changing the glass fiber yarn filling in the main silencer


Warning

Danger of burns The exhaust system gets hot when the vehicle is driven.

– Allow the exhaust system to cool down before performing any work on the vehicle.

Info

Over time, the fibers of the glass fiber yarn filling escape and the damper "burns" out.
Not only is the noise level higher, but the performance characteristics change.



Preparatory work

– Remove main silencer. (p. 75)

Main work

– Remove all the screws on the main silencer.
– Take off silencer cap ❶ with the filter and O-ring ❷.
– Remove glass fiber yarn filling ❸ from main silencer ❹.
– Clean the parts that need to be reinstalled and check for damage.
– Mount the new glass fiber yarn filling between the inner tube and the outer tube.
– Position the silencer cap with the filter and the O-ring in the outer tube.
– Mount and tighten all of the screws.

Guideline

Screws on main silencer	M5	7 Nm (5.2 lbf ft)

Finishing work

– Install the main silencer. (p. 75)

12.33 Removing the fuel tank

Danger

Fire hazard Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

- Do not fuel the vehicle in the vicinity of open flames or lit cigarettes.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it off immediately.
- Observe the specifications for refueling.

Warning

Danger of poisoning Fuel is harmful to health.

- Avoid skin, eye and clothing contact with fuel.
- Immediately consult a doctor if you swallow fuel.
- Do not inhale fuel vapors.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse the eyes thoroughly with water, and consult a doctor in case of fuel contact with the eyes.
- Change your clothing if fuel spills on them.
- Keep fuels correctly in a suitable canister, and out of the reach of children.

Preparatory work

- Remove the seat. (p. 71)

Main work



- Clean quick release coupling ❶ thoroughly with compressed air.

Info

Under no circumstances should dirt enter into the fuel line. Dirt in the fuel line clogs the injection valve!


- Disconnect the quick release coupling.

Info


Remaining fuel may flow out of the fuel line.

- Mount the wash cap set.


Wash cap set (81212016100)



- Unplug fuel pump connector ❷.
- Remove screw ❸ with the rubber bushing.
- Remove the hose from the fuel tank breather.



– Remove screws ❹.
– Hang the horn and horn bracket to one side.



– Pull both spoilers laterally off the radiator and lift off the fuel tank.

12.34 Installing the fuel tank

Danger

Fire hazard Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

– Do not fuel the vehicle in the vicinity of open flames or lit cigarettes.
– Switch off the engine for refueling.
– Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
– If any fuel is spilled, wipe it off immediately.
– Observe the specifications for refueling.


Warning

Danger of poisoning Fuel is harmful to health.


– Avoid skin, eye and clothing contact with fuel.
– Immediately consult a doctor if you swallow fuel.
– Do not inhale fuel vapors.
– Rinse the affected area immediately with plenty of water in the event of contact with the skin.
– Rinse the eyes thoroughly with water, and consult a doctor in case of fuel contact with the eyes.
– Change your clothing if fuel spills on them.

Main work

– Check the throttle cable routing. (📖 p. 86)



– Position the fuel tank and fit the two spoilers to the sides in front of the radiator bracket.
– Make sure that no cables or throttle cables are trapped or damaged.




– Attach the fuel tank breather hose.
– Mount and tighten screw ❶ with the rubber bushing.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)


– Plug in fuel pump connector ❷.
– Position the horn with the horn bracket.



– Mount and tighten screws ❸.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)



– Remove the wash cap set.
– Clean the quick release coupling thoroughly with compressed air.

Info
Under no circumstances should dirt enter into the fuel line. Dirt in the fuel line clogs the injection valve!

– Spray silicone spray onto a lint-free cleaning cloth and lightly lubricate the O-ring of the quick-release coupling.


Silicone spray (📖 p. 153)

– Join quick release coupling ❹.

Info
Route the cable and fuel line at a safe distance from the exhaust system.

Finishing work
– Mount the seat. (📖 p. 72)

12.35 Checking for chain dirt accumulation



– Check the chain for coarse dirt accumulation.
  » If the chain is very dirty:
    – Clean the chain. (📖 p. 81)


12.36 Cleaning the chain

Warning
Danger of accidents Lubricants on the tires reduces the road grip.
– Remove lubricants from the tires using a suitable cleaning agent.

Warning
Danger of accidents Oil or grease on the brake discs reduces the braking effect.
– Always keep the brake discs free of oil and grease.
– Clean the brake discs with brake cleaner when necessary.

Note
Environmental hazard Hazardous substances cause environmental damage.
– Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.

Info
The service life of the chain depends largely on its maintenance.



Preparatory work
– Raise the motorcycle with a lift stand. (📖 p. 59)

Main work
– Rinse off loose dirt with a soft jet of water.
– Remove old grease residue with chain cleaner.

Chain cleaner (📖 p. 153)

– After drying, apply chain spray.

Off-road chain spray (📖 p. 153)

Finishing work
– Remove the motorcycle from the lift stand. (📖 p. 59)

12.37 Checking the chain tension

Warning

Danger of accidents Incorrect chain tension damages components and results in accidents.


If the chain is tensioned too much, the chain, engine sprocket, rear sprocket, transmission and rear wheel bearings wear more quickly. Some components may break if overloaded.

If the chain is too loose, the chain may fall off the engine sprocket or the rear sprocket. As a result, the rear wheel locks or the engine will be damaged.

– Check the chain tension regularly.
– Set the chain tension in accordance with the specification.

Preparatory work

– Raise the motorcycle with a lift stand. (p. 59)



Main work

– Pull the chain at the end of the chain sliding piece upward to measure chain tension Ⓐ.

Info

Lower chain section ❶ must be taut.
When the chain guard is mounted, it must be possible to pull up the chain at least to the point where it makes contact with chain guard Ⓑ.
Chain wear is not always even, so you should repeat this measurement at different chain positions.

Chain tension	58 … 61 mm (2.28 … 2.4 in)

» If the chain tension does not meet the specification:
– Adjust the chain tension. (p. 82)

Finishing work

– Remove the motorcycle from the lift stand. (p. 59)

12.38 Adjusting the chain tension

Warning

Danger of accidents Incorrect chain tension damages components and results in accidents.


If the chain is tensioned too much, the chain, engine sprocket, rear sprocket, transmission and rear wheel bearings wear more quickly. Some components may break if overloaded.

If the chain is too loose, the chain may fall off the engine sprocket or the rear sprocket. As a result, the rear wheel locks or the engine will be damaged.

– Check the chain tension regularly.
– Set the chain tension in accordance with the specification.

Preparatory work

– Raise the motorcycle with a lift stand. (p. 59)
– Check the chain tension. (p. 82)



Main work

– Loosen nut ❶.
– Loosen nuts ❷.
– Adjust the chain tension by turning adjusting screws ❸ left and right.

Guideline

Chain tension	58 … 61 mm (2.28 … 2.4 in)
Turn adjusting screws ❸ on the left and right so that the markings on the left and right chain adjusters are in the same position relative to reference marks Ⓐ. The rear wheel is then correctly aligned.	

– Tighten nuts ❷.
– Make sure that chain adjusters ❹ are fitted correctly on adjusting screws ❸.
– Tighten nut ❶.

Guideline

Nut, wheel spindle, rear	M22x1.5	80 Nm (59 lbf ft)

Info
The wide adjustment range of the chain adjusters (32 mm (1.26 in)) enables different secondary ratios with the same chain length.
Chain adjusters ❹ can be turned by 180°.


Finishing work

– Remove the motorcycle from the lift stand. (📖 p. 59)

12.39 Checking the chain, rear sprocket, engine sprocket, and chain guide

Preparatory work


– Raise the motorcycle with a lift stand. (📖 p. 59)



Main work

– Shift the transmission into neutral.
– Check the chain, rear sprocket and engine sprocket for wear.
  » If the chain, rear sprocket or engine sprocket is worn:
    – Change the drivetrain kit.

Info
The engine sprocket, rear sprocket and chain should always be replaced together.



– Pull on the top section of the chain with the specified weight Ⓐ.

Guideline

Weight of chain wear measurement	10 … 15 kg (22 … 33 lb.)

– Measure distance Ⓑ of 18 chain rollers in the lower chain section.


Info
Chain wear is not always even, so you should repeat this measurement at different chain positions.

Maximum distance Ⓑ from 18 chain rollers at the longest chain section	272 mm (10.71 in)

» If distance Ⓑ is greater than the specified measurement:

– Change the drivetrain kit.

Info
When a new chain is mounted, the rear sprocket and engine sprocket should also be changed.
New chains wear out faster on old, worn sprockets.



– Check the chain sliding guard for wear.

» If the lower edge of the chain pins is in line with, or below, the chain sliding guard:

– Change the chain sliding guard.


– Check that the chain sliding guard is firmly seated.

» If the chain sliding guard is loose:

– Tighten the screws on the chain sliding guard.

Guideline


Screw, chain sliding guard	M6	6 Nm (4.4 lbf ft) **Loctite®243™**


F03481-10

– Check the chain sliding piece for wear.
  » If the lower edge of the chain pins is in line with or below the chain sliding piece:
    – Change the chain sliding piece.
– Check that the chain sliding piece is firmly seated.
  » If the chain sliding piece is loose:
    – Tighten the screw of the chain sliding piece.

    Guideline


Screw, chain sliding piece	M8	15 Nm (11.1 lbf ft)


400985-01

– Check the chain guide for wear.

Info
Wear can be seen on the front of the chain guide.

  » If the light part of the chain guide is worn:
    – Change the chain guide.


F00322-01


– Check that the chain guide is firmly seated.
  » If the chain guide is loose:
    – Tighten the fitting on the chain guide.

    Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
Remaining nuts, chassis	M6	10 Nm (7.4 lbf ft)

Finishing work
– Remove the motorcycle from the lift stand. (p. 59)

12.40 Checking the frame



F00255-01

– Check the frame for damage, cracking, and deformation.
  » If the frame shows signs of damage, cracking, or deformation:
    – Change the frame.

    Guideline

    Repairs on the frame are not permitted.

12.41 Checking the link fork


401520-01

– Check the link fork for damage, cracking, and deformation.
  » If the link fork exhibits damage, cracking, or deformation:
    – Change the link fork.

Info
Always replace a damaged link fork. Repair of the link fork is not authorized by Husqvarna Motorcycles.

12.42 Checking the throttle cable routing

Warning
Danger of accidents The throttle cable can become kinked, trapped or blocked if it is not routed correctly.

If the throttle cable is kinked, trapped or blocked, the speed can no longer be controlled.

– Make sure that the throttle cable routing and the play in throttle cable complies with the specification.

Preparatory work
– Remove the seat. (p. 71)
– Remove the fuel tank. (p. 78)



Main work

– Check the throttle cable routing.

Both throttle cables must be routed, side by side, on the back of the handlebars and above the fuel tank bracket, to the throttle valve body. Both throttle cables must be secured behind the rubber strap of the fuel tank support.

» If the throttle cable routing is not as specified:


– Correct the throttle cable routing.

Finishing work

– Install the fuel tank. (p. 79)

– Mount the seat. (p. 72)

12.43 Checking the rubber grip




– Check the rubber grips on the handlebar for damage, wear, and looseness.

Info

The rubber grips are vulcanized onto a sleeve on the left and onto the handle tube of the throttle grip on the right. The left sleeve is clamped onto the handlebar. The rubber grip can only be replaced with the sleeve or the throttle tube.

» If a rubber grip is damaged, worn, or loose:

– Change the rubber grip.




– Check that screw 1 is firmly seated.

Guideline

Screw, fixed grip	M4	5 Nm (3.7 lbf ft) **Loctite®243™**

Diamond A must be positioned visibly as shown in the figure.

12.44 Adjusting the basic position of the clutch lever



– Adjust the basic position of the clutch lever to your hand size by turning adjusting screw ❶.

Info

Turn the adjusting screw clockwise to increase the distance between the clutch lever and the handlebar.
Turn the adjusting screw counterclockwise to decrease the distance between the clutch lever and the handlebar.
The range of adjustment is limited.
Turn the adjusting screw by hand only, and do not apply any force.
Do not make any adjustments while riding.

12.45 Checking/correcting the fluid level of hydraulic clutch

Warning

Skin irritation Brake fluid is a harmful substance.

– Keep brake fluid out of the reach of children.
– Wear suitable protective clothing and safety glasses.
– Do not allow brake fluid to come into contact with the skin, the eyes or clothing.
– Consult a doctor immediately if brake fluid has been swallowed.
– Rinse the affected area with plenty of water in the event of contact with the skin.
– Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
– If brake fluid spills on to your clothing, change the clothing.


Note

Environmental hazard Hazardous substances cause environmental damage.

– Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.

Info

The fluid level rises with increasing wear of the clutch facing discs.
Avoid contact between brake fluid and painted parts. Brake fluid corrodes paint.



– Move the hydraulic clutch fluid reservoir mounted on the handlebar into a horizontal position.
– Remove screws ❶.
– Take off cover ❷ with membrane ❸.
– Check the fluid level.

Fluid level below container rim	4 mm (0.16 in)

» If the fluid level does not meet specifications:
– Correct the fluid level of the hydraulic clutch.

Brake fluid DOT 4 / DOT 5.1 (📖 p. 151)

– Position the cover with the membrane. Mount and tighten the screws.


Info
Use water to immediately clean up any brake fluid that has overflowed or spilled.

12.46 Changing the hydraulic clutch fluid


Warning
Skin irritation Brake fluid is a harmful substance.
– Keep brake fluid out of the reach of children.
– Wear suitable protective clothing and safety glasses.
– Do not allow brake fluid to come into contact with the skin, the eyes or clothing.
– Consult a doctor immediately if brake fluid has been swallowed.
– Rinse the affected area with plenty of water in the event of contact with the skin.
– Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
– If brake fluid spills on to your clothing, change the clothing.

Note
Environmental hazard Hazardous substances cause environmental damage.
– Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.

Info
Avoid contact between brake fluid and painted parts. Brake fluid corrodes paint.




– Move the hydraulic clutch fluid reservoir mounted on the handlebar into a horizontal position.
– Remove screws ❶.
– Take off cover ❷ with membrane ❸.



– Fill bleeding syringe ❹ with the appropriate hydraulic fluid.

Syringe (50329050000)
Brake fluid DOT 4 / DOT 5.1 (📖 p. 151)

– On the clutch slave cylinder, remove the protection cap, remove bleeder screw ❺ and mount bleeding syringe ❹.



– Inject the liquid into the system until it escapes from openings ❻ of the master cylinder without bubbles.
– Occasionally extract the fluid from the master cylinder reservoir to prevent overflowing.
– Remove the bleeding syringe. Mount and tighten the bleeder screw. Mount the protection cap.
– Correct the fluid level of the hydraulic clutch.


Guideline

Fluid level below container rim	4 mm (0.16 in)

– Position the cover with the membrane. Mount and tighten the screws.


Info
Use water to immediately clean up any brake fluid that has overflowed or spilled.

12.47 Removing the engine guard



– Remove screws ❶ and engine guard.

12.48 Installing the engine guard




– Attach the engine guard on the frame at the rear and swing up at the front.
– Mount and tighten screws ❶.

Guideline

Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)

13.1 Adjusting the basic position of the hand brake lever



– Adjust basic position of the hand brake lever to your hand size by turning adjusting screw ❶.

Info

Turn the adjusting screw clockwise to increase the distance between the hand brake lever and the handlebar.

Turn the adjusting screw counterclockwise to decrease the distance between the hand brake lever and the handlebar.

The range of adjustment is limited.

Turn the adjusting screw by hand only, and do not apply any force.


Do not make any adjustments while riding.

13.2 Checking the brake discs

Warning

Danger of accidents Worn-out brake discs reduce the braking effect.

– Make sure that worn-out brake discs are replaced immediately. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



– Check the front and rear brake disc thickness at multiple points for the dimension Ⓐ.

Info

Wear reduces the thickness of the brake disc around the contact surface of the brake linings.

Brake discs - wear limit	
front	2.5 mm (0.098 in)
rear	3.5 mm (0.138 in)

» If the brake disc thickness is less than the specified value:
  – Change the front brake disc.
  – Change the rear brake disc.

– Check the front and rear brake discs for damage, cracking, and deformation.

» If the brake disc exhibits damage, cracking, or deformation:
  – Change the front brake disc.
  – Change the rear brake disc.

13.3 Checking the front brake fluid level


Warning
Danger of accidents An insufficient brake fluid level will cause the brake system to fail.

If the brake fluid level drops below the **MIN** marking, the brake system is leaking or the brake linings are worn down.

– Check the brake system and do not continue riding until the problem is eliminated. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

Warning
Danger of accidents Brake fluid which is too old or of the wrong type impairs the function of the brake system.

– Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)
– Make sure that only clean, approved brake fluid from a tightly sealed container is used. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



– Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
– Check the brake fluid level in level viewer ❶.
  » If the brake fluid level has dropped below the **MIN** marking Ⓐ:
    – Add front brake fluid. (📖 p. 92)

13.4 Adding front brake fluid

Warning
Danger of accidents An insufficient brake fluid level will cause the brake system to fail.

If the brake fluid level drops below the specified marking or the specified value, the brake system is leaking or the brake linings are worn down.

– Check the brake system and do not continue riding until the problem is eliminated. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

Warning
Skin irritation Brake fluid is a harmful substance.

– Keep brake fluid out of the reach of children.
– Wear suitable protective clothing and safety glasses.
– Do not allow brake fluid to come into contact with the skin, the eyes or clothing.
– Consult a doctor immediately if brake fluid has been swallowed.
– Rinse the affected area with plenty of water in the event of contact with the skin.
– Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
– If brake fluid spills on to your clothing, change the clothing.

Warning

Danger of accidents Brake fluid which is too old or of the wrong type impairs the function of the brake system.

– Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)
– Make sure that only clean, approved brake fluid from a tightly sealed container is used. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

Note

Environmental hazard Hazardous substances cause environmental damage.


– Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.

Info

Avoid contact between brake fluid and painted parts. Brake fluid corrodes paint.

Preparatory work

– Check that the brake linings of the front brake are secured. (p. 93)



Main work

– Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
– Remove screws 1.
– Take off cover 2 with membrane 3.
– Add brake fluid to level A.

Guideline

Level A (brake fluid level below reservoir rim)	5 mm (0.2 in)

Brake fluid DOT 4 / DOT 5.1 (p. 151)

– Position the cover with the membrane. Mount and tighten the screws.

Info


Use water to immediately clean up any brake fluid that has overflowed or spilled.

13.5 Checking that the brake linings of the front brake are secured

Warning

Danger of accidents Worn-out brake linings reduce the braking effect.

– Ensure that worn-out brake linings are replaced immediately. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



– Check the brake linings for lining thickness Ⓐ.

Minimum thickness Ⓐ	≥ 1 mm (≥ 0.04 in)

» If it is less than the minimum thickness:
– Change the brake linings of the front brake. 🔧 (📖 p. 94)

– Check the brake linings for damage and cracking.
» If there is damage or cracking:
– Change the brake linings of the front brake. 🔧 (📖 p. 94)

– Check that the brake linings are secured.
» If the brake linings are not secured correctly:
– Secure brake linings, replace with new parts if necessary.

13.6 Changing the brake linings of the front brake 🔧

Warning
Danger of accidents Incorrect servicing will cause the brake system to fail.
– Ensure that service work and repairs are performed professionally. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

Warning
Skin irritation Brake fluid is a harmful substance.
– Keep brake fluid out of the reach of children.
– Wear suitable protective clothing and safety glasses.
– Do not allow brake fluid to come into contact with the skin, the eyes or clothing.
– Consult a doctor immediately if brake fluid has been swallowed.
– Rinse the affected area with plenty of water in the event of contact with the skin.
– Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
– If brake fluid spills on to your clothing, change the clothing.

Warning
Danger of accidents Brake fluid which is too old or of the wrong type impairs the function of the brake system.
– Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)
– Make sure that only clean, approved brake fluid from a tightly sealed container is used. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

Warning
Danger of accidents Oil or grease on the brake discs reduces the braking effect.
– Always keep the brake discs free of oil and grease.
– Clean the brake discs with brake cleaner when necessary.

Warning

Danger of accidents Brake linings which have not been approved alter the braking efficiency.

Not all brake linings are tested and approved for Husqvarna motorcycles. The structure and friction coefficient of the brake linings, and thus their brake power, may vary greatly from that of original brake linings.

If brake linings are used that differ from the original equipment, compliance with the original homologation is not guaranteed. In this case, the vehicle no longer corresponds to its condition at delivery and the manufacturer warranty shall be void.

– Only use brake linings approved and recommended by Husqvarna motorcycles.


Note

Environmental hazard Hazardous substances cause environmental damage.


– Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.

Info

Avoid contact between brake fluid and painted parts. Brake fluid corrodes paint.



– Move the brake fluid reservoir mounted on the handlebar to a horizontal position.
– Remove screws ❶.
– Take off cover ❷ with membrane ❸.




– Manually press the brake caliper toward the brake disc to push back the brake pistons. Ensure that brake fluid does not flow out of the brake fluid reservoir, extract some if necessary.


Info

Make sure that you do not press the brake caliper against the spokes when pushing back the brake pistons.

– Remove cotter pin ❹.
– Pull out pin ❺.
– Remove the brake linings.
– Clean the brake caliper and the brake caliper bracket.



– Check that spring plate ❻ in the brake caliper and brake pad sliding plate ❼ in the brake caliper bracket are seated correctly.




– Insert the new brake linings.
– Mount pin ❺.
  ✔ Spring plate ❻ engages in the groove on the pin.

Info
Always change the brake linings in pairs.

– Mount cotter pins ❹.
  Guideline

Mount the outer cotter pins from the front to the rear.
Mount the inner cotter pins from the rear to the front.

– Operate the hand brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.



– Add brake fluid up to level Ⓐ.
  Guideline

Level Ⓐ (brake fluid level below reservoir rim)	5 mm (0.2 in)

Brake fluid DOT 4 / DOT 5.1 (📖 p. 151)

– Position cover ❷ with membrane ❸.
– Mount and tighten screws ❶.


Info
Use water to immediately clean up any brake fluid that has overflowed or spilled.

13.7 Checking the free travel of foot brake lever

Warning
Danger of accidents The brake system will fail if it overheats or is adjusted incorrectly.

If there is no free travel on the foot brake lever, pressure builds up in the brake system on the rear brake.

– Set the free travel on the foot brake lever in accordance with the specification.
– Ensure that the adjustment steps are performed properly. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



– Disconnect spring ❶.
– Move the foot brake lever back and forth between the end stop and the contact to the foot brake cylinder piston and check free travel Ⓐ.

Guideline

Free travel at foot brake lever	3 … 5 mm (0.12 … 0.2 in)

» If the free travel does not meet specifications:
– Adjust the basic position of the foot brake lever. 🔧 (📖 p. 97)

– Reconnect spring ❶.


13.8 Adjusting the basic position of the foot brake lever 🔧

Warning

Danger of accidents The brake system will fail if it overheats or is adjusted incorrectly.

If there is no free travel on the foot brake lever, pressure builds up in the brake system on the rear brake.

– Set the free travel on the foot brake lever in accordance with the specification.
– Ensure that the adjustment steps are performed properly. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



– Detach spring ❶.
– Loosen nut ❹ and, with push rod ❺, turn it back until you have maximum free travel.
– To adjust the basic position of the foot brake lever to individual requirements, loosen nut ❷ and turn screw ❸ accordingly.

Info
The range of adjustment is limited.

– Turn push rod ❺ accordingly until you have free travel Ⓐ. If necessary, adjust the basic position of the foot brake lever.

Guideline

Free travel at foot brake lever	3 … 5 mm (0.12 … 0.2 in)

– Hold screw ❸ and tighten nut ❷.

Guideline

Rear brake lever stop nut	M8	20 Nm (14.8 lbf ft)

– Hold push rod ❺ and tighten nut ❹.

Guideline

Remaining nuts, chassis	M6	10 Nm (7.4 lbf ft)

– Attach spring ❶.

13.9 Checking the rear brake fluid level


Warning
Danger of accidents An insufficient brake fluid level will cause the brake system to fail.

If the brake fluid level drops below the **MIN** marking, the brake system is leaking or the brake linings are worn down.

– Check the brake system and do not continue riding until the problem is eliminated. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

Warning
Danger of accidents Brake fluid which is too old or of the wrong type impairs the function of the brake system.

– Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)
– Make sure that only clean, approved brake fluid from a tightly sealed container is used. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



– Position the vehicle vertically.
– Check the brake fluid level in level viewer 1.
  » If the brake fluid level has dropped below the **MIN** marking A:
    – Add rear brake fluid. (p. 98)

13.10 Adding rear brake fluid

Warning
Danger of accidents An insufficient brake fluid level will cause the brake system to fail.

If the brake fluid level drops below the specified marking or the specified value, the brake system is leaking or the brake linings are worn down.

– Check the brake system and do not continue riding until the problem is eliminated. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

Warning
Skin irritation Brake fluid is a harmful substance.

– Keep brake fluid out of the reach of children.
– Wear suitable protective clothing and safety glasses.
– Do not allow brake fluid to come into contact with the skin, the eyes or clothing.
– Consult a doctor immediately if brake fluid has been swallowed.
– Rinse the affected area with plenty of water in the event of contact with the skin.
– Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
– If brake fluid spills on to your clothing, change the clothing.

Warning

Danger of accidents Brake fluid which is too old or of the wrong type impairs the function of the brake system.

– Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)
– Make sure that only clean, approved brake fluid from a tightly sealed container is used. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

Note

Environmental hazard Hazardous substances cause environmental damage.


– Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.

Info

Avoid contact between brake fluid and painted parts. Brake fluid corrodes paint.

Preparatory work

– Check that the brake linings of the rear brake are secured. (📖 p. 99)



Main work

– Stand the vehicle upright.
– Remove screw cap ❶ with membrane ❷.
– Add brake fluid up to the marking Ⓐ.

Brake fluid DOT 4 / DOT 5.1 (📖 p. 151)

– Mount and tighten the screw cap with the membrane.

Info


Use water to immediately clean up any brake fluid that has overflowed or spilled.

13.11 Checking that the brake linings of the rear brake are secured

Warning

Danger of accidents Worn-out brake linings reduce the braking effect.

– Ensure that worn-out brake linings are replaced immediately. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



– Check the brake linings for lining thickness Ⓐ.

Minimum thickness Ⓐ	≥ 1 mm (≥ 0.04 in)

» If it is less than the minimum thickness:
– Change the rear brake linings. 🔧 (📖 p. 100)

– Check the brake linings for damage and cracking.

» If there is damage or cracking:
– Change the rear brake linings. 🔧 (📖 p. 100)

– Check that the brake linings are secured.

» If the brake linings are not secured correctly:

– Secure brake linings, replace with new parts if necessary.

13.12 Changing the rear brake linings

Warning

Danger of accidents Incorrect servicing will cause the brake system to fail.

– Ensure that service work and repairs are performed professionally. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

Warning

Skin irritation Brake fluid is a harmful substance.

– Keep brake fluid out of the reach of children.
– Wear suitable protective clothing and safety glasses.
– Do not allow brake fluid to come into contact with the skin, the eyes or clothing.
– Consult a doctor immediately if brake fluid has been swallowed.
– Rinse the affected area with plenty of water in the event of contact with the skin.
– Rinse eyes thoroughly with water immediately and consult a doctor if brake fluid comes into contact with the eyes.
– If brake fluid spills on to your clothing, change the clothing.

Warning

Danger of accidents Brake fluid which is too old or of the wrong type impairs the function of the brake system.

– Make sure that brake fluid for the front and rear brake is changed in accordance with the service schedule. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)
– Make sure that only clean, approved brake fluid from a tightly sealed container is used. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)

Warning

Danger of accidents Oil or grease on the brake discs reduces the braking effect.

– Always keep the brake discs free of oil and grease.
– Clean the brake discs with brake cleaner when necessary.

Warning

Danger of accidents Brake linings which have not been approved alter the braking efficiency.

Not all brake linings are tested and approved for Husqvarna motorcycles. The structure and friction coefficient of the brake linings, and thus their brake power, may vary greatly from that of original brake linings.

If brake linings are used that differ from the original equipment, compliance with the original homologation is not guaranteed. In this case, the vehicle no longer corresponds to its condition at delivery and the manufacturer warranty shall be void.

– Only use brake linings approved and recommended by Husqvarna motorcycles.


Note

Environmental hazard Hazardous substances cause environmental damage.


– Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.

Info
Avoid contact between brake fluid and painted parts. Brake fluid corrodes paint.

Preparatory work
- Remove the right side cover. (p. 74)
- Remove the frame protector. (p. 62)




Main work
- Stand the vehicle upright.
- Remove screw cap ❶ with membrane ❷.



- Manually press the brake caliper toward the brake disc to push back the brake piston. Ensure that brake fluid does not flow out of the brake fluid reservoir; extract some if necessary.

Info
Make sure that you do not press the brake caliper against the spokes when pushing back the brake piston.


- Remove cotter pin ❸.
- Pull out pin ❹.
- Remove the brake linings.
- Clean the brake caliper and the brake caliper bracket.
- Check that spring plate in the brake caliper and brake pad sliding plate in the brake caliper bracket are fitted correctly.



- Insert the new brake linings.
- Mount pin ❹.
  ✓ The spring plate engages in the groove on the pin.

Info
Always change the brake linings in pairs.

- Mount cotter pins ❸.
- Operate the foot brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.



– Correct brake fluid level to marking Ⓐ.

Brake fluid DOT 4 / DOT 5.1 (📖 p. 151)

– Mount and tighten screw cap ❶ with membrane ❷.

Info
Use water to immediately clean up any brake fluid that has overflowed or spilled.


Finishing work

– Install the frame protector. (📖 p. 63)
– Install the right side cover. (📖 p. 75)

14.1 Removing the front wheel

Preparatory work


– Raise the motorcycle with a lift stand. (p. 59)


S04840-10

Main work


– Manually press the brake caliper toward the brake disc to push back the brake pistons.

Info
Make sure that you do not press the brake caliper against the spokes when pushing back the brake pistons.



S04841-10


– Loosen screw ❶ by several rotations.
– Loosen screws ❷.
– Press on screw ❶ to push the wheel spindle out of the axle clamp.
– Remove screw ❶.


S04842-10

Warning
Danger of accidents Damaged brake discs reduce the braking effect.
– Always lay the wheel down in such a way that the brake disc is not damaged.

– Hold front wheel and remove wheel spindle. Take front wheel out of the fork.

Info
Do not actuate the hand brake lever when the front wheel is removed.




H00934-10

– Remove spacers ❸.

14.2 Installing the front wheel


Warning
Danger of accidents Oil or grease on the brake discs reduces the braking effect.
– Always keep the brake discs free of oil and grease.
– Clean the brake discs with brake cleaner when necessary.



– Check the wheel bearing for damage and wear.
  » If the wheel bearing is damaged or worn:
    – Change front wheel bearing.
– Clean and grease shaft seal rings ❶ and contact surfaces Ⓐ of the spacers.

Long-life grease (📖 p. 153)

– Insert the spacers.



– Clean and grease the wheel spindle.

Long-life grease (📖 p. 153)

– Position the front wheel and insert the wheel spindle.
  ✔ The brake linings are correctly positioned.
– Mount and tighten screw ❷.
  Guideline


Screw, front wheel spindle	M20x1.5	35 Nm (25.8 lbf ft)

– Operate the hand brake lever several times until the brake linings are seated correctly against the brake disc.
– Remove the motorcycle from the lift stand. (📖 p. 59)
– Operate the front brake and compress the fork a few times firmly.
  ✔ The fork legs straighten.
– Tighten screws ❸.
  Guideline

Screw, fork stub	M8	15 Nm (11.1 lbf ft)

14.3 Removing the rear wheel

Preparatory work
– Raise the motorcycle with a lift stand. (📖 p. 59)



Main work

– Manually press the brake caliper toward the brake disc to push back the brake piston.

Info
Make sure that you do not press the brake caliper against the spokes when pushing back the brake piston.


– Remove nut ❶.
– Take off chain adjuster ❷. Pull out wheel spindle ❸ far enough to allow the rear wheel to be pushed forward.
– Push the rear wheel forward as far as possible. Remove the chain from the rear sprocket.

Info
Cover the components to protect them against damage.

Warning
Danger of accidents Damaged brake discs reduce the braking effect.
– Always lay the wheel down in such a way that the brake disc is not damaged.

– Hold the rear wheel and remove the wheel spindle. Take the rear wheel out of the link fork.


Info
Do not operate the foot brake lever when the rear wheel is removed.



– Remove spacers ❹.

14.4 Installing the rear wheel

Warning
Danger of accidents Oil or grease on the brake discs reduces the braking effect.
– Always keep the brake discs free of oil and grease.
– Clean the brake discs with brake cleaner when necessary.




Main work

– Check the wheel bearing for damage and wear.
  » If the wheel bearing is damaged or worn:
    – Change the rear wheel bearing.
– Clean and grease shaft seal rings ❶ and contact surfaces Ⓐ of the spacers.

Long-life grease (📖 p. 153)


– Insert the spacers.



– Clean and grease the wheel spindle.

Long-life grease (📖 p. 153)

– Position rear wheel and insert wheel spindle ❷.
– Mount the chain.
  ✔ The brake linings are correctly positioned.



– Position chain adjuster ❸. Mount nut ❹, but do not tighten it yet.
– Make sure that chain adjusters ❸ are fitted correctly on adjusting screws ❺.
– Check the chain tension. (📖 p. 82)
– Tighten nut ❹.

  Guideline

Nut, wheel spindle, rear	M22x1.5	80 Nm (59 lbf ft)

Info

The wide adjustment range of the chain adjusters (32 mm (1.26 in)) enables different secondary ratios with the same chain length.

Chain adjusters ❸ can be turned by 180°.


– Operate the foot brake lever repeatedly until the brake linings are in contact with the brake disc and there is a pressure point.

Finishing work

– Remove the motorcycle from the lift stand. (📖 p. 59)

14.5 Checking the tire condition

Info
Only mount tires approved and/or recommended by Husqvarna Motorcycles.
Other tires could have a negative effect on handling characteristics.
The type, condition, and pressure of the tires all have a major impact on the handling characteristic of the motorcycle.
The tires mounted on the front and rear wheels must have a similar profile.
Worn tires have a negative effect on handling characteristics, especially on wet surfaces.




– Check the front and rear tires for cuts, run-in objects, and other damage.
  » If the tires have cuts, run-in objects, or other damage:
    – Change the tires.
– Check the tread depth.

Info
Adhere to the legally required minimum tread depth.

Minimum tread depth	≥ 2 mm (≥ 0.08 in)

  » If the tread depth is less than the minimum tread depth:
    – Change the tires.




– Check the tire age.

Info
The tire date of manufacture is usually contained in the tire label and is indicated by the last four digits of the **DOT** number. The first two digits indicate the week of manufacture and the last two digits the year of manufacture.
Husqvarna Motorcycles recommends that the tires be changed after 5 years at the latest, regardless of the actual state of wear.

  » If the tires are more than 5 years old:
    – Change the tires.

14.6 Checking tire pressure

Info
Low tire pressure leads to abnormal wear and overheating of the tire.
Correct tire pressure ensures optimal riding comfort and maximum tire service life.



– Remove the protection cap.
– Check tire pressure when the tires are cold.

Offroad tire pressure	
front	1.0 bar (15 psi)
rear	1.0 bar (15 psi)

Street tire pressure	
front	2.0 bar (29 psi)
rear	2.0 bar (29 psi)


» If the tire pressure does not meet specifications:
  – Correct tire pressure.
– Mount the protection cap.

14.7 Checking spoke tension

Warning
Danger of accidents Incorrectly tensioned spokes impair the handling characteristic and result in secondary damage.

The spokes break due to being overloaded if they are too tightly tensioned. If the tension in the spokes is too low, then lateral and radial run-out will form in the wheel. Other spokes will become looser as a result.

– Check spoke tension regularly, and in particular on a new vehicle. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



– Strike each spoke briefly using a screwdriver blade.

Info
The frequency of the sound depends on the spoke length and spoke diameter.
If you hear different tone frequencies from different spokes of equal length and diameter, this is an indication of different spoke tensions.

You should hear a high note.

» If the spoke tension differs:
  – Correct the spoke tension.
– Check the spoke torque.

Guideline

Spoke nipple, front wheel	M4.5	6 Nm (4.4 lbf ft)
Spoke nipple, rear wheel	M4.5	6 Nm (4.4 lbf ft)

Torque wrench kit (58429094000)

15.1 Removing the 12-V battery

Note

Environmental hazard 12 V batteries contain environmentally hazardous materials.

- Do not dispose of 12 V batteries as household waste.
- Dispose of 12 V batteries at a collection point for used batteries.


Note

Environmental hazard Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.

Preparatory work

- Remove the seat. (p. 71)



Main work

Warning


Risk of injury 12 V batteries contain harmful substances.

- Keep 12 V batteries out of the reach of children.
- Keep sparks and open flames away from 12 V batteries.
- Only charge 12 V batteries in well-ventilated rooms.
- Maintain a minimum clearance from inflammable materials when charging 12 V batteries.

  Minimum clearance 1 m (3 ft)
- Do not charge deeply discharged 12 V batteries if the charge is already below the minimum voltage.


  Minimum voltage before the start of the charge 9 V
- Dispose of 12 V batteries correctly if they have less than the minimum voltage.

- Disconnect negative cable ❶ from the 12-V battery.
- Pull back positive terminal cover and disconnect positive cable ❷ from the 12-V battery.
- Pull off starter relay ❸ and OCU ❹ and hang to the side.



– Open the battery holding bracket in the area Ⓐ and fold it upward.
– Take out the 12-V battery to the front.

15.2 Installing the 12-V battery




Main work

– Insert the 12-V battery into the battery compartment with the terminals facing forward and secure with holding bracket.

12-V battery (HJTZ5S-FP-C) (📖 p. 146)

– Attach the battery holding bracket in area Ⓐ and engage it.



– Attach starter relay ❶ and OCU ❷ to the holding bracket.
– Connect positive cable ❸ to the 12-V battery.

Guideline

Screw, battery terminal	M5	2.5 Nm (1.84 lbf ft)

Info
Contact disks Ⓑ must be mounted under the screws and the cable lug with the claws toward the battery terminal.

– Connect negative cable ❹ to the 12 V battery.

Guideline

Screw, battery terminal	M5	2.5 Nm (1.84 lbf ft)

Info
Contact disks Ⓑ must be mounted under the screws and the cable lug with the claws toward the battery terminal.

– Slide the positive terminal cover over the positive terminal.

Finishing work
– Mount the seat. (📖 p. 72)

15.3 Charging the 12-V battery

Warning
Risk of injury 12 V batteries contain harmful substances.
– Keep 12 V batteries out of the reach of children.
– Keep sparks and open flames away from 12 V batteries.
– Only charge 12 V batteries in well-ventilated rooms.
– Maintain a minimum clearance from inflammable materials when charging 12 V batteries.
Minimum clearance 1 m (3 ft)
– Do not charge deeply discharged 12 V batteries if the charge is already below the minimum voltage.
Minimum voltage before the start of the charge 9 V
– Dispose of 12 V batteries correctly if they have less than the minimum voltage.

Note
Environmental hazard 12 V batteries contain environmentally hazardous materials.
– Do not dispose of 12 V batteries as household waste.
– Dispose of 12 V batteries at a collection point for used batteries.

Note
Environmental hazard Hazardous substances cause environmental damage.
– Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.

Info

Even if there is no load on the 12-V battery, it discharges each day.
The charging level and the method of charging are very important for the service life of the 12-V battery.
Rapid recharging with a high charging current shortens the service life of the battery.
If the charging current or charging voltage are exceeded, the 12 V battery will be destroyed.
If the 12-V battery is depleted by repeated starting, the 12-V battery must be charged immediately.
If the 12-V battery is left in a discharged state for an extended period, it will become deeply discharged and suffer a loss of capacity, destroying the battery.
The 12-V battery is maintenance-free.

Preparatory work

– Remove the seat. (p. 71)
– Remove the 12-V battery. (p. 109)



Main work

– Check the battery voltage.
  » Battery voltage: < 9 V
    – Do not charge the 12 V battery.
    – Replace the 12 V battery and dispose of the old 12 V battery properly.
  » If the specifications have been met:
  Battery voltage: ≥ 9 V
    – Connect a battery charger to the 12-V battery. Switch on the battery charger.

    Guideline

The charging current, charging voltage, and charging time must not be exceeded.	
Maximum charging voltage	14.4 V
Maximum charging current	3.0 A
Maximum charging time	24 h
Recharge the 12-V battery regularly when the motorcycle is not being used	6 months
Ideal charging and storage temperature of the lithium-ion battery	10 … 20 °C (50 … 68 °F)

Battery charger (26529974000)

This battery charger tests whether the 12-V battery retains its voltage. It is also impossible to overcharge the 12-V battery with this battery charger. The charging time may be longer at low temperatures.

This battery charger is only suitable for lithium iron phosphate batteries. Read the accompanying instructions for **Husqvarna Motorcycles** accessories.

Info

Never remove cover 1.

– Switch off the battery charger after charging and disconnect it from the 12-V battery.

Finishing work

– Install the 12-V battery. (🔧 (📖 p. 110))
– Mount the seat. (📖 p. 72)

15.4 Changing the main fuse

Warning

Fire hazard Incorrect fuses overload the electrical system.


– Only use fuses with the required ampere value.
– Do not bypass or repair fuses.

Info

The main fuse protects all electrical power consumers of the vehicle.

Preparatory work

– Remove the seat. (📖 p. 71)
– Remove the 12-V battery. (🔧 (📖 p. 109))



Main work

– Take off the protection caps and remove faulty fuse ❶.


Info

A faulty fuse has a burned-out fuse wire Ⓐ.
A spare fuse ❷ is located in the starter relay.


Finishing work

– Install the 12-V battery. (🔧 (📖 p. 110))
– Mount the seat. (📖 p. 72)

15.5 Removing the headlight mask with the headlight




– Remove screws ❶. Slide the headlight mask up and swing it forward.
– Detach the brake line and wiring harness from the headlight mask.
– Pivot the headlight mask forwards and place it on the fender.




– Detach plug-in connectors ❷ and take off the headlight mask with the headlight.

15.6 Installing the headlight mask with the headlight



Main work

– Join plug-in connectors ❶.



– Position the brake line and the wiring harness in the cable guide.
– Position the headlight mask.
  ✔ The holding lugs engage in the fender.
– Mount and tighten screws ❷.


Finishing work

– Check the headlight setting. (📖 p. 116)

15.7 Changing the headlight bulb

Preparatory work

– Remove the headlight mask with the headlight. (📖 p. 113)




Main work

– Turn LED unit ❶ counterclockwise all the way and take it out of the reflector.

  Guideline

Only touch the LED unit on the cooling element.



– Insert the LED unit into the reflector and turn it clockwise all the way.

Headlight (LED)

Info
Ensure that O-ring ❷ is seated properly.

Finishing work
– Install the headlight mask with the headlight. (📖 p. 114)
– Check the headlight setting. (📖 p. 116)


15.8 Changing the turn signal bulb

Note
Impairments to reflectors and lamps Grease on the reflector reduces the emitted light.

Grease on the bulb will evaporate due to the heat and be deposited on the reflector.

Grease residue on the bulb reduces heat dissipation and increases the heat of the bulb, thus reducing its service life.

– Clean and degrease the bulbs before mounting.
– Do not touch the bulbs with your bare hands.



Main work
– Remove the screw and carefully take off turn signal glass ❶.
– Press the turn signal bulb ❷ carefully into the socket, turn it counterclockwise by about 30°, and pull it out of the socket.

Info
Do not touch the reflector with your fingers and keep it free from grease.


– Press the new turn signal bulb carefully into the socket and turn it clockwise until it stops.

Turn signal (RY10W / socket BAU15s) (📖 p. 146)

– Position the turn signal glass.
– Insert the screw and first turn counterclockwise until it engages in the thread with a small jerk. Tighten the screw lightly.

Finishing work
– Check that the turn signal system is functioning properly.

15.9 Checking the headlight setting



– Position the vehicle upright on a horizontal surface in front of a light wall and make a marking at the height of the center of the low beam headlight.
– Make another mark at a distance Ⓑ under the first marking.

Guideline

Distance Ⓑ	5 cm (2 in)

– Position the vehicle vertically at a distance Ⓐ away from the wall.

Guideline

Distance Ⓐ	5 m (16 ft)


– The rider now sits down on the motorcycle.
– Switch on the low beam.
– Check the headlight setting.

The boundary between light and dark must be exactly on the lower mark for a motorcycle with rider.

» If the boundary between light and dark does not meet specifications:
– Adjust the headlight range. (📖 p. 116)

15.10 Adjusting the headlight range

Preparatory work
– Check the headlight setting. (📖 p. 116)



Main work
– Loosen screw ❶.
– Adjust the headlight range by pivoting the headlight.

Guideline


The boundary between light and dark must be exactly on the lower mark for a motorcycle with rider (instructions on how to apply the mark: Checking the headlight setting).

Info
A change in weight on the vehicle may require a correction of the headlight range.

– Tighten screw ❶.


15.11 Changing the combination instrument battery

Preparatory work
– Remove the headlight mask with the headlight. (📖 p. 113)



Main work


– Remove screws ❶ with the washers.
– Pull the combination instrument upward out of the holder.



– Using a coin, turn protection cap ❷ all the way counter-clockwise and take it off.
– Remove combination instrument battery ❸.
– Insert the combination instrument battery with the label facing outward.

Combination instrument battery (CR 2430) (📖 p. 146)

– Check the O-ring of the protection cap for correct seating.




– Position protection cap ❷ and turn all the way clockwise using a coin.
– Press any button on the combination instrument.
  ✔ The combination instrument is activated.
– Position the combination instrument in the holder.
– Mount and tighten the screws with washers.

Finishing work

– Install the headlight mask with the headlight. (📖 p. 114)
– Check the headlight setting. (📖 p. 116)
– Set the combination instrument.


◆

15.12 Diagnostics connector



Diagnostics connector ❶ is located under the seat.

15.13 OCU



OCU ❶ is located under the seat.

The OCU replaces the electronic fuses and relays.

All outputs are switched depending on the signals of the voltage regulator and ECU.

The outputs are deactivated individually in the event of overcurrent.

This enables easy error detection because the status of each output is indicated via LED lights.


The OCU monitors the electronics system completely independently.

As soon as an indicated error is rectified, the status light of the OCU changes from red to green.

Overview

A	Ignition
B	Light
C	Brake light + horn
D	Fuel pump
E	Radiator fan

16.1 Cooling system



Water pump ❶ in the engine ensures forced circulation of the coolant.

The pressure resulting from the warming of the cooling system is regulated by a valve in radiator cap ❷. This ensures that operating the vehicle at the specified coolant temperature will not result in a risk of malfunctions.

120 °C (248 °F)

Cooling is effected by the air stream.

The lower the speed, the less the cooling effect. Dirty cooling fins also reduce the cooling effect.

Additional cooling is provided by the radiator fan, which is activated on a temperature-dependent basis.

16.2 Checking the antifreeze and coolant level

Warning


Danger of scalding During motorcycle operation, the coolant gets hot and is under pressure.

- Do not open the radiator, the radiator hoses or other cooling system components if the engine or the cooling system are at operating temperature.
- Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses or other components of the cooling system.
- In the event of scalding, rinse the area affected immediately with lukewarm water.

Warning

Danger of poisoning Coolant is harmful to health.

- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with the skin, the eyes and clothing.
- Consult a doctor immediately if coolant is swallowed.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant gets into the eyes.
- Change clothing if coolant spills onto your clothing.



Condition

The engine is cold.

- Stand the motorcycle upright on a horizontal surface.
- Remove the radiator cap.
- Check the antifreeze in the coolant.

−25 … −45 °C (−13 … −49 °F)

» If the antifreeze in the coolant does not match the specified value:

  - Correct the antifreeze in the coolant.

- Check the coolant level in the radiator.

Coolant level Ⓐ above the radiator fins	10 mm (0.39 in)

» If the coolant level does not match the specified value:

  - Correct the coolant level.

Coolant (📖 p. 151)

– Mount the radiator cap.

16.3 Checking the coolant level

Warning


Danger of scalding During motorcycle operation, the coolant gets hot and is under pressure.

– Do not open the radiator, the radiator hoses or other cooling system components if the engine or the cooling system are at operating temperature.
– Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses or other components of the cooling system.
– In the event of scalding, rinse the area affected immediately with lukewarm water.

Warning

Danger of poisoning Coolant is harmful to health.

– Keep coolant out of the reach of children.
– Do not allow coolant to come into contact with the skin, the eyes and clothing.
– Consult a doctor immediately if coolant is swallowed.
– Rinse the affected area immediately with plenty of water in the event of contact with the skin.
– Rinse eyes thoroughly with water and consult a doctor immediately if coolant gets into the eyes.
– Change clothing if coolant spills onto your clothing.



Condition

The engine is cold.

– Stand the motorcycle upright on a horizontal surface.
– Remove the radiator cap.
– Check the coolant level in the radiator.

Coolant level A above the radiator fins	10 mm (0.39 in)

» If the coolant level does not match the specified value:
– Correct the coolant level.

Coolant (📖 p. 151)

– Mount the radiator cap.

16.4 Draining the coolant

Warning

Danger of scalding During motorcycle operation, the coolant gets hot and is under pressure.

– Do not open the radiator, the radiator hoses or other cooling system components if the engine or the cooling system are at operating temperature.
– Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses or other components of the cooling system.
– In the event of scalding, rinse the area affected immediately with lukewarm water.

Warning

Danger of poisoning Coolant is harmful to health.


- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with the skin, the eyes and clothing.
- Consult a doctor immediately if coolant is swallowed.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant gets into the eyes.
- Change clothing if coolant spills onto your clothing.

Condition

The engine is cold.

Preparatory work

- Remove the engine guard. (p. 90)



Main work

- Position the motorcycle upright.
- Place an appropriate container under the water pump cover.
- Remove screw 1. Take off radiator cap 2.
- Completely drain the coolant.
- Mount and tighten screw 1 with a new seal ring.

  Guideline


Screw, water pump cover	M6	10 Nm (7.4 lbf ft)

16.5 Refilling with coolant

Warning

Danger of poisoning Coolant is harmful to health.

- Keep coolant out of the reach of children.
- Do not allow coolant to come into contact with the skin, the eyes and clothing.
- Consult a doctor immediately if coolant is swallowed.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse eyes thoroughly with water and consult a doctor immediately if coolant gets into the eyes.
- Change clothing if coolant spills onto your clothing.



Main work

- Make sure that screw 1 is tightened.
- Position the motorcycle upright.
- Pour coolant in up to measurement A above the radiator fins.

  Guideline

10 mm (0.39 in)

Coolant	1.2 l (1.3 qt.)	Coolant (p. 151)

- Mount the radiator cap.

Finishing work

- Go for a short test ride.
- Check the coolant level. (p. 120)

– Install the engine guard. (📖 p. 90)

16.6 Changing the coolant

Warning

Danger of scalding During motorcycle operation, the coolant gets hot and is under pressure.

– Do not open the radiator, the radiator hoses or other cooling system components if the engine or the cooling system are at operating temperature.
– Allow the cooling system and the engine to cool down before you open the radiator, the radiator hoses or other components of the cooling system.
– In the event of scalding, rinse the area affected immediately with lukewarm water.

Warning

Danger of poisoning Coolant is harmful to health.


– Keep coolant out of the reach of children.
– Do not allow coolant to come into contact with the skin, the eyes and clothing.
– Consult a doctor immediately if coolant is swallowed.
– Rinse the affected area immediately with plenty of water in the event of contact with the skin.
– Rinse eyes thoroughly with water and consult a doctor immediately if coolant gets into the eyes.
– Change clothing if coolant spills onto your clothing.

Condition

The engine is cold.

Preparatory work

– Remove the engine guard. (📖 p. 90)




Main work

– Position the motorcycle upright.
– Place an appropriate container under the water pump cover.
– Remove screw ❶. Take off radiator cap ❷.
– Completely drain the coolant.
– Mount and tighten screw ❶ with a new seal ring.

Guideline

Screw, water pump cover	M6	10 Nm (7.4 lbf ft)



– Pour coolant in up to level Ⓐ above the radiator fins.

Guideline

10 mm (0.39 in)


Coolant	1.2 l (1.3 qt.)	Coolant (📖 p. 151)

– Mount the radiator cap.

Finishing work

– Install the engine guard. (📖 p. 90)
– Go for a short test ride.
– Check the coolant level. (📖 p. 120)

17.1 Checking the play in the throttle cable



– Check the throttle grip for smooth operation.
– Move the handlebar to the straight-ahead position. Turn the throttle grip back and forth slightly and determine the play in throttle cable Ⓐ.

Play in throttle cable	3 … 5 mm (0.12 … 0.2 in)

» If the throttle cable play does not meet the specified value:
  – Adjust the play in the throttle cable. 🔧 (📖 p. 123)
– Push the cold start button in all the way.

When the throttle grip is turned forward, the cold start button returns to its original position.

» If the cold start button does not return to its original position:
  – Adjust the play in the throttle cable. 🔧 (📖 p. 123)

Danger
Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.
– Always make sure there is sufficient ventilation when running the engine.
– Use effective exhaust extraction when starting or running the engine in an enclosed space.

– Start the engine and let it run at idle speed. Move the handlebar to and fro over the entire steering range.


The idle speed must not change.

» If the idle speed changes:
  – Adjust the play in the throttle cable. 🔧 (📖 p. 123)

17.2 Adjusting the play in the throttle cable 🔧

Info
If the correct routing of the throttle cables has already been secured, the fuel tank does not need to be removed.

Preparatory work
– Remove the seat. (📖 p. 71)
– Remove the fuel tank. 🔧 (📖 p. 78)
– Check the throttle cable routing. (📖 p. 86)



Main work

- Move the handlebar to the straight-ahead position.
- Push back sleeve ❶.
- Loosen nut ❷.
- Turn adjusting screw ❸ in as far as possible.
- Loosen nut ❹.
- Push cold start button ❻ all the way to the stop.
- Turn adjusting screw ❺ so that the cold start button moves to the basic position when the throttle grip is turned to the front.
- Tighten nut ❹.
- Turn adjusting screw ❸ so that there is play in the throttle cable at the throttle grip.

  Guideline

Play in throttle cable	3 … 5 mm (0.12 … 0.2 in)

- Tighten nut ❷.
- Slide on sleeve ❶.
- Check the throttle grip for smooth operation.


Finishing work

- Check the play in the throttle cable. (📖 p. 123)

17.3 Adjusting the characteristic map of the throttle response


Info

On the throttle grip, the characteristic map of the throttle response is changed by changing the guide plate.
A guide plate with a different characteristic map is supplied.



Main work

- Push back sleeve ❶.
- Remove screws ❷ and half-shells ❸.
- Detach the throttle cables and take off the grip tube.



– Remove guide plate ❹ from handle tube ❺.
– Position the required guide plate on the grip tube.

Guideline

The label **OUTSIDE** must be visible. Marking Ⓐ must be positioned at marking Ⓑ.

Grey guide plate (79002014000)

Alternative 1


Black guide plate (79002014100)

Info

The gray guide plate opens the throttle valve more slowly.

The black guide plate opens the throttle valve more quickly.

The gray guide plate is mounted upon delivery.



– Clean the outside of the handlebar and the inside of the grip tube. Mount the grip tube on the handlebar.
– Attach the throttle cables to the guide plate and route correctly.
– Position half-shells ❸, mount and tighten screws ❷.

Guideline

Screw, throttle grip	M6	5 Nm (3.7 lbf ft)


– Slide on sleeve ❶ and check the throttle grip for ease of movement.

Finishing work

– Check the play in the throttle cable. (📖 p. 123)

17.4 Adjusting the idle speed

Warning
Danger of accidents The engine may go out spontaneously if the idle speed is set too low.
– Set the idle speed to the specified value. (Your authorized Husqvarna Motorcycles workshop will be glad to help.)



– Run the engine until warm.
✓ The cold start button is deactivated – The cold start button is in its basic position. (p. 22)

Danger
Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.
– Always make sure there is sufficient ventilation when running the engine.
– Use effective exhaust extraction when starting or running the engine in an enclosed space.

– Adjust the idle speed by turning idle speed adjusting screw 1 using a suitable tachometer.

Guideline


Idle speed	1,800 … 1,900 rpm

Service hour counter with revolution counter (A54012920100)

Info
Turning counterclockwise lowers the idle speed. Turning clockwise raises the idle speed.

17.5 Programming the throttle valve position

Info
If the control unit detects that the throttle valve position at idle speed needs to be reprogrammed, then the malfunction indicator lamp flashes 2x per second.



Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

- Always make sure there is sufficient ventilation when running the engine.
- Use effective exhaust extraction when starting or running the engine in an enclosed space.

– Allow the vehicle to run at idle speed.

✓ The malfunction indicator lamp stops flashing once programming is completed.

Info

If the engine becomes too warm, perform a cool-down ride at medium speed.


After this, do not switch off the engine, but leave it running at idle speed until the programming is finished.

17.6 Checking the basic position of the shift lever

Info

When driving, the shift lever must not touch the rider's boot when in the basic position.

When the shift lever keeps touching the boot, the transmission will be subject to an excessive load.




– Sit on the vehicle in the riding position and determine distance Ⓐ between the upper edge of your boot and the shift lever.

Gap between the shift lever and the top of the boot	10 … 20 mm (0.39 … 0.79 in)


» If the distance does not meet specifications:

– Adjust the basic position of the shift lever. (📖 p. 127)

17.7 Adjusting the basic position of the shift lever



– Remove screw ❶ with the washers and take off shift lever ❷.



– Clean gear teeth Ⓐ of the shift lever and shift shaft.
– Mount the shift lever on the shift shaft in the required position and engage gearing.

Info
The range of adjustment is limited.
The shift lever must not come into contact with any other vehicle components during the shift procedure.

– Mount and tighten screw ❶ with washers.

Guideline

Screw, shift lever	M6x16	14 Nm (10.3 lbf ft) **Loctite®243™**

18.1 Changing the fuel screen

Danger

Fire hazard Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

- Do not fuel the vehicle in the vicinity of open flames or lit cigarettes.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it off immediately.
- Observe the specifications for refueling.

Warning


Danger of poisoning Fuel is harmful to health.

- Avoid skin, eye and clothing contact with fuel.
- Immediately consult a doctor if you swallow fuel.
- Do not inhale fuel vapors.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse the eyes thoroughly with water, and consult a doctor in case of fuel contact with the eyes.
- Change your clothing if fuel spills on them.

Note

Environmental hazard Improper handling of fuel is a danger to the environment.

- Do not allow fuel to enter the groundwater, the soil, or the sewage system.



- Clean quick release coupling ❶ thoroughly with compressed air.

Info

Under no circumstances should dirt enter into the fuel line. Dirt in the fuel line clogs the injection valve!

- Disconnect the quick release coupling.

Info

Remaining fuel may flow out of the fuel hose.

- Pull fuel screen ❷ out of the connecting piece.
- Insert the new fuel screen all the way into the connecting piece.
- Spray silicone spray onto a lint-free cleaning cloth and lightly lubricate the O-ring of the quick-release coupling.

Silicone spray (📖 p. 153)

- Join the quick release coupling.

Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.


– Always make sure there is sufficient ventilation when running the engine.
– Use effective exhaust extraction when starting or running the engine in an enclosed space.

– Start the engine and check the response.

18.2 Checking the engine oil level

Preparatory work

– Stand the motorcycle upright on a horizontal surface.



Condition

The engine is cold.

– Check the engine oil level.

The engine oil reaches the lower edge of level viewer Ⓐ.

» If the engine oil does not reach the lower edge of the level viewer:
– Add engine oil. (📖 p. 133)

Condition

The engine is at operating temperature.

– Check the engine oil level.

Info

After switching off the engine, wait one minute before checking the level.

The engine oil is at a level between lower edge Ⓐ and middle Ⓑ of the level viewer.

» If the engine oil is not at a level between lower edge Ⓐ and middle Ⓑ of the level viewer:
– Add engine oil. (📖 p. 133)

18.3 Changing the engine oil and oil filter, cleaning the oil screens

Warning

Danger of scalding Engine and gear oil get hot when the motorcycle is operated.

– Wear suitable protective clothing and safety gloves.
– In the event of scalding, rinse the area affected immediately with lukewarm water.

Note


Environmental hazard Hazardous substances cause environmental damage.

– Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.


Info
Drain the engine oil with the engine at operating temperature.

Preparatory work
- Remove the engine guard. (p. 90)
- Park the motorcycle on a level surface.

Main work




- Position an appropriate container under the engine.
- Remove oil drain plug ❶ with the magnet and seal ring.




- Remove screw plug ❷ with the O-ring.

Info
Do not remove screw Ⓐ.




- Remove screw plug ❸ with long oil screen ❹ and the O-rings.
- Allow the engine oil to drain completely.
- Thoroughly clean the parts and the sealing surfaces.




- Mount and tighten screw plug ❷ with new O-ring.

Guideline

Screw plug, crankcase	M16x1.5	15 Nm (11.1 lbf ft)



– Position long oil screen ❹ with the O-rings on a pin wrench.
– Position the pin wrench through the drill hole of the screw plug in the opposite section of the engine case.
– Push the oil screen all the way into the engine case.



– Mount and tighten screw plug ❸ with the O-ring.


Guideline

Screw plug, oil screen	M20x1.5	15 Nm (11.1 lbf ft)


– Mount and tighten oil drain plug ❶ with the magnet and a new seal ring.

Guideline

Oil drain plug with magnet	M12x1.5	20 Nm (14.8 lbf ft)




– Remove screws ❺. Take off the oil filter cover with the O-ring.



– Pull oil filter ❻ out of the oil filter housing.

Lock ring plier (51012011000)

– Allow the engine oil to drain completely.
– Thoroughly clean the parts and the sealing surface.




– Lay the motorcycle on its side and fill the oil filter housing to about ⅓ full with engine oil.
– Insert the new oil filter into the oil filter housing.
– Oil the O-ring of the oil filter cover and mount it together with oil filter cover ❼.
– Mount and tighten the screws.

Guideline

Screw, oil filter cover	M6x16	10 Nm (7.4 lbf ft)

– Stand the motorcycle upright.



– Remove filler plug ❽ with the O-ring, and fill up with engine oil.

Engine oil	1.2 l (1.3 qt.)	Engine oil (SAE 10W/50) (📖 p. 151)

Info
Too little engine oil or poor-quality engine oil will result in premature wear of the engine.

– Mount and tighten the filler plug together with the O-ring.


Danger
Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.
– Always make sure there is sufficient ventilation when running the engine.
– Use effective exhaust extraction when starting or running the engine in an enclosed space.

– Start the engine and check it for leaks.

Finishing work
– Install the engine guard. (📖 p. 90)
– Check the engine oil level. (📖 p. 130)

18.4 Adding engine oil

Info
Too little engine oil or poor-quality engine oil will result in premature wear of the engine.



Main work
– Remove filler plug ❶ with the O-ring.
– Fill engine oil to the middle Ⓐ of the level viewer.

Engine oil (SAE 10W/50) (📖 p. 151)

Info
In order to achieve optimal engine oil performance, it is not advisable to mix different engine oils.
Husqvarna Motorcycles recommends changing the engine oil.

– Mount and tighten the filler plug together with the O-ring.

Danger

Danger of poisoning Exhaust gases are toxic and inhaling them may result in unconsciousness and death.

– Always make sure there is sufficient ventilation when running the engine.
– Use effective exhaust extraction when starting or running the engine in an enclosed space.

– Start the engine and check for leaks.

Finishing work

– Check the engine oil level. (📖 p. 130)

19.1 Cleaning the motorcycle

Note

Material damage Components become damaged or destroyed if a pressure cleaner is used incorrectly.

The high pressure forces water into the electrical components, connectors, throttle cables, and bearings, etc.

Pressure which is too high causes malfunctions and destroys components.

– Do not direct the water jet directly on to electrical components, connectors, throttle cables or bearings.
– Maintain a minimum distance between the nozzle of the pressure cleaner and the component.

Minimum clearance	60 cm (23.6 in)


Note

Environmental hazard Hazardous substances cause environmental damage.

– Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.

Info

To maintain the value and appearance of the motorcycle over a long period, clean it regularly.
Avoid direct sunshine when cleaning the motorcycle.



– Close off the exhaust system to keep water from entering.
– Remove the coarse dirt particles with a gentle water jet.
– Spray the heavily soiled parts with a normal commercial motorcycle cleaner and clean using a brush.

Info

Use warm water containing normal motorcycle cleaner and a soft sponge.
Never apply motorcycle cleaner to a dry vehicle; always rinse the vehicle with water first.

– After rinsing the motorcycle with a gentle spray of water, allow it to dry thoroughly.
– Remove the closure of the exhaust system.

Warning

Danger of accidents Moisture and dirt impair the brake system.

– Brake carefully several times to dry out and remove dirt from the brake linings and the brake discs.

– After cleaning, ride the vehicle a short distance until the engine warms up.

Info

The heat produced causes water at inaccessible locations in the engine and on the brake system to evaporate.

– After the motorcycle has cooled down, lubricate all moving parts and pivot points.
– Clean the chain. (📖 p. 81)

– Treat bare metal (except for brake discs and the exhaust system) with a corrosion inhibitor.

Preserving materials for paints, metal and rubber (📖 p. 153)

– Treat all plastic parts and powder-coated parts with a mild cleaning and care product.

Special cleaner for glossy and matte paint finishes, metal and plastic surfaces (📖 p. 153)

– Lubricate the steering lock.


Universal oil spray (📖 p. 154)

– Grease the ignition switch.

Universal oil spray (📖 p. 154)

19.2 Checks and maintenance steps for winter operation

Info
If you use the vehicle in winter, you must expect salt on the roads. You should therefore take precautions against aggressive road salt.
If the vehicle was operated in road salt, clean it with cold water after riding. Warm water would enhance the corrosive effects of salt.



– Clean the motorcycle. (📖 p. 135)
– Clean brake system.

Info
After **EVERY** trip on salted roads, thoroughly clean the brake calipers and brake linings, after they have cooled down and without removing them, with cold water and dry them carefully.
After riding on salted roads, thoroughly clean the vehicle with cold water and dry it well.

– Treat the engine, link fork, and all other bare or zinc-plated parts (except the brake discs) with a wax-based corrosion inhibitor.

Info
Corrosion inhibitor must not come in contact with the brake discs as this would greatly reduce the braking force.

– Clean the chain. (📖 p. 81)

20.1 Storage

Warning


Danger of poisoning Fuel is harmful to health.

- Avoid skin, eye and clothing contact with fuel.
- Immediately consult a doctor if you swallow fuel.
- Do not inhale fuel vapors.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse the eyes thoroughly with water, and consult a doctor in case of fuel contact with the eyes.
- Change your clothing if fuel spills on them.
- Keep fuels correctly in a suitable canister, and out of the reach of children.

Info

If you plan to garage the motorcycle for a longer period, perform the following steps or have them performed.

Before storing the motorcycle, check all parts for function and wear. If service, repairs, or replacements are necessary, you should do this during the storage period (less workshop overload). In this way, you can avoid long workshop waiting times at the start of the new season.



- When refueling for the last time before taking the motorcycle out of service, add fuel additive.
- Refuel. (p. 47)

Tip

Fill the fuel tank completely as specified, using fuel with the lowest possible ethanol content.

- Clean the motorcycle. (p. 135)
- Change the engine oil and the oil filter, clean the oil screens. (p. 130)
- Check the antifreeze and coolant level. (p. 119)
- Check the tire pressure. (p. 107)
- Remove the 12-V battery. (p. 109)
- Charge the 12-V battery. (p. 111)

  Guideline

Ideal charging and storage temperature of the lithium-ion battery	10 … 20 °C (50 … 68 °F)

- Store the vehicle in a dry location that is not subject to large fluctuations in temperature.


Info

Husqvarna Motorcycles recommends jacking up the motorcycle.

- Raise the motorcycle with a lift stand. (p. 59)
- Preferably cover the motorcycle with a tarp or similar cover that is permeable to air. Do not use non-porous materials since they prevent humidity from escaping, thus causing corrosion.

Info
Avoid running the engine for a short time only. Since the engine cannot warm up properly, the water vapor produced during combustion condenses and causes valves and the exhaust system to rust.

20.2 Preparing for use after storage



- Remove the motorcycle from the lift stand. (p. 59)
- Install the 12-V battery. (p. 110)
- Perform checks and maintenance measures when preparing for use. (p. 43)
- Take a test ride.

Faults	Possible cause	Action
The engine cannot be cranked (starter motor)	Operating error	– Carry out start procedure. (📖 p. 43)
	12-V battery discharged	– Charge the 12-V battery. 🔧 (📖 p. 111) – Check charging voltage. 🔧 – Check the open-circuit current. 🔧 – Check the stator winding of the alternator. 🔧
	Main fuse blown	– Change the main fuse. (📖 p. 113)
	Starter relay defective	– Check the starter relay. 🔧
	Starter motor defective	– Check the starter motor. 🔧
The engine turns but does not start	Operating error	– Carry out start procedure. (📖 p. 43)
	Quick release coupling not joined	– Join quick release coupling.
	Fuse **1** blown	– Change the fuses of individual electrical power consumers.
	Fuse **4** blown	– Change the fuses of individual electrical power consumers.
	Idle speed is not set correctly	– Adjust the idle speed. 🔧 (📖 p. 126)
	Spark plug sooty or wet	– Clean and dry the spark plug and spark plug connector, or change if necessary.
	Plug gap of spark plug too wide	– Adjust plug gap. Guideline Spark plug electrode gap 1.0 mm (0.039 in)
	Ignition system defective	– Check the ignition system. 🔧
	Short-circuit cable in wiring harness frayed, stop button or emergency OFF switch faulty	– Check the wiring harness. (visual check) – Check the electrical system.
	Error in the electronic fuel injection	– Read out the fault memory using the Husqvarna Motorcycles diagnostics tool. 🔧
Engine does not speed up	Error in the electronic fuel injection	– Read out the fault memory using the Husqvarna Motorcycles diagnostics tool. 🔧
	Ignition system defective	– Ignition coil - check the secondary winding. 🔧 – Check the spark plug connector. 🔧 – Check the stator winding of the alternator. 🔧
Engine has too little power	Air filter heavily contaminated	– Clean the air filter and air filter box. 🔧 (📖 p. 74)
	Fuel filter is very dirty	– Change the fuel filter. 🔧
	Fuel screen is very dirty	– Change the fuel screen. 🔧 (📖 p. 129)
	Error in the electronic fuel injection	– Read out the fault memory using the Husqvarna Motorcycles diagnostics tool. 🔧
	Exhaust system leaky, deformed or too little glass fiber yarn filling in the main silencer	– Check exhaust system for damage. – Change the glass fiber yarn filling in the main silencer. 🔧 (📖 p. 77)

Faults	Possible cause	Action
Engine has too little power	Valve clearance too little	– Adjust the valve clearance. 🔧
	Ignition system defective	– Ignition coil - check the secondary winding. 🔧 – Check the spark plug connector. 🔧 – Check the stator winding of the alternator. 🔧
The engine dies during the trip	Lack of fuel	– Refuel. (📖 p. 47)
	Fuse **1** blown	– Change the fuses of individual electrical power consumers.
	Fuse **4** blown	– Change the fuses of individual electrical power consumers.
Engine overheats	Coolant level low in cooling system	– Check the cooling system for leaks. – Check the coolant level. (📖 p. 120)
	Insufficient airflow	– Switch off engine when stationary.
	Radiator fins very dirty	– Clean radiator fins.
	Foam formation in cooling system	– Drain the coolant. 🔧 (📖 p. 120) – Refill with coolant. 🔧 (📖 p. 121)
	Bent radiator hose	– Change the radiator hose. 🔧
	Thermostat defective	– Check the thermostat. 🔧 Guideline Opening temperature: 70 °C (158 °F)
	Defect in radiator fan system	– Check fuse **3**. – Check the radiator fan. 🔧
Malfunction indicator lamp lights up or flashes	Error in the electronic fuel injection	– Check wiring for damage and electrical plug-in connectors for corrosion and damage. – Read out the fault memory using the Husqvarna Motorcycles diagnostics tool. 🔧
High oil consumption	Engine vent hose bent	– Route the vent hose without bends or replace it if necessary.
	Engine oil level too high	– Check the engine oil level. (📖 p. 130)
	Engine oil too thin (low viscosity)	– Change the engine oil and the oil filter, clean the oil screens. 🔧 (📖 p. 130)
	Piston and cylinder worn	– Measure the piston/cylinder mounting clearance. 🔧
12-V battery discharged	The 12-V battery is not being charged by the alternator	– Check charging voltage. 🔧 – Check the stator winding of the alternator. 🔧
	Unwanted electrical power consumer	– Check the open-circuit current. 🔧
Combination instrument values deleted (time, stop watch, lap times)	The combination instrument battery is empty	– Change combination instrument battery. (📖 p. 116)
The high beam, low beam, tail light, position light, and license plate lamp are not working	Fuse **2** blown	– Change the fuses of individual electrical power consumers.

Faults	Possible cause	Action
The horn, brake light, turn signal, and radiator fan are not working	Fuse **3** blown	– Change the fuses of individual electrical power consumers.

22 TECHNICAL SPECIFICATIONS

22.1 Engine

Design	1-cylinder 4-stroke engine, water-cooled
Displacement	510.9 cm³ (31.177 cu in)
Stroke	72 mm (2.83 in)
Bore	95 mm (3.74 in)
Compression ratio	12.75:1
Control	OHC, 4 valves controlled via rocker arm
Valve diameter, intake	40 mm (1.57 in)
Valve diameter, exhaust	33 mm (1.3 in)
Valve clearance	
Intake at: 20 °C (68 °F)	0.10 … 0.15 mm (0.0039 … 0.0059 in)
Exhaust at: 20 °C (68 °F)	0.12 … 0.17 mm (0.0047 … 0.0067 in)
Crankshaft bearing	2 cylinder roller bearing
Conrod bearing	Slide bearing
Piston pin bearing	Bearing bush
Pistons	Forged light alloy
Piston rings	1 compression ring, 1 oil scraper ring
Engine lubrication	Pressure circulation lubrication with 2 trochoidal pumps
Primary transmission	29:72
Clutch	Multidisc clutch in oil bath, hydraulically activated
Gearbox	6-gear transmission, claw shifted
Transmission ratio	
first-gear	13:33
second-gear	16:30
third-gear	18:26
fourth-gear	22:26
fifth-gear	23:23
sixth-gear	26:22
Alternator	14 V, 196 W
Ignition	Contactless controlled fully electronic ignition with digital ignition adjustment
Spark plug	NGK LZMAR8BI - 10
Spark plug electrode gap	1.0 mm (0.039 in)
Cooling	Water cooling, permanent circulation of coolant by water pump
Starting aid	Starter motor

22.2 Engine tightening torques

Oil nozzle for the clutch lubrication (alternator cover sealing surface)	M4	0.8 Nm (0.59 lbf ft)
Screw, oil nozzle bent for piston cooling	M4	2 Nm (1.5 lbf ft) **Loctite®243™**
Crankshaft speed sensor screw and cable retainer	M5	6 Nm (4.4 lbf ft) **Loctite®243™**
Oil nozzle for piston cooling	M5	2 Nm (1.5 lbf ft) **Loctite®243™**
Oil nozzle for timing chain lubrication	M5	2 Nm (1.5 lbf ft) **Loctite®243™**
Screw, bearing retainer	M5	6 Nm (4.4 lbf ft) **Loctite®243™**
Screw, clutch adjusting ring	M5x16	6 Nm (4.4 lbf ft)
Screw, clutch spring retainer	M5	8 Nm (5.9 lbf ft)
Screw, gear position sensor	M5x14	5 Nm (3.7 lbf ft) **Loctite®243™**
Screw, lock washer, oil pump idler gear	M5x10	6 Nm (4.4 lbf ft) **Loctite®243™**
Screw, locking lever	M5	6 Nm (4.4 lbf ft) **Loctite®243™**
Screw, pressure pump cover	M5x16	6 Nm (4.4 lbf ft) **Loctite®243™**
Screw, stator	M5	6 Nm (4.4 lbf ft) **Loctite®2701™**
Screw, suction pump cover	M5x16	6 Nm (4.4 lbf ft) **Loctite®243™**
Screws, main bearing lock washer, transmission bearings	M5x12	6 Nm (4.4 lbf ft)
Nut, water pump impeller	M6	6 Nm (4.4 lbf ft) **Loctite®243™**
Remaining screws, alternator cover	M6	10 Nm (7.4 lbf ft)
Remaining screws, clutch cover	M6	10 Nm (7.4 lbf ft)
Screw, alternator cover	M6x25	10 Nm (7.4 lbf ft)
Screw, balancer shaft fastening to water pump cover	M6	10 Nm (7.4 lbf ft) **Loctite® 222™**
Screw, clutch cover	M6x25	10 Nm (7.4 lbf ft)
Screw, clutch cover	M6x55	10 Nm (7.4 lbf ft)
Screw, clutch slave cylinder	M6	10 Nm (7.4 lbf ft)
Screw, cylinder head	M6x75	10 Nm (7.4 lbf ft)
Screw, engine case	M6x65	10 Nm (7.4 lbf ft)
Screw, engine case	M6x80	10 Nm (7.4 lbf ft)
Screw, exhaust flange	M6x16	10 Nm (7.4 lbf ft) **Loctite®243™**
Screw, fuel vapor retention system connection	M6	2.5 Nm (1.84 lbf ft) **Loctite®2701™**

Screw, oil filter cover	M6x16	10 Nm (7.4 lbf ft)
Screw, shift drum locating unit	M6x30	10 Nm (7.4 lbf ft) **Loctite®243™**
Screw, shift lever	M6x16	14 Nm (10.3 lbf ft) **Loctite®243™**
Screw, starter motor	M6x25	10 Nm (7.4 lbf ft)
Screw, tensioning rail	M6	10 Nm (7.4 lbf ft) **Loctite®243™**
Screw, timing chain clip	M6	10 Nm (7.4 lbf ft) **Loctite®243™**
Screw, timing chain tensioner	M6	10 Nm (7.4 lbf ft)
Screw, torque governor	M6	10 Nm (7.4 lbf ft) **Loctite®243™**
Screw, valve cover	M6	10 Nm (7.4 lbf ft)
Screw, water pump cover	M6x20	10 Nm (7.4 lbf ft)
Screw, water pump cover	M6x25	10 Nm (7.4 lbf ft) **Loctite®243™**
Screw, water pump cover	M6x45	10 Nm (7.4 lbf ft)
Screws, section of the engine case	M6	10 Nm (7.4 lbf ft)
Plug, oil channel	M7	9 Nm (6.6 lbf ft) **Loctite®243™**
Screw, camshaft retaining bracket	M7x1	15 Nm (11.1 lbf ft)
Screw, rocker arm bearing	M7x1	15 Nm (11.1 lbf ft)
Crankshaft clamp screw plug	M8	10 Nm (7.4 lbf ft)
Crankshaft locking bolt	M8	10 Nm (7.4 lbf ft)
Plug, timing chain tensioner	M8	8 Nm (5.9 lbf ft)
Plug, oil channel	M10	15 Nm (11.1 lbf ft) **Loctite®243™**
Screw, engine sprocket	M10	60 Nm (44.3 lbf ft) **Loctite®2701™**
Screw, rotor	M10x1	70 Nm (51.6 lbf ft)
Spark plug	M10x1	10 … 12 Nm (7.4 … 8.9 lbf ft)
Engine coolant temperature sensor	M10x1.25	12 Nm (8.9 lbf ft)
Screw, cylinder head	M10x1.25	1st stage 10 Nm (7.4 lbf ft) 2nd stage 30 Nm (22.1 lbf ft) 3rd stage 50 Nm (36.9 lbf ft) Collar and thread oiled
Oil drain plug with magnet	M12x1.5	20 Nm (14.8 lbf ft)
Screw plug, oil pressure control valve	M12x1.5	20 Nm (14.8 lbf ft)
Screw plug, crankcase	M16x1.5	15 Nm (11.1 lbf ft)
Nut, inner clutch hub	M18x1.5	100 Nm (73.8 lbf ft)
Nut, primary gear wheel	M18LHx1.5	120 Nm (88.5 lbf ft)
Screw plug, oil screen	M20x1.5	15 Nm (11.1 lbf ft)

Screw plug, alternator cover	M24x1.5	18 Nm (13.3 lbf ft)

22.3 Capacities

22.3.1 Engine oil

Engine oil	1.2 l (1.3 qt.)	Engine oil (SAE 10W/50) (📖 p. 151)

22.3.2 Coolant

Coolant	1.2 l (1.3 qt.)	Coolant (📖 p. 151)

22.3.3 Fuel

Total fuel tank capacity, approx.	8.0 l (2.11 US gal)	Super unleaded (ROZ 95) (📖 p. 152)

Fuel reserve, approx.	1.5 l (1.6 qt.)

22.4 Chassis

Frame	Central tube frame made of chrome molybdenum steel tubing
Fork	**WP XPLOR CC**
Suspension travel	
front	300 mm (11.81 in)
rear	310 mm (12.2 in)
Fork offset	22 mm (0.87 in)
Shock absorber	**WP XPLOR LDS**
Brake system	Disc brakes, floating brake calipers
Brake discs - diameter	
front	260 mm (10.24 in)
rear	220 mm (8.66 in)
Brake discs - wear limit	
front	2.5 mm (0.098 in)
rear	3.5 mm (0.138 in)
Offroad tire pressure	
front	1.0 bar (15 psi)
rear	1.0 bar (15 psi)
Street tire pressure	
front	2.0 bar (29 psi)
rear	2.0 bar (29 psi)
Final drive	13:50
Chain	5/8 x 1/4"
Rear sprockets available	45, 48, 49, 50, 51, 52
Steering head angle	63.9°
Wheelbase	1,487 ± 10 mm (58.54 ± 0.39 in)
Seat height unloaded	952 mm (37.48 in)
Ground clearance unloaded	343 mm (13.5 in)

Weight without fuel, approx.	110.8 kg (244.3 lb.)
Maximum permissible front axle load	145 kg (320 lb.)
Maximum permissible rear axle load	190 kg (419 lb.)
Maximum permissible overall weight	335 kg (739 lb.)

22.5 Electrical system

12-V battery	HJTZ5S-FP-C	Lithium-ion battery Battery voltage: 12 V Nominal capacity: 2.0 Ah Maintenance-free
Combination instrument battery	CR 2430	Battery voltage: 3 V
Fuse	75011088005	5 A
Fuse	75011088010	10 A
Fuse	58011109120	20 A
Headlight	LED	
Parking light	LED	
Indicator lamp	W2.3W / socket W2x4.6d	12 V 2.3 W
Turn signal	RY10W / socket BAU15s	12 V 10 W
Tail light	LED	
Brake light	LED	
License plate lamp	LED	

22.6 Tires

Front tire	**Rear tire**
90/90 - 21 M/C 54S M+S TT Continental TKC 80	**120/90 - 18 M/C 65R M+S TT** Continental TKC 80
The tires specified represent one of the possible series production tires. For alternative manufacturers, if any, contact an authorized dealer or qualified tire dealership. If local road approval regulations apply, these and the respective technical specifications must be observed. Additional information is available in the Service section under: www.husqvarna-motorcycles.com	

22.7 Fork

Fork article number	A390C169X402000
Fork	**WP XPLOR CC**
Compression damping	
Comfort	17 clicks
Standard	15 clicks
Sport	7 clicks
Rebound damping	
Comfort	19 clicks
Standard	17 clicks
Sport	9 clicks
Spring preload – preload adjuster	0 turns

Spring length with preload spacer(s)	476 mm (18.74 in)
Spring rate	
Weight of rider: 65 … 75 kg (143 … 165 lb.)	4.4 N/mm (25.1 lb/in)
Weight of rider: 75 … 85 kg (165 … 187 lb.)	4.6 N/mm (26.3 lb/in)
Weight of rider: 85 … 95 kg (187 … 209 lb.)	4.8 N/mm (27.4 lb/in)
Fork length	940 mm (37.01 in)

Oil capacity, external mechanism	390 ml (13.19 fl. oz.)	Fork oil (SAE 4) (48601166S1) (📖 p. 152)
Oil capacity, cartridge	175 ml (5.92 fl. oz.)	Fork oil (SAE 4) (48601166S1) (📖 p. 152)

22.8 Shock absorber

Shock absorber article number	A390C467X408000
Shock absorber	**WP XPLOR LDS**
Lowspeed compression damping	
Comfort	18 clicks
Standard	15 clicks
Sport	12 clicks
Highspeed compression damping	
Comfort	2.5 turns
Standard	2 turns
Sport	1.5 turns
Rebound damping	
Comfort	18 clicks
Standard	15 clicks
Sport	12 clicks
Spring preload	7 mm (0.28 in)
Spring rate	
Weight of rider: 65 … 75 kg (143 … 165 lb.)	42 N/mm (240 lb/in)
Weight of rider: 75 … 85 kg (165 … 187 lb.)	45 N/mm (257 lb/in)
Weight of rider: 85 … 95 kg (187 … 209 lb.)	48 N/mm (274 lb/in)
Spring length	240 mm (9.45 in)
Gas pressure	10 bar (145 psi)
Static sag	40 mm (1.57 in)
Riding sag	110 mm (4.33 in)
Fitted length	456.3 mm (17.965 in)

Shock absorber oil	Shock absorber fluid (SAE 2.5) (50180751S1) (📖 p. 152)

22.9 Chassis tightening torques

Fitting, inlet sleeve to throttle valve body	-	2.8 Nm (2.07 lbf ft)
Hose clamp, radiator	-	2.4 Nm (1.77 lbf ft)
Hose connector, active carbon filter	-	3.8 Nm (2.8 lbf ft)
Outer membrane screw cap	**EJOT PT®** 35x25	0.8 Nm (0.59 lbf ft)
Remaining screws, chassis	**EJOT PT®** K60x25-Z	2 Nm (1.5 lbf ft)
Schraube Kraftstoffpumpe		2.5 Nm (1.84 lbf ft)
Screw cap, inner membrane	**EJOT PT®** 30x5.5	1 Nm (0.7 lbf ft)
Screw, air filter box, on subframe	**EJOT PT®** K70x25	5 Nm (3.7 lbf ft)
Screw, fuel pump	**EJOT PT®** K60x25-Z	2.5 Nm (1.84 lbf ft)
Screw, intake air temperature sensor	**EJOT PT®** K50x18	0.7 Nm (0.52 lbf ft)
Screw, intake air temperature sensor		0.7 Nm (0.52 lbf ft)
Screw, pressure regulator	**EJOT PT®** K60x25-Z	2.3 Nm (1.7 lbf ft)
Screw, fixed grip	M4	5 Nm (3.7 lbf ft) **Loctite®243™**
Spoke nipple, front wheel	M4.5	6 Nm (4.4 lbf ft)
Spoke nipple, rear wheel	M4.5	6 Nm (4.4 lbf ft)
Remaining nuts, chassis	M5	5 Nm (3.7 lbf ft)
Remaining screws, chassis	M5	5 Nm (3.7 lbf ft)
Screw, battery terminal	M5	2.5 Nm (1.84 lbf ft)
Screw, frame protector	M5	3 Nm (2.2 lbf ft)
Screw, shock absorber adjusting ring	M5	5 Nm (3.7 lbf ft)
Screw, spoiler on fuel tank	M5x12	2 Nm (1.5 lbf ft)
Screw, throttle valve body cover	M5	2.6 Nm (1.92 lbf ft)
Screws on main silencer	M5	7 Nm (5.2 lbf ft)
Nut, starter motor	M6	4 Nm (3 lbf ft)
Nut, throttle cable on throttle valve body	M6	3 Nm (2.2 lbf ft)
Remaining nuts, chassis	M6	10 Nm (7.4 lbf ft)
Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)
Screw for spoiler attachment	M6	6 Nm (4.4 lbf ft)
Screw, ball joint of push rod on rear brake cylinder	M6	10 Nm (7.4 lbf ft) **Loctite®243™**
Screw, battery support bracket	M6	6 Nm (4.4 lbf ft)
Screw, brake lever	M6	5 Nm (3.7 lbf ft)
Screw, brake line guide on link fork	M6	4.5 Nm (3.32 lbf ft)
Screw, cable on starter relay	M6	6 Nm (4.4 lbf ft)
Screw, chain guide on link fork	M6	10 Nm (7.4 lbf ft)
Screw, chain sliding guard	M6	6 Nm (4.4 lbf ft) **Loctite®243™**
Screw, clutch lever	M6	5 Nm (3.7 lbf ft)

Screw, front brake disc	M6	14 Nm (10.3 lbf ft) **Loctite®243™**
Screw, ground wire in tail section	M6	10 Nm (7.4 lbf ft)
Screw, rear brake disc	M6	14 Nm (10.3 lbf ft) **Loctite®243™**
Screw, rear seat fixing	M6	10 Nm (7.4 lbf ft)
Screw, throttle grip	M6	5 Nm (3.7 lbf ft)
Fuel connection on fuel pump	M8	15 Nm (11.1 lbf ft)
Nut, rear sprocket screw	M8	35 Nm (25.8 lbf ft) **Loctite®2701™**
Nut, rim lock	M8	12 Nm (8.9 lbf ft)
Rear brake lever stop nut	M8	20 Nm (14.8 lbf ft)
Remaining nuts, chassis	M8	25 Nm (18.4 lbf ft)
Remaining screws, chassis	M8	25 Nm (18.4 lbf ft)
Screw, bottom triple clamp	M8	12 Nm (8.9 lbf ft)
Screw, chain sliding piece	M8	15 Nm (11.1 lbf ft)
Screw, engine brace	M8x15	25 Nm (18.4 lbf ft) **Loctite®2701™**
Screw, engine brace	M8x20	25 Nm (18.4 lbf ft) **Loctite®243™**
Screw, engine sprocket cover	M8	15 Nm (11.1 lbf ft)
Screw, fork stub	M8	15 Nm (11.1 lbf ft)
Screw, front brake caliper	M8	25 Nm (18.4 lbf ft) **Loctite®243™**
Screw, handlebar clamp	M8	20 Nm (14.8 lbf ft)
Screw, manifold	M8	15 Nm (11.1 lbf ft)
Screw, side stand attachment	M8	33 Nm (24.3 lbf ft) **Loctite®2701™**
Screw, subframe	M8x20	30 Nm (22.1 lbf ft) **Loctite®2701™**
Screw, subframe	M8x30	30 Nm (22.1 lbf ft) **Loctite®2701™**
Screw, top steering stem	M8	20 Nm (14.8 lbf ft) **Loctite®243™**
Screw, top triple clamp	M8	17 Nm (12.5 lbf ft)
Screw, wheel speed sensor on axle clamp	M8	4.5 Nm (3.32 lbf ft)
Engine attachment bolt	M10	60 Nm (44.3 lbf ft)
Remaining nuts, chassis	M10	45 Nm (33.2 lbf ft)
Remaining screws, chassis	M10	45 Nm (33.2 lbf ft)
Screw, bottom shock absorber	M10	60 Nm (44.3 lbf ft) **Loctite®2701™**
Screw, handlebar holder	M10	40 Nm (29.5 lbf ft) **Loctite®243™**
Screw, top shock absorber	M10	60 Nm (44.3 lbf ft) **Loctite®2701™**
Nut, fuel pump fixation	M12	15 Nm (11.1 lbf ft)
Nut, angle lever to link fork	M14x1.5	80 Nm (59 lbf ft)

Nut, fork pivot	M16x1.5	100 Nm (73.8 lbf ft)
Nut, frame on linkage lever	M16x1.5	80 Nm (59 lbf ft)
Nut, linkage lever on angle lever	M16x1.5	80 Nm (59 lbf ft)
Screw, front wheel spindle	M20x1.5	35 Nm (25.8 lbf ft)
Screw, top steering head	M20x1.5	12 Nm (8.9 lbf ft)
Nut, wheel spindle, rear	M22x1.5	80 Nm (59 lbf ft)
Screw-in fitting, cooling system	M24x1.5	7.5 Nm (5.53 lbf ft)

Brake fluid DOT 4 / DOT 5.1

Standard/classification

– DOT

Guideline

– Use only brake fluid that complies with the specified standard (see specifications on the container) and that exhibits the corresponding properties.

Recommended supplier

Castrol

– **REACT PERFORMANCE DOT 4**

MOTOREX®

– **Brake Fluid DOT 5.1**

Coolant

Guideline

– Only use high-grade, silicate-free coolant with corrosion inhibitor additive for aluminum motors. Low grade and unsuitable antifreeze causes corrosion, deposits and frothing.

– Do not use pure water as only coolant is able to meet the requirements needed in terms of corrosion protection and lubrication properties.

– Only use coolant that complies with the requirements stated (see specifications on the container) and that has the relevant properties.

Antifreeze protection to at least	−25 °C (−13 °F)

The mixture ratio must be adjusted to the necessary antifreeze protection. Use distilled water if the coolant needs to be diluted.

The use of premixed coolant is recommended.

Observe the coolant manufacturer specifications for antifreeze protection, dilution and miscibility (compatibility) with other coolants.

Recommended supplier

MOTOREX®

– **COOLANT M3.0**

Engine oil (SAE 10W/50)

Standard/classification

– JASO T903 MA2 (📖 p. 155)

– SAE (📖 p. 155) (SAE 10W/50)

Guideline

– Use only engine oils that comply with the specified standards (see specifications on the container) and that possess the corresponding properties.

Fully synthetic engine oil

Recommended supplier

MOTOREX®

– **Cross Power 4T**

Fork oil (SAE 4) (48601166S1)

Standard/classification

– SAE (📖 p. 155) (SAE 4)

Guideline

– Use only oils that comply with the specified standards (see specifications on the container) and that exhibit the corresponding properties.

Shock absorber fluid (SAE 2.5) (50180751S1)

Standard/classification

– SAE (📖 p. 155) (SAE 2.5)

Guideline

– Use only oils that comply with the specified standards (see specifications on the container) and that exhibit the corresponding properties.

Super unleaded (ROZ 95)

Standard/classification

– DIN EN 228 (ROZ 95)

Guideline

– Only use super unleaded fuel that matches or is equivalent to the specified standard.

– Fuel with an ethanol content of up to 10% (E10 fuel) is safe to use.

Info

Do **not** use fuel containing methanol (e.g., M15, M85, M100) or more than 10% ethanol (e.g., E15, E25, E85, E100).

Air filter cleaner

Recommended supplier
MOTOREX®
– **Racing Bio Dirt Remover**

Chain cleaner

Recommended supplier
MOTOREX®
– **Chain Clean**

High viscosity grease

Recommended supplier
SKF®
– **LGHB 2**

Long-life grease

Recommended supplier
MOTOREX®
– **Bike Grease 2000**

Off-road chain spray

Recommended supplier
MOTOREX®
– **Chainlube Offroad**

Oil for foam air filter

Recommended supplier
MOTOREX®
– **Racing Bio Liquid Power**

Preserving materials for paints, metal and rubber

Recommended supplier
MOTOREX®
– **Moto Protect**

Silicone spray

Recommended supplier
MOTOREX®
– **Silicone Spray**

Special cleaner for glossy and matte paint finishes, metal and plastic surfaces

Recommended supplier
MOTOREX®
– **Quick Cleaner**

Universal oil spray

Recommended supplier
MOTOREX®
– **Joker 440 Synthetic**

JASO T903 MA2

Different technical development directions required a separate specification for motorcycles – the **JASO T903 MA2** standard.
Earlier, engine oils from the automobile industry were used for motorcycles because there was no separate motorcycle specification.
Whereas long service intervals are demanded for automobile engines, the focus for motorcycle engines is on high performance at high engine speeds.
In most motorcycle engines, the transmission and clutch are lubricated with the same oil.
The **JASO T903 MA2** standard meets these special requirements.

SAE

The SAE viscosity classes were defined by the Society of Automotive Engineers and are used for classifying oils according to their viscosity. The viscosity describes only one property of oil and says nothing about quality.

OBD	On-board diagnosis	Vehicle system, which monitors the specified parameters of the vehicle electronics

Art. no.	Article number
ca.	circa
cf.	compare
e.g.	for example
etc.	et cetera
i.a.	inter alia
no.	number
poss.	possibly

28 LIST OF SYMBOLS

28.1 Yellow and orange symbols

Yellow and orange symbols indicate an error condition that requires prompt intervention. Active driving aids are also represented by yellow or orange symbols.

	Malfunction indicator lamp lights up/flashes yellow – The OBD has detected an error in the vehicle electronics. Come safely to a halt, and contact an authorized Husqvarna Motorcycles workshop.
	The fuel level warning lamp lights up yellow – The fuel level has reached the reserve mark.

28.2 Green and blue symbols

Green and blue symbols reflect information.

	The high beam indicator lamp lights up blue – The high beam is switched on.
	Turn signal indicator lamp flashes green – The turn signal is switched on.

1

12-V battery
charging 111
starting power 40

12-V battery
installing 110
removing 109

A

Accessories 14

Air filter
cleaning 74
installing 73
removing 73

Air filter box
cleaning 74

Air filter box cover
installing 72
removing 72

Antifreeze
checking 119

Auxiliary substances 14

B

Basic chassis setting
rider's weight, checking with 50

Brake discs
checking 91

Brake fluid
front brake, adding 92
rear brake, adding 98

Brake fluid level
of front brake, checking 92
of rear brake, checking 98

Brake lining retainers
of front brake, checking 93
of rear brake, checking 99

Brake linings
of front brake, changing 94
of front brake, checking 93
of rear brake, checking 99
of the rear brake, changing 100

Brake system 91-102

C

Capacity
coolant 121-122, 145
engine oil 133, 145
fuel 47, 145

Chain
checking 83
cleaning 81

Chain guide
checking 83

Chain tension
adjusting 82
checking 82

Characteristic map of the throttle response
adjusting 124

Clutch
fluid level, checking/correcting 88
fluid, changing 89

Clutch lever 19
basic position, adjusting 88

Cold start button 22

Combination instrument
adjusting 27
combination instrument battery, changing . . 116
overview 26
setting kilometers or miles 26
the clock, setting 28
viewing the lap time 28

Compression damping
fork, adjusting 56

Coolant
antifreeze and coolant level, checking 119
changing 122
draining 120
level, checking 120
refilling 121

Cooling system 119
Customer service 14

D

Defined use 7
Diagnostics connector 117

Difficult operating conditions 40
dry sand 40
high temperatures 42
low temperature 42
muddy surfaces 41
slow speed 42
snow 42
wet sand 41
wet surfaces 41

E

Engine
running in 39

Engine guard
installing 90
removing 90
Engine number 17
Engine oil
adding 133
changing 130
Engine oil level
checking 130
Engine sprocket
checking 83
Environment 13

F

Figures 14
Filling up
fuel 47
Foot brake lever 24
basic position, adjusting 97
free travel, checking 96
Fork legs
basic setting, checking 55
bleeding 59
dust boots, cleaning 60
installing 62
removing 61
Fork protector
installing 61
removing 60
Frame
checking 86
Frame protector
installing 63
removing 62
Front fender
installing 68
removing 67
Front wheel
installing 104
removing 103
Fuel screen
changing 129
Fuel tank
installing 79
removing 78
Fuel tank filler cap
closing 22
opening 21
Fuel, oils, etc. 14
Fuse
main fuse, changing 113

H

Hand brake lever 19
basic position, adjusting 91
Handlebar position 57
adjusting 57
Headlight
range, adjusting 116
Headlight bulb
changing 114
Headlight mask with headlight
installing 114
removing 113
Headlight setting
checking 116
High-speed compression damping
shock absorber, adjusting 51
Horn button 20

I

Idle speed
adjusting 126
Idle speed adjusting screw 23
Ignition lock 19
Implied warranty 14
Intended use 7

K

Key number 17

L

Light switch 20
Link fork
checking 86
Lower triple clamp
installing 64
removing 63
Low-speed compression damping
shock absorber, adjusting 50

M

Main fuse
changing 113
Main silencer
clean spark arrestor 76
glass fiber yarn filling, changing 77
installing 75
removing 75

Manufacturer warranty 14
Misuse 7
Motorcycle
cleaning 135
lift stand, raising with 59
lift stand, removing from 59

O

OCU 118
Oil filter
changing 130
Oil screens
cleaning 130
Overview of indicator lights 21
Owner's Manual 13

P

Play in throttle cable
adjusting 123
checking 123
Preparing for use
advice on preparing for first use 38
after storage 138
checks and maintenance measures when preparing for use 43
Protective clothing 12

R

Rear sprocket
checking 83
Rear wheel
installing 105
removing 104
Rebound damping
fork, adjusting 56
shock absorber, adjusting 52
Riding sag
adjusting 55
Rubber grip
checking 87

S

Safe operation 11
Seat
mounting 72
removing 71
Service 14
Service schedule 48-49
Shift lever 23
basic position, adjusting 127
basic position, checking 127
Shock absorber
installing 69
removing 68
riding sag, checking 53
spring preload, adjusting 54
static sag, checking 53
Side cover, right
installing 75
removing 74
Side stand 24
Spare parts 14
Spoke tension
checking 108
Start button 20
Starting 43
Starting power of lithium-ion batteries at low temperatures 40
Steering
locking 25
unlocking 25
Steering head bearing
lubricating 67
Steering head bearing play
adjusting 66
checking 66
Stop button 20
Storage 137-138

T

Technical specifications
capacities 145
chassis 145
chassis tightening torques 148
electrical system 146
engine 142
engine tightening torques 143
fork 146
shock absorber 147
tires 146
Throttle cable routing
checking 86
Throttle grip 19
Throttle valve position
programming 126
Tire condition
checking 107
Tire pressure
checking 107
Transporting 46

Troubleshooting 139-141
Turn signal bulb
changing 115
Turn signal switch 21
Type label 17

V

Vehicle identification number 17
View of vehicle
front left 15
rear right 16

W

Winter operation
checks and maintenance steps 136
Work rules 12

3402722en

30.11.2023



Husqvarna Motorcycles GmbH
Stallhofnerstraße 3 | 5230 Mattighofen | Austria
www.husqvarna-motorcycles.com

Photo: Mitterbauer/KISKA,
Husqvarna Motorcycles GmbH