DIAMO® Blaze

PARTS CATALOG

Third Edition August 2008



Copyright © 2004-2008 LS MotorSports, LLC. Reproduction without written permission is completely forbidden.

The information and diagrams included in this catalog are the exclusive property of LS MotorSports, LLC and may not be reproduced in any media without the express written consent of LS MotorSports, LLC.
For more information contact:

LS MotorSports, LLC
10215 S Sam Houston Pkwy
Houston, TX 77071
281-277-6140

Information contained in this publication is subject to change without notice.
For the most up to date information please contact DIAMO USA or an Authorized Dealer

GO PLACES

DIAMO™


www.DIAMOUSA.com

Copyright © 2004-2008 LS MotorSports, LLC. Reproduction without written permission is completely forbidden.

CONTENTS

PAGE	TITLE
4	CYLINDER HEAD CYLINDER BLOCK
5	COVER, CYLINDER HEAD INTAKE
6	CAMSHAFT & VALVES
7	CAM CHAIN, TENSIONER
8	CRANKCASE
9	CRANKSHAFT, PISTON
10	STARTER MOTOR
11	COVER, LEFT CRANKCASE AND GENERATOR
12	STARTER CLUTCH AND COVER
13	COVER, RIGHT CRANKCASE
14	PRIMARY CLUTCH
15	SECONDARY CLUTCH
16	TRANSMISSION
17	EXHAUST
18	FRONT FENDER
19	REAR FENDER & FOOTREST
20	SEAT
21	FUEL TANK
22	STEERING
23	FRONT WHEEL
24	BUMPER
25	HANDLEBAR & CABLES
26	FRONT SUSPENSION
27	DRIVE CHAIN
28	REAR SUSPENSION
29	FRAME
30	REAR AXLE
31	ELECTRICAL
32	HEADLIGHT
33	AIR CLEANER
34	CARBURETOR

CYLINDER HEAD CYLINDER BLOCK




E-1

REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-E0101	JH70.20102	Cylinder Block	
2	05-32-E0102	JH70.20101	Gasket, Cylinder	
3	05-32-E0103	JH70.20153	Cylinder Head Assy	
4	05-32-E0104	JH70.20143	Gasket Assy, Cylinder Head	
5	05-32-E0105	JH70.20132	Pin, Dowel	
6	05-32-E0106	JH70.20131	Bolt	
7	05-32-E0107	JH70.20134	Bush	
8	05-32-E0108	JH70.20128	Washer	
9	05-32-E0109	JH70.20127	Gasket	
10	05-32-E0110	JH70.20130	Gasket	
11	05-32-E0111	JH70.20135	Sealing-Ring	
12	05-32-E0112	JH70.20133	Pin, Dowel	


COVER, CYLINDER HEAD INTAKE

E-2



REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-E0201	JH70.20140	Cylinder Head Cover	
2	05-32-E0202	JH70.20162	L Cover Cylinder Head	
3	05-32-E0203	JH70.20120	R Cover Cylinder Head Cover	
4	05-32-E0204	JH70.20108	Valve Cover	
5	05-32-E0205	JH70.20139	Gasket, Cylinder Head Cover	
6	05-32-E0206	JH70.20136	Gasket, R Cylinder Head Cover	
7	05-32-E0207	JH70.20121	Gasket, L Cylinder Head Cover	
8	05-32-E0208	JH70.20104	Gasket, Carburetor	
9	05-32-E0209	113611-0040010	Intake Pipe	
10	05-32-E0210	JH70.20107	O-Ring	
11	05-32-E0211	JH70.20106	Washer	
12	05-32-E0212	JH70.20141	Washer	
13	05-32-E0213	JH70.20142	Washer	
14	05-32-E0214	90401-C20-00	Washer	
15	05-32-E0215	JH70.20107	O-ring	
16	05-32-E0216	Q/QD921.2-87	Bolt	
17	05-32-E0217	Q/QD921.2-87	Bolt	
18	05-32-E0218	GB802-88	Nut Cap	
19	05-32-E0219	JH70.20138	Bolt	
20	05-32-E0220	Q/QD921.2-87	Bolt	
21	05-32-E0221	JH70.30002	Spark Plug	

CAMSHAFT & VALVES




E-3

REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-E0301	JH70.20148	Seal, Valve Stem	
2	05-32-E0302	JH70.20165	Camshaft Comp	
3	05-32-E0303	JH70.20111	Arm, Valve Rocker Assy	
4	05-32-E0304	JH70.20112	Shaft, Rocker	
5	05-32-E0305	JH70.20113	Inlet Valve	
6	05-32-E0306	JH70.20114	Outlet Valve	
7	05-32-E0307	JH70.20116	Spring, Valve Outer	
8	05-32-E0308	JH70.20117	Spring, Valve Inner	
9	05-32-E0309	JH70.20118	Seat, Valve Spring	
10	05-32-E0310	JH70.20115	Seat, Valve Spring	
11	05-32-E0311	JH70.20119	Cotter Valve	


CAM CHAIN, TENSIONER ASSY

E-4



REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-E0401	JH70.2012	Timing Driven Sprocket	
2	05-32-E0402	14302-C20-00	Timing chain	
3	05-32-E0403	1453A-095-0000	Arm Comp, Camchain Tensioner	
4	05-32-E0404	JH70.20473	Roller Camchain Tensioner	
5	05-32-E0405	JH70.20425	Pivot Camchain Tensioner	
6	05-32-E0406	JH70.20415	Spring Camchain Tensioner	
7	05-32-E0407	JH70.20460	Rod Comp Camchain Tensioner	
8	05-32-E0408	JH70.20126	Washer	
9	05-32-E0409	JH70.20151	Roller Comp Cam Chain Guide	
10	05-32-E0410	JH70.20125	Pin Cam Chain Guide roller	
11	05-32-E0411	JH70.20449	Sprocket Cam Chain Roller	
12	05-32-E0412	JH70.20408	Sprindel Camchain Guide Sprocket	
13	05-32-E0413	JH70.20413	Bolt Sealing	
14	05-32-E0414	JH70.20124	Washer	
15	05-32-E0415	JH70.20414	Washer	
16	05-32-E0416	GB9074.1-02	Bolt M6x18	

CRANKCASE




E-5

REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-E0501	110A-061B-0000	Crankcase Comp R	
2	05-32-E0502	JH70.20401	Gasket Crankcase	
3	05-32-E0503	1120A-061B-0000	Crankcase Comp L	
4	05-32-E0504	JH70.20423	Tube, Breather	
5	05-32-E0505	JH70.20420	Clip	
6	05-32-E0506	JH70.20428	Clip, Overflow Tube	
7	05-32-E0507	JH70.20427	Bolt A, Cylinder Stud	
8	05-32-E0508	JH70.250426	Bolt B, Cylinder Stud	
9	05-32-E0509	JH70.20412	Washer	
10	05-32-E0510	Q/QD921.1-87	Pin 92401-10014	
11	05-32-E0511	JH70.20411	Bolt	
12	05-32-E0512	JH70.20447	Strainer Oil Filler	
13	05-32-E0513	Q/QD921.2-87	Bolt 92140-06060B	
14	05-32-E0514	Q/QD921.2-87	Bolt 92140-06050B	
15	05-32-E0515	Q/QD921.1-87	Bolt 92140-06065B	
16	05-32-E0516	15100-005-0001	Oil Pump Assy	
17	05-32-E0517	JH70.20410	Gasket Oil Pump	
18	05-32-E0518	JH70.20409	Pivot Oil Flier	
19	05-32-E0519	GB823.88	Screw M6x16	
20	05-32-E0520	GB823-88	Screw M6x22	


CRANKSHAFT PISTON

E-6



REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-E0601	13200-095-0000	Crankshaft Assy	
2	05-32-E0602A	JH70.20307	Ring Set A, Piston	
2	05-32-E0602B	JH70.20308	Ring Set B, Piston	
2	05-32-E0602C	JH70.20309	Ring	
2	05-32-E0602D		Piston Ring Kit, includes A, B, C	
3	05-32-E0603	JH70.20310	Piston	
4	05-32-E0604	JH70.20305	Pin, Piston	
5	05-32-E0605	JH70.20304	Circlip, Piston Pin	
6	05-32-E0606	JH70.20301	Key, Woodruff	

STARTER MOTOR




E-7

REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-E0701	31200-C20-00	Starter Motor Assy	
2	05-32-E0702	GB5783-86	Bolt	


COVER, L CRANKCASE & GENERATOR

E-8



REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-E0801	11401-041-0000	Front Cover L Crankcase	
2	05-32-E0802	11411-041-0000	Rear Cover L crankcase	
3	05-32-E0803	11039-041-0000	Gasket L Crankcase	
4	05-32-E0804	31110-061-0000	Rotor Comp	
5	05-32-E0805	11002-A25-00	View Window B	
6	05-32-E0806	11001-A25-00	Cover View Window A	
7	05-32-E0807	Q/QD924.1-87	Pin Dowel	
8	05-32-E0808	11081-A25-00	O-Ring View Window A	
9	05-32-E0809	11082-A25-00	O-ring B View Window	
10	05-32-E0810	31120-041-0000	Stator Assy	
11	05-32-E0811	Q/QD921.2-87	Bolt	
12	05-32-E0812	Q/QD921.2-87	Bolt	
13	05-32-E0813	Q/QD921.2-87	Bolt	
14	05-32-E0814	Q/QD921.2-87	Bolt	
15	05-32-E0815	GB823-88	Screw M6x16	
16	05-32-E0816	Q/QD921.2-87	Bolt	
17	05-32-E0817	JH70.20313	Nut M10x125	
18	05-32-E0818	11004-041-0000	Compression Plate	
19	05-32-E0819	11016-C20-00	Holding Plate	
20	05-32-E0820	Q/QD921.2-87	Bolt	
21	05-32-E0821	GB823-88	Screw M6x5	


STARTER CLUTCH AND COVER



E-9

REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-E0901	11015-041-0000	Plate Cover	
2	05-32-E0902	2401B-041-0000	Chain, Electrical Start	
3	05-32-E0903	11017-041-0000	Guide Plate Chain	
4	05-32-E0904	11018-041-0000	Tensioner Chain Cam	
5	05-32-E0905	2441A-041-0000	Driven Sprocket Assy	
6	05-32-E0906	11016-C20-01	Plate Limit	
7	05-32-E0907	24311-C20-01	Lirettion Guide Comp	
8	05-32-E0908	91101-C20-00	Oil Seal 30x42x45	
9	05-32-E0909	JH70.30104	Oil Seal	
10	05-32-E0910	31112-061-0000	O-Ring	
11	05-32-E0911	Q/QD921.87	Bolt	
12	05-32-E0912	GB70-85	Screw	
13	05-32-E0913	11020-041-0000	Bracket	
14	05-32-E0914	Q/QD921.2-87	Bolt	
15	05-32-E0915	Q/QD924.1-87	Pin Dowel	
16	05-32-E0916	JH70.20135	Ring	


COVER, RGT CRANKCASE



E-10

REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-E1001	1133A-095-0000	Cover Comp R Crankcase	
2	05-32-E1002	JH70.20202	Gasket R Crankcase Cover	
3	05-32-E1003	Q/QD924.1-87	Pin, Dowel	
4	05-32-E1004	GB/T276-94	Bearing 60012	
5	05-32-E1005	11301-095-0000	Plug, Oil Filter	
6	05-32-E1006	JH70.20212	O-Seal Ring	
7	05-32-E1007	Q/QD921.2-87	Bolt	
8	05-32-E1008	Q/QD921.2-87	Bolt	
9	05-32-E1009	Q/QD921.2-87	Bolt	
10	05-32-E1010	JH70.20129	Clip, Dynano Cord	


PRIMARY CLUTCH



E-11


REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-E1101	21501-095-0000	thrust Washer	
2	05-32-E1102	21505-095-0000	Secondary Driven Gear	
3	05-32-E1103	21502-095-0000	Bush	
4	05-32-E1104	JH70.20502	Bush	
5	05-32-E1105	2153A-095-0000	Housing, Primary Clutch	
6	05-32-E1106	21524-037-0000	Circlip	
7	05-32-E1107	21523-095-0000	Washer	
8	05-32-E1108	2155A-095-0000	Weight, Primary Clutch	
9	05-32-E1109	21525-095-0000	Spring	
10	05-32-E1110	2157B-005-0000	Damper Clutch	
11	05-32-E1111	2154A-095-0000	Clutch Plate Assy	
12	05-32-E1112	21584-005-0000	Washer, Lock	
13	05-32-E1113	JH70.20512	Washer	
14	05-32-E1114	JH70.20511	Nut M10x125	
15	05-32-E1115	21582-005-0000	Gasket, Cover	
16	05-32-E1116	21581-005-0000	Gasket, Cover	
17	05-32-E1117	GB818-85	Screw	

SECONDARY CLUTCH



E-12

REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-E1201	2110A-095-0000	Secondary Clutch Assy	
	05-32-E1201A		Secondary Clutch Assy Kit 1-5	
2	05-32-E1202	21147-095-0000	Bush	
3	05-32-E1203	JH70.20512	Washer	
4	05-32-E1204	JH70.20511	Nut M10x125	
5	05-32-E1205	2110B-095-0000	Driven Sprocket Comp	



E-13

REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-E1301	2220A-095-0000	Mainshaft Assy	
2	05-32-E1302	2220B-095-0000	Countershaft Assy	
3	05-32-E1303	GB/T276-94	Bearing Radial Bolt 6201	
4	05-32-E1304	GB/T276-94	Bearing Radial Ball 6203	
5	05-32-E1305	JH70.20430	Oil Seal	
6	05-32-E1306	JH70.20601	Drive Sprocket	
7	05-32-E1307	JH70.20602	Fix Plate	
8	05-32-E1308	90101-C20-00	Bolt M6x8	
9	05-32-E1309	GB/T276-94	Bearing Radial Belly	
10	05-32-E1310	GB/T276-94	Bearing Radial Bolt 6001	

EXHAUST MUFFLER ASSY




FIG. 1

REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-0101	117000	Exhuast Muffler Assy	
2	05-32-0102	GB56	Nut M6	
3	05-32-0103	SB0816	Bolt M8x16	
4	05-32-0104	117073	Gasket	

FRONT FENDER




FIG. 2

REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-0201	806100	Front Fender	
2	05-32-0202	SA0616	Bolt with Washer	
3	05-32-0203	810000	Front Cover	
4	05-32-0204	TE1955-06	Nut, Spring	
5	05-32-0205	D20612	Screw	

REAR FENDER, FOOT REST




FIG. 3

REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-0301	807100	Rear Fender	
2	05-32-0302	H40616	Bolt with Washer	
3	05-32-0303	303273	Damper, Battery	
4	05-32-0304	815204	Foot Rest, Left	
5	05-32-0305	815205	Foot Rest, Right	
6	05-32-0306	H40612	Bolt with Washer	
7	05-32-0307	M80600	Nut M6	
8	05-32-0308	310000	Reflector Comp	

SEAT




FIG. 4

REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-0401	701000	Seat Assy	

FUEL TANK





FIG. 5

REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-0501	801500	Fuel Tank Comp	
2	05-32-0502	804000	Cap Assy	
3	05-32-0503	801084	Gromment	
4	05-32-0504	850685	Bolt M6x85	
5	05-32-0505	Q10600	Washer	
6	05-32-0506	912219	Bushing	
7	05-32-0507	MD0600-A	Lock Nut M6	
8	05-32-0508	SB0625	Bolt M6x25	
9	05-32-0509	803000	Fuel Cock Assy	
10	05-32-0510	801088	Clip	
11	05-32-0511	801086	Hose L90	
12	05-32-0512	801086	Hose L70	

STEERING

FIG. 6



REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-0601	611000	Steering Stem	
2	05-32-0602	S60855-6	Bolt M8x125x55	
3	05-32-0603	611019	Oil Seal	
4	05-32-0604	Q11000-A	Washer 10	
5	05-32-0605	MD1000	Self-Lock Nut M10	
6	05-32-0606	X00220	Pin, Cotter	
7	05-32-0607	S60855	Bolt M8x55	
8	05-32-0608	611001	Holder Handle	
9	05-32-0609	611018	Plane Bearing Steering	
10	05-32-0610	611021	Collar, Bush	
11	05-32-0611	611020	Washer, Lock	
12	05-32-0612	T551150	O-Ring	
13	05-32-0613	615000	Steering Rod Assy	
14	05-32-0614	611501	Steering Rod	
15	05-32-0615	611502	Joint Comp (IN)	
16	05-32-0616	611503	Joint Comp (OUT)	
17	05-32-0617	608071	Bracket, Choke	

FRONT WHEEL




FIG. 7

REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-0701	406300	Hub Assy Front Drum Brake	
2	05-32-0702	406200	Brake Shoe Set	
3	05-32-0703	406401	Brake Assy L	
4	05-32-0704	406501	Brake Assy R	
5	05-32-0705	402001	Front Tire	
6	05-32-0706	401100	Front Hub	
	05-32-0706A		Front Wheel and Tire Assy 5-6	
7	05-32-0707	402102	Valve	
8	05-32-0708	M80800	Nut M8	
9	05-32-0709	ME1400	Nut M14	
10	05-32-0710	X02E30	Cotter Pin 25x30	

BUMPER




FIG. 8

REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-0801	519100	Bumper	
2	05-32-0802	SB0816	Bolt M8x16	
3	05-32-0803	519015	Plug, Bumper	

HANDLEBAR AND CABLES




FIG. 9

REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-0901	601001	Handle-Bar	
2	05-32-0902	602100	Grip	
3	05-32-0903	601075	Handlebar Rubber	
4	05-32-0904	601074	Sleeve	
5	05-32-0905	324330	Throttle Accelerator	
6	05-32-0906	324200	Left Lever Holder Assy	
7	05-32-0907	605000	Front Brake Cable	
8	05-32-0908	607000	Cable, Throttle	
9	05-32-0909	610000	Rear Brake Cable	

FRONT SUSPENSION




FIG. 10

REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-1001	525400	Steering Knuckle Assy, L	
2	05-32-1002	525404	Joint, Steering Knuckle Assy	
3	05-32-1003	T21800	Washer	
4	05-32-1004	Q21000-A	Washer 10	
5	05-32-1005	MD1000-6	Nut M10x125	
6	05-32-1006	X00220	Cotter Pin 25x20	
7	05-32-1007	525204	Upper Front A-Arm	
8	05-32-1008	525205	Lower Front A-Arm	
9	05-32-1009	525202	Bushing, Left Front A-Arm	
10	05-32-1010	525207	Bushing, Left Front A-Arm	
11	05-32-1011	TA4885-082540	Bolt 8x40	
12	05-32-1012	TA4885-08C5E0	Bolt 8x140	
13	05-32-1013	TA4885-0895B0	Bolt 8x110	
14	05-32-1014	SB1040-06	Bolt M10x40	
15	05-32-1015	MC1000-6	Nut M10	
16	05-32-1016	505100	Shock Absorber Assy L	
17	05-32-1017	Q21000-A	Washer 10	
18	05-32-1018	MC0600	Nut M6	
19	05-32-1019	52500	Steering Knuckle Assy, R	

DRIVE CHAIN





FIG. 11

REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-1101	203100	Chain	
2	05-32-1102	107281	Drive sprocket	
3	05-32-1103	Q31600-A	Washer 16	

REAR SUSPENSION

FIG. 12



REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-1201	508100	Rear Fork	
2	05-32-1202	508200	chain Adjuster	
3	05-32-1203	506100	RR Shock Absorber	
4	05-32-1204	206171	Proctection Plate	
5	05-32-1205	SB1055-B	Bolt M10x55	
6	05-32-1206	MC1000-A	Nut M10	
7	05-32-1207	SB0812-A	Bolt M8x12	
8	05-32-1208	SB1225-B	Bolt M12x25	
9	05-32-1209	SB1040-B	Bolt M10x40	
10	05-32-1210	SB1060-B	Bolt M10x60	

FRAME




FIG. 13

REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-1301	501100	Frame	
2	05-32-1302	SB08C0	Bolt M8x120	
3	05-32-1303	SB0825-B	Bolt M8x25	
4	05-32-1304	SA0816-6	Bolt M8x16	
5	05-32-1305	815273	Bracket, Left Foot-Step	
6	05-32-1306	815274	Bracket, Right Foot-Step	
7	05-32-1307	MD0800-A	Nut M8	
8	05-32-1308	510003	Cover, Footrest	
9	05-32-1309	501003	Connect Plate	

REAR AXLE





FIG. 14

REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-1401	204204	Rear Axle	
2	05-32-1402	411000	Rear Brake Assy	
3	05-32-1403	206101	Rear Axle Housing	
4	05-32-1404	405101	Sprocket Wheel Holder	
5	05-32-1405	405201	Sprocket Wheel	
6	05-32-1406	405105	Gasket	
7	05-32-1407	S60816-A	Bolt M8x16	
8	05-32-1408	912203	L Bush RR Tire	
9	05-32-1409	412000	Connection Plate	
10	05-32-1410	TD2003-165003	Washer	
11	05-32-1411	ME1400-A	Nut M14	
12	05-32-1412	GB91	Cotter Pin 25x30	
13	05-32-1413	411074	Brake Discholder	
14	05-32-1414	411001	Brake Disc	
15	05-32-1415	SB1016-A	Bolt M10x16	
16	05-32-1416	912204	R Bush	
17	05-32-1417	Q01000	Washer 10	

ELECTRICAL

FIG. 15



REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-1501	307000	Main Cable	
2	05-32-1502	307051	Cable, Starter	
3	05-32-1503	313300	Remote Controller Assy	
4	05-32-1504	303000	Battery	
5	05-32-1505	324100	Ignition Switch	
6	05-32-1506	324311	Off Switch	
7	05-32-1507	301000	Starter Solinoid	
8	05-32-1508	305000	Ignition Coil	
9	05-32-1509	302000	Rectifier	
10	05-32-1510	SB0616	Bolt M6x16	
11	05-32-1511	350000	Stop Relay	
12	05-32-1512	307071	Clamp, Hose	
13	05-32-1513	303272	Band, Battery	
14	05-32-1514	306000	CDI	
15	05-32-1515	307071	Clamp, Hose	

HEADLIGHT




FIG. 16

REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-1601	314000	Headlight Assy	
2	05-32-1602	314002	Bulb, Headlight	

AIR CLEANER




FIG. 17

REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-1701	115000	Air Filter Assy	
2	05-32-1702	SA0616	Bolt M6x16	

CARBURETOR




FIG. 18

REF. No.	PART NUMBER	CODE	DESCRIPTION	REMARK
1	05-32-1801	113100	Carburetor Assy	