UNITED MOTORS
Move On.

PARTS CATALOGUE

EARTHLANDER 50/90
2005



REVISED 05/20/04

INDEX










ENGINE

SECTION	FIG #
CYLINDER/CYLINDER HEAD	E01
CRANKSHAFT/PISTON	E02
FAN COVER/SHROUD	E03
OIL PUMP	E04
AIR INTAKE SYSTEM	E05
CARBURETOR	E06
CRANKCASE COVER 50cc	E07
CRANKCASE COVER 90cc	E08
KICK SHAFT ASSY	E09
CLUTCH ASSY	E10
DRIVE ASSY (REVERSE VERSION)	E11
GENERATOR/STARTER MOTOR	E12
ELECTRICAL EQUIPMENT	E13




FRAME


SECTION	FIG #
FRAME	F01
BODY	F02
METER SYSTEM	F03
SEAT	F04
OIL TANK/FUEL TANK	F05
FRONT SWINGARM	F06
SUSPENSION	F07
STEERING	F08
HANDLE COMP.	F09
BRAKE	F10
REAR WHEEL AXLE	F11
WHEEL	F12
CHAIN	F13
EXHAUST PIPE	F14
REVERSE GEAR SHIFT	F15
ELECTRICAL PARTS	F16
LIGHTS	F17
TOOLS	F18
DECALS AND LABELS	F19

CONTENTS ENGINE GROUP










E01 CYLINDER HEAD	E02 CRANKSHAFT/PISTON	E03 FAN COVER/SHROUD
		
E04 OIL PUMP	**E05 AIR INTAKE SYSTEM**	**E06 CARBURETOR**
		
E07 50cc CRANKCASE/ COVER	**E08 90/100cc CRANK CASE/ COVER**	**E09 KICK SHAFT ASSY**
		

CONTENTS ENGINE GROUP










E10 CLUTCH ASSY	E11 DRIVE ASSY (REVERSE VERSION)	E12 GENERATOR/STARTER MOTOR
		

E13 ELECTRICAL EQUIPMENT


CONTENTS FRAME GROUP


F01 FRAME	F02 BODY	F03 METER SYSTEM
		
F04 SEAT	**F05 OIL TANK/FUEL TANK**	**F06 FRONT SWINGARM**
		
F07 SUSPENSION	**F08 STEERING**	**F09 HANDLE COMP.**
		

CONTENTS FRAME GROUP

F10 BRAKE	F11 REAR WHEEL AXLE	F12 WHEEL
		
F13 CHAIN	**F14 EXHAUST PIPE**	**F15 REVERSE GEAR SHIFT**
		
F16 ELECTRICAL PARTS	**F17 LIGHTS**	**F18 TOOLS**
		


CONTENTS FRAME GROUP

F19 DECALS & LABELS




E01 CYLINDER / CYLINDER HEAD

REF#	PART #	DESCRIPTION	QTY	2004	2005
1-1	12200-3XG-00	HEAD, CYLINDER (50c.c.)	1	1	1
	12200-4DM-00	HEAD, CYLINDER (90c.c.)	1	1	1
1-2	12251-4DM-00	GASKET, CYLINDER HEAD 1	1	1	1
1-3	94701-00264	PLUG, SPARK (NGK BP7HS)	1	1	1
1-4	12100-3XG-00	CYLINDER (50c.c.)	1	1	1
	12100-4DM-00	CYLINDER (90c.c.)	1	1	1
1-5	12191-3XG-00	GASKET, CYLINDER BASE (50c.c.)	1	1	1
	12191-4DM-00	GASKET, CYL. BASE (90c.c)	1	1	1
1-6	90301-07110-C	BOLT, STUD (50c.c.)	4	4	4
	90301-07125-C	BOLT, STUD (90c.c)	4	4	4
1-7	94050-07000-C	NUT	4	4	4




Enlarged figure
next page

E01 CYLINDER / CYLINDER HEAD




E02 CRANKSHAFT / PISTON

REF#	PART #	DESCRIPTION	QTY	2004	2005
2-1	13000-3XG-00	CRANKSHAFT ASSY (50c.c.)	1	1	1
	13000-4DM-00	CRANKSHAFT ASSY	1	1	1
2-2	90701-03017	KEY, WOODRUFF	1	1	1
2-3	96100-62044-10	BEARING.	2	2	2
2-4	91202-4DM-00	SEAL, OIL	1	1	1
2-5	91201-4DM-00	SEAL, OIL	1	1	1
2-6	98117-3XG-00	COLLAR (50c.c.)	1	1	1
	98117-4DM-00	COLLAR (90c.c.&100c.c.)	1	1	1
2-7	13101-3XG-00	PISTON(STD)(50c.c.)	1	1	1
	13101-4DM-00	PISTON(STD)(90c.c.)	1	1	1
2-8	13111-3XG-00	PIN, PISTON(50c.c.)	1	1	1
	13111-4DM-00	PIN, PISTON(90c.c.)	1	1	1
2-9	13011-3XG-00	RING SET, PISTON (STD)(50c.c.)	1	1	1
	13011-4DM-00	RING SET, PISTON (STD)(90c.c.)	1	1	1
2-10	94601-3XG-00	CIRCLIP (50c.c.)	2	2	2
	94601-4DM-00	CIRCLIP (50c.c.&90c.c.)	2	2	2
2-11	91100-3XG-00	BEARING, NEEDLE (50c.c.)	1	1	1
	91100-4DM-00	BEARING, NEEDLE (90c.c.)	1	1	1




Enlarged figure next page

E02 CRANKSHAFT / PISTON




E03 FAN COVER/ SHROUD

REF#	PART #	DESCRIPTION	QTY	2004	2005
3-1	19620-3XG-00	COVER ASSY, CYLINDER (50c.c.)	1	1	1
	19620-4DM-00	COVER ASSY, CYLINDER	1	1	1
3-2	11207-4DM-00	GROMMET	2	2	2
3-3	1961A-4DM-00	FAN COVER ASSY	1	1	1
3-3-1	19610-4DM-00	COVER ASSY FAN	1	1	1
3-3-2	19616-4DM-00	FAN COVER CAP	1	1	1
3-3-3	93903-05016	TRUSS	1	1	1
3-3-4	94104-05316	WASHER	1	1	1
3-4	94608-4DM-00	O-RING	1	1	1
3-5	93893-06016-K	SCREW WASHER	3	3	3
3-6	19510-3XG-00	FAN COMP, COOLING (50c.c.)	1	1	1
	19510-4DM-00	FAN COMP, COOLING	1	1	1
3-7	17910-4DM-00	CABLE ASSY, THROTTLE	1	1	1
3-8	80153-4DM-00	DEFLECTOR	1	1	1
3-9	93891-06020-K	SCREW WASHER	2	2	2
3-10	93901-240C0	TAPPING SCREW, PAN	1	1	1




Enlarged figure next page

E03 FAN COVER/ SHROUD




E04 OIL PUMP

REF#	PART #	DESCRIPTION	QTY	2004	2005
4-1	15100-3XG-00	OIL PUMP ASSY(50c.c.)	1	1	1
	15100-4DM-00	OIL PUMP ASSY(90c.c.&100c.c.)	1	1	1
4-2	93500-05014-K	BOLT, BREATHER	1	1	1
4-3	15131-4DM-00	GEAR, PUMP DRIVE	1	1	1
4-4	94303-03118	PIN, DOWEL	1	1	1
4-5	94510-19000	CIRCLIP	2	2	2
4-6	15151-26019	SPG.WAVE F19*26	1	1	1




E05 AIR INTAKE SYSTEM

REF#	PART #	DESCRIPTION	QTY	2004	2005
5-1	1410A-4DM-00	REED VALVE ASSY	1	1	1
5-2	16201-4DM-00	GASKET, VALVE SEAT	1	1	1
5-3	1711A-4DM-00	MANIFOLD, INTAKE	1	1	1
5-7	1720A-4DM-00	AIR CLEANER ASSY.	1	1	1
5-8	17205-4DM-00	ELEMENT, AIR CLEANER	1	1	1
5-11	93500-05020	BOLT M6x20	2	2	2
5-12	94104-06130	PLAN WASHER F6	2	2	2




E06 CARBURETOR

REF#	PART #	DESCRIPTION	QTY	2004	2005
6-1	1610A-3XG-01	CARBURETOR ASSY(50cc)	1	1	1
	1610A-4DM-01	CARBURETOR ASSY(90cc)	1	1	1
6-2	16101-4DM-00	MAINTENANCE KIT ASSY A	1	1	1
6-3	16102-4DM-00	MAINTENANCE KIT ASSY B	1	1	1




E07 50cc CRANK CASE/ CRANK COVER

REF#	PART #	DESCRIPTION	QTY	2004	2005
7-1	11394-4DM-00	GASKET, CRANKCASE COVER	1	1	1
7-2	93500-06012-K	SCREW WASHER	1	1	1
7-3	11121-4DM-00	HOLDER	1	1	1
7-4	93500-06035-K	SCREW, PAN	10	10	8
7-5	11103-4DM-00	RUBBER BUSH, ENGINE	2	2	2
7-6	11100-3XG-00	CRANKCASE RIGHT	1	1	1
7-7	94301-12160	PIN, DOWEL	2	2	1
7-8	11220-4DM-00	BREATHER COMP	1	1	1
7-9	11200-3XGR-00	CRANK CASE LEFT (50cc)	1	1	1
	11200-4DMR-00	CRANK CASE LEFT (90cc)	1	1	1
7-10	15651-4DM-00	PLUG OIL M14	1	1	1
7-11	94608-13825	O-RING F14*2.5	1	1	1
7-12	94104-08015	WASHER F15*F8	1	1	1
7-13	95701-08016-K	BOLT FLANGE M8*16	1	1	1
7-14	94520-42000	CIRCLIP EX F42	1	1	1
7-15	94301-10140	KNOCK PIN F10*14	4	4	2
7-16	11395-4DM-00	GASKET CRANK CASE COVER L	1	1	1
7-17	11341-3XG-00	COVER SIDE	1	1	1
7-18	93500-06025-K	SCREW PAN M6*25	3	3	8
7-19	11342-4DM-00	SHAFT F8*31	1	1	1
7-20	11362-3XG-00	ELEMENT	1	1	1
7-21	11363-3XG-00	GUIDE ELEMENT	1		1
7-22	93500-06065-K	SCREW PAN M6*65	1	1	1
7-23	93500-05008-K	SCREW PAN M5*8	2	4	2
7-24	11364-3XG-00	PLATE	1	1	1
7-25	91000-06035	HEXAGON BOLT(M6*35)	9		9
7-26	23100-4DMR-00	MISSION COVER(50cc;90cc)	1	1	1
7-27	21395-4DMR-00	GASKET, MISSION COVER	1	1	
7-28	96100-62013-10	BRG	1		1
7-29	96010-14021	BOLT FLANGE	1		1
7-30	95000-03020	SPRING	1		1
7-31	95100-09500	BALL	1		1
7-32	96100-62023-10	BRG	1		1
7-33	11203-4DM-00	BUSH REAR SHOCK ABSRBER	1	1	1
7-34	94101-1422010	WASHER	1		1




Enlarged figure next page

E07 50cc CRANK CASE/ CRANK COVER



E08 90cc CRANK CASE/ CRANK COVER


REF#	PART #	DESCRIPTION	QTY	2004	2005
8-1	11394-4DM-00	GASKET, CRANK CASE COVER	1	1	1
8-2	93500-06012-K	SCREW WASHER	1	1	1
8-3	11121-4DM-00	HOLDER	1	1	1
8-4	93500-06035-K	SCREW, PAN	10	1	10
8-5	11103-4DM-00	RUBBER BUSH ENGINE	2	2	2
8-6	11100-4DM-00	CRANKCASE, RIGHT	1	2	1
8-7	94301-12160	PIN, DOWEL	2	3	2
8-8	11220-4DM-00	BREATHER COMP	1	3	1
8-9	11200-4DMR-00	CRANK CASE LEFT (50cc;90cc)	1	1	1
8-10	15651-4DM-00	PLUG OIL M14	1	8	1
8-11	94608-13825	O-RING	1	9	1
8-12	11203-4DM-00	BUSH, REAR SHOCK ABSORBER	1	9	1
8-13	94104-08015	WASHER Φ15*Φ8	1	1	1
8-14	95701-08016-K	BOLT FLANGE M8*16	1	11	11
8-15	94520-42000	CIRCLIP EX Φ42	1	11	1
8-16	94301-10140	KNOCK PIN Φ10*14	2	2	2
8-17	11364-4DM-00	PLATE	1	1	1
8-18	11395-4DM-00	GASKET CRANK CASE COVER L	1	1	1
8-19	11341-4DM-00	COVER SIDE	1	1	1
8-20	93500-06025-K	SCREW PAN	8	8	8
8-21	11362-4DM-00	ELEMENT	1	1	1
8-22	11363-4DM-00	COVER ELEMENT	1	1	1
8-23	94050-06060-K	NUT FLANGE M6	3	3	3
8-24	93500-06065-K	SCREW PAN M6*65	1		1
8-25	1135A-4DM-00	COVER SHOURD ASS'YL	1	1	1
8-26	1137A-4DM-00	BOLT M6*23	2	2	2
8-27	91000-06035	BOLT	9		9
8-28	23100-4DMR-00	MISSION COVER(50cc;90cc & 100cc)	1	1	1
8-29	21395-4DMR-00	GASKET,MISSION COVER	1	1	1
8-30	96100-62013-10	BEARING	1		1
8-31	96010-14021	BOLT FLANGE	1		1
8-32	94101-1422010	WASHER	1		1
8-33	95000-03020	SPRING	1		1
8-34	95100-09500	BALL	1		1
8-35	96100-62023-10	BEARING	1		1



Enlarged figure next page


E08 90cc CRANK CASE/ CRANK COVER

REF#	PART #	DESCRIPTION	QTY	2004	2005
8-36	11342-4DM-00	SHAFT	1	1	1




E09 KICK SHAFT ASSY

REF#	PART #	DESCRIPTION	QTY	2004	2005
9-1	28110-3XG-00	WHEEL, STARTER(50c.c.)	1	1	1
	28110-4DM-00	WHEEL, STARTER(90c.c.)	1	1	1
9-2	91100-555913	BEARING.	1	1	1
9-3	28115-4DM-00	BOSS, GEAR 2	1	1	1
9-4	94104-55506	WASHER, PLATE	1	1	1
9-5	28120-3XG-00	STARTER CLUTCH ASSY(50c.c.)	1	1	1
	28120-4DM-00	STARTER CLUTCH ASSY(90c.c)	1	1	1
9-6	28100-3XG-00	IDLE GEAR ASSY(50c.c.)	1	1	1
	28100-4DM-00	IDLE GEAR ASSY(90c.c.)	1	1	1
9-7	28102-3XG-00	SHAFT, IDLE GEAR(50c.c.)	1	1	1
	28102-4DM-00	SHAFT, IDLE GEAR(90c.c.)	1	1	1
9-8	94104-08212	WASHER, PLATE	2	2	2
9-9	28105-4DM-00	PLATE, IDLE GEAR	1	1	1
9-10	93892-06012	SCREW, PAN HEAD	2	2	2
9-11	28250-4DM-00	KICK SHAFT ASSY	1	1	1
9-12	28281-4DM-00	SPRING, TORSION	1	1	1
9-13	28254-4DM-00	BUSH, SOLID	1	1	1
9-14	94104-15010	WASHER, PLATE	1	1	1
9-15	94510-15000	CIRCLIP	1	1	1
9-16	28300-4DM-00	KICK CRANK ASSY	1	1	1
9-17	2823A-4DM-00	KICK PINION ASSY	1	1	1




Enlarged figure next page

E09 KICK SHAFT ASSY




E10 CLUTCH ASSY

REF#	PART #	DESCRIPTION	QTY	2004	2005
10-1	23411-3XG-00	GEAR, PRIMARY DRIVE(50c.c.)	1	1	1
	23411-4DM-00	GEAR, PRIMARY DRIVE(90c.c)	1	1	1
10-2	94510-17000	CIRCLIP Φ17	1	1	1
10-3	96100-60030	BEARING.	1	1	1
10-4	91203-4DM-00	SEAL, OIL 6202-27,HTCL 17,Φ28*5.5	1	1	1
10-5	2310A-3XG-00	SECONDARY SHEAVE ASSY(50c.c.	1	1	1
	2310A-4DM-00	SECONDARY SHEAVE ASSY(90c.c.	1	1	1
10-16	94050-10080-K	NUT M10	1	1	1
10-17	96130-6382-10	BEARING 6382	1	1	1
10-18	94608-64531	O-RING Φ9–Φ7*3mm	1	1	1
10-19	22121-3XG-00	WEIGHT(50c.c.)	6		6
10-20	22121-4DM-00	WEIGHT(90c.c)	6		6
10-21	22105-3XG-00	COLLAR(50c.c.)	1	1	1
10-22	22105-4DM-00	COLLAR(90c.c.)	1	1	1
10-23	23100-4DM-00	V-BELT	1	1	1
10-24	22102-3XG-00	SHEAVE, PRIMARY FIXED(50c.c.)	1	1	1
10-25	22102-4DM-00	SHEAVE, PRIMARY FIXED(90c.c.)	1	1	1
10-26	28211-3XG-00	CLUTCH, ONEWAY(50c.c.)	1	1	1
10-27	28211-4DM-00	CLUTCH, ONEWAY(90c.c.)	1	1	1
10-28	9700W-10126	WASHER, CONICAL SPRING	1	1	1
10-29	94001-100C0	NUT M10	1	1	1
10-30	2211A-3XG-00	FACE ASS'Y MOVABLE DRIVE(50c.c.)	1	1	1
	2211A-4DM-00	FACE ASS'Y MOVABLE DRIVE(90c.c.)	1	1	1




Enlarged figure next page

E10 CLUTCH ASSY




E11 DRIVE ASSY (REVERSE VERSION)

REF#	PART #	DESCRIPTION	QTY	2005
11-1	23430-3XGR-00	DRIVE AXLE ASS'Y	1	1
11-2	91160-253316	BEARING	1	1
11-3	94530-32000	CIRCLIP	1	1
11-4	91204-4DM-00	SEAL, OIL 25*35*6	1	1
11-5	96150-601040-10	BEARING	1	1
11-6	94520-42000	CIRCLIP	1	1
11-7	94102-2028010	WASHER	1	1
11-8	94517-MAA-000	CIRCLIP	1	1
11-9	15234-MAA-010	SPORKET/FR.15T	1	1
	15235-MEC-010	SPORKET/FR. 19T	1	1
11-10	12811-4DMR-00	PLATE FIXING	1	1
	15232-MAA-010	SPORKET/FR.15T	1	1
11-15	24301-4DMR-000	DRUM GEAR SHIFT	1	1
11-16	24241-4DMR-00	SHIFT FORK GUIDE	1	1
11-17	24211-4DMR-00	GEAR SHIFT	1	1
11-18	94102-1218010	WASHER	1	1
11-19	23450-4DMR-00	REVERSE AXLE ASS'Y	1	1
11-20	23420-4DMR-00	MAIN AXLE COMP	1	1
11-21	24610-4DMR-00	SPINDLE COMP,GEAR SHIFT	1	1
11-22	94513-MAA-000	CIRCLIP	1	1
11-23	92104-MAA-000	SEAL.OIL	1	1
11-24	23411-4DMR-00	PRIMAY, DRIVE GEAR	1	1




Enlarged figure next page

E11 DRIVE ASSY (REVERSE VERSION)




E12 GENERATOR/ STARTER MOTOR

REF#	PART #	DESCRIPTION	QTY	2004	2005
12-1	31120-4DM-00	STATOR, COMP	1	1	1
12-2	31110-3XG-00	FLYWHEEL, COMP (50c.c.)	1	1	1
	31110-4DM-00	FLYWHEEL, COMP (90c.c)	1	1	1
12-3	94102-10520	WASHER	1	1	1
12-4	94001-100C0	NUT, HEX	1	1	1
12-5	93500-06016-K	SCREW, PAN	2	2	2
12-6	31200-3XG-00	STARTER MOTOR ASSY(50c.c.)	1	1	1
	31200-4DM-00	STARTER MOTOR ASSY(90c.c)	1	1	1
12-7	96001-06022-0H	BOLT, FLANGE	2	2	2




E13 ELECTRICAL EQUIPMENT

REF#	PART #	DESCRIPTION	QTY	2004	2005
13-1	30510-4DM-00	COIL, IGN COMP	1	1	1
13-2	30410-3XG-00	C.D.I.UNIT, COMP (50c.c.)	1	1	1
	30410-4DM-00	C.D.I. UNIT, COMP (90c.c.)	1	1	1
	30410-5JG-00	C.D.I. UNIT, COMP (100c.c.)	1	1	1
13-3	31600-4DM-00	RECTIFIER / REGULATOR COMP	1	1	1
13-4	35400-4DM-00	RESISTOR, COMP	1	1	1
13-5	35850-4DM-00	RELAY, STARTER COMP	1	1	1
13-6	96000-06016	BOLT, FLANGE (M6X16)	2	2	2
13-7	93500-05012	BOLT(M5X12)	2	2	2
13-8	92000-06012	BOLT(M6X12)	1	1	1




F01 FRAME

REF#	PART #	DESCRIPTION	QTY	2004	2005
1-2	50202-CAB-000BK	REAR STAY(CAB)	1	1	1
1-3	50251-CAB-000	FR. BUCKHEAD COVER FIXED STAY/L	1	1	1
1-4	50252-CAB-000	FR. BUCKHEAD COVER FIXED STAY/R	1	1	1
1-5	50253-CAB-000	FR. RACK FIXED STAY A	2	2	2
1-6	50254-CAB-000	FR. RACK FIXED STAY ASS'Y B/L	1	1	1
1-7	50255-CAB-000	FR. RACK FIXED STAY ASS'Y B/R	1	1	1
1-8	50255-CAB-000BK	RR. RACK FIXED STAY	1	1	1
1-9	50270-CAB-000BK	FR. BUMPER ASS'Y	1	1	1
1-10-1	50258-CAB-000BK	FOOT WELL PLATE(CAB)/L	1	1	1
1-10-2	50259-CAB-000BK	FOOT WELL PLATE(CAB)/R	1	1	1
1-11	50210-MAA-000BK	ENG. HANGER PLATE	2	2	2
1-12	64312-MAA-000	SQUARE STOPPER	4	4	4
1-13	64313-MAA-000	PIPE STOPPER	2	2	2
1-14	52371-CAB-010BK	REAR FORK COMP.(CAB)	1	1	1
1-15	11400-MAA-000	REAR FORK SEAL COVER	2	2	2
1-16	22135-MAA-000	BUSH CONTAIN OIL	2	2	2
1-17	44170-MAA-000	RR FORK SPAER SLEEVE	1	1	1
1-18	53436-MAA-000	RUBBER SLEEVE	1	1	1
1-19	44130-MAA-000	ENG MOUNTING SPACE PIPE 1	1	1	1
1-20	44140-MAA-000	ENG MOUNTING SPACE PIPE 2	1	1	1
1-21	96000-08014	FLAGE BOLT	6	6	6
1-22	96000-08016	FLAGE BOLT	10	10	10
1-23	96000-08020	FLAGE BOLT	2	2	2
1-24	96000-08040	FLAGE BOLT	8	8	8
1-25	96000-08036	FLAGE BOLT	2	2	2
1-26	96000-12220	FLANGE BOLT	1	1	1
1-27	96000-14290	FLANGE BOLT	1	1	1
1-28	90350-08000	LOCK NUT	10	10	10
1-29	17630-MAA-010	CUSHION RUBBER	8	8	8
1-30	90350-12000	LOCK NUT	1	1	1
1-31	90350-14000	LOCK NUT	1	1	1
1-33	94100-03500	RIVET	2	2	2
1-34	88001-MAA-000	FLAGPOLE ASS'Y	1	1	1
1-35	94111-08000	SPRING WASHER	8	8	8
1-36	81149-MAA-000	LIFT WIRE	5	8	8




Enlarged figure next page

F01 FRAME


22
2
22
22
1
25
11
21
26
24
36
36
36
13
24
10-1
22
5
21
8
22
34
22
12
36
29
28
27
16
15
14
21
5
35
22
25
17
16
20
19
30
33
35
18
24
32
31
23
11
10-2
24
35
21
9
29
28
35
21
24
3
29
28
24
12
4
6
22
7
22

F02 BODY


REF#	PART #	DESCRIPTION	QTY	2004	2005
2-1	64301-CAB-000GR	FR. COVER(GREEN)	1	1	1
	64301-CAB-000BK	FR. COVER(BLACK)	1	1	1
	64301-CAB-000RD	FR. COVER(RED)	1		1
2-2	81260-CAB-000GR	RR. COVER(GREEN)	1	1	1
	81260-CAB-000BK	RR. COVER(BLACK)	1	1	1
	81260-CAB-000RD	RR. COVER(RED)	1		1
2-3	60400-CAB-000GR	FR. BUCKHEAD COVER(GREEN)	1	1	1
	60400-CAB-000BK	FR. BUCKHEAD COVER(BLACK)	1	1	1
	60400-CAB-000RD	FR. BUCKHEAD COVER(RED)	1		1
2-4	61100-CAB-000GR	RR. DASHBOARD COVER(GREEN)	1	1	1
	61100-CAB-000BK	RR. DASHBOARD COVER(BLACK)	1	1	1
	61100-CAB-000RD	RR. DASHBOARD COVER(RED)	1		1
2-5	64308-CAB-000BK	FR. RACK(BLACK)	1	1	1
2-6	64408-CAB-000BK	RR. RACK(BLACK)	1	1	1
2-7	71710-CAB-000GR	SPOILER ASS'Y(GREEN)	1	1	1
	71710-CAB-000BK	SPOILER ASS'Y(BLACK)	1	1	1
	71710-CAB-000RD	SPOILER ASS'Y(RED)	1		1
2-8	64330-CAB-000BK	FOOTBOARD/L(BLACK)	1	1	1
2-9	64310-CAB-000BK	FOOTBOARD/R(BLACK)	1	1	1
2-10	61105-CAB-000BK	TOP COVER(BLACK)	1	1	1
2-11	53205-CAB-000GR	HANDLE COVER(GREEN)	1	1	1
	53205-CAB-000BK	HANDLE COVER(BLACK)	1	1	1
	53205-CAB-000RD	HANDLE COVER(RED)	1		1
2-11-1	87559-CAB-00F	QUADZILLA LABEL STRIPE(FR.)	1		1
2-12	68010-CAB-000BK	TAIL COVER/L(BLACK)	1	1	1
2-13	68020-CAB-000BK	TAIL COVER/R(BLACK)	1	1	1
2-14	77310-CAB-000BK	SCREEN ASS'Y	1	1	1
2-15	77410-CAB-000BK	FR. CARRIER ASS'Y	1	1	1
2-16	77420-CAB-000BK	RR. CARRIER ASS'Y	1	1	1
2-17	85278-CAB-000	RUBBER STOPPER	1	1	1
2-18	96000-06012	FLAGE BOLT	14	14	14
2-19	96000-06016	FLAGE BOLT	7	7	7
2-20	96000-08016	FLAGE BOLT	6	6	6
2-21	93000-06012	ROUND HEAD BOLT	31	31	29
2-22	93000-06015	ROUND HEAD BOLT	10	10	10



Enlarged figure
2 pages down


F02 BODY

REF#	PART #	DESCRIPTION	QTY	2004	2005
2-23	93000-06020	ROUND HEAD BOLT	16	16	16
2-24	93000-06025	ROUND HEAD BOLT	4	4	4
2-25	93000-06060	ROUND HEAD BOLT	2	2	2
2-26	90350-06000	LOCK NUT	18	18	18
2-27	94121-08000	TOOTH WASHER	4	4	4
2-28	93093-04008	TAPPING SCREW	5	5	5
2-29	93093-04012	TAPPING SCREW	9	9	9
2-30	93093-04016	TAPPING SCREW	2	2	2
2-31	90344-04000	SPRING NUT	6	6	6
2-32	90345-06000	SPRING NUT	4	4	4
2-33	90344-06000	SPRING NUT	34	34	34




Enlarged figure
2 pages down

F02 BODY


24
25
22
26
23
7
24
26
6
23
26
23
26
22
21
23
12
33
2
18
23
13
26
21
4
16
19
19
18
21
33
21
20
27
32
21
33
18
9
21
1
33
21
28
29
14
21
22
3
21
22
20
27
20
20
20
11-1
21
21
11
29
21
30
10
31
33
31
33
8
18
21
23
17
21
23
21
5
32
15
20
19
17


F03 METER SYSTEM

REF#	PART #	DESCRIPTION	QTY	2005
3-1	67220-CAB-000BK	METER CASE(BLACK)-FAKE METER	1	1
3-2	67230-CAB-000BK	METER CASE PLUG COVER(BK)-FAKE METER	1	1
3-3	67240-CAB-000BK	METER SWITCH PLATE-TWO(BLACK)-TWO HOLE	1	1
3-4	87560-CAB-00A	METER STRIPE(AIE)	1	1
3-5	33501-MAA-000	OIL ALARM LAMP ASS'Y(RED)	1	1
3-6	35110-MAA-000	SAFTY SWITCH ASS'Y	1	1
3-7	35111-MAA-000	PROTECT HAND RING	1	1
3-8	35100-MAA-000	KEY SWITCH ASS'Y	1	1
3-9	75582-MAA-010	KEY SET SPG. LOCK	1	1
3-10	93000-05012	ROUND HEAD BOLT	1	1
3-11	93000-06012	ROUND HEAD BOLT	2	2
3-12	93093-02510	TAPPING SCREW	4	4




F04 SEAT

REF#	PART #	DESCRIPTION	QTY	2004	2005
4-1	77100-CAB-00ABK	UM SEAT ASS'Y(BLACK)	1	1	1
4-2	77235-MAA-000	SEAT LOCK ASS'Y	1	1	1
4-2-6	90350-06000	LOCK NUT	2	2	2
4-3	85258-MAA-000	FR SEAT CUSHION RUBBER	2	2	2
4-4	85268-MAA-000	RR SEAT CUSHION RUBBER	2	2	2
4-5	77236-MAA-000	SEAT LOCK ARM	1		1
4-6	77237-MAA-000	COLLAR	1		1
4-7	94101-0622010	WASHER	2		2
4-8	90350-06000	LOCK NUT(M6)	1		1
4-9	75583-MAA-000	SEAT DRIVER BRKT	1		1
4-10	93093-05015	TAPPING SCREW	3		3
4-11	77238-MAA-000	DRAW SPRING	1		1




F05 OIL TANK / FUEL TANK

REF#	PART #	DESCRIPTION	QTY	2004	2005
5-1	17500-CAB-000BK	FUEL TANK(BLACK)	1	1	1
5-2	17620-MAA-000BK	FUEL TANK CAP(BLACK)	1	1	1
5-3	17800-MAA-000WH	OIL TANK(WHITE)	1	1	1
5-5	81146-MAA-010	CUSHION RUBBER	4	4	4
5-6	16950-MAA-000	FUEL COCK ASS'Y	1	1	1
5-7	33650-CAB-010SL	FUEL FILTER ASS'Y	1	1	1
5-8	95002-01100	CLIP2	10	7	10
5-9	17684-MAA-000	FUEL HOSE 1	2	2	2
5-10	17682-MAA-000	FUEL HOSE 2	1	1	1
5-11	17683-MAA-000	FUEL HOSE 3	1	1	1
5-12	17685-MAA-000	FUEL HOSE 4	1	1	1
5-13	39801-MAA-000	OIL LEVEL GAUGE ASS'Y	1	1	1
5-14	50250-MAA-010	OIL TANK HANGER	1	1	1
5-15	92000-06012	BOLT	1	1	1
5-16	92000-06016	WASHER BOLT	4	4	4
5-17	17652-MAA-000	OIL TANK CAP STOPPER	1	1	1




Enlarged figure next page

F05 OIL TANK / FUEL TANK




F06 FRONT SWINGARM

REF#	PART #	DESCRIPTION	QTY	2004	2005
6-1	51450-CAB-010BK	FR.SWING ARM COMP./L	1	1	1
6-2	51460-CAB-010BK	FR.SWING ARM COMP./R	1	1	1
6-3	22115-MAA-000	BUSH CONTAIN OIL(UPPER)	2	2	2
6-4	22125-MAA-000	BUSH CONTAIN OIL(LOWER)	2	2	2
6-5	11303-MAA-000	BUSH	4	4	4
6-6	43350-MAA-000	GREASE VALVE	2	2	2
6-7	52225-MAA-000	GREASE VALVE CAP	2	2	2
6-8	52235-MAA-000	WATER PROOF COVER	2	2	2
6-9	52245-MAA-000	DUST SEAL	2	2	2
6-10	96000-10048	FLAGE BOLT	4	4	4
6-11	90350-08000	LOCK NUT	4	4	4




F07 SUSPENSION

REF#	PART #	DESCRIPTION	QTY	2004	2005
7-1	52500-MAA-010RD	FR.SHOCK ABSORBER ASS'Y(RED	2	2	2
7-2	52400-CAB-000RD	RR.SHOCK ABSORBER ASS'Y(RED	1	1	1
7-3	96000-10040	FLAGE BOLT	4	4	4
7-4	92000-10040	BOLT	2	2	2
7-5	90350-10000	LOCK NUT	4	4	4




F08 STEERING

REF#	PART #	DESCRIPTION	QTY	2004	2005
8-2	53217-MAA-000	SLEEVE	1	1	1
8-3	53434-MAA-000	HOLDER STEERING SHAFT	2	2	2
8-4	92101-MAA-000	OIL SEAL	1	1	1
8-5	90601-MAA-000	C CLIP	1	1	1
8-6	96100-6002ZZ	BEARING	1	1	1
8-7	22112-MAA-000	COLLAR	1	1	1
8-8	92102-MAA-000	OIL SEAL	1	1	1
8-9	53180-MAA-000	STEERING TIE ROD ASS'Y	2	2	2
8-10	51215-MAA-000	KNUCKLE/L	1	1	1
8-11	51210-MAA-000	KNUCKLE/R	1	1	1
8-12	90350-08000	LOCK NUT	2	2	2
8-13	90350-10000	LOCK NUT	4	4	4
8-14	90350-14000	LOCK NUT	1	1	1
8-15	90352-10000	CASTAL NUT	2	2	2
8-16	94201-02020	SPLIT PIN	2	2	2
8-17	94201-03030	SPLIT PIN	1	1	1
8-18	94201-30032	SPLIT PIN	4	4	4




Enlarged figure next page

F08 STEERING




F09 HANDLE COMP

REF#	PART #	DESCRIPTION	QTY	2004	2005
9-1	53100-CAB-010BK	HANDLE COMP.(CAB)	1	1	1
9-2	53140-CAB-000BK	GRIP(BLACK)	2	2	2
9-3	53178-MAA-000BK	LEVEL ASS'Y LEFT(DRUM)	1	1	1
9-4	53179-MAA-000BK	LEVEL ASS'Y RIGHT	1	1	1
9-5-1	35160-MMC-020BK	LEFT HANDLE SW.ASS'Y(MMC)	1		1
9-5-2	35160-MAA-000BK	LEFT HANDLE SW.ASS'Y(MAA)	0	0	0
9-6	33650-CAB-010SL	HANDLE HOLDER	1	1	1
9-7	53175-MAA-000	HANDLE HOLDER	1	1	1
9-8	45517-MAA-000	HANDLE HOLDER ASS'Y(LOWER)	2	2	2
9-9	91000-06038	HEXAGON BOLT	4	4	4
9-10	90350-10000-G	LOCK NUT	2	2	2
9-11	53130-CAB-000BK	METER CASE ASS'Y	1	1	1
9-12	45118-MEC-000	HANDLE POSITION BUSHING	4	4	4
9-13	43316-MAA-000	CHOCK CABLE ASS'Y	1		1




Enlarged figure next page

F09 HANDLE COMP




F10 BRAKE

REF#	PART #	DESCRIPTION	QTY	2004	2005
10-1	45101-MAA-000	FR/L BRAKE SHOE COMP./SINGLE HOLE	1	1	1
10-2	45102-MAA-000	FR/R BRAKE SHOE COMP./SINGLE HOLE	1	1	1
10-3	45200-MAC-000	RR.CALIPER ASS'Y	1	1	1
10-4	50295-MAC-000	RR.CALIPE BRKT ASS'Y	1	1	1
10-5	45121-MAC-000	RR. BRAKE DISK	1	1	1
10-6	45122-MAC-000	RR. DISK BRKT	1	1	1
10-7	46961-MAC-010	BRAKE FLUID HOSE ASS'Y	1	1	1
10-8	46965-MAC-000	BRAKE FLUID HOSE BRKT	1	1	1
10-9	46963-MAC-000	BRAKE FLUID HOSE BOLT	2	2	2
10-10	46964-MAC-000	BRAKE FLUID HOSE WASHER	4	4	4
10-11	45450-MAA-010	FR. BRAKE CABLE ASS'Y	2	2	2
10-12	50230-MAA-000BK	REAR BRAKE COVER	1	1	1
10-13	50270-CEA-00IIBK	LOCK NUT	2	2	2
10-14	92000-12050	BOLT	2	2	2
10-15	94111-12000	SPRING WASHER	2	2	2
10-16	96000-08012	FLANGE BOLT	2	2	2
10-17	91000-06012	HEXAGON BOLT	4	4	4
10-18	96000-08025	FLANGE BOLT	2	2	2
10-19	45120-MAA-000	FR.BRAKE SHOE COMP	2		2
10-20	43022-MAC-000	RR.PAD ASS'Y	2		2




Enlarged figure
next page

F10 BRAKE




F11 REAR WHEEL AXLE

REF#	PART #	DESCRIPTION	QTY	2004	2005
11-1	23511-MAA-000	REAR WHEEL AXLE	1	1	1
11-2	44150-MAA-000BK	SPACE PIPE 1	1	1	1
11-3	44160-MAA-000BK	SPACE PIPE 2	1	1	1
11-4	15233-MAA-000	SPORKET/RR.-MAA	1	1	1
11-6	52350-MAA-010BK	RR. WHEEL AXLE SEAT ASS'Y	1	1	1
11-7	33650-CAB-010SL	OIL SEAL	2	2	2
11-8	96100-6006ZZ	BALL BEARING	2	2	2
11-9	44620-MAA-000	SPACE TUBE	1	1	1
11-10	51312-MAA-000	SPACER	2	2	2
11-11	96000-12028	FLANGE BOLT	2	2	2
11-12	90350-12000	LOCK NUT	2	2	2
11-13	90350-14000	LOCK NUT	1	1	1




F12 WHEEL

REF#	PART #	DESCRIPTION	QTY	2004	2005
12-1	42711-MAA-000	TIRE	2	2	2
12-2	42712-MAB-000	TIRE	2	2	2
12-3	42706-CAB-000SL	FR. RIM (SILVER)	2	2	2
12-4	42707-CAB-000SL	RR. RIM (SILVER)	2	2	2
12-5	44610-MAA-000	FR. HUB ASS'Y	2	2	2
12-6	44630-MAA-000	RR WHEEL AXLE FIXED BRKT ASS'Y	2	2	2
12-7	33650-CAB-010SL	BOLT	16	16	16
12-8	94111-10000	SPRING WASHER	16	16	16
12-9	90501-1240046	WASHER	2	2	2
12-10	90501-1440046	WASHER	2	2	2
12-11	94051-12000	CASTAL NUT	2	2	2
12-12	94052-14000	CASTAL NUT	2	2	2
12-13	94201-30032	SPLIT PIN	4	4	4
12-14	53456-MAA-000	RUBBER CAP	4	4	4
12-15	42751-MAA-000	VALVE RIM	4	4	4




F13 CHAIN

REF#	PART #	DESCRIPTION	QTY	2004	2005
13-1	50240-MAA-010BK	LOWER CHAIN COVER ASS'Y	1	1	1
13-2	96000-08012	FLAGE BOLT	3	3	3
13-3	14428-CAB-000	CHAIN	1	1	1
13-4	50205-MAA-000	CHAIN ADJUSTER ASS'Y	1	1	1
13-5	94101-0613010	WASHER	1	1	1
13-6	94001-06000	NUT	2	2	2
13-7	50245-MAC-000BK	UPPER CHAIN COVER ASS'Y	1	1	1
13-8	96000-08016	FLANGE BOLT	2	2	2




F14 EXHAUST PIPE

REF#	PART #	DESCRIPTION	QTY	2004	2005
14-1	18301-CAB-000	EXHAUST PIPE ASS'Y(CAB)	1	1	1
14-1-1	18291-MAA-000	EX. PIPE GASKET	1	1	1
14-2	50220-MAA-000BK	MUFFLER COVER	1	1	1
14-3	96000-08030	FLAGE BOLT	1	1	1
14-4	90350-08000	LOCK NUT	1	1	1
14-5	55490-PA851	SPRING WASHER BOLT	2	2	2
14-6	96000-06018	FLAGE BOLT	2	2	2
14-7	50225-MAC-000	MUFFLER BRKT	1	1	1
14-8	96000-08014	FLAGE BOLT	2	2	2
14-9	94111-08000	SPRING WASHER	2	2	2




F15 REVERSE GEAR SHIFT

REF#	PART #	DESCRIPTION	QTY	2005
15-1	72100-MAA-000	WELDING DRAW	1	1
15-2	72317-MEC-01II	GEAR LEVER	1	1
15-3	72315-MEC-010-1	FR. OUT PATCH	1	1
15-4	72201-MEC-010	SHIFT CONTRAL KNOB	1	1
15-5	72100-MAA-000-5	BOX BRKT	1	1
15-6	36210-MEC-000	BRAKE SWITCH	1	1
15-7	72352-MAA-000	ELECTROMAGNET	1	1
15-8	72100-MAA-000-2	SAFETY LEAD	1	1
15-9	35150-MEC-000	REVERSE GEAR SAFTY SWITCH ASS'Y	1	1
15-10	72100-MAA-000-4	RESTORE SPRING	2	2
15-11	72100-MAA-010-6	RESTORE SPRING	1	1
15-12	90600-03000	LOCK PIN	1	1
15-13	90600-03075	LOCK PIN	1	1
15-14	93500-03008	HEXAGON BOLT	4	4
15-15	93500-04006	BOLT	2	2
15-16	94101-030610	SHIFT SEPARATE PLATE	6	6
15-17	94111-03000	SPRING WASHER	6	6
15-18	96000-06020	FLANGE BOLT	2	2
15-19	90350-06000	LOCK NUT	1	1
15-20	91000-05018	FLANGE BOLT	2	2
15-21	96000-08014	FLANGE BOLT	3	3




Enlarged figure next page

F15 REVERSE GEAR SHIFT




F16 ELECTRICAL PARTS


REF#	PART #	DESCRIPTION	QTY	2004	2005
16-2	31500-MAA-000	BATTERY ASS'Y	1	1	1
16-3	81146-MAA-000	CUSHION RUBBER	4	4	4
16-4	53458-CAB-000	BAND, RUBBER	1	1	1
16-5	35100-MAA-000	KEY SWITCH ASS'Y	1	1	1
16-6	75582-MAA-010	KEY SET SPG. LOCK	1	1	1
16-7	33650-CAB-010SL	HORN ASS'Y	1	1	1
16-8	52255-MAA-000	KICK STARTER SPINDLE CAP	1	1	1
16-9	81147-MAA-000	BAND	5	5	5
16-10	35120-MAA-000	REMOTE CONTROL ASS'Y	1	1	1



F17 LIGHTS


REF#	PART #	DESCRIPTION	QTY	2004	2005
17-1	33700-CAB-000	TAIL LIGHT ASS'Y(SQUARE)	2	2	2
17-2	64501-MAA-000	REFLEX PLATE	2	2	2
17-3	90350-06000	LOCK NUT	2	2	2
17-4	93000-05012	ROUND HEAD BOLT	4	4	4
17-5	64405-CAB-000BL	HEAD LIGHT LINS(BLUE)	2	2	2
17-6	64410-CAB-000SL	HEAD LIGHT BASE(SILVER)	2	2	2
17-7	33650-CAB-000	BULD FLANGE	2	2	2
17-8	93094-03512	TAPPING SCREW	2	2	2
17-9	90351-05000	LOCK NUT	2	2	2
17-10	94101-0514010	WASHER	4	4	4
17-11	95000-05020	SPRING	2	2	2
17-12	92000-05035	BOLT	2	2	2






F18 TOOLS

REF#	PART #	DESCRIPTION	QTY	2004	2005
18-1	89010-MAA-000	TOOL SET	1	1	1
18-2	89023-MAA-000	PRESSURE GAUGE	1	1	1



F19 DECALS & LABELS

REF#	PART #	DESCRIPTION	QTY	2004	2005
19-1	87501-CAB-00A	COVER STRIPE SET(UM)	1	1	1
19-2	81218-MAA-000	AGE WARNING LABEL	1	1	1
19-3	87511-MAA-000	RIDE WARNING LABEL	1	1	1
19-4	87505-MAA-000	TIRE PRESSURE LABEL	1	1	1





www.umamerica.com

© 2004 UNITED MOTORS OF AMERICA, INC.