PARTS CATALOG

START RIDING®

UM GENUINE PARTS

2005 POWERMAXX 150 GP1



INDEX













ENGINE

SECTION	FIG #
FAN COVER/SHROUD	E01
CYLINDER HEAD	E02
CAMSHAFT VALVE	E03
CAM CHAIN TENSIONER	E04
CYLINDER HEAD COVER	E05
CYLINDER	E06
CRANKSHAFT PISTON	E07
RIGHT CRANKCASE COVER	E08
LEFT CRANKCASE COVER	E09
GENERATOR, OIL PUMP	E10
STARTING MOTOR, CLUTCH	E11
DRIVER, STARTER	E12
BOLT, DRIVEN PULLEY	E13
REAR DRIVE SET	E14
CRANKCASE	E15
CARBURETOR	E16


FRAME

SECTION	FIG #
SIDE COVER	F01
R. & L. S/W ASSY	F02
STAND	F03
WINKER (TURNING SIGNAL LAMP)	F04
FRONT BOX	F05
CENTRAL COVER	F06
STAND-BY OIL CYLINDER, FRONT BRAK	F07
FUEL TANK	F08
METER ASSY	F09
BATTERY	F10
CUSHION	F11
EX.MUFFLER	F12
L. & R. REAR PROTECTING BAR	F13
TAIL LIGHT	F14
MIRROR COMP	F15
HEAD LIGHT	F16
FRONT WHEEL	F17
COVER FR	F18
L. & R. FRONT PROTECTING BAR	F19
AIR CLEANER	F20
FOOTREST	F21
REAR WHEEL	F22
REAR SHOCK ABSORBER	F23
REAR FENDER (I)	F24
REAR FENDER (II)	F25
STEERING STEM AND FR. SHOCK ABSO	F26
STEERING HANDLE	F27
FENDER FOR FRAME	F28
WIRE HARNESS	F29
FRAME	F30
TOOLS	F31
GRAPHICS	F32


CONTENTS ENGINE GROUP

E01 FAN COVER SHROUD	E02 CYLINDER HEAD	E03 CAMSHAFT VALVE
		
E04 CAMCHAIN TENSIONER	**E05 CYLINDER HEAD COVER**	**E06 CYLINDER**
		
E07 CRANKSHAFT, PISTON	**E08 RIGHT CRANKCASE COVER**	**E09 LEFT CRANKCASE COVER**
		
E10 GENERATOR, OIL PUMP	**E11 STARTING MOTOR, CLUTCH**	**E12 DRIVER, STARTER**
		


E13 BELT, DRIVEN PULLEY




E14 REAR DRIVE SET















E15 CRANKCASE





















E16 CARBURETOR



CONTENTS FRAME GROUP


F01 SIDE COVER	F02 R. & L. S/W ASSY	F03 STAND
		
F04 WINKER (TURNING SIGNAL LAMP)	**F05 FRONT BOX**	**F06 CENTRAL COVER**
		
F07 STAND-BY OIL CYLINDER, FRONT BRA	**F08 FUEL TANK**	**F09 METER ASSY**
		
F10 BATTERY	**F11 CUSHION**	**F12 EX. MUFFLER**
		

		
F13 L. & R. REAR PROTECTING BAR	**F14 TAIL LIGHT**	**F15 MIRROR COMP**
		
F16 HEAD LIGHT	**F17 FRONT WHEEL**	**F18 COVER FR.**
		
F19 L. & R. FRONT PROTECTING BAR	**F20 AIR CLEANER**	**F21 FOOTREST**
		
F22 REAR WHEEL	**F23 REAR SHOCK ABSORBER**	**F24 REAR FENDER (I)**
		

F25 REAR FENDER (II)	F26 STEERING STEM AND FR. SHOCK ABS(	F27 STEERING HANDLE
		
F28 FENDER FOR FRAME	**F29 WIRE HARNESS**	**F30 FRAME**
		
F31 TOOLS	**F32 GRAPHICS**	
		


E01 FAN COVER/SHROUD

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
1- 1	125.T.10.812	COVER ASSY, BREATHE	1	1	1
1- 2	125T.10.115	CLAMPER, OIL DRAIN TUBE	1	1	1
1- 3	125T.01.610	BOLT	3	3	3
1- 4	125T.10.106	SHROUD, BELOW	1	1	1
1- 5	125T.10.110	SEAL, BELOW	1	1	1
1- 6	GB845-85-ST	SCREW, TAPPING 4.8 X 16-F-H	6	6	6
1- 7	125T.10.109	SEAL, TAPPING	1	1	1
1- 8	125T.10.116	RUBBER GROMMET	1	1	1
1- 9	125T.10.121	CLIP, HIGH TENSION CORD	1	1	1
1- 10	125T.10.114	CLIP, HIGH TENSION CORD	1	1	1
1- 11	125T.10.814	SHROUD ASSY, VP	1	1	1
1- 12	125T.0.107	BREATHER TUBE	1	1	1
1- 13	125T.10.112	CLAMPER, SRATER CABLE	1	1	1
1- 14	125T.10.108	GROMMET, OBSIVE	1	1	1




Enlarged figure
Next page

E01 FAN COVER/SHROUD




E02 CYLINDER HEAD

REF#	PART #	DESCRIPTION	QTY	2004	2005
2- 1	150T.01.852	CYLINDER HEAD ASSY	1	1	1
2- 2	125T.01.515	HOLDER, CAMSHAFT	1	1	1
2- 3	125T.01.617	WASHER, CYLINDER HEAD	4	4	4
2- 4	125T.01.616	NUT, CYLINDER HEAD	6	6	6
2- 5	125T.06.930	PLUG, SPARK	1	1	1
2-6	125T.01.524	GASKET, CARBURETOR	1	1	1
2-7	125T.01.525	INSULATOR,CARBURETOR	1	1	1
2-8	125T.01.123	O-RING 18 X 3	1	1	1
2-9	125T.01.954	HOLDER ASSY, CARBURETOR	1	1	1
2-10	GB818-85	SCREW M4 X 25	1	1	1
2-11	125T.01.856	BAND, CARBURETOR	1	1	1
2-12	125TT.01.517	GASKET, CYLINDER HEAD	1	1	1
2-13	125T.01.516	PIN, DOWEL	1	1	1
2-14	125T.01.606	BOLT	1	1	1




Enlarged figure next page

E02 CYLINDER HEAD




E03 CAMSHAFT VALVE

REF#	PART #	DESCRIPTION	QTY	2004	2005
3-1	150T.02.118	VALVE EX.	1	1	1
3-2	125T.02.811	SEAL ASSY, VALVE	2	2	2
3-3	12T.02.121	VALVE SPRING, VP	2	2	2
3-4	12T.02.120	SPRING, VLAVE OUTER	2	2	2
3-5	12T.02.119	SPRING VALVE INNER	2	2	2
3-6	12T.02.122	VALVE SPRING, BELOW	2	2	2
3-7	12T.02.123	COTTER, VALVE	2	2	2
3-8	12T.02.114	SHAFT, IN. ROCKER ARM	1	1	1
3-9	12T.02.911	CAMSHAFT ASSY	1	1	1
3-10	12T.02.116	SHAFT, EX. ROCKER ARM	1	1	1
3-11	12T.02.111	ROCKER ARM	2	2	2
3-12	12T.02.107	SCREW, TAPPET ADJUSTING	2	2	2
3-13	12T.02.108	NUT, TAPPET ADJUSTING	2	2	2
3-14	12T.02.812	STOPPER PLATE ASSY	1	1	1
3-15	12T.02.117	VALVE , IN	1	1	1



Enlarged figure
Next page


E03 CAMSHAFT VALVE



E04 CAM CHAIN TENSIONER


REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
4-1	125T.02.922	TIMING CHAIN	1	1	1
4-2	125T.02.822	TENSIONER ASSY	1	1	1
4-3	125T.02.203	GASKET, TENSIONER LIFTER	1	1	1
4-4	125T.02.921	LIFTER ASSY, TENSIONER	1	1	1
4-5	125T.01.601	BOLT	2	2	2
4-6	125T.02.221	O-RING	1	1	1
4-7	125T.02.220	SCREW	1	1	1
4-8	125T.02.821	GUIDE ASSY	1	1	1

Enlarged figure
Next page




E05 CYLINDER HEAD COVER

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
5-1	125T.01.522	BREATHER TUBE, CRANKCASE	1	1	1
5-2	125T.01.523	CLIP TUBER ASSY	1	1	1
5-3	125T.01.952	COVER ASSY	1	1	1
5-4	125T.01.61	BOLT	4	4	4
5-5	125T.01.536	CLIP TUBE (10)	1	1	1




E06 CYLINDER

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
6-1	150T.01.851	CYLINDER ASSY	1	1	1
6-2	150T.01.503	GASKET, CYLINDER	1	1	1
6-3	125T.01.516	PIN, DOWEL	2	2	2
6-4	GB5286-85-6	WASHER COPPER	1	1	1
6-5	GB5787-86	BOLT 06 X 12	1	1	1




E07 CRANKSHAFT PISTON

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
7-1	125T.01.940	CRANKSHAFT COMPLETE	1	1	1
7-2	125T.01.407	WOODRUF KEY	1	1	1
7-3	125T.01.306	PISTON PIN	1	1	1
7-4	125T.01.307	CLIP, PISTON PIN	2	2	2
7-5	125T.01.301	PISTON	1	1	1
	125T.01.302	PISTON RING, FIRST	1	1	1
	125T.01.303	PISTON RING SECOND	1	1	1
	125T.01.304	RING BLADE	2	2	2
7-6	125T.01.305	LOADED OIL CONTROL RINGS	1	1	1




E08 RIGHT CRANKCASE COVER

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
8-1	125T.01.205	COVER, R.	1	1	1
8-2	125T.01.217	GASKET, R. COVER	1	1	1
	125T.01.822	OIL SAL	1	1	1
8-3	125T.01.208	SPRING, OIL SEAL	1	1	1
8-4	125T.01.516	PIN, DOWEL	2	2	2
8-5	125T.01.823	OIL FILTER SCREEN	1	1	1
8-6	125T.01.213	SPRING, OIL FILTER SCREEN	1	1	1
8-7	125T.01.514	O-RING	1	1	1
8-8	125T.01.522	COVER, OIL FILTER SCREEN	1	1	1
8-9	125T.01.609	BOLT	1	1	1
8-10	125T.01.607	BOLT	4	4	4
8-11	125T.01.606	BOLT	1	1	1
8-12	125T.01.608	BOLT	2	2	2
8-13	125T.01.216	CLAMPER, GENERATOR CORD	1	1	1
8-14	125T.01.209	GAUGE, OIL LEVEL	1	1	1
8-15	125T.01.210	O-RING	1	1	1
8-16	125T.01.602	BOLT	1	1	1




Enlarged figure
Next page

E08 RIGHT CRANKCASE COVER



E09 LEFT CRANKCASE COVER


REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
9-1	125T.01.124	GASKET, L. COVER	1	1	1
9-2	125T.01.131B	COVER, L.	2	2	2
9-2-1	125T.01.131C	COVER, L.	2	2	2
9-3	125T.01.603	BOLT	6	6	6
9-4	125T.01.602	BOLT	1	1	1
9-5	125T.01.128	CLAMPER, BRAKE CABLE	1	1	1
9-6	125T.01.125	HOLDER, OIL DRAIN TUBE	1	1	1
9-7	125T.01.817	CLAMPER ASSY	2	2	2
9-8	125T.01.516	PIN, DOWEL	1	1	1
9-9	125T.01.130	PLATE, L. COVER	4	4	4
9-10	GB845-85-ST	SCREW, TAPPING 4.2 X 8-F-H	3	3	3



Enlarged figure
Next page


E09 LEFT CRANKCASE COVER






E10 GENERATOR OIL PUMP

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
10-1	125T.01.605	BOLT	4	4	4
10-2	125T.10.101	FAN, COOLING	1	1	1
10-3	125T.01.409	NUT, CRANKSHAFT	1	1	1
10-4	125T.01.410	GENERATOR ASSY	1	1	1
10-5	A-C125T.06.900	GENERATOR ASSY	1	1	1
10-6	125T.01.604	BOLT	2	2	2
10-7	GB578-86	BOLT M5 X 12	2	2	2
10-8	125T.09.900	OIL PUMP ASSY	1	1	1
10-9	125T.01.610	BOLT	2	2	2
10-10	125T.09.106	SPROCKET, OIL PUMP DRIVEN	1	1	1
10-11	GB6187-86	NUT M6	1	1	1
10-12	125T.09.910	CHAIN, OIL PUMP	1	1	1
10-13	125T.09.107	COVER, OIL PUMP	1	1	1
10-14	GB818-85	SCREW M6 X 12	2	2	2




Enlarged figure
Next page

E10 GENERATOR OIL PUMP




E11 STARTING MOTOR, CLUTCH

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
11-1	125T.07.900	STARTER MOTOR ASSY	1	1	1
11-2	125T.01.613	BOLT (M6 X 16)	2	2	2
11-3	125T.07.202	GEAR	1	1	1
11-4	125T.07.201	STARTER REDUCTION GEAR	1	1	1
11-5	125T.01.407	WOODRUFF KEY	1	1	1
11-6	125T.07.209	FLANGE STARTING CLUTCH	1	1	1
11-7	125T.07.207	SPRING	1	1	1
11-8	125T.07.206	PIN	1	1	1
11-9	GB4661	ROLLER 10 X 10 III +³/b	3	3	3
11-10	125T.07.821	OUTER COMP., STARTING CLUTCH SCREW	1	1	1
11-11	GB-85	SCREW M6 X 10	3	3	3
11-12	125T.07.218	BEARING	1	1	1
11-13	125T.07.203	PIN, DOWER	1	1	1
11-14	125T.07.823	INNER COMP, STARTING	1	1	1
11-15	125T.07.211	WASHER, LOCK NUT	1	1	1
11-16	125T.07.210	NUT, LOCK	1	1	1




Enlarged figure
Next page

E11 STARTING MOTOR, CLUTCH




E12 DRIVER, STARTER

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
12-1	125T.07.115	PLATE, SPRING STOP	1	1	1
12-2	125T.04.101	FACE DRIVE	1	1	1
12-3	125T.04.109	BOSS, DRIVER	1	1	1
12-4	125T.04.201	FACE COMP., MOVABLE DRIVE	1	1	1
12-5	125T.04.812	ROLLER SET	6	6	6
12-6	125T.04.107	PLATE, RAMP	1	1	1
12-7	125T.04.108	BUFFER, PLATE RAMP	3	3	3
12-8	125T.07.101	GEAR, KICK DRIVEN	1	1	1
12-9	125T.07.105	CLIP	1	1	1
12-10	125T.07.811	IDLE GEAR COMP	1	1	1
12-11	125T.07.108	SHAFT, STARTER IDLE	1	1	1
12-12	125T.07.106	SPRING, STARTER IDLE	1	1	1
12-13	125T.07.812	KICK SHAFT COMP	1	1	1
12-14	125T.07.114	BUSH, 12 X 16 X 12	1	1	1
12-15	125T.07.109	BUSH, 14 X 18 X 116	1	1	1
12-16	125T.07.109-1	SPRING, TORSION	1	1	1
12-17	125T.07.116	PIN, 4.6MM	1	1	1
12-18	125T.07.410	THRUST, FLANGE, 12MM	1	1	1
12-19	125T.07.113	WASHER, 14.1MM	1	1	1
12-20	125T.07.102	WASHER, 12.5MM	1	1	1
12-21	125T.01-409	THRUST, FLANGE, 12MM	1	1	1
12-22	GB578F86	BOLT M6	1	1	1
12-23	125.07.107	ROLLER, 3 X 8.5	1	1	1
12-24	125T.04.103	COLLAR	1	1	1
12-25	125T.04.104	CLIP	2	2	2
12-26	125.07.912B	POLE, ANCHOR	1	1	1
12-27	M6 X 22	BOLT	1	1	1




Enlarged figure
Next page

E12 DRIVER, STARTER




E13 BELT, DRIVEN PULLEY

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
13-1	125T.03.101	OUTER CLUTCH	1	1	1
13-2	125T.03.814	PLATE COMP DRIVE	1	1	1
13-3	125T.03.109	COCER, CLUTCH	1	1	1
13-4	125T.03.106	SPRING CLUTCH	3	3	3
13-5	125T.03.812	WEIGHT CLUTCH	3	3	3
13-6	125T.03.813	DAMPER COMP	3	3	3
13-7	150T.04.301	V-BELT	1	1	1
13-8	125T.04.821	LEFT COMP, DRIVEN	1	1	1
13-9	125T.04.208	PIN, ROLLER GUIDE	3	3	3
13-10	125T.04.216	ROLLER GUIDE	3	3	3
13-11	125T.04.205	SPRING, DRIVEN	1	1	1
13-12	125T.04.206	RIGHT SEAT, SPRING	1	1	1
13-13	125T.04.206-1	LEFT SEAT, SPRING	1	1	1
13-14	125T.01.409	NUT, FLANGE, 12MM	1	1	1
13-15	125T.04.214	NUT, SPEVIAL, 28MM	1	1	1
13-16	125T.01.410	WASHER, 12.2 X 25 X 2.5	1	1	1
13-17	125T.03.112	CIRCLIP, 7MM	3	3	3
13-18	125T.04.823	SEAL, DRIVEN PULLEY	2	2	2
13-19	125T.04.215	O-RING, DRIVEN	2	2	2
13-20	125T.04.921	PULLEY ASSY, DRIVEN	1	1	1
13-21	125T.03.911	PLATE-ASSY, DRIVEN	1	1	1
13-22	125T.04.822	RIGHT COMP., DRIVEN	1	1	1
13-23	125T.04.824	BEARING, NEEDLE, 20 X 29	1	1	1
13-24	125T.04.217	LEFT BEARING, DRIVEN	1	1	1
13-25	GB893.1-86-28	CIRCLIP, 28MM	1	1	1




Enlarged figure
Next page

E13 BELT, DRIVEN PULLEY




E14 REAR DRIVE SET

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
14-1	125T.01.132	COVER, REAR DRIVE	1	1	1
14-2	125T.01.133	GASKET, REAR COVER	1	1	1
14-3	125T.05.101	SHAFT, DRIVE	1	1	1
14-4	125T.05.911	COUNTERSHAFT COMP	1	1	1
14-5	125T.05.105	SHAFT, FINAL	1	1	1
14-6	125T.05.104	GEAR, FINAL	1	1	1
14-7	125T.01.612	BOLT M6 X 28	3	3	3
14-8	125T.01.611	BOLT M6 X 35	3	3	3
14-9	125T.01.504	BOLT, SPECIAL, 8MM	2	2	2
14-10	125T.01.505	WASHER, 8MM	2	2	2
	125T.01.816	SEAL, 20 X 32 X 6	1	1	1
14-11	125T.01.136	SPRING, SEAL	1	1	1
14-12	125T.01.516	PIN, 8 X 14	2	2	2
14-13	GB894.1-86	CIRCLIP, 20MM	1	1	1
14-14	202-GB276-89	BEARING, BALL 202	1	1	1
14-15	203-GB276-89	BEARING, BALL 203	1	1	1
14-16	125T.05.107	L-BEARING	1	1	1




Enlarged figure
Next page

E14 REAR DRIVE SET




E15 CRANKCASE

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
15-1	125T.01.820	CRANKCASE ASSY, R.	1	1	1
15-2	125T.01.812	BUSH, HANGE	2	2	2
15-3	125T.01.122	GASKET	1	1	1
15-4	125T.01.810	CRANKCASE ASSY, L.	1	1	1
15-5	125T.01.105	BLICK	1	1	1
15-6	125T.01.813	BUSH HANGE	1	1	1
15-7	125T.01.104	TUBE, BREATHER	1	1	1
15-8	125T.01.203	STUD 8 X 187.5	2	2	2
15-9	125T.01.103	STUD 8 X 195.5	2	2	2
15-10	125T.01.138	R-BEARING	1	1	1
15-11	GB276-89	BEARING, BALL 102	1	1	1
15-12	GB279-89	BEARING SEAL 180104	1	1	1
	125T.01.814	SEAL, 27 X 42 X 7	1	1	1
15-13	125T.01.116	SPRING, SEAL	1	1	1
15-14	125T.01.123	PIN, DOWER 8 X 14	2	2	2
15-15	125T.01.615	NBOLT M6 X 50	2	2	2
	125T.01.822	SEAL, 19.8 X 30 X 5	1	1	1
15-16	125T.01.208	SPRING, SEAL	1	1	1
15-17	125T.01.112	PIN, BRAKE SHOE	1	1	1
15-18	125T.01.113	O-RING 7.5 X 1.5	1	1	1
15-19	125T.01.616	NUT, FLANGE 8MM	1	1	1
15-20	125T.01.120	DRAIN PLUG 12MM	1	1	1
15-21	125T.01.121	WASHER, PLUG 12MM	1	1	1




Enlarged figure
Next page

E15 CRANKCASE




E16 CARBURETOR

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
16-1	ORDER REF. 16-13	GASKET SET	1	1	1
16-2	ORDER REF. 16-13	VALVE SET, FLOAT	1	1	1
16-3	ORDER REF. 16-13	NEEDLE SET	1	1	1
16-4	ORDER REF. 16-13	FLOAT CHAMBER	1	1	1
16-5	ORDER REF. 16-13	CHAMBER SET, FLOAT	1	1	1
16-6	ORDER REF. 16-13	SCREW SET A	1	1	1
16-7	ORDER REF. 16-13	SCREW SET B	1	1	1
16-8	ORDER REF. 16-13	PLATE SET, VALVE	1	1	1
16-9	ORDER REF. 16-13	VALVE SET, STARTER	1	1	1
16-10	ORDER REF. 16-13	VALVE SET, AIRCUT	1	1	1
16-11	ORDER REF. 16-13	SPRING	1	1	1
16-12	ORDER REF. 16-13	SCREW, PAN, 5 X 12	2	2	2
16-13	150T.08.900	CARBURETOR ASSY	1	1	1
16-14	ORDER REF. 16-13	TOP COMP	1	1	1
16-15	ORDER REF. 16-13	PISTON COMP, VACUUM	1	1	1
16-16	ORDER REF. 16-13	HOLDER, JET	1	1	1
16-17	ORDER REF. 16-13	BINDER	1	1	1
16-18	ORDER REF. 16-13	CAP, STARTER	1	1	1
16-19	ORDER REF. 16-13	TUBE	1	1	1
16-20	ORDER REF. 16-13	TUBE	1	1	1
16-21	ORDER REF. 16-13	SCREW, PAN 4 X 8	4	4	4
16-22	ORDER REF. 16-13	SCREW, PAN 4 X 14	4	4	4
16-23	ORDER REF. 16-13	SCREW-WASHER, 4 X 10	2	2	2
16-24	ORDER REF. 16-13	SCREW-WASHER, 5 X 12	2	2	2
16-25	ORDER REF. 16-13	CLIPB7	2	2	2
16-26	ORDER REF. 16-13	CLIPB8	2	2	2
16-27	ORDER REF. 16-13	TUBE, 4 X 195	1	1	1
16-28	ORDER REF. 16-13	JET, MAIN #112	1	1	1
16-29	ORDER REF. 16-13	JET, SLOW #35	1	1	1




Enlarged figure
Next page

E16 CARBURETOR




F01 SIDE COVER

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
1-1	SGI.17.01RD	L. SIDE COVER RED	1	1	
	SGI.17.01BU	L. SIDE COVER BLUE	1	1	
	SGI.17.01YW	L. SIDE COVER YELLOW	1	1	
	SGI.17.GP1OR	L. SIDE COVER ORANGE GP1	1		1
	SGI.17.GP1RD	L. SIDE COVER RED GP1			1
	SGI.17.GP1BU	L. SIDE COVER BLUE GP1			1
	SGI.17.GP1GY	L. SIDE COVER GRAY GP1			1
1-2	SGI.18.02RD	R. SIDE COVER RED	1	1	
	SGI.18.02BU	R. SIDE COVER BLUE	1	1	
	SGI.18.02YW	R. SIDE COVER YELLOW	1	1	
	SGI.18.GP1OR	R. SIDE COVER ORANGE GP1			1
	SGI.18.GP1RD	R. SIDE COVER RED GP1			1
	SGI.18.GP1BU	R. SIDE COVER BLUE GP1			1
	SGI.18.GP1GY	R. SIDE COVER GRAY GP1			1
1-3	SGI.17.03	SCREW	6	6	6
1-4	SGI.17.04	SCREEN	1	1	1
1-5	SGI.17.05	SCREW	4	4	4
1-6	SGI.17.06	SEAT LOCK	1	1	1
1-7	SGI.17.07	LOCKING PLATE	1	1	1
1-8	SGI.17.08	RETAINER	1	1	1
1-9	SGI.17.09	REAR COVER RED	1	1	1
1-9	SGI.17.09BU	REAR COVER BLUE		1	1
1-9	SGI.17.09GY	REAR COVER GREY		1	1
1-9	SGI.17.09OR	REAR COVER ORANGE			1
1-9	SGI.17.09RD	REAR COVER RED			1




Enlarged figure
Next page

F01 SIDE COVER




F02 R & L. S/W ASSY

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
2-1	SGI.18.01	SWITCH ASSY, R.	1	1	1
2-2	SGI.18.02	SCREW	1	1	1
2-3	SGI.18.03	BOLT	1	1	1
2-4	SGI.18.04	BOLT	1	1	1
2-5	SGI.18.05	HANDLE BAR R.	1	1	1
2-6	SGI.18.06	NUT	1	1	1
2-7	SGI.18.07	FRONT BRAKE MASTER CYLINDER	1	1	1
2-8	SGI.18.08	WASHER	1	1	1
2-9	SGI.18.09	HOSE ASSY, FR BRAKE	1	1	1
2-10	SGI.18.10	WASHER	1	1	1
2-11	SGI.18.11	BOLT	1	1	1
2-12	SGI.18.12	HOLDER, OIL CYLINDER	1	1	1
2-13	SGI.18.13	BRACKET HANDLE, L.	1	1	1
2-14	SGI.18.14	HANDLE BAR L.	1	1	1
2-15	SGI.18.15	HOLDER LEVER BRACKET L.	1	1	1
2-16	SGI.18.16	SWITCH ASSY, SEAT L	1	1	1
2-17	SGI.18.17	DIMMER S/W	1	1	1
2-18	SGI.18.18	WINKER S/W	1	1	1
2-19	SGI.18.19	SWITCH, HORN	1	1	1
2-20	SGI.18.20	SWITCH STARTER	1	1	1
2-21	SGI.18.21	SWITCH LIGHTING	1	1	1
2-22	SGI.18.22	CABLE, BRAKE	1	1	1
2-23	SGI.18.23	THROTTLE CABLE COMP	1	1	1
2-24	SGI.18.24	SPEEDOMETER CABLE	1	1	1




Enlarged figure
Next page

F02 R & L. S/W ASSY




F03 STAND

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
3-1	SGI.19.01	MAIN STAND	1	1	1
3-2	SGI.19.02	SIDE STAND	1	1	1
3-3	SGI.19.03	SPRING, SIDE STAND	1	1	1
3-4	SGI.19.04	SCREW, SIDE STAND	1	1	1
3-5	SGI.19.05	NUT, SIDE STAND	1	1	1
3-6	SGI.19.06	RUBBER, STAND	1	1	1
3-7	SGI.19.07	BOLT	2	2	2
3-8	SGI.19.08	BUSH, MAIN STAND	2	2	2
3-9	SGI.19.09	SPRING, MAIN STAND	1	1	1
3-10	SGI.19.10	STARTING ROD ASSY	1	1	1
3-11	SGI.19.11	BOLT	1	1	1




Enlarged figure
Next page

F03 STAND




F04 WINKER (TURNING SIGNAL LAMP)

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
4-1	SGI.20.01	COVER L FR TURN SIGNAL	1	1	1
4-2	SGI.20.02	BULB, TURN SIGNAL	1	1	1
4-3	SGI.20.03	LIGHT BASE COMP	1	1	1
4-4	SGI.20.04	HOUSING	1	1	1
4-5	SGI.20.05	COVER R. FR. TURN SIGNAL	1	1	1
4-6	SGI.20.06	BULB	1	1	1
4-7	SGI.20.07	LIGHT BASE COMP	1	1	1
4-8	SGI.20.08	R TURN SIGNAL HOUSING	1	1	1




Enlarged figure
Next page

F04 (TURNING SIGNAL LAMP)




F05 FRONT BOX

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
5-1	SGI.21.01	FRONT BOX	1	1	1
5-2	SGI.21.02	BOLT	2	2	2
5-3	SGI.21.03	BOX, LOCK	1	1	1
5-4	SGI.21.04	SCREW	2	2	2
5-5	SGI.21.05	SCREW	2	2	2
5-6	SGI.21.06	CLIP	2	2	2
5-7	SGI.21.07	BOX COVER	1	1	1
5-8	SGI.21.08	SEAL, RUBBER	1	1	1
5-9	SGI.21.09	HINGE	2	2	2




Enlarged figure
Next page

F05 FRONT BOX




F06 CENTRAL COVER

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
6-1	SGI.22.01	CENTRAL COVER	1	1	1
6-2	SGI.22.02	BOLT	1	1	1
6-3	SGI.22.03	SCREW	1	1	1
6-4	SGI.22.04	MOUNTING PLATE, HANGER	1	1	1
6-5	SGI.22.05	HANGER	1	1	1
6-6	SGI.22.06	LID, CHECKING VIEW HOLE	1	1	1




F07 CALIPER ASSY., FRONT BRAKE

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
7-1	SGI.23.01	DUST SEAL SET, PISTON	2	2	2
7-2	SGI.23.02	BLEEDER	1	1	1
7-3	SGI.23.03	CAP, BLEEDER	1	1	1
7-4	SGI.23.04	COLLAR, N, FR. BRAKE	1	1	1
7-5	SGI.23.05	DUST SEAL	2	2	2
7-6	SGI.23.06	PISTON	2	2	2
7-7	SGI.23.07	SPRING	1	1	1
7-8	SGI.23.08	BRACKET COMP.	1	1	1
7-9	SGI.23.09	BUSH	2	2	2
7-10	SGI.23.10	BUSH, PIN	1	1	1
7-11	SGI.23.11	BOLT-PIN B	1	1	1
7-12	SGI.23.12	BOLT-PIN A	1	1	1
7-13	SGI.23.13	RUBBER PLUG	1	1	1
7-14	SGI.23.14	POSITION PIN	2	2	2
7-15	SGI.23.15	POSITION BOLT-PIN	2	2	2
7-16	SGI.23.16	BUSH, TORQUE LINK	2	2	2
7-17	SGI.23.17	SPACER, TORQUE LINK	1	1	1
7-18	SGI.23.18	DUST SEAL	2	2	2
7-19	SGI.23.19	BRAKE PADS SET	1	1	1
7-20	SGI.23.20	CALIPER ASSY	1	1	1




Enlarged figure
Next page

F07 CALIPER ASSY., FRONT BRAKE




F08 FUEL TANK

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
8-1	SGI.24.01	PETCOCK, ASSY	1	1	1
8-2	SGI.24.02	STRAINER	1	1	1
8-3	SGI.24.03	GASKET, PETCOCK BODY	1	1	1
8-4	SGI.24.04	FUEL TANK COMP	1	1	1
8-5	SGI.24.05	SEAL COMP, FUEL TANK	1	1	1
8-6	SGI.24.06	CAP COMP FUEL FILLER	1	1	1
8-7	SGI.24.07	SEAL RING FUEL TANK	1	1	1
8-8	SGI.24.08	TUBE COMP, FUEL	1	1	1
8-9	SGI.24.09	TUBE COMP, VACUUM	1	1	1
8-10	SGI.24.10	LEVEL SENSOR SET, FUEL	1	1	1
8-11	SGI.24.11	POSITION PLATE FUEL SENSOR	1	1	1
8-12	SGI.24.12	POSITION PLATE FUEL SENSOR	1	1	1
8-13	SGI.24.13	JOINT, THREE WAY	1	1	1
8-14	SGI.24.14	TUBE A	1	1	1
8-15	SGI.24.15	TUBE B	4	4	4
8-16	SGI.24.16	TUBE C	2	2	2
8-17	SGI.24.17	HOSE	1	1	1
8-18	SGI.24.18	NUT	3	3	3
8-19	SGI.24.19	BOLT	1	1	1
8-20	SGI.24.20	FILTER	1	1	1




Enlarged figure
Next page

F08 FUEL TANK




F09 METER ASSY

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
9-1	SGI.25.01	INDICATOR BULB A	3	3	3
9-2	SGI.25.02	INDICATOR BULB B	1	1	1
9-3	SGI.25.03	BOLT M5 X 20	1	1	1
9-4	SGI.25.04	CLAMP LEAD	1	1	1
9-5	SGI.25.05	WIRE HARNESS, METER	1	1	1
9-6	SGI.25.06	METER HOUSING	1	1	1
9-7	SGI.25.07	METER	1	1	1
9-8	SGI.25.08	PLATE COMP REFLECTING	1	1	1
9-9	SGI.25.09	LENS	2	2	2
9-10	SGI.25.10	SCREW	2	2	2
9-11	SGI.25.11	NUT M5	1	1	1




Enlarged figure
Next page

F09 METER ASSY




F10 BATTERY

REF	PART NUMBER	DESCRIPTION	QTY	#	#
10-1	SGI.26.01	BATTERY	1	1	1
10-3	SGI.26.02	CABLE, BATTERY	1	1	1
10-4	SGI.26.03	CABLE, EARTH	1	1	1
10-6	SGI.26.04	SOCKET HEAD, CAPSCREW	2	2	2
10-7	SGI.26.05	BAND, BATTERY	1	1	1
10-8	SGI.26.06	BOLT	1	1	1



F11 SEAT


REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
11-1	SGI.27.01	SEAT	1	1	1
	SGI.27.01-BL	SEAT BLUE BLACK			1
	SGI.27.01-BL	SEAT RED BLACK			1
	SGI.27.01-YW	SEAT BLUE YELLOW			1
	SGI.27.01-BL	SEAT GRAY BLACK			1
11-2	SGI.27.02	NUT	2	2	2
11-3	SGI.27.03	BRACKET	1	1	1
11-4	SGI.27.04	LUGGAGE BOX	1	1	1
11-5	SGI.27.05	RUBBER BAND	2	2	2
11-6	SGI.27.06	RUBBER PAD	2	2	2
11-7	SGI.27.07	REAR RAIL	1	1	1



F12 EX. MUFFLER


REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
12-1	SGI.28.01	EX. MUFFLER	1	1	1
12-2	SGI.28.02	GUARD EX PIPE	1	1	1
12-3	SGI.28.03	BOLT	2	2	2
12-4	SGI.28.04	WASHER	2	2	2
12-5	SGI.28.05	NUT	2	2	2
12-6	SGI.28.06	WASHER	1	1	1
12-7	SGI.28.07	NUT	2	2	2
12-8	SGI.28.08	BOLT M8 X 90	1	1	1

NOTE: FOR DIMONZA EXHAUST, PLEASE REFER TO MATRIX XX PARTS BOOK PAGE F20



F13 L. & R. REAR PROTECTING BAR


REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
13-1	SGI.29.01RD	REAR PROTECTING BAR (L) RED	1	1	1
	SGI.29.01BU	REAR PROTECTING BAR (L) BLUE	1	1	1
	SGI.29.01YW	REAR PROTECTING BAR (L) YELLOW			1
	SGI.29.GP1RD	REAR PROTECTING BAR (L) RED GP1			1
	SGI.29.GP1OR	REAR PROTECTING BAR (L) ORANGE GP1			1
	SGI.29.GP1YW	REAR PROTECTING BAR (L) YELLOW GP1			1
	SGI.29.GP1GY	REAR PROTECTING BAR (L) GREY GP1			1
	SGI.30.01RD	REAR PROTECTING BAR (R) RED	1	1	1
	SGI.30.01BU	REAR PROTECTING BAR (R) BLUE	1	1	1
	SGI.30.01YW	REAR PROTECTING BAR (R) YELLOW			1
	SGI.30.GP1RD	REAR PROTECTING BAR (R) RED GP1			1
	SGI.30.GP1OR	REAR PROTECTING BAR (R) ORANGE GP1			1
	SGI.30.GP1YW	REAR PROTECTING BAR R) YELLOW GP1			1
13-2	SGI.30.GP1GY	REAR PROTECTING BAR (R) GREY GP1			1



Enlarged figure next page


F14 TAIL LIGHT

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
14-1	SGI.30.01	COVER, TAILLIGHT	1	1	1
14-2	SGI.30.02	BASE COMP, TAILLIGHT	1	1	1
14-3	SGI.30.03	BULB	1	1	1
14-4	SGI.30.04	SCREW	1	1	1
14-5	SGI.30.05	SCREW	2	2	2
14-6	SGI.30.06	SOCKET COMP	1	1	1




F15 MIRROR COMP

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
15-1	SGI.31.01	GRIP L. HANDLE	1	1	1
15-2	SGI.31.02	GRIP R.R. HANDLE	1	1	1
15-3	SGI.31.03	ADJUSTING NUT	1	1	1
15-4	SGI.31.04	MIRROR ASSY, L.	1	1	1
15-5	SGI.31.05	ADJUSTING NUT	1	1	1
15-6	SGI.31.06	MIRROR ASSY, R.	1	1	1




F16 HEADLIGHT

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
16-1	SGI.32.01	COVER, HEADLIGHT	1	1	1
16-2	SGI.32.02	BULB HEADLIGHT	1	1	1
16-3	SGI.32.03	CASE, HEADLIGHT	1	1	1
16-4	SGI.32.04	LOCK BASE	1	1	1
16-5	SGI.32.05	SPRING	1	1	1
16-6	SGI.32.06	LOCK PIECE	1	1	1
16-7	SGI.32.07	PIN SHAFT	1	1	1




F17 FRONT WHEEL

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
17-1	SGI.33.01	VALVE STEM	1	1	1
17-2	SGI.33.02	AXLE BOLT	1	1	1
17-3	SGI.33.03	BUSH, SHAFT	1	1	1
17-4	SGI.33.04	SPACER, SHAFT	1	1	1
17-5	SGI.33.05	BEARING	1	1	1
17-6	SGI.33.06	DUST SEAL	1	1	1
17-7	SGI.33.07	DISK, FR. BRAKE	1	1	1
17-8	SGI.33.08	BOLT	3	3	3
17-9	SGI.33.09	BEARING	1	1	1
17-10	SGI.33.10	SEAL, DRIVING GEAR BOX FOR MILEOMETER	1	1	1
17-11	SGI.33.11	NUT	1	1	1
17-12	SGI.33.12	DRIVING, GEAR BOX ASSY FOR SPEEDOMETE	1	1	1
17-13	SGI.33.13	TIRE FR	1	1	1
17-14	SGI.33.14	RIM FR. WHEEL	1	1	1
	SGI.33.14YW	RIM FR. WHEEL YELLOW			1
	SGI.33.14BK	RIM FR. WHEEL BLACK			1
	SGI.33.14OR	RIM FR. WHEEL ORANGE			1




Enlarged figure
Next page

F17 FRONT WHEEL



F18 COVER FR.


REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
18-1	SGI.34.01	COVER FR.RED	1	1	1
	SGI.34.01YW	COVER FR.YELLOW	1	1	1
	SGI.34.01BU	COVER FR.BLUE	1	1	1
	SGI.34.GP1OR	COVER FR. ORANGE GP1			1
	SGI.34.GP1RD	COVER FR. RED GP1			1
	SGI.34.GP1BU	COVER FR. BLUE GP1			1
	SGI.34.GP1GY	COVER FR. GRAY GP1			1
18-2	SGI.34.02SV	FENDER, FR. SILVER	1	1	1
	SGI.34.02BL	FENDER, FR. BLACK	1	1	1
	SGI.34.GP1CF	FENDER, FR. GP1 CARBON FIBER			1
18-3	SGI.34.03	SCREEN, HEAD LAMP	1	1	1
18-4	SGI.34.04	SCREW M6	1	1	1
18-5	SGI.34.05	SCREW M6X20	4	4	4



Enlarged figure next page


F19 L. & R. FRONT PROTECTING BAR

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
19-1	SGI.35.01SV	L. PROTECTING BAR SILVER	1	1	1
	SGI.35.01BL	L. PROTECTING BAR BLACK	1	1	1
	SGI.35.GP1OR	L. PROTECTING BAR ORANGE GP1			1
	SGI.35.GP1YW	L. PROTECTING BAR YELLOW GP1			1
	SGI.35.GP1BKWH	L. PROTECTING BAR BLCK/WHITE GP1			1
	SGI.35.GP1BKGY	L. PROTECTING BAR BLACK/GRAY GP1			1
19-2	SGI.38.01SV	R. PROTECTING BAR SILVER	1	1	1
	SGI.38.01BL	R. PROTECTING BAR BLACK	1	1	1
	SGI.38.GP1OR	R. PROTECTING BAR ORANGE GP1			1
	SGI.38.GP1YW	R. PROTECTING BAR YELLOW GP1			1
	SGI.38.GP1BKWH	R. PROTECTING BAR BLCK/WHITE GP1			1
	SGI.38.GP1BKGY	R. PROTECTING BAR BLACK/GRAY GP1			1
19-3	SGI.35.03	SIDE REFLECTOR	1		1




F20 AIR CLEANER

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
20-1	SGI.36.01	COVER, AIR CLEANER	1	1	1
20-2	SGI.36.02	FILTER ELEMENT COMP., AIR CLEANER	1	1	1
20-3	SGI.36.03	FILTER ELEMENT, AIR CLEANER	1	1	1
20-4	SGI.36.04	COVER, INLET CHAMBER	1	1	1
20-5	SGI.36.05	CONNECTING TUBE, AIR CLEANER	1	1	1
20-6	SGI.36.06	CASE COMP., AIR CLEANER	1	1	1
20-7	SGI.36.07	CONNECTING BAND AIR CLEANER	1	1	1
20-8	SGI.36.08	SCREW	1	1	1
20-9	SGI.36.09	SCREW	2	2	2
20-10	SGI.36.10	SCREW	1	1	1
20-11	SGI.36.11	SCREW	5	5	5
20-12	SGI.36.12	TUBE, BREATHER	1	1	1




Enlarged figure
Next page

F20 AIR CLEANER




F21 FOOTREST

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
21-1	SGI.37.01	FOOTREST	1	1	1
21-2	SGI.37.02	COVER, BATTERY	1	1	1
21-3	SGI.37.03	BOLT	4	4	4




F22 REAR WHEEL

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
22-1	SGI.38.01	TIRE RR	1	1	1
22-2	SGI.38.02	RR RIM	1	1	1
	SG1.38.02BK	RR RIM BLACK			1
	SG1.38.02YW	RR RIM YELLOW			1
	SGI.38.02OR	RIM RR ORANGE			1
22-3	SGI.38.03	WASHER	1	1	1
22-4	SGI.38.04	NUT	1	1	1
22-5	SGI.38.05	VALVE STEM	1	1	1
22-6	SGI.38.06	BRAKE SHOE SET	1	1	1
22-7	SGI.38.07	BRAKE BLOCK	2	2	2
22-8	SGI.38.08	SPRING RR. BRAKE	2	2	2
22-9	SGI.38.09	CAM. RR. BRAKE	1	1	1
22-10	SGI.38.10	ROCKER, COMP, RR. BRAKE	1	1	1
22-11	SGI.38.11	ADJUSTING NUT, RR. BRAKE ROD	1	1	1
22-12	SGI.38.12	BOLT	1	1	1
22-13	SGI.38.13	PIN RR. BRAKE ROD	1	1	1
22-14	SGI.38.14	RETURN SPRING, RR. BRAKE ROCKER	1	1	1




Enlarged figure
Next page

F22 REAR WHEEL




F23 REAR SHOCK ABSORBER

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
23-1	SGI.39.01	RR, SHOCK ABROBER ASSY	1	1	1
23-2	SGI.39.02	RUBBER BUSH	1	1	1
23-3	SGI.39.03	BUSH, SHAFT	1	1	1
23-4	SGI.39.04	BOLT, HEX 8 X 32	1	1	1
23-5	SGI.39.05	BOLT 10 X 35	1	1	1




F24 REAR FENDER (I)

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
24-1	SGI.40.01	REAR FENDER	1	1	1
24-2	SGI.40.02	REAR FENDER	1	1	1
24-3	SGI.40.03	WATER GUARD	1	1	1
24-4	SGI.40.04	MOUNTING PLATE (A)	1	1	1
24-5	SGI.40.05	BOLT	1	1	1
24-6	SGI.40.06	MOUNTING PLATE (B)	1	1	1
24-7	SGI.40.07	BOLT	2	2	2
24-8	SGI.40.08	NUT	1	1	1
24-9	SGI.40.09	NUT	1	1	1




F25 REAR FENDER (II)

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
25-1	SGI.41.01	L. REAR TURNING SIGNAL LAMP ASSY	1	1	1
25-2	SGI.41.02	REAR FENDER	1	1	1
25-3	SGI.41.03	REAR FENDER	1	1	1
25-4	SGI.41.04	CASE, R. TURNING SIGNAL LAMP	1	1	1
25-5	SGI.41.05	BASE R. TURNING SIGNAL LAMP	1	1	1
25-6	SGI.41.06	BULB	1	1	1
25-7	SGI.41.07	COVER, R. TURNING SIGNAL LAMP	1	1	1
25-8	SGI.41.08	CONNECTING PLATE	2	2	2
25-9	SGI.41.09	NUT	2	2	2
25-10	SGI.41.10	NUT	1	1	1
25-11	SGI.41.11	REAR REFLECTOR	1	1	1
25-12	SGI.41.12	SCREW	2	2	2
25-13	SGI.41.13	WASHER	1	1	1
25-14	SGI.41.14	WASHER	1	1	1




Enlarged figure
Next page

F25 REAR FENDER (II)




F26 STEERING STEM AND FR. SHOCK ABSORBER

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
26-1	SGI.42.01	STEERING STEM	1	1	1
26-2	SGI.42.02	FR. SHOCK ABSORBER ASSY	1	1	1
26-3	SGI.42.03	BOLT	1	1	1
26-4	SGI.42.04	SCREW	1	1	1
26-5	SGI.42.05	LOCKING NUT STEERING STEM	1	1	1
26-6	SGI.42.06	TOP PAD TOP BEARING STEERING STEM	1	1	1
26-7	SGI.42.07	STEEL BALL ASSY STEERING STEM	1	1	1
26-8	SGI.42.08	RACE STEERING BOTTOM CONE	1	1	1
26-9	SGI.42.09	RACE STEERING TOP CONE	1	1	1
26-10	SGI.42.10	BALL ASSY STEERING STEM	1	1	1
26-11	SGI.42.11	RACE STEERING STEM	1	1	1
26-12	SGI.42.12	BOLT	2	2	2
26-13	SGI.42.13	FR. SHOCK ABSORBER ASSY	1	1	1




Enlarged figure
Next page

F26 STEERING STEM AND FR. SHOCK ABSORBER




F27 STEERING HANDLE

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
27-1	SGI.42.01SV	RIGHT HANDLE SHIELD SILVER	1	1	1
	SGI.42.01BL	RIGHT HANDLE SHIELD BLACK	1	1	1
	SGI.42.GP1OR	RIGHT HANDLE SHIELD ORANGE GP1			1
	SGI.42.GP1RD	RIGHT HANDLE SHIELD RED GP1			1
	SGI.42.GP1BU	RIGHT HANDLE SHIELD BLUE GP1			1
27-2	SGI.44.01SV	LEFT HANDLE SHIELD SILVER	1	1	1
	SGI.44.01BL	LEFT HANDLE SHIELD BLACK	1	1	1
	SGI.44.GP1OR	LEFT HANDLE SHIELD ORANGE GP1			1
	SGI.44.GP1RD	LEFT HANDLE SHIELD RED GP1			1
	SGI.44.GP1BU	LEFT HANDLE SHIELD BLUE GP1			1
27-3	SGI.43.03RD	FR. LIGHT COVER RED	1	1	1
	SGI.43.03BU	FR. LIGHT COVER BLUE	1	1	1
	SGI.43.03YW	FR. LIGHT COVER YELLOW	1	1	1
	SGI.43.GP1OR	FR. LIGHT COVER ORANGE GP1			1
	SGI.43.GP1RD	FR. LIGHT COVER RED GP1			1
	SGI.43.GP1BU	FR. LIGHT COVER BLUE GP1			1
	SGI.43.GP1GY	FR. LIGHT COVER GRAY GP1			1
27-4	SGI.43.05	STEERING HANDLE	1	1	1
27-5	SGI.43.09	REAR HANDLE COVER	1	1	1
27-6	SGI.43.06	SCREW	1	1	1
27-7	SGI.43.07	NUT	1	1	1
27-8	SGI.43.08	FR. POSITION LIGHT	1	1	1




Enlarged figure
next page

F27 STEERING HANDLE




F28 FENDER FOR FRAME

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
28-1	SGI.44.01	FENDER	1	1	1
28-2	SGI.44.02	SCREW	2	2	2
28-3	SGI.44.03	BOLT	4	4	4




F29 WIRE HARNESS

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
29-1	SGI.45.01	C.D.I.	1	1	1
29-2	SGI.45.02	BOLT	1	1	1
29-3	SGI.45.03	CAP ASSY, SPARK PLUG	1	1	1
29-4	SGI.45.04	REGULATOR COMP	1	1	1
29-5	SGI.45.05	FLASHER	1	1	1
29-6	SGI.45.06	KEY SET	1	1	1
29-7	SGI.45.07	SWITCH ASSY, COMBINATION LOCK	1	1	1
29-8	SGI.45.08	KEY	1	1	1
29-9	SGI.45.09	RUBBER GROOVE	1	1	1
29-10	SGI.45.10	HARNESS WIRE	1	1	1
29-11	SGI.45.11	RESISTOR COMP	1	1	1
29-12	SGI.45.12	BOLT	1	1	1
29-13	SGI.45.13	SCREW	1	1	1
29-14	SGI.45.14	IGNITION COIL COMP	1	1	1
29-15	SGI.45.15	RELAY	1	1	1
29-16	SGI.45.16	NUT	1	1	1
29-17	SGI.45.17	HARNESS WIRE	1	1	1
29-18	SGI.45.18	NUT	1	1	1




Enlarged figure
Next page

F29 WIRE HARNESS




F30 FRAME

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
30-1	SGI.46.01	HORN COMP	2	2	2
30-2	SGI.46.02	HORN HOLDER	1	1	1
30-3	SGI.46.03	BOLT	2	2	2
30-4	SGI.46.04	L, FOOTREST	1	1	1
30-5	SGI.46.05	PIN	1	1	1
30-6	SGI.46.06	PIN	1	1	1
30-7	SGI.46.07	L, DECORATION PLATE	1	1	1
30-8	SGI.46.08	HANGER COMP ENGINE	1	1	1
30-9	SGI.46.09	FRAME BODY	1	1	1
30-10	SGI.46.10	SCREW	1	1	1
30-11	SGI.46.11	R, FOOTREST	1	1	1
30-12	SGI.46.12	R, DECORATION PLATE	1	1	1
30-13	SGI.46.13	SCREW	2	2	2
30-14	SGI.46.14	BOLT, ENGINE HANGER	1	1	1




Enlarged figure
Next page

F30 FRAME



F31 TOOLS

REF	PART NUMBER	DESCRIPTION	QTY	2004	2005
31-1	SGI.47.01	TOOL SET	1	1	1
31-2	SGI.47.02	WRENCH, EYE (18X19)	1	1	1
31-3	SGI.47.03	12X14 SPANNER	1	1	1
31-4	SGI.47.04	SPANNER, 8X10	1	1	1
31-5	SGI.47.05	PLIERS, 165	1	1	1
31-6	SGI.47.06	SCREW DRIVER, DOUBLE USE	1	1	1
31-7	SGI.47.07	TOOL BAG	1	1	1
31-8	SGI.47.08	WRENCH BAR	1	1	1
31-9	SGI.47.09	BAG, SERVICE BOOK	1	1	1



F32 GRAPHICS

REF	PART NUMBER	DESCRIPTION	QTY	2005
32-1	UMPX0001-WH	GRAPHIC FRONT COVER R. WHITE	1	1
	UMPX0001-YW	GRAPHIC FRONT COVER R. YELLOW	1	1
32-2	UMPX0002-WH	GRAPHIC FRONT COVER L. WHITE	1	1
	UMPX0002-YW	GRAPHIC FRONT COVER L. YELLOW	1	1
32-3	UMPX0003-WH	GRAPHIC FRONT COVER SIDE R. WHITE	1	1
	UMPX0003-GYC10	GRAPHIC FRONT COVER SIDE R. GRAY C10	1	1
32-4	UMPX0004-WH	GRAPHIC FRONT COVER SIDE L. WHITE	1	1
	UMPX0004-GRC10	GRAPHIC FRONT COVER SIDE L.GRAY C10	1	1
32-5	UMPX0005-WH	GRAPHIC BACK COVER R. WHITE	1	1
	UMPX0005-YW	GRAPHIC BACK COVER R. YELLOW	1	1
32-6	UMPX0006-WH	GRAPHIC BACK COVER L. WHITE	1	1
	UMPX0006-YW	GRAPHIC BACK COVER L. YELLOW	1	1
32-7	UMPX0007-YW	GRAPHIC POWERMAX (YELLOW LETTERS) R.	1	1
32-8	UMPX0008-YW	GRAPHIC POWERMAX (YELLOW LETTERS) L.	1	1
32-9	UMPX0009	UNITED MOTORS GRAPHIC R.	1	1
32-10	UMPX0010	UNITED MOTORS GRAPHIC L.	1	1
32-11	UMPX0011	UM GRAPHICS FRONT COVER	1	1
32-12	UMPX0012-WH	#1 GRAPHIC BACK COVER SIDE R. WHITE	1	1
	UMPX0012-BL	#1 GRAPHIC BACK COVER SIDE R. BLACK	1	1
32-13	UMPX0013-WH	#1 GRAPHIC BACK COVER SIDE L. BLACK	1	1
	UMPX0013-BL	#1 GRAPHIC BACK COVER SIDE L. BLACK	1	1
32-14	UMPX0014-WH	#1 GRAPHIC FRONT COVER SIDE R. WHITE	1	1
	UMPX0014-BL	#1 GRAPHIC FRONT COVER SIDE R. BLACK	1	1
32-15	UMPX0015-WH	#1 GRAPHIC FRONT COVER SIDE L. WHITE	1	1
	UMPX0015-BL	#1 GRAPHIC FRONT COVER SIDE L. BLACK	1	1
32-16	UMPX0016	125 GRAPHIC BACK COVER SIDE R.	1	1
32-17	UMPX0017	126 GRAPHIC BACK COVER SIDE L.	1	1
32-18	UMPX0018	GP GRAPHIC BACK COVER SIDE R.	1	1
32-19	UMPX0019	GP GRAPHIC BACK COVER SIDE L.	1	1



Enlarged figure next page



Order Online! www.umamerica.com



START RIDING®

© 2006 United Motors of America