
PARTS CATALOG

2006 V2S-650 / 650R






CYLINDER HEAD/(FRONT)



CYLINDER HEAD/(FRONT)

Ref #	Part #	Description	Quantity	Remarks
1	11110SN9100HPA	HEAD ASSY, cylinder front	1	
1-1	11110HN9100HPA	HEAD COMP, cylinder	1	
2	11171HN91000S1	COVER, cylinder head front	1	
3	11173HN9100	GASKET, cylinder head cover	1	
4	11141HN9101	GASKET, cylinder head	1	
5	13110HN9100	PIPE COMP, intake front	1	
6	09402-56208	CLAMP, carburetor	1	
7	11131HN9100PCH	HOUSING, camshaft intake	1	Not for Sale
8	11132HN9100PCH	HOUSING, camshaft exhaust	1	Not for Sale
9	09482-00456	PLUG, spark CR8E	1	
10	13131HN9100	O-RING, intake pipe	1	
11	09109H07018	BOLT, cylinder head cover NO.1	2	
12	09161H11008	WASHER, cylinder head cover	2	
13	09106H07017	BOLT, cylinder head cover NO.2	2	
14	09103H06002	BOLT, camshaft housing	12	
15	09206-08001	KNOCK PIN, camshaft housing	4	
16	09103H10001	BOLT, cylinder head (M10)	4	
17	09160H10002	WASHER, cylinder head bolt	4	
18	07120-06408	BOLT, cylinder head NO.1 (M6)	1	
19	09103H06001	BOLT, cylinder head NO.2 (M6)	2	
20	04213-13189	PIN, cylinder knock	4	
21	01514-08128	BOLT, oil gallery	2	
22	09168-08008	GASKET, oil gallery bolt	2	
23	02122-06208	SCREW, crank outer	2	


CYLINDER HEAD/(REAR)



CYLINDER HEAD/(REAR)

Ref #	Part #	Description	Quantity	Remarks
1	11120SN9100HPA	HEAD ASSY, cylinder rear	1	
1-0-1		HEAD ASSY, cylinder rear	1	KM4MP51C051101217
1-1	11120HN9100HPA	HEAD COMP, rear	1	
1-1-1		HEAD COMP, rear	1	KM4MP51C051101217
2	11171HN91000S1	COVER, cylinder head rear	1	
3	11173HN9100	GASKET, cylinder head cover	1	
4	11141HN9101	GASKET, cylinder head	1	
5	13120HN9101	PIPE COMP, intake rear	1	
6	09402-56208	CLAMP, carburetor	1	
7	11131HN9100PCH	HOUSING, camshaft intake	1	Not for Sale
8	11132HN9100PCH	HOUSING, camshaft exhaust	1	Not for Sale
9	09482-00456	PLUG, spark CR8E	1	
10	13131HN9100	O-RING, intake pipe	1	
11	09109H07018	BOLT, cylinder head cover NO.1	2	
12	09161H11008	WASHER, cylinder head cover	2	
13	09106H07017	BOLT, cylinder head cover NO.2	2	
14	09103H06002	BOLT, camshaft housing	12	
15	09206-08001	KNOCK PIN, camshaft housing	4	
16	09103H10001	BOLT, cylinder head (M10)	4	
17	09160H10002	WASHER, cylinder head bolt	4	
18	07120-06408	BOLT, cylinder head NO.1 (M6)	1	
19	09103H06001	BOLT, cylinder head NO.2 (M6)	2	
20	04213-13189	PIN, cylinder head knock	4	
21	01514-08128	BOLT, oil gallery	2	
22	09168-08008	GASKET, oil gallery bolt	2	
23	02122-06208	SCREW, crank outer	2	


CYLINDER /FRONT, REAR



CYLINDER /FRONT, REAR

Ref #	Part #	Description	Quantity	Remarks
1	11210HN9100HPA	CYLINDER COMP, front	1	
2	11220HN9100HPA	CYLINDER COMP, rear	1	
3	11241HN9101	GASKET, cylinder	2	
4	04213-13189	PIN, cylinder head knock	4	
5	08316-16068	NUT, cylinder (M6)	4	
6	01421-06258	BOLT, cylinder stud (M6)	4	


RADIATOR


0
경 고
뜨거울때 열지 마시오.
DO NOT OPEN WHEN HOT.
DANGER
14
3
4
2
7
8
9
5
1
6
9
8
7
11
12
12
12
5
11
11
10
9
8
7
13
DOHC
8 valves
V-TWIN
FWD

RADIATOR

Ref #	Part #	Description	Quantity	Remarks
1	17710HN9102121	RADIATOR COMP, water(V2S 650S ONLY Black Color)	1	
1-1	17710HN9102	RADIATOR COMP, water(V2S 650R ONLY Silver Color)	1	
2	17720HN9100	CAP COMP, radiator	1	
3	17800HN9102	FAN ASSY, radiator	1	
4	17810HN9100	MOTOR ASSY, radiator fan	1	
5	02142-05165	BOLT, radiator fan	3	
6	09404-06429	CLAMP, radiator fan	1	
7	09116-06143	BOLT, radiator	3	
8	09180-06030	SPACER, radiator	3	
9	09320-10015	CUSHION, radiator	3	
10	17761HN9100	MUD GUARD, radiator	1	
11	09229-03011	RIVET, mud guard	3	
12	68928-09F00	WASHER, mud guard rivet	3	
13	68150HN9100	PLATE, radiator	2	
14	68170HN9100	LABEL, radiator	1	


CRANKCASE


12
4
12
13
14
2
18
6
19
24
20
25
10
10
22
7
17
16
17
23
16
15
23
5
22
26
20
13
14
11
8
3
27
8
7
10
12
8
8
9
27
20
21
22
10
12
11
0
1
8
10

CRANKCASE

Ref #	Part #	Description	Quantity	Remarks
0	11300HN9100HPA	CRANKCASE ASSY	1	
1	11320HN9104PCC	CRANKCASE COMP, L	1	
2	11310HN9104PCC	CRANKCASE COMP, R	1	
3	41171HN910103P	LINK, engine mounting L	1	
3-1		LINK, engine mounting L (Black)	1	V2S 650S:KM4MP51B161100909
			1	V2S 650R:KM4MP51C161101504
4	41161HN910103P	LINK, engine mounting R	1	
4-1		LINK, engine mounting R (Black)	1	V2S 650S:KM4MP51B161100909
			1	V2S 650R:KM4MP51C161101504
5	09206H18001	PIN, crankcase knock	1	
6	04213-13189	PIN, crankcase knock	2	
7	07120-08608	BOLT, crankcase M8	2	
8	01547-06608	BOLT, crankcase M6	6	
9	07120-08708	BOLT, crankcase M8	2	
10	01547-06808	BOLT, crankcase M6	6	
11	02112-06958	SCREW, crankcase	2	
12	01517-10458	BOLT, engine mounting link & cyl head	4	
13	01514-08128	BOLT, oil gallery	2	
14	09168-08008	GASKET, oil gallery bolt	2	
15	31135HN91000S1	BRACKET, starter motor	1	
16	01547-06258	BOLT, starter motor bracket	2	
17	01547-06308	BOLT, starter motor	2	
18	17481HN9100	UNION, water pump hose	1	
19	07110-06108	BOLT, water hose union	1	
20	09280H04001	O-RING, oil jet	3	
21	11440HN9100	JET COMP, starter clutch oil	1	
22	02112-06108	SCREW, oil jet	3	
23	08313-11068	NUT, starter motor bracket	2	
24	09280H21001	O-RING, water pump union	1	
25	11430HN9100	JET COMP, piston rear oil	1	
26	11420HN9100	JET COMP, piston front oil	1	
27	09103H08001	BOLT, crankcase M8(L100)	2	


CRANKCASE COVER



CRANKCASE COVER

Ref #	Part #	Description	Quantity	Remarks
1	11331SN9101HPA	COVER COMP, clutch (With oil lens & plug)	1	
2	11351HN91020S1	COVER , magneto	1	
3	11481HN9101	GASKET, clutch cover	1	
4	11483HN9101	GASKET, magneto cover	1	
5	09247-14026	PLUG, oil check	1	
6	09168H14003	GASKET, oil check plug	1	
7	09259-2000903P	PLUG, engine oil filler	1	
8	09280-17003	O-RING, engine oil filler plug	1	
9	04213-13189	PIN, clutch cover knock	2	
10	04213-09129	PIN, magneto cover knock	1	
11	01547-06358	BOLT, magneto cover	8	
12	01547-06558	BOLT, magneto cover	2	
13	09404-06401	CLAMP, clutch cover	1	
14	09259-2601503P	PLUG, crankshaft hole	1	
15	09280-22008	O-RING, crankshaft hole plug	1	
16	01547-06358	BOLT, clutch cover	9	
17	01547-06258	BOLT, clutch cover outer	4	
18	01547-06708	BOLT, clutch cover outer	3	
19	01547-06508	BOLT, clutch cover outer	1	
20	09247H12102	PLUG, TDC	1	
21	09168H12003	GASKET, TDC plug	1	
22	11361HN91000S1	COVER, engine sprocket	1	
23	11482HN9100	O-RING, clutch outer cover	1	
24	09243-11005	PLUG, oil gallery	3	~KM4MP51A541100124
25	01547-06258	BOLT, engine sprocket cover	3	
26	11332HN9100	LENS, oil level check	1	
27	11341SR91600S1	COV CLUTCH, outer	1	
28	09168H06019	GASKET, magneto cover bolt	1	
29	09404-06401	CLAMP	1	
30	13353HP9401	BRACKET, carburetor adjust	1	R TYPE ONLY
31	01547-06408	BOLT, magnet cover	2	R TYPE ONLY
32	08321-31088	LOCK, washer	2	


CRANKSHAFT


20
21
22
19
23
15
11
26
25
18
16
12
14
24
17
18
8
13
10
9
7
2
3
24
3
24
18
5
1
2
4
18
16
17
22
21
20
6
27
7
FWD

CRANKSHAFT

Ref #	Part #	Description	Quantity	Remarks
1	12200HN9100HPA	CRANKSHAFT ASSY	1	Includes ref # 2,3,4,5,6 and 24
2	12161HN9101	ROD, connecting	2	
3	09263H37001	BEARING, crank pin	2	
4	12211HN9100	PIN COMP, crank	1	
5	12221HN9102CSA	CRANKSHAFT, R	1	
6	12261HN9102CSA	CRANKSHAFT, L	1	
7	08113-63070	BEARING, crankshaft	2	
8	02112-06126	SCREW, crankshaft oil seal retainer	1	
9	21111HN9100	GEAR, primary drive	1	
10	21112HN9100	GEAR, primary drive NO.2	1	
11	12281HN9100	RETAINER, crankshaft oil seal	1	
12	21114-35C00	SPRING, primary drive gear	3	
13	08211-22422	WASHER, primary drive gear thrust	1	
14	09140H18001	NUT, primary drive gear	1	
15	09282-12001	SEAL, crankshaft oil RH	1	
16	12111HN9101	PISTON	2	
17	12151HN9101	PIN, piston	2	
18	09381H20001	CIRCLIP, piston pin	4	
19	12140HN9100	RING SET, piston	2	Not for Sale
20	12141HN9100	RING, piston 1st	2	
21	12142HN9100	RING, piston 2nd	2	
22	12144HN9100	RING, piston oil	2	
23	12291HN9100	JET, crankshaft RH	1	
24	09160H37001	WASHER, conn rod thrust	3	
25	17511HN9103	GEAR, water pump drive	1	
26	09164H18001	WASHER, water pump drive gear lock	1	
27	12212HN9100	PLUG, crank pin	2	


STARTER CLUTCH



STARTER CLUTCH

Ref #	Part #	Description	Quantity	Remarks
1	12611HN9100	GEAR, starter idle	1	
2	12612HN9100	PIN, starter idle gear	1	~KM4MP52C661100152
2~1	09206-13003	PIN, starter idle gear	1	KM4MP52C661100153~
3	12614HN9100	CLUTCH, starter one way	1	
4	12620HN9101	GEAR COMP, starter clutch	1	
5	12620HN9101	GEAR, starter clutch	1	Not for Sale
6	07110-08168	BOLT, starter clutch	6	
7	09304H27001	BUSH, starter clutch gear	1	Not for Sale


CAMSHAFT / VALVE



CAMSHAFT / VALVE

Ref #	Part #	Description	Quantity	Remarks
1	12710HN9100HPA	CAMSHAFT ASSY, front intake	1	
2	12730HN9100HPA	CAMSHAFT ASSY, front exhaust	1	
3	12720HN9100HPA	CAMSHAFT ASSY, rear intake	1	
4	12740HN9100HPA	CAMSHAFT ASSY, rear exhaust	1	
5	12922HN9100	SPRING, valve outer	8	
6	09289H04002	SEAL, valve stem oil	8	
7	12933HN9100	SEAT, valve spring	8	
8	12911HN9100	VALVE, intake	4	
9	12912HN9100	VALVE, exhaust	4	
10	12921HN9101	SPRING, valve inner	8	
11	12931HN9100	RETAINER, valve spring	8	
12	12932HJ8200	COTTER, valve	16	
13	12892-05C00XXX	SHIM, tappet (size 152-230)	8	XXX=shim size
14	12881HN9100	TAPPET	8	


CAM CHAIN



CAM CHAIN

Ref #	Part #	Description	Quantity	Remarks
1	12760HN9100	CHAIN COMP, camshaft drive	2	
2	12771HN9100	GUIDE, cam chain NO.1	2	
3	12811HN9100	TENSIONER, cam chain	2	
4	08211-06181	WASHER, cam chain tensioner bolt	2	
5	12812H35C00	BOLT, cam chain tensioner	1	
5-1	12812HN9101	BOLT, cam chain tensioner (magneto)	1	
6	12837H31321	GASKET, tensioner adjuster	2	
7	12830HN9102	ADJUSTER ASSY, tensioner	2	
8	07110-06208	BOLT, tensioner adjuster	4	
9	12839-38200	PLUG, adjuster	2	
10	12782HN9100	GUIDE, cam chain No.2	2	
11	07110-06108	BOLT, cam chain guide No.2	6	


CARBURETOR ASSY



CARBURETOR ASSY

Ref #	Part #	Description	Quantity	Remarks
0	13200HP9400	CARBURETOR ASSY	1	
1	13301HN9100	MIXING BODY ASSY	1	
2	13302HN9100	MIXING BODY ASSY	1	
3	13310HN9100	DIAPHRAGM COVER	2	
4	13311HN9100	COMPRESSION SPRING	2	Not for Sale
5	13338HN9100	DIAPHRAGM	2	Not for Sale
6	13551HN9100	PISTON VALVE (25KW)	2	
7	13312HN9100	HOLDER	2	
8	13313HN9100	0-RING	2	
9	13314HN9100	COMPRESSION SPRING	2	
10	13316HN9100	WASHER	2	
11	13315HG5100	E-RING	2	
12	13305HN9100	RING	2	
13	13333HN9100	JET NEEDLE (JN)	2	
14	13323HN9100	O-RING	2	
15	13339HN9100	VENTURI	2	
16	13320HN9100	SCREW	4	
17	13364HN9100	PILOT JET	2	
18	13309HG5100	WASHER	2	
19	13307HN9100	COMPRESSION SPRING	2	
20	13308HN9100	ADJUSTER (PS)	2	
22	13306HG5100	O-RING	2	
23	13365HN9100	PILOT JET (PJ)	2	
24	13327HN9100	JET HOLDER	2	
25	13324HN9100	MAIN JET (MJ)	2	
26	13375HN9100	NEEDLE VALVE ASSY (VS)	2	
27	13378HN9100	PIN	2	
29	13379HN9100	FLOAT ASSY	2	


CARBURETOR ASSY



CARBURETOR ASSY

Ref #	Part #	Description	Quantity	Remarks
30	13377HG5100	SCREW	2	
31	13354HG5100	SCREW	6	
32	13376HN9100	SCREW (REST)	2	
33	13326HN9100	SCREW (REST)	4	
34	13332HN9100	COVER ASSY	2	
35	13334HN9100	COMPRESSION SPRING	2	
36	13335HN9100	DIAPHRAGM ASSY	2	
38	13336HN9100	SCREW	4	
40	13369HN9100	PLUNGER ASSY	2	
41	13368HN9100	COMPRESSION SPRING	2	
42	13370HN9100	O-RING	2	
43	13367HN9100	GUIDE HOLDER	2	
44	13337HN9100	PLATE	2	
45	13374HN9100	SCREW	2	
46	13366HN9100	CAP	2	
47	13352HN9100	FLOAT BODY	2	
49	13386HN9100	COMPRESSION SPRING	2	
50	13351HP9400	ADJUSTER (V2S 650R)	2	
	13351HN9100	ADJUSTER (V2S 650/V2S 650R)	2	
51	13356HN9100	COMPRESSION SPRING	2	
52	13373HG5100	SCREW	2	
53	13342HG5100	NUT	2	
54	13343HG5100	SPRING WASHER	2	
55	13340HN9100	THROTTLE LEVER ASSY	2	
56	13319HN9100	RING	2	
57	13344HN9100	TORSION SPRING	2	


CARBURETOR FITTINGS



CARBURETOR FITTINGS

Ref #	Part #	Description	Quantity	Remarks
0				
1	13325HN9100	HOSE	1	
3	44199HM7900	HOSE FUEL	1	
4	13330HN9100	HOSE	1	
5	13360HG5100	NIPPLE	1	
6	13383HN9100	CLIP	4	
7	13329HN9100	HOSE	2	
8	13385HN9100	CLIP	1	
10	13328HN9100	PLATE	1	
11	13341HN9100	PLATE	1	
12	13384HN9100	SCREW	4	
13	13353HN9100	BOLT	2	
14	13348HN9100	LEVER ASSY	1	
15	13347HN9100	PIN	2	
16	13318HN9100	WASHER	2	


AIR CLEANER & CHAMBER



AIR CLEANER & CHAMBER

Ref #	Part #	Description	Quantity	Remarks
1	13700HN9160	CLEANER ASS'Y, air	1	
2	13720HN9102	CASE, air cleaner	1	Not for Sale
3	13740HN9101	CAP COMP, air cleaner	1	Not for Sale
4	13780HM8100	FILTER COMP, air cleaner	1	
5	13871HN9100	TUBE, outlet front	1	
6	09402-56208	CLAMP, outlet tube	2	
7	13895HF4500	PLUG, oil drain	1	
8	09401-14301	CLIP, oil drain plug	1	
9	02142-05165	SCREW, air cleaner filter	4	
10	16810HN9101	TANK ASS'Y, breather oil return	1	
11	13881HN9100	TUBE, outlet	1	
12	03241-05165	SCREW	2	
13	09320-12029	CUSHION, oil return tank	1	
14	16821HN9101	HOSE, breather oil return No.1	1	
15	16831HN9100	HOSE, breather oil return No.2	1	
16	09401H14401	CLAMP, breather oil return	4	


MUFFLER


0
1
12
13
13
13
14
4
7
10
3
11
15
6
9
17
10
11
8
15
15
20
18
16
5
9
21
BOLT, exhaust pipe cover
07110-06308
Q'TY 2
10
17
10
19
8
6
11
2
11
FWD

MUFFLER

Ref #	Part #	Description	Quantity	Remarks
0	14305HN9130PLH	MUFFLER, ASS'Y	1	
0~1	14305HN9133PLH	MUFFLER, ASS'Y	1	KM4MP52CX61100253~
1	14310HN9131	BODY COMP, muffler	1	
1~1	14310HN9133	BODY COMP, muffler	1	KM4MP52CX61100253~
2	14160HN91020BF	PIPE COMP, exhaust front	1	
3	14150HN91020BF	PIPE COMP, exhaust rear	1	
4	14411HN91040BF	BRACKET, muffler support		
5	14170HN91030BF	PIPE COMP, muffler joint	1	
6	14770HN91010BF	CONNECTOR COMP, exhaust pipe	2	
7	14314HN9101	GASKET, connector flange	1	
8	14773HN9100	GASKET, connector exhaust pipe	2	
9	01517-08358	BOLT, exhaust pipe connector comp	2	
10	01421-08258	BOLT, exhaust pipe stud	4	
11	09143H08001	NUT, exhaust pipe	4	
12	01517-10458	BOLT, muffler support	1	
13	09160-10102	WASHER, muffler support	3	
14	08316-26108	NUT, muffler support	1	
15	07120-08208	BOLT, connector flange	3	after 11/6 - 07120-08207
16	01517-08168	BOLT, muffler chamber bracket	1	
17	14181HN9101	GASKET, exhaust	2	
18	14186HN91000BF	COV ASSY, exhaust pipe	1	
19	14776HN9100	CLAMP, out muff no1	1	
20	14778HN9100	CLAMP, out muff no2	1	
21	07110-06308	BOLT, exhaust pipe cov	2	


OIL PUMP


19
19
18
20
15
19
18
16
17
13
14
6
9
7
7
8
12
10
10
11
10
4
2
5
1
3
22
5
5
24
21
23
FWD

OIL PUMP

Ref #	Part #	Description	Quantity	Remarks
1	16400HN9101	PUMP ASS'Y, oil	1	
2	16331HN9101	GEAR, oil pump driven	1	
3	09261H04001	PIN, oil pump driven gear	1	
4	08331-31109	CIRCLIP, oil pump driven gear	1	
5	02112-06258	SCREW, oil pump	3	
6	16520HN9100	STRAINER COMP, engine oil	1	
7	02112-95126	SCREW, engine oil strainer	2	
8	16523HN9100	CAP, oil strainer	1	
9	09280H82001	O-RING, oil strainer cap	1	
10	01547-06208	BOLT, oil strainer cap	3	
11	09247-14002	PLUG, oil drain	1	~KM4MP51C561101486
11~1	09247-14019	PLUG, oil drain	1	KM4MP51C561101487~
12	09168H14003	GASKET, drain plug	1	
13	16510HN9101HAS	FILTER COMP, engine oil	1	Includes O-Rings
14	09280H16001	O-RING, oil filter	1	
15	16512HN91010S1	CAP, oil filter	1	
16	09280H69001	O-RING, oil filter cap	1	
17	09440H18001	SPRING, oil filter cap	1	
18	01421-06128	BOLT, oil filter cap stud	2	
19	08313-11068	NUT, oil filter cap	3	
20	01421-06758	BOLT, oil filter cap stud	1	
21	08331-31389	CIRCLIP, oil pump drive gear	1	
22	08221-10185	SHIM, oil pump driven gear	1	
23	16321HN9103	GEAR, oil pump drive	1	
24	09261H06001	PIN, oil pump drive gear	1	


WATER PUMP



WATER PUMP

Ref #	Part #	Description	Quantity	Remarks
1	17400HN9101	PUMP ASS'Y, water	1	
1-1	17410HN9100	CASE COMP, WATER PUMP		
1-2	17433HN9100	O-RING, WATER PUMP		
2	01547-06308	BOLT, water pump	2	
3	17491HN9100	HOSE, water pump outlet	1	
4	09401H26402	CLAMP, water pump hose	2	
5	17521HN9102	GEAR, water pump driven	1	
6	08221-10185	SHIM, water pump driven gear	1	
7	08331-31109	CIRCLIP, water pump driven gear	1	
8	09261H04001	PIN, water pump driven gear	1	


RADIATOR HOSE



RADIATOR HOSE

Ref #	Part #	Description	Quantity	Remarks
0	17610HN9100HPA	THERMOSTAT COMP	1	
1	17621HN91020S1	CONNECTOR COMP, thermostat inlet	1	
1-A	17621HN91030S1	CONNECTOR COMP, thermostat inlet	1	E/G No:GT650-108818
2	17631HN91000S1	CAP, thermostat connector	1	
3	17741HN9101	HOSE, radiator inlet	1	
4	17751HN9101	HOSE, radiator outlet	1	
5	09401H26402	CLAMP, radiator inlet hose radiator side	3	
6	09401H31402	CLAMP, radiator inlet hose thermostat side	1	
7	01547-06208	BOLT, thermostat connector	2	
8	17641HN9100	HOSE, thermostat bypass	1	
9	09401H13401	CLAMP, thermostat bypass hose	2	
10	17661HN9100	HOSE, connector inlet	2	
11	09401H24402	CLAMP, connector inlet hose	4	
12	17610HN9100	THERMOSTAT COMP	1	
13	17650HN9100	GAUGE UNIT, water temperature	1	
14	17981HN9100	HOSE, reserve tank inlet	1	
15	09401H11403	CLAMP, reserve tank	2	
16	17911HN9104	TANK COMP, reserve	1	
17	09136-06017	SCREW, reserve tank	2	
18	17982HN9100	HOSE, reserve tank overflow	1	
19	17921HN9100	CAP, reserve tank	1	
20	17860HN9100	SWITCH ASS'Y, thermo	1	
21	17912HN9100	CUSHION, reserve tank	1	
22	09401-09101	CAP, reserve tank overflow	1	
23	17622HN9101	UNION, thermostat connector	1	
23-A	17622HN9102	UNION, thermostat connector	1	E/G No:GT650-108818


2ND AIR


10
4
17
17
15
15
15
14
16
11
15
1
12
13
3
15
3
7
7
6
5
3
17
2
17
5
3
1
5
2
5
9
8
6
7
7
FWD

2ND AIR

Ref #	Part #	Description	Quantity	Remarks
1	18500HN9100	VALVE ASS'Y, 2ND air	2	
2	18631HN9101	HOSE, 2ND air pipe	2	
3	01547-06208	BOLT, 2ND air valve	4	
4	09401H09401	CLAMP, carburetor vacuum hose	1	
5	09401H13401	CLAMP, 2ND air pipe	4	
6	18615HN9101	GASKET, 2ND air pipe	2	
7	01107-06168	BOLT, 2ND air pipe	4	
8	18610HN9101	PIPE COMP, 2ND air front	1	
9	18620HN9101	PIPE COMP, 2ND air rear	1	
10	18691HN9100	HOSE, carburetor vacuum front	1	
11	18651HN9101	HOSE, 2ND air cleaner RH	1	
12	18661HN9100	HOSE, 2ND air cleaner LH	1	
13	18681HN9100	HOSE, 2ND vacuum LH	1	
14	18671HN9100	HOSE, 2ND vacuum RH	1	
15	09401H08401	CLAMP, 2ND vacuum hose	5	
16	09367H05001	NIPPLE, fuel pump joint	1	
17	09401H14401	CLAMP, 2ND air cleaner hose	4	


CLUTCH ASSY


8
20
21
22
24
23
19
18
17
16
14
13
12
11
15
9
10
25
26
27
6
7
6
5
2
3
4
1
28
4
FWD

CLUTCH ASSY

Ref #	Part #	Description	Quantity	Remarks
1	21210HN9101HPA	GEAR COMP, primary driven	1	
2	09167H20001	WASHER, clutch sleeve hub thrust	1	
3	21411HN9102	HUB, clutch sleeve	1	~KM4MP51A841100117
4	09160H20002	WASHER, primary driven gear thrust	2	
4	09160H20003	W/S, PRIMARY DRIVEN GR	2	~KM4MP578871104016
5	09140H20001	NUT, clutch sleeve hub	1	
6	23114HN9100	ROD, clutch push	1	
6-1	23115HN9100	ROD, CLUTCH PUSH NO.2	1	
7	23110HN9102	ROD COMP, clutch push M	1	
8	09136-06017	STOPPER, clutch release camshaft oil seal	1	
9	21441HN9100	PLATE, clutch drive	6	
10	21451HN9100	PLATE, clutch driven	6	
11	23121-38201	PIECE, clutch push	1	
12	09134-06010	SCREW, clutch release adjuster	1	
13	08310-22068	NUT, clutch release adjust	1	
14	09263H15001	BEARING, clutch release thrust	1	
15	09160-15015	WASHER, clutch release thrust	1	
16	21462HN9101	DISK, clutch pressure	1	
17	09440H20003	SPRING, clutch	6	
18	21471HN9101	RETAINER, clutch spring	6	
19	09100H06009	BOLT, clutch spring	6	
20	23271HN9100	ARM, clutch release	1	
21	09282H12002	OIL SEAL, clutch release camshaft	1	
22	08211-12281	THRUST WASHER, clutch release cam shaft	1	
23	23122HN9100	SHAFT, clutch release cam	1	
24	01107-06208	BOLT, clutch release arm	1	
25	21442HN9100	PLATE, clutch drive No.2	1	
26	21443HN9100	WASHER, clutch wave	1	
27	21444HN9101	SEAT, clutch wave washer	1	
28	21251HN9101	SPACER, primary driven gear	1	


TRANSMISSION



TRANSMISSION

Ref #	Part #	Description	Quantity	Remarks
1	24131HN9100	SHAFT COMP, drive	1	
2	24121HN9104	SHAFT COMP, counter	1	
3	24361HN9101	GEAR, 6th driven	1	
4	24221HN9102	GEAR, 2nd drive	1	
5	24231HN9101	GEAR, 3rd & 4th drive	1	
6	24251HN9101	GEAR, 5th drive	1	
7	09380H25001	CIRCLIP, 5th drive gear	1	
8	08113-63040	BEARING, counter shaft R (#6304)	1	
9	08123-63050	BEARING, counter shaft L (#6305)	1	
10	24741HN9100	RETAINER, counter shaft bearing	1	
11	02112-06128	SCREW, counter shaft bearing retainer	1	
12	09159H20001	NUT, engine sprocket	1	
13	24311HN9100	GEAR, 1st driven	1	
14	09181H20001	SHIM, 1st driven gear	1	
15	24312HN9100	BUSH,1st driven gear	1	
16	24321HN9101	GEAR, 2nd driven	1	
17	09380H25001	CIRCLIP, 4th driven gear	1	
18	24331HN9101	GEAR, 3rd driven	1	
19	09167H25001	THRUST WASHER, 4th driven gear	1	
20	24341HN9100	GEAR, 4th driven	1	
21	24351HN9101	GEAR, 5th driven	1	
22	09167H25002	WASHER, 3rd &4th driven gear thrust	1	
23	08113-62030	BEARING, drive shaft R	1	
24	08123-63050	BEARING, drive shaft L	1	
25	09380H25001	CIRCLIP, 3rd driven gear	1	
26	09167H25001	THRUST WASHER, 3rd driven gear	1	
27	09282H36002	OIL SEAL, drive shaft	1	
28	24751HN9100	RETAINER, drive shaft oil seal	1	
29	01107-06106	BOLT, drive shaft oil seal retainer	1	
30	27510HN9100	SPROCKET COMP, engine 15T (#525)	1	
31	27531HN9100	SPACER, engine sprocket	1	
32	09280H24001	O-RING, engine sprocket	1	
33	09167H25004	LOCK WASHER, engine sprocket	1	
34	27600HN9100	CHAIN ASS'Y, drive 108L (#525)	1	
35	09380H25001	CIRCLIP, 6th driven gear	1	


TRANSMISSION



TRANSMISSION

Ref #	Part #	Description	Quantity	Remarks
36	24261HN9101	GEAR, 6th drive	1	
37	09181H17001	SHIM, drive shaft	1	
38	09380H25001	CIRCLIP, 2nd drive gear	1	
39	09380H22001	CIRCLIP, 2nd drive gear	1	
40	24761HN9102	PIPE, transmission oil	1	
41	24741HN9100	RETAINER, transmission oil pipe	1	
42	02112-06128	SCREW, transmission oil pipe retainer	1	
43	24252HN9100	BUSH, 5th drive gear	1	
44	09181H25001	SHIM, 5th drive gear	1	
45	24332HN9100	BUSH, 4th drive gear	1	
46	09167H25003	WASHER, thrust washer lock	1	
47	24332HN9100	BUSH, 3rd driven gear	1	
48	24322HN9100	BUSH, 2nd driven gear	1	
49	24262HN9100	BUSH, 6th drive gear	1	
50	09167H25001	WASHER, 6th drive gear	1	
51	24125-38201	BUSH	2	


GEAR SHIFTING



GEAR SHIFTING

Ref #	Part #	Description	Quantity	Remarks
1	25231HN9100	FORK, gear shift No.3	1	
2	25211HN9100	FORK, gear shift No.1	1	
3	25411HN9100	SHAFT, gear shift fork No.1	1	
4	25421HN9100	SHAFT, gear shift fork No.2	1	
5	25310HN9102	CAM COMP, gear shift	1	
6	25221HN9100	FORK, gear shift No.2	1	
7	25380HN9104	PLATE COMP, gear shift cam	1	
8	04221-04089	PIN, gear shift cam plate	2	
9	25321HN9100	BOLT, gear shift cam plate	1	
10	24741HN9100	RETAINER, gear shift cam bearing R	2	
11	09262H25002	BEARING, gear shift cam R	2	
12	09261-04002	PIN, gear shift cam plate	6	
13	02122-06128	SCREW, gear shift cam bearing retainer	2	
14	09263H25001	BEARING, gear shift cam L	1	
15	09440-04010	SPRING, gear shift switch contact	1	
16	09209-05011	CONTACT, gear shift switch	1	
17	09440H17001	SPRING, gear shift cam drive plate	1	
18	09181H14001	SHIM, gear shift shaft thrust	2	
19	09280-26003	O-RING, gear shift switch	1	
20	37720HN9101	SWITCH ASS'Y, gear shift	1	
21	02112-95208	SCREW, gear shift switch	2	
22	09140-06011	NUT, gear shift link rod L (M6)	2	
23	09448H17001	SPRING, gear shift cam stopper	1	
24	09111-06019	BOLT, gear shift cam stopper	1	
25	25350HN9100	STOPPER COMP, gear shift cam	1	
26	08211-06121	WASHER, gear shift shaft thrust	1	
27	25521HN9100	PLATE, gear shift cam drive	1	
28	25510HN9101	SHAFT COMP, gear shift	1	
29	09444H20002	SPRING, gear shift shaft return	1	
30	25525HP9200	ROD, gear shift link (L=240)	1	
OP	25525HP9250	ROD, gear shift link (L=258)	1	
31	25671-01000	STOPPER, gear shift arm	1	
32	09160H14003	WASHER, gear shift shaft thrust	1	
33	08331-31149	CIRCLIP, gear shift shaft	3	
34	09283H14002	SEAL, gear shift shaft oil	1	
35	25520-32C00	ARM COMP, gear shift link	1	
36	01107-06208	BOLT, gear shift link arm (M6X10)	1	
37	08310-11068	NUT, gear shift link rod R (M6)	1	


STARTING MOTOR



STARTING MOTOR

Ref #	Part #	Description	Quantity	Remarks
1	31100HN9100	MOTOR ASS'Y, starting	1	
2	08316-16068	NUT, starter motor terminal	1	
3	08319-21068	NUT, start motor bracket	2	
4	01547-06308	BOLT, start motor bracket	2	


MAGNETO ASSY



MAGNETO ASSY

Ref #	Part #	Description	Quantity	Remarks
1	32100HN9101	MAGNETO ASS'Y	1	
2	32101HN9101	STATOR ASS'Y	1	
3	32102HN9100	ROTOR, fly wheel	1	
4	02142-05128	SCREW, pick-up coil (M5X12)	2	
5	07110-06308	SCREW, magneto stator (M5X30)	3	
6	09103H12001	BOLT, magneto	1	
7	09420H04001	KEY, magneto	1	
8	09160H12003	WASHER, magneto	1	


BATTERY



BATTERY

Ref #	Part #	Description	Quantity	Remarks
1	33610HM8100	BATTERY ASS'Y (12V 12Ah. STX14-BS)	1	
2	33860HN9100	LEAD WIRE, battery minus (-)	1	


ELECTRICAL


16
22
16
22
15
5
6
7
6
9
9
19
20
21
14
13
10
12
11
4
2
3
2
14
11
12
10
13
9
9
8
1
17
17
17
18
18
18
FWD

ELECTRICAL

Ref #	Part #	Description	Quantity	Remarks
1	31800HG5100	RELAY ASS'Y, starting motor	1	
2	08316-26066	NUT, starter motor relay terminal	2	
3	33840HM8101	LEAD WIRE, battery (+)	1	
4	33850HG5800	LEAD WIRE, starter motor	1	
5	32800HN9101	RECTIFIER REGULATOR ASS'Y	1	
6	09128-06005	BOLT, rectifier	2	
7	33410HN9100	COIL ASS'Y, ignition front	1	
8	33430HN9100	COIL ASS'Y, ignition rear	1	
9	09128-06035	BOLT, ignition coil	4	
10	33500HN9100	CAP ASS'Y spark plug	2	
11	33541-23E01	SEAL, spark plug	2	
12	33510-05C01	CAP, spark plug	2	
13	33542-98000	SEAL, high tension cord	2	
14	33545HN9100	BUSH, spark plug cap	2	Not for Sale
15	32900HN9111	IGNITER ASS'Y	1	KM4MP51C751100307~
16	07110-06208	BOLT, igniter	2	
17	38740HM5401	RELAY ASS'Y.	3	
18	01517-06166	BOLT, relay	3	
19	36740-35C00	BOX ASS'Y, fuse (15A)	1	
20	36740HN9100	BOX ASS'Y, fuse (30A)	1	
21	32910HN9101	PULSE CONTROL UNIT	1	
22	08322-21065	WASHER, igniter	2	Not for Sale


SPEEDOMETER ASSY (V2S 650)



SPEEDOMETER ASSY (V2S 650)

Ref #	Part #	Description	Quantity	Remarks
1	34100HN9101	SPEEDOMETER ASS'Y	1	
2	34950HP9200	BRACKET	1	
3	34105HM8100	LOWER CASE, speedometer	1	
4	34106HM8100	LOWER CASE, tachometer	1	
5	34110HN9100	SPEEDOMETER	1	
6	34120HN9100	TACHOMETER	1	
7	34910H93B00	CABLE ASS'Y, speedometer	1	
8	34171HN9100	WIRING ASS'Y, speedometer	1	
9	09116-06010	BOLT, speedometer bracket	2	
10	09471-12077	BULB (12V ,1.7W, T10)	2	
11	09471-12072	BULB (12V, 1.7W, T6.5)	5	
12	39110HM8100	INDICATOR LAMP, upper	1	
13	34136HN9100	COVER, temp meter	1	
14	01517-06208	BOLT, speedometer & brace	2	
15	09180-06011	SPACER, speedometer bkt cushion	2	
16	94433H07C00	CUSHION, speedometer bracket	2	
17	09471-12072	BULB (12V, 1.7W, T6.5)	1	
18	59410HN9101	GUIDE COMP, brake hose & s/w lea	1	
19	59420HN9101	GUIDE COMP, cable & s/w lead wir	1	


SPEEDOMETER ASSY (V2S 650 R/S)



SPEEDOMETER ASSY (V2S 650 R/S)

Ref #	Part #	Description	Quantity	Remarks
1	34100HP9260	SPEEDOMETER ASS'Y	1	
2	34150HP9200	WINDOWS, case	1	
3	34160HP9200	CASE SUB, housing	1	
4	34121HP9200	TACHOMETER ASSY, movement	1	
5	34500HP9200	DISPLAY ASSY, speedometer	1	"Not for Sale"
6	34600HP9200	PCB ASSY, speedometer	1	"Not for Sale"
6-1	34111HP9260	SPEEDOMETER COMP	1	
7	34950HP9200	BRACKET, speedometer	1	
8	34170HP9201	WIRING ASSY, speedometer	1	
9	01517-06208	BOLT, speedometer bracket	3	
10	09471-12072	BULB (12V 1.7W T6.5)	2	
11	94647HP9200	CUSHION, Exclude Light	1	


HEAD LAMP (V2S 650)



HEAD LAMP (V2S 650)

Ref #	Part #	Description	Quantity	Remarks
1	35100HM8171	HEAD LAMP ASS'Y	1	
2	35120HM8150	REFLECTOR, headlamp	1	
3	35111HM8100	RIM, headlamp	1	
4	35173HM8100	DUST COVER	1	
5	09471H12103	BULB, head lamp(12v 60/55w)	1	
6	09148-05039	NUT, head lamp(M5)	3	
7	09471-12110	BULB,position lamp	1	


HEAD LAMP (V2S 650 R/S)



HEAD LAMP (V2S 650 R/S)

Ref #	Part #	Description	Quantity	Remarks
1	35100HP9250	HEAD LAMP ASS'Y	1	
2	09471H12250	BULB, head lamp hi (12v H1:55w)	1	
3	09471H12230	BULB, head lamp hi (12v H3:55w)	1	
4	35173HP9200	DUST COVER	2	
5	09148-05039	NUT, head lamp speedometer	3	
6	09320-09016	CUSHION, head lamp & brace comp	4	
7	09180-06011	SPACER, head lamp & brace comp	4	
8	09136-06113	BOLT, head lamp & brace comp	4	
9	35192HP9200	CUSHION, Head Lamp	1	
10	35193HP9200	TAPE, Cushion Head Lamp R	1	
11	35194HP9200	TAPE, Cushion Head Lamp L	1	


TURN SIGNAL LAMP (V2S 650)



TURN SIGNAL LAMP (V2S 650)

Ref #	Part #	Description	Quantity	Remarks
1	35601HM8151	LAMP ASS'Y, FT turnsignal R	1	
2	35602HM8151	LAMP ASS'Y, FT turnsignal L	1	
3	09471-12142	BULB, FT turnsignal lamp(12V,R10W	2	
4	09160-06019	WASHER, FT turnsignal lamp	4	
5	08316-26066	NUT, FT turnsignal lamp	4	
6	35603HM8151	LAMP ASS'Y, RR turnsignal R	1	
7	35604HM8151	LAMP ASS'Y, RR turnsignal L	1	
8	09471-12003	BULB, RR turnsignal lamp(12V, R10	2	
9	38610HL7300	RELAY ASS'Y, turn signal	1	
10	01517-06166	BOLT, turnsignal, relay	1	
11	35612HM8100	LENS, FT turnsignal R	2	
12	35632HM8100	LENS, FT turnsignal L	2	


TURN SIGNAL LAMP (V2S 650 R/S)



TURN SIGNAL LAMP (V2S 650 R/S)

Ref #	Part #	Description	Quantity	Remarks
1	35601HP9250	LAMP ASS'Y, FT turn signal R	1	
2	35602HP9250	LAMP ASS'Y, FT turn signal L	1	
3	09471-12003	BULB, FT turn signal lamp (12V,10W)	2	
4	09160-06019	BOLT, turn signal relay	1	
5	08316-26066	NUT, FT turn signal lamp	4	
6	35603HM8151	LAMP ASS'Y, RR turn signal R	1	
7	35604HM8151	LAMP ASS'Y, RR turn signal L	1	
8	09471-12003	BULB, RR turn signal lamp (12V, 10W)	2	
9	38610HL7300	RELAY ASS'Y, turn signal	1	
10	35612HM8100	LENS, FT turn signal R	2	
11	35632HM8100	LENS, FT turn signal L	2	


WIRING HARNESS



WIRING HARNESS

Ref #	Part #	Description	Quantity	Remarks
1	36610HP9202	HARNESS, wiring	1	
2	38500HM8101	HORN ASS'Y	1	
3	37000HP9260	LOCK ASS'Y, steering	1	
4	01517-06206	BOLT, steering lock	1	
4-1	09139H06016	SCREW, steer lock	1	
5	37740HN9100	SWITCH ASS'Y, rear stop	1	
6	09407-14403	CLAMP, wiring harness	4	
7	02112-36128	SCREW, horn	1	after 11/06 - 09106H06150
8	09407-254A1	CLAMP, wiring harness	2	
9	09443H06006	SPRING	1	
10	36618-30610	BOOT W/HARNESS	1	
11	09407-22402	CLAMP, wiring harness	2	
12	37550HP9200	SPACER, STEERING LOCK	1	

REAR COMBINATION LAMP






REAR COMBINATION LAMP

Ref #	Part #	Description	Quantity	Remarks
1	35710HM8152	LAMP ASS`Y, tail & stop	1	
2	09471-12047	BULB, tail & stop (12V P21/5W)	1	
3	03241-05166	SCREW, tail & stop	3	
4	09160-05017	WASHER, tail & stop	3	
5	09404-06401	CLAMP, tail & stop	2	


FRAME


26
25
26
26
26
26
26
26
20
22
18
18
21
17
19
1
27
24
23
16
12
11
10
9
13
8
7
15
24
28
14
14
23
6
3
4
5
2
3
FWD

FRAME

Ref #	Part #	Description	Quantity	Remarks
1	41100HP926003P	FRAME COMP	1	
2	41165HN9101	SHAFT, engine mounting link	1	
3	09141H26001	LOCK NUT, engine mounting link & shaft	1	
4	41191HN9101	SHAFT, engine mounting RR lower	2	
5	09141H20001	LOCK NUT, engine mounting RR lower	1	
6	61211HN9101	SHAFT, RR swinging arm pivot	1	
7	41181HN9101	SHAFT, engine mounting RR upper	1	
8	07110-08258	BOLT, frame & engine mounting adjuster	1	
9	41185HN9100	SPACER, frame & engine rear upper (L=49)	1	
10	08319-31128	NUT, engine mounting link & shaft	1	
11	08319-31108	NUT, frame & engine RR upper	1	
12	09159H14008	NUT, RR swinging arm pivot	1	
13	41772HN9101	BRKT, radiator upper	1	
14	01517-06125	SCREW, radiator upper brkt	1	
15	08319-31108	NUT, frame & engine RR lower	2	
16	15100HG5100	PUMP ASS'Y, fuel	1	
17	41351HN9100	BRKT, fuel pump	1	
18	02142-06126	SCREW, fuel pump	1	
19	01517-06126	BOLT, fuel pump brkt	2	
20	44199HL7302	HOSE, fuel pump & carburetor vacuum (L=330)	1	
21	09401-10401	CLIP, fuel pump vacuum	1	
22	09401-08401	CLIP, carburetor vacuum	1	
23	01134-06306	GUIDE CLAMP, harness	1	
24	94417HP9201	PLATE COMP, frame & body side COW'G	2	
25	47510HP9202	RIDER, pillion	1	
26	07120-08258	BOLT, grip handle	6	
27	94478HP9202	BRKT COMP, frame body side	1	
28	94479HP9202	BRKT COMP, frame body side	1	
29	68149HP9400	TAPE, FRAME SIDE (tracing tape)	8	KM4MP51C251100148~
30	52530HN9160	BODY COMP CANISTER	1	
31	52550HN9160	VALVE ASSY	1	
32	46111HN9160	JOINT CANISTER HOSE	1	


PROP STAND



PROP STAND

Ref #	Part #	Description	Quantity	Remarks
1	42310HN910003P	STAND COMP, prop	1	
1~1		STAND COMP, prop	1	KM4MP51B861100907~
2	09100-10031	BOLT, prop stand	1	
3	08310-22106	NUT, prop stand	1	
4	09443-15047	SPRING, prop stand outer	1	
5	09443-06001	SPRING, prop stand inner	1	
6	37840HN9102	SWITCH ASS'Y, side stand	1	
7	01517-06205	BOLT, side stand	2	


REAR BRAKE


7
7
6
4
14
5
12
20
2
19
20
16
19
15
17
18
9
10
11
11
8
27
26
27
25
21
22
3
23
24
1
FWD

REAR BRAKE

Ref #	Part #	Description	Quantity	Remarks
1	43110HM810003P	PEDAL COMP, brake	1	
2	43530HM810503P	BRACKET COMP, front footrest R	1	~ KM4MP52A241100049
2~1	43530HM810603P	BRACKET COMP, front footrest R	1	KM4MP52A241100050 ~
3	09448H30002	SPRING, brake pedal return	1	
4	43560HM8100	FOOTREST ASS'Y, front R	1	
5	43561HM8100	FOOTREST, bar front R	1	
6	43530H30A40	RUBBER COMP, front footrest R	1	
7	02112-05126	SCREW, front footrest	2	
8	69609HN9100	CYLINDER ASS'Y rear master	1	
9	69740HM8100	TANK ASS'Y reserve	1	
10	69700HM8101	HOSE ASS'Y reserve	1	
11	09400H13001	CLAMP, reserve tank hose	2	
12	01517-06168	BOLT, reserve tank	1	
14	43533H30A40	BOLT, front footrest bar	1	
15	09180H08008	SPACER, front footrest	1	
16	43579HM8101	PIN, front footrest	1	
17	09448H14007	SPRING, front footrest	1	
18	08332-11079	E-RING, front footrest	1	
19	07120-08208	BOLT, front footrest bracket	2	after 11/6 - 07120-08207
20	07120-08258	BOLT, master cylinder	2	
21	08322-21068	WASHER, rear master cylinder	1	
22	04111-20208	COTTER PIN, rear master cylinder	1	
23	09160H15002	WASHER, brake pedal	1	
24	08331-31159	CIRCLIP, brake pedal	1	
25	09200H06040	PIN, rear master cylinder	1	
26	43550HP9201	BRKT, front footrest back step R	2	
27	07120-08258	BOLT, grip handle	2	


FOOTREST


16
13
14
15
18
20
21
16
19
16
17
16
17
18
20
21
19
16
12
22
23
27
9
10
3
3
11
1
6
5
7
8
10
2
4
28
26
25
24
FWD

FOOTREST

Ref #	Part #	Description	Quantity	Remarks
1	43570HM8100	FOOTREST ASS'Y, front L	1	
2	43571HM8100	FOOTREST BAR, front L	1	
3	02112-05126	SCREW, front footrest	2	
4	43533H30A40	BOLT, front footrest bar	1	
5	09180H08008	SPACER, front footrest	1	
6	43579HM8101	PIN, front footrest bar	1	
7	09448H14007	SPRING, front footrest	1	
8	08332-11079	E-RING, front footrest	1	
9	43540HN910103P	BRACKET COMP, front footrest L	1	
10	07120-08258	BOLT, front footrest bracket	2	
11	43532H30A40	RUBBER, front footrest	1	
12	43621HM810403P	BRACKET, pillion footrest R	1	
13	43661HM8101	FOOTREST BAR, pillion R	1	
14	43721HM810303P	BRACKET, pillion footrest L	1	
14-1	43721HM810403P	BRACKET, pillion footrest L	1	
15	43671HM8101	FOOTREST BAR, pillion L	1	
16	07120-08258	BOLT, pillion footrest bracket	4	
17	43679HM8101	PIN, pillion footrest	2	
18	09448H08008	SPRING, pillion footrest	2	
19	08332-11048	E-RING, pillion footrest	2	
20	43631HM8101	PLATE, pillion stopper No.1	2	
21	43641HM8101	PLATE, pillion stopper No.2	2	
22	09320-14015	CUSHION, muffler support	1	
23	09180-10044	SPACER, muffler support	1	
24	25609HP920003P	LEVER COMP, gear shift cam	1	
25	08331-31159	CIRCLIP, gear shift lever	1	
26	09160H15002	WASHER, gear shift lever	1	
27	43560HP9201	BRKT, front footrest back step L	1	
28	07120-08258	BOLT, front footrest back step	2	


FUEL TANK


16
14
1
1-2
10
11
12
13
7
6
7
8
9
15
4
4
3
5
5
19
20
21
22
23
24
25
30
2
3
29
28
27
26
29
17
18
FWD

FUEL TANK

Ref #	Part #	Description	Quantity	Remarks
1	44110SR91600BK	TANK COMP, fuel (BLACK)	1	49 STATE
1	44110SR91600DS	TANK COMP, fuel (SILVER/BLACK)	1	49 STATE
1	44110SR91600WB	TANK COMP, fuel (BURGUNDY/BLACK)	1	49 STATE
1	44110SR91600DR	TANK COMP, fuel (RED/BLACK)	1	49 STATE
1~1	44100SR91600BK	TANK COMP, fuel (BLACK)	1	CALIF ONLY
1~1	44100SR91600DS	TANK COMP, fuel (SILVER/BLACK)	1	CALIF ONLY
1~1	44100SR91600WB	TANK COMP, fuel (BURGUNDY/BLACK)	1	CALIF ONLY
1~1	44100SR91600DR	TANK COMP, fuel (RED/BLACK)	1	CALIF ONLY
1-2	68319H05350PL	LABEL, CAUTION	1	
2	44520HM8100	BRKT COMP, fuel tank front	1	
3	09329-10007	CUSHION, fuel tank inner front	2	
4	01517-06166	BOLT, fuel tank front brkt	2	
5	09329H28001	CUSHION, fuel tank side	2	
6	44530HM8100	BRKT COMP, fuel tank RR	1	
7	01517-06206	BOLT, fuel tank RR brkt	2	
8	44215HM8100	CUSH, F/TANK IN 2	1	
9	44216HM8100	CUSH, F/TANK IN 3	1	
10	09116H08078	BOLT, fuel tank RR	1	
11	09320-14013	CUSHION, fuel tank RR up	1	
12	09180H08007	SPACER, fuel tank RR cushion	1	
13	09320H10020	CUSHION, fuel tank RR lower	1	
14	44200H35C30	CAP ASS'Y, fuel tank filler	1	
15	09401H11401	CLIP, strainer outlet & fuel pump	1	
16	09106-05017	BOLT, fuel tank filler	4	
17	34810HM8102	GAUGE ASS'Y, fuel lever	1	
18	01134-05106	BOLT, fuel level gauge	5	
19	44199H11202	HOSE, fuel strainer outlet (L=170)	1	
20	09401-10401	CLIP, fuel strainer outlet	1	
21	44910HG2600	STRAINER COMP, fuel	1	
22	09401-08401	CLIP, fuel strainer inlet NO.2	1	
23	44197HK2701	HOSE, fuel strainer inlet	1	
24	09401-10401	CLIP, fuel strainer inlet NO.2	1	
25	44300HN9100	COCK ASS'Y, fuel	1	
26	09128-06035	BOLT, fuel cock	2	
27	09168-06010	GASKET, fuel cock	2	
28	44197HE6102	HOSE, fuel cock vacuum & intake pipe (L=320)	1	
29	09401-08401	CLIP, fuel hose	2	
30	09352H70103650	HOSE, fuel tank drain (L=650)	1	


SEAT



SEAT

Ref #	Part #	Description	Quantity	Remarks
1	45110HN9100	SEAT SET, front	1	
2	45120HM8101	KNOB COMP, seat front	1	
3	09440-11016	SPRING, seat front knob	1	
4	08322-11088	WASHER, seat front knob	1	
5	04111-20208	PIN, seat front knob	1	
6	45200HP9200	SEAT SET, rear	1	
7	01517-06206	BOLT, rear seat	1	
8	09160-06057	WASHER, rear seat	1	


COW'G BODY (S,R)


1-1
1
1-3
1-2
2
12
5
33
34
32
3
29
22
26
23
28
7
9
21
20
19
18
17
15
16
14
31
13
11
4
27
10
24
25
30
8
6
FWD

COW'G BODY (S,R)

Ref #	Part #	Description	Quantity	Remarks
1	94611HP9202HPA	WINDSCREEN ASSY (COLOR :LIQUID)	1	
	94601HP9202HPA	WIND SCREEN ASSY (COLOR : TONED)	1	
1-1	94611HP9202	WINDSCREEN	1	
1-2	68500HP9200	TAPE, WINDSCREEN	1	
1-3			1	Not Used
2	94641HP9200	PANEL, meter	1	
3	94411HP92020BK	COW'G, body side R (BLACK)	1	
3	94411HP92020DS	COW'G, body side R (SILVER/BLACK)	1	
3	94411HP92020WB	COW'G, body side R (BURGUNDY/BLACK)	1	
3	94411HP92020DR	COW'G, body side R (RED/BLACK)	1	
4	94421HP92020BK	COW'G, body side L (BLACK)	1	
4	94421HP92020DS	COW'G, body side L (SILVER/BLACK)	1	
4	94421HP92020WB	COW'G, body side L (BURGUNDY/BLACK)	1	
4	94421HP92020DR	COW'G, body side L (RED/BLACK)	1	
5	94431HP92000BK	COW'G, body side R inner (BLACK)	1	
5	94431HP92000DS	COW'G, body side R inner (SILVER/BLACK)	1	
5	94431HP92000WB	COW'G, body side R inner (BURGUNDY/BLACK)	1	
5	94431HP92000DR	COW'G, body side R inner (RED/BLACK)	1	
6	94491HP9200BK	COW'G, body side lower L (BLACK)	1	"S" TYPE ONLY
6	94491HP9200DS	COW'G, body side lower L (SILVER/BLACK)	1	"S" TYPE ONLY
6	94491HP9200WB	COW'G, body side lower L (BURGUNDY/BLACK)	1	"S" TYPE ONLY
6	94491HP9200DR	COW'G, body side lower L (RED/BLACK)	1	"S" TYPE ONLY
7	94481HP9200BK	COW'G, body side lower R (BLACK)	1	"S" TYPE ONLY
7	94481HP9200DS	COW'G, body side lower R (SILVER/BLACK)	1	"S" TYPE ONLY
7	94481HP9200WB	COW'G, body side lower R (BURGUNDY/BLACK)	1	"S" TYPE ONLY
7	94481HP9200DR	COW'G, body side lower R (RED/BLACK)	1	"S" TYPE ONLY
8	94671HP9200121	COW'G, air duct L	1	
9	94661HP9200121	COW'G, air duct R	1	
10	94441HP92000BK	COW'G, body center lower (BLACK)	1	
10	94441HP92000DR	COW'G, body center lower (RED/BLACK)	1	


COW'G BODY (S,R)



COW'G BODY (S,R)

Ref #	Part #	Description	Quantity	Remarks
11	94510HP9202	BRACE, cowling	1	
12	03241-05125	BOLT, meter panel & body side cow R/L	8	
13	09103H08254	BOLT, brace comp & frame head pipe	2	
14	09180H06208	SPACER, body side cow R/L & brace comp	4	
15	09320-09034	CUSHION, body side cow R/L & brace comp	4	
16	09136-06113	BOLT, body side COW'G R/L & brace comp	4	
17	09180H06208	SPACER, body side COW'G R/L & frame	2	
18	09320-09034	CUSHION, body side COW'G R/L & frame	2	
19	09136-06113	BOLT, body side COW'G R/L & frame	4	
20	09320-07012	CUSHION, windscreen & body side COW'G up	6	
21	09106H05150	BOLT, windscreen & body side COW'G up	6	
22	09148-05004	NUT, body side COW'G R/L & meter panel	8	
23	03241-05106	SCREW, side COW'G & lower COW'G	8	"S" TYPE ONLY
24	09148-05004	NUT, lower COW'G ctr & body side COW'G R/L	1	
25	03241-05125	SCREW, lower COW'G ctr & body side COW'G R/L	1	
26	09148-06020	NUT, body side COW'G R/L & brace comp	4	
27	94425HP9200	PLATE, body side COW'G & lower COW'G No.2 L	1	"S" TYPE ONLY
28	94425HP9200	PLATE, body side COW'G & lower COW'G No.2 R	1	"S" TYPE ONLY
29	08316-26055	NUT, windscreen & body side COW'G up	6	
30	03211-05166	SCREW, lower COW'G & body side COW'G R/L	4	
31	08313-11088	NUT, brace comp & frame head pipe	2	
32	03241-04128	SCREW, body side cowling & air duct COW'G	6	
33	09106H06150	BOLT	2	
34	09148-06020	NUT	2	
35	09169-05018	WASHER, Windscreen	6	
36	94454HP9400	CUSHION, Upper Cowling R	1	
37	94455HP9400	CUSHION, Upper Cowling L	1	


COW'G BODY (R TYPE ONLY)



COW'G BODY (R TYPE ONLY)

Ref #	Part #	Description	Quantity	Remarks
0	94409HP9450	UNDER COW'G SET (BLACK)	1	Not for Sale
0	94409HP9450RB	UNDER COW'G SET (RED/BLACK)	1	Not for Sale
1	94432SR91600BK	COW'G, under RH (BLACK)	1	w/ gray & white stickers
1	94432SR91610BK	COW'G, under RH (RED/BLACK)	1	w/ red & white stickers
2	94433SR91600BK	COW'G, under LH (BLACK)	1	w/ gray & white stickers
2	94433SR91610BK	COW'G, under LH (RED/BLACK)	1	w/ red & white stickers
3	94431HP94000BK	COW'G, under center (BLACK)	1	
4	94434HP9402	PLATE, under COW'G RH	1	
5	94435HP9401	PLATE, under COW'G LH	1	
6	94436HP9401	PLATE, under center COW'G	1	
7	94478HP9400	PLATE COMP, under COW'G upper RH	1	
8	94479HP9400	PLATE COMP, under COW'G upper LH	1	
9	01134-06306	BOLT, body under COW'G & frame	2	
10	09106H05150	BOLT, body under COW'G R/L	11	
10-1	09136-06113	BOLT	2	
10-2	09106H06150	BOLT	4	
11	09148-05004	NUT, under COW'G	9	
12	94425HP9401	PLATE, body COW'G side lower	2	
13	94426HP9401	PLATE, body COW'G side	4	
14	94439HP9400120	GRILL, under center COW'G	1	
15	94417HP9201	PLATE COMP, frame & body COW'G No.2	2	
16	03151-05125	SCREW, side COW'G & lower cowl	7	
16-1	03241-05125	SCREW	9	


COW'G BODY (R TYPE ONLY)



COW'G BODY (R TYPE ONLY)

Ref #	Part #	Description	Quantity	Remarks
18	94453HP9400	CUSHION, Under Cow'g Side L	2	
19	94456HP9400	CUSHION, Under Cent Cow'g R	1	
20	94457HP9400	CUSHION, Under Cent Cow'g L	1	
21	94458HP9400	CUSHION, Under Cowling R	1	
22	94459HP9400	CUSHION, Under Cowling L	1	


REAR FENDER



REAR FENDER

Ref #	Part #	Description	Quantity	Remarks
1	63112HM810212A	FENDER, rear front		
1-1	63112HM810412A	FENDER, rear front	1	
2	63113HM810112A	FENDER, rear lower	1	
3	09280-63003	BAND, tool	1	
4	09111H06066	BOLT, rr fender ft up	2	
5	09148-05039	NUT, rr fender ft	2	
6	01517-06166	BOLT, rr fender ft & frame side tube	2	
7	09169-06032	WASHER, rr fender ft & frame side tube	2	
8	02142-06166	SCREW, rr fender lower	2	
9	09169-06032	WASHER, rr fender lower	2	
10	41589HG5900	CUSHION, RR FEN FT & BATTERY	1	
10-1	41589HR9700	CUSHION, RR FEN FT & BATTERY	1	
11	63120HM810003P	TUBE COMP, RR fender FT & frm side	1	
11~1	63120HM810103P	TUBE COMP, RR fender FT & frm side	1	
12	01517-08168	BOLT, frm side tube	2	
13	63115HN9101	TAPE, RR fender FT	1	
14	68350HM8150PL	LABEL, caution NO.1	1	
14-1		LABEL, caution NO.1	1	
14-2		LABEL, caution NO.1	1	
	02142-04088	BOLT, REAR FENDER FT	2	ADDED IN 2006-MAY


SIDE COVER



SIDE COVER

Ref #	Part #	Description	Quantity	Remarks
1	47111HR91A00BK	COVER, side RH (BLACK)	1	V2S 650
1	47111HR91600BK	COVER, side RH (BLACK)	1	V2S 650R
2	47211HR91A00BK	COVER, side LH (BLACK)	1	V2S 650
2	47211HR91600BK	COVER, side LH (BLACK)	1	V2S 650R
3	47113HM8101	BOLT, luggage support	2	
4	08322-11088	WASHER, luggage bolt & frm side	2	
5	02142-06165	SCREW, frm side front	2	
6	09169-06034	WASHER, frm side front	2	
7	02142-06165	SCREW, frm side center	1	
8	09148H05029	NUT, frm side rear up	3	
9	02142-05125	SCREW, frm side rear up	3	
10	02142-06165	SCREW, frm side low & frm	2	
11	02142-05165	SCREW, frm side low & rear fender	6	
12	45220HM8100	LOCK ASS'Y, seat striker rear	1	
13	02122-06308	SCREW, seat striker	2	
14	45280-35C00	CABLE COMP, seat lock	1	
15	92414HF4500	LOCK, key set & seat lock guide	1	
16	45700HG2630	LOCK ASS'Y, seat	1	
17	45381HG2601	GUIDE, seat lock cable	1	
18	92413HF4501	WASHER, key set & seat lock guide	1	
19	47115HN9100	CAP, luggage support bolt	2	


FRONT FORK


16
8
7
17
6
18
5
10-A
4
4
3
2
15
15
4
4
14
9
10-B
1
10
10-C
10-E
10-D
13
12
11
11
10-F
13
12
11
11
FWD

FRONT FORK

Ref #	Part #	Description	Quantity	Remarks
1	51100HP9200HPA	FORK ASS'Y, front	1	~ KM4MP51A341100140
2	51410HP9200HPA	BRACKET COMP, front fork under	1	
3	51411HP9201	BRACKET, front fork under	1	KM4MP51B261100952~
3~0	51411HP9204	BRACKET, front fork under	1	
3-1	51412HM8102	STEER'G STEM	1	Not for Sale
3-2	51413HM8100	STOPPER, ft fork under	1	Not for Sale
4	07110-08258	BOLT, front fork under bracket	4	
5	09265H25001	BEARING, steering lower	1	
6	09265H28001	BEARING, steering upper	1	
7	51631-28000	NUT, steering stem	1	
8	09166H25001	WASHER, steering stem	1	
9	51210HP9200	DAMPER ASS'Y, front fork R	1	~ KM4MP51A341100140
10	51220HP9200	DAMPER ASS'Y, front fork L	1	~ KM4MP51A341100140
10-A	52120HN9100	CAP, OUTER TUBE	2	
10-B	52210-N9100	FORK, upper case	2	
10-C	52110-N9100	FORK, pipe	2	
10-D	51255HG5800	FORK, oil seal	2	
10-E	52280HM8104C10	BOTTOM BLOCK RH	1	
10-F	52270HM8104C10	BOTTOM BLOCK LH	1	
11	09106H08458	BOLT, axle grip	4	
12	07110-08258	BOLT, fork clip	2	
13	90544H93B00	WASHER, spacer	2	
14	51511HN9101	JOINT, front brake hose	1	
15	01517-06308	BOLT, front brake hose joint	2	
16	51631HN9100	NUT, steering stem upper	1	
17	51643HG5801	DUST SEAL, steering upper	1	
18	09164H28001	WASHER, PROTECTOR	1	KM4MP52BX61100079~


STEERING HEAD (HANDLE LOW)



STEERING HEAD (HANDLE LOW)

Ref #	Part #	Description	Quantity	Remarks
1	51311HP940003P	BRACKET, front fork upper	1	
2	07110-08258	BOLT, front fork upper bracket	2	
3	09159H22002	NUT, str upper	1	
4	09160H22032	WASHER, str upper	1	


STEERING HEAD (HANDLE HIGH)



STEERING HEAD (HANDLE HIGH)

Ref #	Part #	Description	Quantity	Remarks
1	51311HM810403P	BRACKET FRONT FORK UPPER	1	
2	07110-08258	BOLT, front fork upper bracket	2	
3	09159H22002	NUT, str upper	1	
4	09160H22032	WASHER, str upper	1	
5	56211-35C00	HOLDER, handle bar	2	
6	56171HF4601	COVER, steering head	1	
7	09106H08458	BOLT, handle holder upper	4	
8	56222HG5100	CAP, handle holder upper bolt	4	


HEAD LAMP & FRONT FENDER (V2S 650)



HEAD LAMP & FRONT FENDER (V2S 650)

Ref #	Part #	Description	Quantity	Remarks
1	53110HM81800BK	FENDER, front (BLACK)	1	
2	51811HM8101PAM	HOUSING, headlamp	1	
3	51550HM8100	BRACE COMP, headlamp housing	1	
4	51540HM8100PLA	BRKT COMP, headlamp housing R	1	
5	51530HM8100PLA	BRKT COMP, headlamp housing L	1	
6	01517-06128	BOLT, plate headlamp	4	
7	01284-08258	BOLT, headlamp housing	2	
8	09180-08092	SPACER, headlamp housing	2	
9	09320-10020	CUSHION, under brkt & headlamp h	2	
10	09329-12002	CUSHION, headlamp housing	2	
11	51820-45000	PLATE COMP, headlamp housing	2	
12	02112-95208	SCREW, housing & headlamp	3	
14	59430HN9100	CLAMP COMP, front brake hose R	1	
15	59440HN9100	CLAMP COMP, front brake hose L	1	
16	01517-08126	BOLT, front brake hose clamp R/L	2	
17	51815HN9100	TAPE, head lamp housing LH	1	


FRONT FENDER (V2S 650 R/S)



FRONT FENDER (V2S 650 R/S)

Ref #	Part #	Description	Quantity	Remarks
1	53110HM81800BK	FENDER, front (BLACK)	1	
2	59430HN9100	CLAMP COMP, front brake hose R	1	
3	59440HN9100	CLAMP COMP, front brake hose L	1	
4	01517-08126	BOLT, front brake hose clamp R/L	2	
5	09404-08403	CLAMP, speed sensor	1	


FRONT WHEEL



FRONT WHEEL

Ref #	Part #	Description	Quantity	Remarks
1	54141HM8102	WHEEL, front (J17xMT3.0)(Silver)	1	
1-1	54141HM8102120	WHEEL, front (J17xMT3.0)(Black)	1	V2S-650S:KM4MP51B161100909
1-2		WHEEL + BEARING	1	V2S-650R:KM4MP51C161101504
2	55100HN9101	TIRE COMP, front (120/60-17 55W)	1	
3	59211HM8100	DISC COMP, front L	1	
3~1	59211HM8101	DISC COMP, front L	1	From 2006-April
4	59421-03A01	BOLT, front brake disc	12	
5	54711HG5101	AXLE, front	1	
6	54740HM8101	SPACER COMP, front axle R	1	
7	54721HM8100	NUT, front axle	1	
8	34860HP9201	SENSOR ASSY, speedometer	1	V2S 650R
8-1	54600HG5102	BOX SP/METER GR	1	V2S 650
9	08124-63027	BEARING, front hub	2	
10	54731HM8100	SPACER, front hub	1	
11	55220-41D10	VALVE ASS'Y, wheel rim	1	
12	59221HM8160	DISC COMP, F/T R	1	
12~1	59221HM8161	DISC COMP, F/T R	1	From 2006-April


HANDLE BAR (LOW)



HANDLE BAR (LOW)

Ref #	Part #	Description	Quantity	Remarks
1	56110HP9203	HANDLE BAR COMP, RH	1	
2	56120HP9204	HANDLE BAR COMP, LH	1	
3	58300HP9201	CABLE ASS'Y, throttle	1	~KM4MP51A341100140
4	58410HP9203	CABLE COMP, starter	1	KM4MP51A341100141~
5	58200HP9203	CABLE ASS'Y clutch	1	
6	09408-00002	CLIP, cable	1	
7	09200-06004	PIN, clutch	1	
8	04111-20158	COTTER PIN, clutch	1	
9	58600HP9201	CABLE ASS'Y, throttle return	1	Improved July 2006
10	56500HP9200	MIRROR ASS'Y, rear view R	1	
11	07110-06208	CABLE ASS'Y, throttle return	1	
12	56503HP9200	CUSHION, rear view mirror	1	
13	56600HP9200	MIRROR ASS'Y, rear view L		
	56501HP9260	MIRROR SET	1	right and left


HANDLE BAR (HIGH)



HANDLE BAR (HIGH)

Ref #	Part #	Description	Quantity	Remarks
1	56110HN9102	HANDLE BAR COMP	1	
2	58200HN9104	CABLE ASS'Y CLUTCH	1	
3	58300HN9103	CABLE ASS'Y, throttle	1	
4	58410HN9103	CABLE COMP, starter	1	
5	56500HN9100	MIRROR ASS'Y, rear view R	1	
6	56600HN9100	MIRROR ASS'Y, rear view L	1	
7	56501HN9100	MIRROR SET	1	
8	09200-06004	PIN, clutch cable	1	
9	04111-20158	COTTER PIN, clutch	1	
10	58600HN9103	CABLE ASS'Y, throttle return	1	
11	09408-00002	CLIP, throttle cable & return cable	1	


HANDLE SWITCH (V2S 650 & S)



HANDLE SWITCH (V2S 650 & S)

Ref #	Part #	Description	Quantity	Remarks
1	37200HN9100	SWITCH ASS'Y, handle R	1	
2	57110HG5803	GRIP COMP, throttle	1	
3	56271HF4501PLA	BALANCER, handlebar	2	
4	57421-13001	LEVER, brake	1	
4-1	57421HN9100	LEVER, brake	1	
4-2	57300HN9102	LEVER, brake	1	
5	07110-08208	BOLT, handle balancer	2	
6	37400HN9100	SWITCH ASS'Y, handle L	1	
7	57211HG5800	GRIP, L	1	
8	09407-14403	CLAMP, handle switch harness	2	
9	57460HJ8250	SWITCH ASS'Y, clutch	1	
10	57431H05D00	BOLT, brake lever pivot	1	
11	08319-21065	NUT, brake lever pivot	1	
12	57460-17C00	SWITCH ASS'Y, stop	1	
13	02112-74108	SCREW, stop switch	1	
14	57620HN9100	LEVER COMP, clutch	1	
14-A	57620HN9101	LEVER COMP, clutch	1	
15	57500HN9100	LEVER ASS'Y, clutch	1	
15-A	57500HN9101	LEVER ASS'Y, clutch	1	
15-B	57500HN9102	LEVER ASS'Y, clutch	1	
16	57511HM8100	HOLDER, clutch lever	1	
16-A	57511HN9100	HOLDER, clutch lever	1	
16-B	57511HN9101	HOLDER, clutch lever	1	
17	57431HG5800	BOLT SET, clutch lever pivot	1	
18	08319-21065	NUT, clutch lever pivot	1	
19	57451HG5800	BOLT, clutch lever holder	1	
20	57442H93B00	LOCK NUT	1	
21	57441H93B00	ADJUSTER, wire	1	
22	57661HJ8200	COVER, clutch lever	1	
22-1	57661HN9100	COVER, clutch lever	1	
23	37281HN3201	BOSS, HANDLE SWITCH R	1	


HANDLE SWITCH (V2S 650 R)



HANDLE SWITCH (V2S 650 R)

Ref #	Part #	Description	Quantity	Remarks
1	37200HP9200	SWITCH ASS'Y, handle R	1	
2	57110HG5803	GRIP COMP, throttle	1	
3	56271HF4501PLA	BALANCER, handlebar	2	
4	57421HN9100	LEVER, brake	1	~ KM4MP51A341100140
4-1	57300HN9102	LEVER, brake	1	KM4MP51C961101458
5	07110-08208	BOLT, handle balancer	2	
6	37400HP9200	SWITCH ASS'Y, handle L	1	
7	57211HG5800	GRIP, L	1	
8	09407-14403	CLAMP, handle switch harness	2	
9	57460HJ8250	SWITCH ASS'Y, clutch	1	
10	57431H05D00	BOLT, brake lever pivot	1	
11	08319-21065	NUT, brake lever pivot	1	
12	57460-17C00	SWITCH ASS'Y, stop	1	
13	02112-74108	SCREW, stop switch	1	
14	57620HN9100	LEVER COMP, clutch	1	
14-A	57620HN9101	LEVER COMP, clutch	1	KM4MP51C661101921
15	57500HN9100	LEVER ASS'Y, clutch	1	
15-A	57500HN9101	LEVER ASS'Y, clutch	1	KM4MP51C961101458
15-B	57500HN9102	LEVER ASS'Y, clutch	1	KM4MP51C661101921
15-1	57511HM8100	HOLDER, clutch lever	1	
15-1-A	57511HN9100	HOLDER, clutch lever	1	KM4MP51C961101458
15-1-B	57511HN9101	HOLDER, clutch lever	1	KM4MP51C661101921
16	57431H93B00	BOLT SET, clutch lever pivot	1	
17	08319-21065	NUT, clutch lever pivot	1	
18	57451HG5800	BOLT, clutch lever holder	1	
19	57442H93B00	LOCK NUT	1	
20	57441H93B00	ADJUSTER, wire	1	
21	57661HJ8200	COVER, clutch lever	1	
22	56502HP9200	SCRIVET	2	~KM4MP51B861100906
22~1	09407-08307	SCRIVET	2	KM4MP51B861100907~
23	37281HN3201	BOSS, HANDLE SWITCH R	1	


CALIPER LH



CALIPER LH

Ref #	Part #	Description	Quantity	Remarks
0	59300HM8102	CALIPER ASS'Y, L	1	KM4MP51C651101124
0-1	59300HP9500	CALIPER ASS'Y, L	1	KM4MP51C651101125~
0-2	59300HN9100	CALIPER ASS'Y, L	1	KM4MP51C961101458
1	07120-08308	BOLT, caliper	2	
2	01514-06106	BOLT, speedometer cable guide	1	
3	59266HN9100	GUIDE, speedometer cable	1	
4	59300HG5800	PAD SET (7.4t)	1	KM4MP51C25110116
4-1	59301HP9500	PAD SET (8.4t)	1	KM4MP51C25110117


CALIPER RH



CALIPER RH

Ref #	Part #	Description	Quantity	Remarks
0-1~1	59400HP9500	CALIPER ASS'Y, R	1	KM4MP51C651101125~
0-1~2	59400HN9100	CALIPER ASS'Y, R	1	KM4MP51C961101458
1	07120-08258	BOLT, caliper	2	
2	59300HG5800	PAD SET (7.4t)	1	KM4MP51C25110116
2-1	59301HP9500	PAD SET (8.4t)	1	KM4MP51C25110117


MASTER CYLINDER



MASTER CYLINDER

Ref #	Part #	Description	Quantity	Remarks
0	59600HN9102	CYLINDER ASS'Y, front master	1	KM4MP51A351103171~
0-1	59600HP9201	CYLINDER ASS'Y, front master	1	KM4MP51C961101458
1	59687HM8162	BODY	1	
2	59669-36510	CAP, reservoir	1	
3	59610-35C00	PISTON, SET	1	Not for Sale
4	59691-35C00	SCREW	2	
5	59671-35C00	HOLDER	1	
6	08322-21064	WASHER	2	
7	01107-35C00	BOLT, holder	2	


FRONT BRAKE HOSE



FRONT BRAKE HOSE

Ref #	Part #	Description	Quantity	Remarks
1	59711H49002	BOOT, brake hose	1	
2	59460HN9100	HOSE COMP, FT brake R	1	
3	09161-10005	WASHER, brake hose	12	
4	59450HN9100	HOSE COMP, front brake upper	1	V2S 650 & S
5	59450HP9202	HOSE COMP, front brake upper	1	V2S 650R
6	69480HM8104	HOSE COMP, rear brake	1	
7	09161-10005	WASHER, rear brake fluid	4	
8	09360-10039	BOLT, rear brake fluid	8	
9	59470HN9100	HOSE COMP, FT brake L	1	
10	09360-10039	BOLT, brake hose	1	V2S 650 ONLY
11	09408H10002	CLIP, ft brake hose & SP/cable	1	V2S 650 ONLY


SWING ARM



SWING ARM

Ref #	Part #	Description	Quantity	Remarks
0	61100HN9106HPA	REAR SWING ARM ASS'Y	1	
		REAR SWING ARM ASS'Y (Black)	1	V2S-650S:KM4MP51B161100909
				V2S-650R:KM4MP51C161101504
1	61100HN9106	SWING ARM COMP, rear	1	
		SWING ARM COMP, rear (Black)	1	V2S-650S:KM4MP51B161100909
				V2S-650R:KM4MP51C161101504
2	61273HN9100	BUFFER, chain touch defense	1	
3	02142-06166	BOLT, chain touch defense buffer	2	
4	09169-06032	WASHER, chain touch defense buffer	2	
5	61510HM8100	GUIDE, rear brake hose No.1	1	
6	09263-22017	BEARING, rear swing arm pivot	2	
7	61252HN9100	SPACER, rear swing arm pivot R	1	
8	61251HM8100	SPACER, rear swing arm pivot bearing	1	
9	02142-06128	BOLT, RR brake hose guide N0.1	1	
10	09283-20031	SEAL, rear cushion rod	2	
11	09263H20003	BEARING, rear cushion rod	2	
12	09180H14001	SPACER, rear cushion rod	1	
13	08211-14341	WASHER, rear cushion rod	2	
14	09159H14008	NUT, rear cushion rod	2	
15	09103H14001	BOLT, rear cushion rod	2	
16	62641HN9100	ROD, rear cushion lever	2	
17	09180H10073	SPACER, rear cushion lever rear	1	
18	09263H17002	BEARING, rear cushion lever rear	1	
19	08316-16088	NUT, chain adjuster	2	
20	09103H08608	BOLT, chain adjuster	2	
21	61262-45002	COVER, rear swing arm pivot	2	
22	09263H20003	BEARING, rear cushion lever center	2	
23	62611HG5800	LEVER, rear cushion	1	
24	09284H33003	DUST SEAL, rear cushion lever front	2	
25	09263-20073	BEARING, rear cushion lever front	1	
26	09180H12001	SPACER, rear cushion lever front	2	
27	09103H12046	BOLT, rear cushion lever front	1	
28	08319-31128	NUT, rear cushion lever front	1	
29	09284H32001	SEAL, rear cushion lever center	2	
30	62611HN9100HPA	LEVER, REAR cushion ASS'Y	1	
31	68320HN9150PL	LABEL, chain case	1	


REAR SHOCK ABSORBER




REAR SHOCK ABSORBER

Ref #	Part #	Description	Quantity	Remarks
1	62100HP9201	SHOCK ABSORBER ASS'Y rear	1	~KM4MP51A341100140
2	09103H10101	BOLT, rear shock absorber upper	1	
3	08319-31108	NUT, rear shock absorber upper	2	
4	09103H10101	BOLT, rear shock absorber lower	1	
5	61310HM8102	CASE COMP, chain	1	
6	09111H06066	BOLT, chain case	2	
7	09160-10001	WASHER, rear shock absorber lower	1	

REAR FENDER






FWD

REAR FENDER

Ref #	Part #	Description	Quantity	Remarks
1	63111HM810112A	FENDER, rear	1	
2	01517-06206	BOLT, rr fender	4	
3	09169-06032	WASHER, rr fender	4	
4	09148-05039	NUT, rr fender	4	
5	09321-06023	CUSHION, license plate	1	
6	35910HG5150	LAMP ASS'Y, license plate	1	
7	08316-26055	NUT, license lamp (M5)	2	
8	35915HL7300	COVER, license lamp	2	
9	08316-26055	NUT, license lamp	2	
10	35970-17303	REFLEX REFLECTOR ASS'Y, rear	1	
11	01107-05605	SCREW, license lamp	2	
12	35911HG5800	LENS, license	1	
13	35912HG5800	HOUSING, license	1	
14	35916HG5800	CORD ASS'Y	1	
15	09471-12210	BULB, license lamp (12V/5W)	1	


REAR WHEEL


26
28
22
2
5
23
25
1-1
21
6
20
19
17
1
27
3
18
10
16
8
14
13
7
11
9
12
24
4
FWD

REAR WHEEL

Ref #	Part #	Description	Quantity	Remarks
1	64150SN9100HPA	WHEEL + TIRE REAR ASS'Y.	1	
1-1	64150HN9100	WHEEL COMP, rear (J17xMT4.50)	1	V2S-650S:KM4MP51B161100909
1-1-1	64150HN9100120	WHEEL COMP, rear (J17xMT4.50)(Black)	1	V2S-650R:KM4MP51C161101504
1-2	64150HN9100HPA		1	V2S-650S:KM4MP51B161100909
1-2-1	64150HN9101HPA	WHEEL + BEARING (Black)	1	V2S-650R:KM4MP51C161101504
2	65100HN9101	TIRE COMP, rear (160/60-17 69W)	1	
3	55220-29C20	VALVE ASS'Y, wheel rim	1	
4	64711HN9101	AXLE, rear	1	
5	09159H16002	NUT, rear axle	1	
6	64741HM8100	SPACER, rear axle R	1	
7	64751HM8100	SPACER, rear axle L	1	
8	64611HN9150120	DRUM, rear sprocket mounting	1	
8~1				KM4MP51B861100907~
9	64511HN9101	SPROCKET, rear (44T)	1	
10	64733HM8100	RETAINER, rear sprocket drum	1	
11	01517-08358	BOLT, rear sprocket	6	
12	08319-31088	NUT, rear sprocket	6	
13	09285-28001	OIL SEAL, rear sprocket mounting drum	1	
14	08133-62047	BEARING, rear sprocket mounting drum	1	
15	64162HN9100	WASHER, rear sprocket	3	Not for Sale
16	64651HM8101	SHOCK ABSORBER, rear wheel	6	
17	64731HM8100	SPACER, rear wheel bearing	1	
18	08133-62037	BEARING, rear wheel L	1	
19	08133-62037	BEARING, rear wheel R	1	
20	09283-27010	O-RING, rear hub R	1	
21	69211HM8101	DISK, rear brake	1	
22	59421-03A01	BOLT, rear brake disk	6	
23	61411HN9100	PLATE, chain adjuster R	1	
24	61511HN9100	PLATE, chain adjuster L	1	
25	69340HM810303P	CARRIER, caliper	1	
25~1		CARRIER, caliper	1	KM4MP51B861100907~
26	61610HM8101	GUIDE, rr brake hose NO. 2	1	
27	09280-55001	O-RING, rear hub L	1	
28	01517-06128	BOLT, rr brake hose guide NO. 2	1	


REAR CALIPER



REAR CALIPER

Ref #	Part #	Description	Quantity	Remarks
0	69300HP9500	CALIPER ASS'Y, rear brake	1	KM4MP51C961101457
0-1	69300HN9102	CALIPER ASS'Y, rear brake	1	KM4MP51C961101458
1	69300HN9101	BOLT, caliper	1	
2	59300HG5800	PAD SET (7.4t)	2	KM4MP51C25110116
2-1	59301HP9500	PAD SET (8.4t)	1	KM4MP51C25110117

STICKERS


68319H05350-PL
68921HR9160
68911HR9160
68160HN9100
68912HR9160
Center에 부착
68204HN9100
68206HN9100
68350HM6150-PL
41762HN9190
68110 H R9160
Center에 부착
Line에 맞출것
68116 H R9160
68130 H R9160
68146 H R9160
68156 H R9160
68166 H R9160
Line에 맞출것
Line에 맞출것
68136 H R9160
Line에 맞출것
68320HN9150-PL
68176 H R9160

STICKERS

Ref #	Part #	Description	PREFIX			
			RED/BLK	SIL/BLK	BURG/BLK	BLACK
1	68204HN9100	TAPE, REAR SEAT & SIDE COVER R.	#	#	#	#
2	68206HN9100	TAPE, REAR SEAT & SIDE COVER L.	#	#	#	#
3	68110HR9160	EMBLEM, FUEL TANK	U11	U21	U41	U31
4	68114HR9160	TAPE, FUEL TANK R.	U12	U12	U12	U12
5	68116HR9160	TAPE, FUEL TANK L.	U12	U12	U12	U12
6	68130HR9160	EMBLEM, 650R	U13	U13	U13	U13
7	68134HR9160	TAPE, SIDE COVER R.	015	015	015	015
8	68136HR9160	TAPE, SIDE COVER L.	015	015	015	015
9	68144HR9160	TAPE, UNDER COWLING NO1 R.	U12	U12	U12	U12
10	68146HR9160	TAPE, UNDER COWLING NO1 L.	U12	U12	U12	U12
11	68154HR9160	TAPE, UNDER COWLING NO2 R.	U12	U12	U12	U12
12	68156HR9160	TAPE, UNDER COWLING NO2 L.	U12	U12	U12	U12
13	68164HR9160	TAPE, UNDER COWLING NO3 R.	U13	U23	U23	U23
14	68166HR9160	TAPE, UNDER COWLING NO3 L.	U13	U23	U23	U23
15	68174HR9160	TAPE, UNDER COWLING NO4 R.	D02	D03	D03	D03
16	68176HR9160	TAPE, UNDER COWLING NO4 L.	D02	D03	D03	D03
17	68170HN9100	LABEL, RADIATOR	#	#	#	#
18	68160HN9100	LABEL, RELAY	#	#	#	#
19	68319H05350PL	LABEL, CAUTION	#	#	#	#
20	68320HN9150PL	LABEL, CHAIN CASE	#	#	#	#
21	68350HM8150PL	LABEL, CAUTION NO1.	#	#	#	#
22	41762HN9190	PLATE, MANUFACTURER	#	#	#	#
23	68911HR9160	LABEL, EPA NOISE EMISSION	#	#	#	#
24	68912HR9160	LABEL, NOISE EMISSION	#	#	#	#
25	68921HR9160	LABEL, EMISSION	#	#	#	#