

# ATLANTIS 150 CHASSIS PARTS

ENGINE





| | PART NUMBER | DESCRIPTION | QTY |
|---|---|---|---|
| 1 | 10100-FYJQ-000 | engine assy. | 1 |
| 2 | 11345-FYGT2-000 | pipe | 1 |

F-1 AIR CLEANER





| F-1 | PART NUMBER | DESCRIPTION | QTY |
|---|---|---|---|
| 1 | 17200-FYT3B-000 | air cleaner assy. | 1 |
| 2 | V241201-FYJT19-0000 | air cleaner element | 1 |
| 3 | GB/T16674.1-M6*25-A2F | hexagon flange bolt | 2 |
| 4 | 16170-ZJ-008 | automatic choke valve | 1 |
| 5 | E140000-FYJQ-0000 | carburetor | 1 |

F-2 HEADLIGHT ASSY.





| F-2 | PART NUMBER | DESCRIPTION | QTY |
|---|---|---|---|
| 1 | V181000-FYJT19-1000 | headlight assembly (DOT/chromeplating ) | 1 |
| 2 | V181004-FYJT19-0000 | headlight ring | 1 |
| 3 | V181002-FYT19-0000 | headlight lens | 1 |
| 4 | 33130-FY19-000 | headlight bulb | 1 |
| 5 | V182001-FYBT-0000 | position light bulb | 1 |
| 6 | V181040-FYJT19-000 | headlight socket | 1 |
| 7 | V181330-FYJT19-1000 | headlight installing stand (chromeplating) | 1 |
| 8 | 90113-06020-L | special bolt M6*20 | 1 |
| 9 | V181021-FYJT19-0000 | lens housing | 1 |

F-3 TURN SIGNALS





| F-3 | PART NUMBER | DESCRIPTION | QTY |
|---|---|---|---|
| 1 | V183100-FYJT19-0000 | front directional assembly(left/DOT) | 1 |
| 2 | V183200-FYJT19-0000 | front directional assembly(right/DOT) | 1 |
| 3 | V183300-FYJT19-0000 | rear directional assembly(DOT/left) | 1 |
| 4 | V183400-FYJT19-0000 | rear directional assembly(DOT/right) | 1 |
| 5 | 33710-FY19-000 | taillight bulb | 4 |
| 6 | GB/T13806.2-ST4.2*12-A2F | cross recess-headed screw | 4 |
| 7 | V183101-FYJT19-0000 | front turning light lens(left) | 1 |
| 8 | V183201-FYJT19-0000 | front turning light lens(ringt) | 1 |
| 9 | V183301-FYJT19-0000 | rear turning light lens(left) | 1 |
| 10 | V183401-FYJT19-0000 | rear turning light lens(ringt) | 1 |

F-4 METER ASSEMBLY





| F-4 | PART NUMBER | DESCRIPTION | QTY |
|---|---|---|---|
| 1 | V190000-FYJT19-0000 | instrument assembly (DOT/ English system/directional lights) | 1 |
| 2 | V191000-FYJT19-0000 | speedometer | 1 |
| 3 | V198000-FYJT19-0000 | signal meter | 1 |
| 4 | V194000-FYJT19-0000 | fuel gauge assembly | 1 |
| 5 | V190200-FYT19-0000 | instrument installing stand(unit) | 1 |
| 6 | V190500-FYJT19-0000 | instrument cable | 1 |
| 7 | V190104-FYT19-0000 | instrument night directional lights(12V1.7W) | 3 |
| 8 | 44830-FYGT9-000 | speedometer cable | 1 |
| 9 | GB819-85-05016-B | sunk screwM5×16 | 1 |
| 10 | GB/T818-M5*12-A2F | cross recess-headed screw M5*12 | 2 |
| 11 | V190105-FYJT19-0000 | high beam directional lights(12V 1.7W) | 1 |

F-5 HANDLEBARS





| F-5 | PART NUMBER | DESCRIPTION | QTY |
|---|---|---|---|
| 1 | V204200-FYJT19-0000 | right handle switch assembly (DOT/chromeplating ) | 1 |
| 2 | 35200-FYGT9-000 | left handle switch assembly | 1 |
| 3 | V091000-FYJT19-1000 | directional handlebar assembly (DOT/chromeplating ) | 1 |
| 4 | 53140-FYGT9-000 | throttle grip and inner tube | 1 |
| 5 | 53116-FYGT9-000 | left handlebar grip | 1 |
| 6 | 43120-FYGT9-000 | rear brake lever assembly | 1 |
| 7 | 53167-FYGT9-000 | rear brake lever | 1 |
| 8 | 53231-FYGT9-000 | upper yoke plate | 1 |
| 9 | 53112-FYGT9-000 | lower handlebar clamp | 2 |
| 10 | 53111-FYGT9-000 | upper handlebar clamp | 1 |
| 11 | GB/T16674.2-M10*1.25*45-A2F | hexagon flange screws | 1 |
| 12 | 53124-FYT3A-000 | directional handle block | 1 |
| 13 | GB6187-86-10000X-G-14 | flange self-locking nutM10×1.25 | 1 |
| 14 | GB/T70.1-M8*16-A2F | Allen column-headed screw | 2 |
| 15 | GB/T70.1-M8*35-F5J | Allen column-headed screw | 2 |
| 16 | V090230-FYT19-1000 | rear brake cable(manual brake/steel pipe) | 1 |
| 17 | V090221-FYT19-0A2F | return spring | 1 |
| 18 | V090222-FYT19-0000 | pin | 1 |
| 19 | V090223-FYT19-0000 | regulating screw | 1 |
| 20 | V090410-FYT19-1000 | accelerator wire assembly(steel wire) | 1 |
| 21 | 88120-FYM-100 | rearview mirror(right/DOT) | 1 |
| 22 | 88110-FYM-100 | rearview mirror(left/DOT) | 1 |
| 23 | 91165-FYBQ-000 | belt | 2 |

F-6 FRONT BRAKE





| F-6 | PART NUMBER | DESCRIPTION | QTY |
|---|---|---|---|
| 1 | V151100-FYT19-0000 | front brake fender main pump assy. | 1 |
| 2 | V151200-FYT19-0000 | front brake fender oil/soft pipe component | 1 |
| 3 | V151300-FYT19-0000 | front brake fender separated pump combinatory | 1 |
| 4 | V151001-FYT19-0000 | front brake fender assy. | 1 |
| 5 | V151102-FYT19-0000 | front brake lever | 1 |
| 6 | 51035-FYT13A-100 | dust cap | 2 |
| 7 | 90301-101515-CU000 | plain washer | 4 |
| 8 | 46006-FYGT9-000 | eye bolt | 2 |
| 9 | V151250-FY7-0000 | braking oil pipe nip | 1 |
| 10 | 35340-FYGT9-000 | front braking switch assembly | 1 |
| 11 | 51007-FYT13A-000 | connecting rod sleeve; | 1 |
| 12 | V151320-FYT19-0000 | fender brake shoe component | 1 |
| 13 | 51050-FYGT9-000 | brake connecting rod component | 1 |
| 14 | V151401-FYT19-0000 | front-right brake clamp | 1 |
| 15 | GB/T16674.1-M8*32-A3H | hexagon flange bolt | 1 |

F-7 FRONT FORK





| F-7 | PART NUMBER | DESCRIPTION | QTY |
|---|---|---|---|
| 1 | 53200-FYGT9-000 | directional post | 1 |
| 2 | 53206-FYT3A-000 | locknut | 1 |
| 3 | 53211-FYT3A-000 | upper steel tray | 1 |
| 4 | 53210-FYT3A-000 | upper steel ball | 1 |
| 5 | 53201-FYT3A-000 | upper steel bowl | 1 |
| 6 | 53202-FYT3A-000 | lower steel bowl | 1 |
| 7 | 53220-FYT3A-000 | lower steel ball | 1 |
| 8 | 53212-FYT3A-000 | lower steel tray | 1 |
| 9 | 53214-FYT3A-000 | directional post dustproof coil | 1 |
| 10 | 53215-FYT3A-000 | directional post down coil | 1 |
| 11 | 51400-FYGT9-000 | fore shock absorber assembly | 2 |
| 12 | GB6187-86-08000-G-12 | self-locking nut M8 | 4 |
| 13 | GB/T16674.1-M8*40-A3H | hexagon flange bolt M8×40 | 2 |
| 14 | 90151-FYT13A-000 | screw(stainless steel) M6×16 | 4 |
| 15 | V022432-FYT19-0000 | right radial shield(electroplating) | 1 |
| 16 | V022431-FYT19-0000 | left radial shield(electroplating) | 1 |
| 17 | 51401-FYT13A-000 | fore shock-absorb shoulder bolt | 2 |
| 18 | 51040-FYGT9-000 | right radial components | 1 |
| 19 | 51030-FYGT9-000 | left radial components | 1 |
| 20 | GB6172-86-08000-G-12 | hexagon thin nut M8 | 2 |
| 21 | V022421-FYT19-0000 | right front fork protecting cover(electroplating) | 1 |
| 22 | V022411-FYT19-0000 | left front fork protecting cover(electroplating) | 1 |
| 23 | GB6187-86-10000X-G-14 | flange self-locking nutM10×1.25 | 2 |
| 24 | 51005-FYT13A-000 | radial block | 2 |
| 25 | GB/T6170-M6-A2F | I-shaped hexagon nut | 2 |
| 26 | 33750-FYT-000 | side reflector | 2 |

## F-8 FRONT FENDER AND COVER





| F-8 | PART NUMBER | DESCRIPTION | QTY |
|---|---|---|---|
| 1 | V022108-FYT19-0000 | front board decoration(right/electeoplating/SanYang) | 1 |
| 2 | V022353-FYT19-0000 | headpipe lower part of rear door(PP/SanYang) | 1 |
| 3 | V02230C-FYT19-0000 | code sight cap (PP/SanYang) | 1 |
| 4 | V022342-FYT19-0000 | headpipe forecover decorating cover(electeoplating/SanYang) | 1 |
| 5 | V022352-FYT19-0000 | headpipe backcover decorating cover(electeoplating/SanYang) | 1 |
| 6 | V022611-FYJT19-0B02 | front fender A(black/SanYang/HT031B) | 1 |
| | V022611-FYT19-0A02 | front fender A(Silver/SanYang) | 1 |
| 7 | V022612-FYJT19-0B02 | front fender B(black/SanYang/HT031B) | 1 |
| | V022612-FYT19-0A02 | front fender B(Silver/SanYang) | 1 |
| 8 | V022101-FYJT19-0B02 | front board(black/SanYang/HT031B) | 1 |
| | V022101-FYT19-0A02 | front board(silver/SanYang) | 1 |
| 9 | V022351-FYJT19-0B02 | headpipe upper part of rear door(black/SanYang/HT031B) | 1 |
| | V022351-FYT19-0A02 | headpipe upper part of rear door(silver/SanYang) | 1 |
| 10 | 97707-50016-00 | recess-headed screw | 2 |
| 11 | GB/T845-ST4.2*12-A3H | cross self-tapping screw ST4.2*12 | 10 |
| 12 | 90183-05807-00 | spring screw cab | 6 |
| 13 | 90151-FYT13A-000 | screw(stainless steel) M6×16 | 4 |
| 14 | 90220-06000-K | clip screw M6 | 2 |
| 15 | 90111-06014-K | shoulder bolt M6*14 | 1 |
| 16 | V022107-FYT19-0000 | front board decoration (left/electroplating/Sanyang) | 1 |
| 17 | GB/T818-M6*25-A3H | cross Recess Head Screw | 1 |
| 18 | 90113-06025-L | cruciform slot pan head screw | 2 |
| 19 | GB/T95-6-A2F | plain washer Lever C | 2 |
| 20 | V034002-FYT19-0000 | helmet hook(PP/Sanyang) | 1 |

## F-9 FRONT WHEEL





| F-9 | PART NUMBER | DESCRIPTION | QTY |
|---|---|---|---|
| 1 | V171100-FYJT19-0000 | front wheel rim assy.(light/DOT) | 1 |
| 2 | 90714-20*32*5-00000 | wheel seal 20x32x5 | 2 |
| 3 | 6201-2RS-GB/T276-94 | ball bearing with sealed coil | 2 |
| 4 | V171103-FYT13A-0000 | front rim middle cover | 1 |
| 5 | 42753-FYT3A-000 | valve stem | 1 |
| 6 | 4CW-F5108-0001 | tire (3.50-10,4PR) | 1 |
| 7 | 46001-FYT13A-000 | front fender | 1 |
| 8 | 90106-FYGT2-000 | front brake bolt | 3 |
| 9 | 44800-FYT13A-000 | counting pinion stand | 1 |
| 10 | 44301-FYT13A-000 | front axle shaft | 1 |
| 11 | 44615-FYT13A-000 | front axle shaft block | 1 |
| 12 | GB6187-86-12000X-B | flange self-locking nut | 1 |

## F-10 REAR WHEEL





| F-10 | PART NUMBER | DESCRIPTION | QTY |
|---|---|---|---|
| 1 | GB/T6187.2-M16*1.5-A3H | all metal hexagon flange locknut | 1 |
| 2 | 42753-FYT3A-000 | valve stem | 1 |
| 3 | 4CW-F5108-0001 | tire (3.50-10,4PR) | 1 |
| 4 | V172100-FYJT19-0000 | rear rim assy.(light shield/DOT) | 1 |

F-11 SEAT ASSY AND BACKREST





| F-11 | PART NUMBER | DESCRIPTION | QTY |
|---|---|---|---|
| 1 | V031000-FYJT19-0000 | seating washer assy. | 1 |
| 2 | 77220-FYGT9-000 | seating washer binder assy. | 1 |
| 3 | GB/T6177.1-M6-A3H | hexagon flange screws | 4 |
| 4 | 33431-FYBQ-000 | block | 2 |
| 5 | V025006-FYT19-0000 | carburetor recovery & maintenance cover(PP/Sanyang) | 1 |
| 6 | V025002-FYT19-0000 | carrier(PP/Sanyang) | 1 |
| 7 | GB/T923-M6-A3H | cap nut M6 | 2 |
| 8 | GB/T96.1-6-A3H | large gasket lever A | 2 |
| 9 | V023207-FYT19-0000 | accumulator cover (PP/Sanyang) | 1 |
| 10 | V251510-FYT19-0000 | seat lock assy.(Sanyang) | 1 |
| 11 | 77240-FYGT9-000 | seat lock lanyard assy. | 1 |
| 12 | 90800-FYT3A-000 | plastic pressed nail | 1 |
| 13 | 77280-FYGT9-000 | backrest assy. | 1 |
| 14 | V051000-FYJT19-0000 | rear storage rack (DOT/chromeplating ) | 1 |
| 15 | GB/T845-ST4.2*16-A3H | cross recess-headed self tapping screw | 3 |
| 16 | GB/T16674.1-M8*30-A2F | hexagon flange screws M8*30 | 2 |
| 17 | GB/T16674.1-M6*30-A2F | hexagon flange bolt | 2 |
| 18 | 43434-FY2-000 | torsion bar rubber mat | 4 |
| 19 | 50628-FYG10-000 | rear footplate installing block B | 2 |
| 20 | 33742-FYT3A-000 | side glisten patch | 2 |
| 21 | GB/T9074.1-M6*12-8.8-S1-L-A3H | bolt and washer groupware | 2 |
| 22 | GB/T6170-M6-A2F | I-shaped hexagon nut | 2 |
| 23 | GB/T6170-M5-A2F | slot hexagon nut | 1 |
| 24 | 33741-FYT3A-000 | rear reflecting piece | 1 |

F-12 FOOT PANELS





| F-12 | PART NUMBER | DESCRIPTION | QTY |
|---|---|---|---|
| 1 | V023124-FYJT19-0B02 | right orbital(black/SanYang/HT031B) | 1 |
| 1 | V023124-FYT19-0A02 | right orbital(Silver/SanYang) | 1 |
| 2 | V023134-FYJT19-0B02 | left orbital (black/SanYang/HT031B) | 1 |
| 2 | V023134-FYT19-0A02 | left orbital (Silver/SanYang) | 1 |
| 3 | V014101-FYT19-0000 | bottom protecting cover(PP/Sanyang) | 1 |
| 4 | 50624-FYGT9-000 | fore footplate stand | 1 |
| 5 | 1753B-FYGT9-000 | protecting cover fasten stand of the mouth of oil box | 1 |
| 6 | V060018-FYT19-0000 | protecting cover fasten stand of the mouth of oilbox(PP/Sanyang) | 1 |
| 7 | V061013-FYT19-0000 | protecting cover of the mouth of oilbox(PP/Sanyang) | 1 |
| 8 | V023201-FYT19-0000 | footplate(PP/Sanyang) | 1 |
| 9 | 64316-FYGT9-000 | floor footplate antiskid plate(right) | 1 |
| 10 | 64315-FYGT9-000 | floor footplate antiskid plate(left) | 1 |
| 11 | V023303-FYT19-0000 | center protecting cover(right/PP/Sanyang) | 1 |
| 12 | V023302-FYT19-0000 | center protecting cover(/left/PP/Sanyang) | 1 |
| 13 | V061014-FYT19-0000 | filler mouth cover(PP/Sanyang) | 1 |
| 14 | 50720-FYGT9-000 | right footplate component | 1 |
| 15 | 50710-FYGT9-000 | left footplate component | 1 |
| 16 | 97707-50016-00 | recess-headed screw | 4 |
| 17 | 90183-05807-00 | spring screw cab | 2 |
| 18 | GB/T16674.1-M6*16-A3H | hexagon flange screws series | 2 |
| 19 | GB/T9074.1-M6*12-8.8-S1-L-A3H | bolt and washer groupware | 4 |
| 20 | GB/T845-ST4.2*16-A3H | cross recess-headed self tapping screw | 16 |
| 21 | GB/T9074.1-M6*25-8.8-S1-L-A3H | bolt and washer groupware | 4 |
| 22 | GB/T16674.1-M6*12-A3H | hexagon flange screws | 2 |
| 23 | V023125-FYT19-0000 | right-middle protecting cover decorated board | 1 |
| 24 | V023135-FYT19-0000 | left-middle protecting cover decorated board | 1 |

F-13 FUEL TANK





| F-13 | PART NUMBER | DESCRIPTION | QTY |
|---|---|---|---|
| 1 | 37810-FYGT9-000 | Fuel lever sensor | 1 |
| 2 | V061000-FYT19-0000 | Fuel pump assy(Sanyang) | 1 |
| 3 | 17620-FYT3A-300 | Fuel pump cover | 1 |
| 4 | 16950-FYT18-000 | Fuel pump | 1 |
| 5 | GB/T16674.1-M6*12-A3H | hexagon flange screws | 4 |
| 6 | V063210-FYT18A-0000 | negative pressure assy(220mm) | 1 |
| 7 | 16972-FYT18-100 | Fuel line component(transparent 150mm) | 2 |
| 8 | 16972-FYT18-200 | Fuel line component(transparent 320mm) | 1 |
| 9 | 90467-09006-00 | stopping clamp | 6 |
| 10 | 16910-FYT3A-000 | fuel cleaner | 1 |

F-14 REAR BODY PANELS





| F-14 | PART NUMBER | DESCRIPTION | QTY |
|---|---|---|---|
| 1 | V023121-FYJT19-0B02 | right-back body protecting cover black | 1 |
| | V023121-FYT19-0A02 | right-back body protecting cover silver | 1 |
| 2 | V024212-FYT19-0000 | back-tail cover(PP/Sanyang) | 1 |
| 3 | V023131-FYJT19-0B02 | left-back body protecting cover black | 1 |
| | V023131-FYT19-0A02 | left-back body protecting cover silver | 1 |
| 4 | V023136-FYJT19-0B02 | left-sided cover notice-installing board black | 1 |
| | V023136-FYT19-0A02 | left-sided cover notice-installing board silver | 1 |
| 5 | V024106-FYT19-0000 | rear-middle cover upper decoration board | 1 |
| 6 | V024107-FYT19-0000 | rear-middle cover lower decoration board | 1 |
| 7 | GB/T845-ST4.2*12-A3H | cross self-tapping screw ST4.2*12 | 13 |
| 8 | 90183-05807-00 | spring screw cab | 2 |
| 9 | 97707-50016-00 | recess-headed screw | 4 |
| 10 | V024361-FYT19-0000 | back-inner fender(PP/Sanyang) | 1 |
| 11 | GB/T845-ST4.8*16-A3H | recess-headed self-tapping screw | 4 |
| 12 | V251000-FYJT19-0000 | lock | 1 |
| 13 | V024311-FYT19-0000 | back fender(PP/Sanyang) | 1 |
| 14 | 90109-063F1-00 | bolt | 1 |
| 15 | 90183-05807-00 | spring screw cab | 2 |
| 16 | 80111-FYJ-000 | back-inner fender bush | 1 |
| 17 | V185023-FYT19-0000 | rear light installing stand strengthen plank | 1 |
| 18 | GB/T6170-M6-A2F | I-shaped hexagon nut M6 | 3 |
| 19 | GB/T9074.1-M6*16-4.8-S3-L-A2F | bolt and washer groupware | 3 |
| 20 | 50126-FYG-000 | rubber washer | 2 |

F-15 TAILLIGHT & BRACKET





| F-15 | PART NUMBER | DESCRIPTION | QTY |
|---|---|---|---|
| 1 | V185000-FYJT19-0000 | rear light assembly(DOT) | 1 |
| 2 | V185301-FYJT19-0000 | rear light eyeglass(Front) | 1 |
| 3 | V18530A-FYJT19-0000 | rear light bulb (12V5W) | 1 |
| 4 | V185305-FYT19-0000 | rear light base (back) | 1 |
| 5 | V185020-FY20-0A01 | rear light installing stand(Silver) | 1 |
| | V185021-FYT19-0000 | rear light installing stand(Sanyang) | 1 |
| 6 | GB/T6170-M6-A2F | I-shaped hexagon nut | 2 |
| 7 | 18293-FYBQ-000 | silica gel | 2 |
| 8 | 90304-FY8-000 | large gasket lever | 2 |
| 9 | GB/T6177.1-M6-A3H | Bolt | 2 |

F-16 EXHAUST ASSY. & AIR INJECTION ASSY.





| F-16 | PART NUMBER | DESCRIPTION | QTY |
|---|---|---|---|
| 1 | V072000-FYJT19-2000 | intake silencer assembly | 1 |
| 2 | 95002-FYIF-200 | pipe clamp 15 | 1 |
| 3 | V072121-FYT19-0000 | exhauster protecting board | 1 |
| 4 | GB/T16674.1-M8*45-A2F | flange blot M8*32 | 2 |
| 5 | 90204-FYT3A-000 | exhauster nut M6 | 2 |
| 6 | 18292-FYT3A-000 | exhauster sealed pad | 1 |
| 7 | 18291-FY2-001 | secondary gulp valve (KOK) | 1 |
| 8 | GB/T16674.1-M6*16-A3H | hexagon flange screws series | 2 |
| 9 | V243010-FYT18A-0000 | gulp valve installing stand | 1 |
| 10 | 91113-FYIQ2-002 | stainless connecting pipe(FY125T) | 1 |
| 11 | 95002-FYIF-000 | pipe clamp | 2 |
| 12 | 91120-FYT6-000 | negative pressure pipe assembly | 1 |
| 13 | V243141-FYT18A-0000 | gulp valve connecting pipe | 1 |
| 14 | 95002-TL-000 | pipe clamp 15 (Φ17) | 1 |
| 15 | 90103-06012-00F5J | hexagon flange screws | 2 |
| 16 | GB/T859-6-A2F | light spring washer | 2 |
| 17 | 90301-061205-00A2F | plain washer | 2 |
| 18 | V070051-FYJT19-2000 | silica gel | 2 |
| 19 | GB/T96.1-6-A3H | larger gasket lever A | 2 |
| 20 | 90103-06020-00F5J | hexagon flange screws | 2 |
| 21 | V072203-FYT13-0000 | insulation blanket | 2 |

F-17 FRAME 0





| F-17 | PART NUMBER | DESCRIPTION | QTY |
|---|---|---|---|
| 1 | 50132-FYGT9-000 | main lock installing stand | 1 |
| 2 | V011000-FYJT19-0000 | frame | 1 |
| 3 | GB/T95-10-A2G | plain washer lever C | 2 |
| 4 | V052402-FYT19-0000 | right handrail | 1 |
| 5 | V052401-FYT19-0000 | left handrail | 1 |
| 6 | 95012-FY-000 | accumulator belt | 1 |
| 7 | GB/T16674.1-M8*20-A2F | hexagon flange screws M8*20 | 2 |
| 8 | 90151-FYT13A-000 | screw(stainless steel) M6×16 | 3 |
| 9 | 33431-FYBQ-000 | block | 2 |
| 10 | V146200-FYT19-0000 | engine hanger(Sanyang) | 1 |
| 11 | GB6187-86-10000X-G-14 | flange self-locking nutM10×1.25 | 1 |
| 12 | GB5789-86-10188X-G | flange blot M10*188 | 1 |
| 13 | 90121-FYT3A-000 | bush | 1 |
| 14 | 81725-FYEY2-001 | nameplate | 1 |
| 15 | GB/T16674.2-M10*1.25*55-A2F | hexagon flange screws | 2 |
| 16 | 4TE-F0002-0000 | crash pad | 8 |

F-18 MAIN & SIDE STAND 0





| F-18 | PART NUMBER | DESCRIPTION | QTY |
|---|---|---|---|
| 1 | V015200-FYJT19-0000 | side stand | 1 |
| 2 | 50531-FYJ-000 | side stand spring | 1 |
| 3 | 90120-FYT8-000 | side stand bolt | 1 |
| 4 | GB5787-86-10025X-G-12 | flange bolt | 2 |
| 5 | 50504-FYT3A-000 | main stand block | 2 |
| 6 | 95014-FYT3A-000 | main stand spring | 1 |
| 7 | V015100-FYT19-0000 | main stand(Sanyang) | 1 |
| 8 | 90113-06016-K | looped-head bolt M6*16 | 1 |
| 9 | GB/T6170-M6-A2F | I-shaped hexagon nut | 1 |
| 10 | 35030-FYT8-000 | side stand switch | 1 |

F-19 REAR SHOCK





| F-19 | PART NUMBER | DESCRIPTION | QTY |
|---|---|---|---|
| 1 | V143000-FYT13A-0000 | rear shock absorber assembly(Europe) | 1 |
| 2 | GB/T16674.1-M8*32-A3H | hexagon flange bolt | 1 |
| 3 | GB5787-86-10040X-G-12 | bolt | 1 |

F-20 ELECTRICAL 0




| F-20 | PART NUMBER | DESCRIPTION | QTY |
|---|---|---|---|
| 1 | 38100-FY3A-000 | horn | 1 |
| 2 | GB/T16674.1-M6*16-A3H | hexagon flange screws series | 2 |
| 3 | V201000-FYJT19-1000 | main cable (DOT) | 1 |
| 4 | 38310-FYJT18-000 | flasher | 1 |
| 5 | 3UH-H1940-0100 | starting relay | 1 |
| 6 | GB/T6177.1-M6-A3H | hexagon flange screws | 2 |
| 7 | 4KC-H2155-0000 | belt | 1 |
| 8 | V203010-FYT19-0000 | battery | 1 |
| 9 | 36Y-82151-0000 | fuse | 1 |
| 10 | 31600-FYT3A-010 | rectifier | 1 |
| 11 | E124000-FYIQ2-0000 | loop | 1 |
| 12 | 91165-FYGT2-000 | belt | 10 |
| 13 | 35700-FYT-000 | control | 1 |
| 14 | V201420-FYJT18-0000 | Diode,Silicon | 1 |
| 15 | 30410-FYT3A-000 | C.D.I discreteness | 1 |
| 16 | 32420-FYT13A-000 | line bear | 1 |

F-21 WARNING DECALS




| F-21 | PART NUMBER | DESCRIPTION | QTY |
|---|---|---|---|
| 1 | 81220-FYT3B-000 | label, warning RR carier weight | 1 |
| 2 | 81219-FYT3B-000 | label, warning FRT storage weight | 1 |
| 3 | 87125-FYT-000 | label, tire pressure | 1 |
| 4 | 87141-FYT3A-000 | label, SWV triangle | 1 |
| 5 | 87531-FYT3B-000 | label, side stand warning | 1 |
| 6 | 87150-FYJT-000 | DOT sticker | 1 |
| 7 | 87150-FYM-100 | EPA sticker | 1 |